





Glenn Grefer
Field Application Engineer
2017-11-08


What is Curve?



Curve is an optional addition to Calypso used to measure non-standard geometries. In GD&T terms, Profile Of A Line





Types of Curves



Plane Curve (2D Curve)

3D Curve




Lift Curve

Plane Curve (2D Curve)



All curve points and all normal vectors lie in a single plane in this case.


Plane curves arise from sectioning a (conceptual) plane with a body. They exist on work pieces with two-dimensional curve properties, for example camshafts.




3D Curve



3D curves have three degrees of freedom: they are, in theory, not restricted in any direction. You can measure and test 3D curves in CALYPSO.



Lift curves are special three-dimensional curves, which form part of a cylindrical surface. As the lift curve runs at a constant distance from the cylinder axis, they only have two variable values: the deviation of the curve in a certain direction (in the example the Z axis) and the angle of rotation on the cylinder surface.



Nominal Values, How do we get them?



In order to define nominal data, you can:

- import an existing file.
 - The file can be one of the following formats: VDA (Cons, Curve, MDI, PSET, POINT, CIRCLE), ASCII, PAB or DXF. In the case of ASCII files, the values read are interpreted in the following order:
 - x-nominal, y-nominal, z-nominal, u-nominal, v-nominal, w-nominal, x, y, z, u, v, w.
- use the point generator to define the curve points: either to mathematically freely define the curve points or to import external files with different formats.
- digitalize a curve. You generate the nominal values of an unknown profile by probing.
- enter the nominal data from the keyboard, for instance from a technical drawing.
- extract the nominal data from the CAD model: from the menu CAD Modification or by mouse click.

Curve Feature Definitions



Inside/ Outside switch

Open/Closed

Features

2D Curve1

Comment Projection Strategy

Nominal Vector Linear projectio Evaluation...

Clearance Group Nominal Data Alignment

CP +Z Nominal point i (Base Alignme

	Nominal	Actual
Point No.	1	EN
X	-6.5000	
Y	32.0000	
Z	0.0000	
Nx	-0.9998	
Ny	0.0183	
Nz	0.0000	

Best Fit Center of Mass Deviation

Sigma	Form	Points
Min	Point no	Point no
		Max


OK Reset

Curve Feature Definitions

How is the Curved Calculated?



Deviation in nominal vector direction




- 1.) Curve is measured, and a curve is then created through ball center (“Measuring curve”).
- 2.) The ball center curve is compensated the stylus radius, and is done so perpendicular to the actual ball center curve. This creates the “Actual curve”.
- 3.) The nominal points are projected along the nominal vector until they pierce the actual curve.
- 4.) The deviation is then reported from the nominal point, along the nominal vector, to the actual curve. (shown in red)

Curve Feature Definitions

How is the Curved Calculated?



Actual -> Nominal deviation




- 1.) Curve is measured, and a curve is then created through ball center (“Measuring curve”).
- 2.) The ball center curve is compensated the stylus radius, and is done so perpendicular to the actual ball center curve. This creates the “Actual curve”.
- 3.) All measured actual points, are projected along their actual vectors until they pierce the nominal curve.
- 4.) The deviation is then reported from the actual curve and points, along the actual vector/s, to the nominal curve. (shown in red)

Curve Feature Definitions

How is the Curved Calculated?



Space Point Evaluation (2-D curves only)




- 1.) Curve is measured, and a curve is then created through ball center (“Measuring curve”).
- 2.) The nominal points are projected along the nominal vector until they pierce the ball center curve.
- 3.) The actual points are then compensated along the nominal vector (not the actual)
- 4.) The deviation is then reported the same as a space point. (shown in red)

Curve Feature Definitions

How is the Curved Calculated?



Space Point Evaluation (without interpolation)



- 1.) The nominal points are projected along their nominal vectors.
- 2.) This creates a theoretical line (“Line A”), and Line A then looks for the closest actual point.
(closest point can be on either side of Line A)
- 3.) That closest point is projected perpendicular to the nominal.
- 4.) The point is now ball compensated along nominal vector.
- 5.) The deviation is then reported from nominal points to these calculated points. (shown in red)


Note: High data density is recommended to reduce any projected errors!

Curve Feature Definitions

How is the Curved Calculated?



Deviation in grid coordinates (2-D curves only)




- 1.) Curve is measured, and a curve is then created through ball center (“Measuring curve”).
- 2.) The ball center curve is compensated the stylus radius, and is done so perpendicular to the actual ball center curve. This creates the “Actual curve”.
- 3.) The nominal points are projected along the nominal vector until they pierce the actual curve (like the “Deviation in nominal vector direction” method)
- 4.) After this theoretical deviation line is made, the other 2 legs of the triangle are made (in the U and V directions).
- 5.) The deviation is then reported as the longest leg of the triangle along U or V. (not the actual point to point distance)

Curve Feature Definitions

How is the Curved Calculated?



Radial deviation (2-D curves only)



- 1.) Curve is measured, and a curve is then created through ball center (“Measuring curve”).
- 2.) The ball center curve is compensated the stylus radius, and is done so perpendicular to the actual ball center curve. This creates the “Actual curve”.
- 3.) A theoretical line is then made from your “Reference point” to each nominal point, and then extended until it pierces the actual curve.
- 4.) The deviation is then reported from the nominal point, in the direction from the reference point, until it pierces the actual curve (shown in red)

Note: Typically this method is used on Cams, and a tappet radius may or may not be entered.

In the vast majority of cases



Nominal Vector Direction

is the recommended setting to calculate the actual values and their deviations from nominal

Best Fit




In metrology, fitting is understood as the mathematical separation of **form deviations** and **positional deviations**. This means you can use best fit to obtain a mathematical correction of positional deviation of the nominal curve.



With "Evaluation" the best fit of the curve can be defined.




- Restrict Translation and Rotation
- Masking Points
- Search distance



CALYPSO provides for the fitting several methods:



- According to Gauss (also called LSQ or L2) Standard calculation, minimizes the square deviations
- According to tolerance with iteration Tries all possible points to be included in the tolerance band. Further input possible: Number of iterations, Simulate best fit.
- According to Tschebyscheff calculates the curve in center between minimum and maximum value
- L1 minimizes the deviation, in contrast to Gauss (minimizes the square deviations) an even greater suppression of deviations



Curve Offset



The offset calculation allows constant positive/negative differences in the dimensions of a work piece or known constant errors in the nominal data to be taken into account.



Actual Values and Evaluation



Tolerances can be defined for:

- the entire curve
- individual curve segments.

The screenshot shows the 'Features' dialog box for a curve. It includes sections for 'Nominal' and 'Actual' data, 'Curve tolerance' settings, and 'Segment tolerances' options.

	Nominal	Actual
Point No.	1	EN
X	17.68500	17.70017
Y	49.85000	49.84751
Z	30.00000	30.00000
Nx	-0.98685	-0.98685
Ny	0.16164	0.16164
Nz	-0.00000	-0.00000

Best Fit Center of Mass Deviation

Sigma	Form	Points
0.00935	0.04874	300
Min	Point no	Point no
-0.02733	154	69
		Max
		0.02141

Curve tolerance

Upper Tolerance: 0.05000
Lower Tolerance: -0.05000

Segment tolerances Settings

Curve jump tolerance Settings

OK Reset →

Curve Strategy



Here we set the Speed and Step Width or Number of Points

If our Curve is “broken” into segments we can define the run parameters here for each segment

