


# UMESS

## Universal Measuring Software for UNIX and LINUX



## Operating Instructions



The dissemination or copying of this manual, use or disclosure of its contents are prohibited without express permission. Violations will be prosecuted.

All rights reserved, especially regarding the granting of patents or the registration of utility models.

We reserve the right to revise this manual and make changes in the version and scope of delivery of the CMM, the software packages and the corresponding documentation.

Carl Zeiss does not guarantee this manual or provide any implied guarantee of its merchantable quality or suitability for any specific purpose whatsoever.

Carl Zeiss shall in no case be held liable for any errors contained in this manual or for any accidental or consequential damage in connection with its provision, function or use.

All product names are registered trademarks or trademarks of the corresponding proprietors.

**Carl Zeiss**  
Industrial Metrology  
Business Group  
D-73446 Oberkochen

Document type: . . . Operating Instructions  
Version: . . . . . 8.2  
Date: . . . . . 08/2000  
Order no.: . . . . . 61212-1010102

# Preface

These operating instructions are based on the assumption that you are already familiar with the operation of the corresponding coordinate measuring machine and its components. Please always keep all of the documents included in delivery within easy reach.

## About these operating instructions

Before beginning work with these operating instructions, please familiarize yourself with the conventions they employ first.

The following text will provide you with information on the fonts, characters and symbols used in this manual and the topics it covers.

### Typographical conventions

The following typographical conventions apply to this manual:

- **bold**
  - A dialog element displayed on the screen  
Example: "... the <TERMIN> button"
  - A term  
Example: "during the calculation the spatial position of a **measured element** is determined in relation to a **reference element**."
- *italics*
  - A highlighted text containing information of special importance  
Example: "Click with the *right* mouse button ..."
  - Cross reference  
Example: "..., see also ► „*Reading in the W-position* <DI 1712>“ auf Seite 16-10"
- **Courier**  
Text in dialog windows and records

## Characters and symbols

Special characters and symbols are used in this manual.



### Danger!

Special caution is required in this case. The warning triangle on the left indicates a danger of injury. If you do not observe this warning you may possibly be injured.



### Important!

This symbol is used to warn the reader of situations involving a possible data loss, measuring errors, faults during a measuring run, collisions, or damage to the CMM and/or the workpiece.




The **NOTE** symbol is placed next to important text passages and helpful additional information.

### Required input

Several possibilities exist:

- Direct selection via a DI number
- Function selection via the pull-down menu
- Selection via a pictograph display

Example:



<u>DI</u>	<u>Pull-down menu</u>	<u>Pictograph</u>
1551 PRBMOD	CMM mode Probe head...	



### Softkey symbol

References to softkeys are displayed in dialogs as shown on the left.

## Chapter overview

These operating instructions describe the function and handling of UMESS LX Universal Measuring Software. The following topics are covered:

- *„Einleitung“ auf Seite 1-1*
- *„Starting, operating and ending Measuring SW“ auf Seite 2-1*
- *„Description of the windows“ auf Seite 3-1*
- *„Data backup UNIX/LINUX“ auf Seite 4-1*
- *„Output of results“ auf Seite 5-1*
- *„Preparations for a measuring run“ auf Seite 6-1*
- *„Probe calibration“ auf Seite 7-1*
- *„Administration of probe data/probe change“ auf Seite 8-1*
- *„Rechnerisches Ausrichten“ auf Seite 9-1*
- *„Measuring“ auf Seite 10-1*
- *„Geometric elements“ auf Seite 11-1*
- *„Linking results“ auf Seite 12-1*
- *„Conversion of results“ auf Seite 13-1*
- *„Dimensional, form and position tolerances“ auf Seite 14-1*
- *„Rotary table operation“ auf Seite 15-1*
- *„Learn programming“ auf Seite 16-1*
- *„Control data modification and management“ auf Seite 17-1*
- *„CNC run“ auf Seite 18-1*
- *„Scanning“ auf Seite 19-1*

## Direct input functions

DI Number	Abbrev.	Function	Page
I		Restore/minimize input window	▶ Seite 3-2
-17		Activate graphic user interface	▶ Seite 3-41
-18		Deactivate graphic user interface	▶ Seite 3-41
-34	<b>REC ON</b>	Deactivate result output on control panel	▶ Seite 5-19
-35	<b>RECOFF</b>	Activate result output on control panel	▶ Seite 5-19
1003	<b>END</b>	End of operation	▶ Seite 2-20
1013	<b>TWCPASSIV</b>	CNC start from another computer	Opt. LX 11
1032	<b>CORRECT</b>	Delete last control data line in PROG	▶ Seite 16-17
1040	<b>FOCDIALDEF</b>	FOCUS: Programming dialog	Opt. LX 17
1041		FOCUS: Change safety (clearance) plane	Opt. LX 17
1042	<b>FOCBBEG</b>	FOCUS: Group start	Opt. LX 17
1043	<b>FOCBREND</b>	FOCUS: Group end	Opt. LX 17
1050	<b>JUMPS</b>	Conditional branching and jumps	▶ Seite 16-44
1051	<b>LOOPS</b>	Loops	▶ Seite 16-17
1055	<b>FOCBBEG</b>	FOCUS: Mark alignment block (start)	Opt. LX 17
1056	<b>FOCBREND</b>	FOCUS: Mark alignment block (end)	Opt. LX 17
1057	<b>FOCCLEARAN</b>	FOCUS: Mark clearance area	Opt. LX 17
1058	<b>FOCDETOUR</b>	FOCUS: Mark connecting points	Opt. LX 17
1059		FOCUS: Dialog	Opt. LX 17
1060	<b>FOCCLEARAN</b>	FOCUS: Define clearance area	Opt. LX 17
1065		FOCUS: Element start	Opt. LX 17
1066		FOCUS: Element end	Opt. LX 17
1070	<b>STEP</b>	CNC debugger	▶ Seite 18-17
1077	<b>MANCNC</b>	Computer controlled manually measured sections	▶ Seite 16-25
1079	<b>EXCALL</b>	Transfer macro to learn program	▶ Seite 16-28
1080	<b>BOREMISS</b>	Continuation with missing bore	▶ Seite 16-32
1081	<b>HOLE</b>	Bore element for safety mode	▶ Seite 16-34
1096	<b>PRG STOP</b>	Programmable stop	▶ Seite 16-21
1100	<b>FILE</b>	Collect points in file	▶ Seite 10-21
1101	<b>POINT</b>	POINT	▶ Seite 11-6
1102	<b>LINE</b>	LINE	▶ Seite 11-22
1103	<b>SURF</b>	SURFACE	▶ Seite 11-27

<b>DI Number</b>	<b>Abbrev.</b>	<b>Function</b>	<b>Page</b>
1104	<b>CIRC</b>	CIRCLE	▶ Seite 11-9
1105	<b>SPHERE</b>	SPHERE	▶ Seite 11-49
1106	<b>CYLIN</b>	CYLINDER	▶ Seite 11-36
1107	<b>CONE</b>	CONE	▶ Seite 11-41
1108	<b>ELLIP</b>	ELLIPSE	▶ Seite 11-19
1109	<b>TORUS</b>	TORUS	▶ Seite 11-46
1110	<b>MINPLA</b>	Min flatness	▶ Seite 14-60
1111	<b>MAXPLA</b>	Max flatness	▶ Seite 14-60
1112	<b>MINROUN</b>	Min roundness	▶ Seite 14-62
1113	<b>MAXROUN</b>	Max roundness	▶ Seite 14-62
1114	<b>CIRCSEG</b>	Circle segment and radius measurement	▶ Seite 11-53
1120	<b>SPCPT</b>	Space point	Opt. LX 6
1121	<b>SPCPTMOD</b>	Space point mode	Opt. LX 6
1132		Call interactive contour graphics	Opt. LX 20
1133		Quit interactive contour graphics	Opt. LX 20
1135		Save points to VDA file	Opt. LX 21
1136		Graphic form tester	Opt. LX 21
1139		Plot a VDA file from <b>&lt;DI 1135&gt;</b>	Opt. LX 21
1140	<b>EXTPLA</b>	Min-max flatness	▶ Seite 14-60
1141	<b>EXTROUN</b>	Min-max roundness	▶ Seite 14-62
1144		Cone angle correction	▶ Seite 13-15
1154	<b>3DCIRC</b>	Space circle	▶ Seite 11-58
1159	<b>BOREPATT</b>	2D bore pattern best fit	Opt. LX 2
1164	<b>3DBEFIT</b>	3D point best fit	Opt. LX 3
1166		Data transfer in VDA format	▶ Seite 10-26
1168		Best fit of circle in curve	Opt. LX 3
1169		Flatness macro	▶ Seite 11-63
1173	<b>PAREPT</b>	Parabola edge point	Opt. LX 6
1174		4-point circle	▶ Seite 11-17
1176		Overlapping mode for scanning	▶ Seite 19-37
1178		Determine probing direc. f. single pnt. in CNC run	▶ Seite 18-21
1179		Specify inner/outer code	▶ Seite 11-5
1180	<b>MCC MIC</b>	MCC/MIC fit	Opt. LX 3
1181	<b>OUTLIER</b>	Consideration of outliers on/off	▶ Seite 14-66

<b>DI Number</b>	<b>Abbrev.</b>	<b>Function</b>	<b>Page</b>
1184	PBCDEF	Determine bend parameters for unclamped scanning	▶ Seite 7-46
1185	FILTER	Filter mode	▶ Seite 14-69
1186	PBC	Measurement with compensation of probe bend	▶ Seite 7-47
1187	CORRPRB	Probing correction	▶ Seite 10-13
1188	INTRES	Switch on display of interm. results; switch on Auto_Termin, Auto_Nominal and warning limit	▶ Seite 10-8 ▶ Seite 10-10
1189		Find kink points	▶ Seite 10-27
1190		Macro definition, standard geometric forms	▶ Seite 10-27
1202	DIST	Distance in cartesian coordinates	▶ Seite 12-20
1203	DISPOL2D	Polar distance in the plane	▶ Seite 13-7
1204	ANG	Calculation of rotation and tilt angle	▶ Seite 13-2
1206	SYMM	Symmetry elements	▶ Seite 12-22
1215	SECT3D	Intersection point of axes in space	▶ Seite 12-7
1216	CORNPT	Corner point	Opt. LX 6
1217	ROTPT	Penetration point	▶ Seite 13-11
1218	SECTPLA	Plane intersections	▶ Seite 12-2
1219	SECTMAN	Surface sections	▶ Seite 12-9
1220	CONTPT	Edge point	Opt. LX 6
1243	ADDCONE	Additional cone program	▶ Seite 13-13
1251	CONVANG	Change reference axis and direction of rotation	▶ Seite 13-5
1261	DISTPOL3D	Space diagonal	▶ Seite 13-9
1262	XYZ	Supplementary coordinates	▶ Seite 10-47
1265		Generate plane by linking	▶ Seite 12-42
1266		Generate point by projecting from point to line	▶ Seite 12-45
1267		Generate line by projecting in plane	▶ Seite 12-50
1271		Link coordinates and direction	▶ Seite 12-19
1272		Perpendicular/Perpendicular distance	▶ Seite 12-19
1285	PERPCYL	Perpendicular cylinder	▶ Seite 12-15
1286	PERDIS	Perpendicular distance	▶ Seite 12-17
1301	RECALL	Recall of a coordinate system Recall of an address	▶ Seite 9-37 ▶ Seite 10-29
1303		Write to intermediate file for duplex CMM	Duplex opt.
1304		Read from intermediate file for duplex CMM	Duplex opt.
1310	PITCH	Pitch measurements	▶ Seite 12-30



<b>DI Number</b>	<b>Abbrev.</b>	<b>Function</b>	<b>Page</b>
1311	<b>CIRCPIT</b>	Circular pitch	▶ Seite 12-30
1312	<b>LINPIT</b>	Linear pitch	▶ Seite 12-30
1341		Determine minimum from measuring results	▶ Seite 12-40
1343		Determine maximum from measuring results	▶ Seite 12-40
1345	<b>MEANVAL</b>	Mean value calculation	▶ Seite 12-25
1379	<b>FORMULA</b>	Formula calculation	▶ Seite 12-27
1401	<b>GDTSTR</b>	Straightness	▶ Seite 14-19
1402	<b>GDTPLA</b>	Flatness	▶ Seite 14-21
1403	<b>GDTROUN</b>	Roundness	▶ Seite 14-26
1404	<b>GDTCYL</b>	Cylindricity	▶ Seite 14-28
1407	<b>GDTPOS</b>	Position with MMC	▶ Seite 14-45
1408	<b>GDTCON</b>	Concentricity with MMC	▶ Seite 14-55
1409	<b>GDTCOA</b>	Coaxiality with MMC	▶ Seite 14-57
1410	<b>GDTSYM</b>	Symmetry	▶ Seite 14-49
1415	<b>GDTPAR</b>	Parallelism	▶ Seite 14-31
1425	<b>GDTPERP</b>	Perpendicularity with MMC	▶ Seite 14-41
1435	<b>GDTANG</b>	Angularity	▶ Seite 14-38
1445	<b>GDTRUN</b>	Runout	▶ Seite 14-52
1449	<b>FORM</b>	Form error	▶ Seite 10-46
1454	<b>NAMODE</b>	Nominal/actual mode	▶ Seite 14-2
1456		Reserve address	▶ Seite 16-29
1459	<b>NOM</b>	Nominal input (old 1452)	▶ Seite 14-8
1460	<b>EXTREM</b>	Extreme values	▶ Seite 10-45
1461		Fast plot (form plot with default values)	Opt. LX 2
1470	<b>FPLOT</b>	Request form plots	Opt.LX 2
1472	<b>GDTFLAPART</b>	Flatness with reference length	▶ Seite 14-21
1473	<b>NAGRAPHI</b>	Plotting results from nominal-actual comparisons	Opt. LX 1
1502	<b>VECFORCE</b>	Measuring probe head mode	▶ Seite 6-18
1506	<b>JSTANG</b>	Travel in the workpiece or control coordinate system	▶ Seite 10-19
1507		Coordinate display on the control panel	▶ Seite 10-19
1509	<b>JSTXYZ</b>	Joystick assignment	▶ Seite 10-18
1510		Intermediate position	▶ Seite 16-31
1511	<b>POSITION</b>	Position to workpiece coordinates	▶ Seite 10-37

<b>DI Number</b>	<b>Abbrev.</b>	<b>Function</b>	<b>Page</b>
1513	<b>POS-RES</b>	Position to result	▶ Seite 10-38
1514	<b>POSNORM</b>	Position to normal vector	▶ Seite 10-40
15141		Change probe number in ACE	Opt. MFT
1515	<b>STEP</b>	Step in WP system	▶ Seite 10-41
1516	<b>REF STEP</b>	Travel a fixed interval from a probing point	▶ Seite 10-43
1520	<b>RTZEROP</b>	Set rotary table position to zero	▶ Seite 15-10
1521	<b>RTPOS</b>	Rotate rotary table to angular position	▶ Seite 15-4
15211	<b>TEMCOM</b>	Temperature compensation by input	▶ Seite 6-22
15218		RDS: Display and selection of angular positions	Opt. RDS
15219		RDS: List of calibrated angular positions	Opt. RDS
1522	<b>RT STEP</b>	Rotate rotary table one angle step	▶ Seite 15-7
15228		Semiautomatic probe calibration (tensor calibration) for unclamped probe head	▶ Seite 7-19
1523	<b>RT PITCH</b>	Rotate rotary table by a pitch angle	▶ Seite 15-8
1524	<b>RT ANG</b>	Align rotary table parallel to machine coordinates	▶ Seite 15-9
15250		Large coordinate display	▶ Seite 10-19
1526	<b>DSEPOS</b>	DSE position	Opt. DSE
1527	<b>DSE STEP</b>	DSE step	Opt. DSE
1528	<b>DSE ANG</b>	DSE angle acc. to result	Opt. DSE
1530	<b>SCAN MOD</b>	Scanning mode	▶ Seite 19-6
1546		DSE: Sensor calibration	Opt. DSE
1547		DSE: End calibration	Opt. DSE
1548		DSE: Calibration mode	Opt. DSE
1551	<b>PRBMOD</b>	Probe head mode	▶ Seite 10-16 ▶ Seite 16-24
1553	<b>PRBCHN</b>	Change probe cluster automatically	▶ Seite 8-17
1554	<b>RELPRB</b>	Remove probe manually	▶ Seite 8-12
1555	<b>PUPRB</b>	Pick up probe manually	▶ Seite 8-15
1556	<b>LISTSTR</b>	Storage (magazine) mode	▶ Seite 6-29
1557	<b>CALSTR</b>	Define probe storage positions (magazine)	▶ Seite 6-32
1558		List magazine positions	▶ Seite 6-32
1559		Activate/deactivate calibration interval	▶ Seite 7-49
1566	<b>RTLINK</b>	Rotate control coordinate system along with workpiece	▶ Seite 15-19

<b>DI Number</b>	<b>Abbrev.</b>	<b>Function</b>	<b>Page</b>
1567		Uncouple control coordinate system from work-piece	▶ Seite 15-19
1568	<b>RTCAL</b>	Store, read in, deactivate rotary table axis	▶ Seite 15-14
1570	<b>RERPT</b>	Reference point travel	▶ Seite 6-2 ▶ Seite 15-10
1572	<b>OFFSET</b>	Linear offset correction	▶ Seite 6-4
1574		Adapt probing behavior for small probes	▶ Seite 6-20
1578		Read and execute machine commands from a file	Opt. LX 11
1590	<b>CMM INIT</b>	Initialize machine	▶ Seite 6-37
1601	<b>CHNGCOMB</b>	Change combination	▶ Seite 8-11
1602		DSE: Probe calibration	Opt. DSE
1604		Print the last 10 measurement records	▶ Seite 5-43
1605		DSE: Articulating probe holder	Opt. DSE
1608	<b>INITSTATUS</b>	Set the initial status	▶ Seite 6-7
1610	<b>RECORD</b>	Call standard record head and variable record head I	▶ Seite 5-24
1611	<b>VAR RECORD</b>	Call variable record head II	▶ Seite 5-27
1612	<b>MODREC</b>	Modification of variable record head I	▶ Seite 5-22
1613	<b>REPEAT</b>	Repeat record	▶ Seite 5-40
1614	<b>PRINT</b>	Record output to terminal and printer	▶ Seite 5-12
1615	<b>TERMINAL</b>	Record output to terminal only	▶ Seite 5-12
1617	<b>STATUS</b>	System information	▶ Seite 6-36
1618	<b>TIME</b>	Time function	▶ Seite 5-38
1624	<b>CONFLIS</b>	List probe data	▶ Seite 8-6
1625	<b>PDEVICES</b>	Set mode for graphic output devices	▶ Seite 5-47
1627	<b>PRBCORR</b>	Modify probe data	▶ Seite 8-7
1630	<b>CNCADM</b>	Control data administration Workpiece catalog administration	▶ Seite 17-28 ▶ Seite 17-5
1631		Create a control data catalog	▶ Seite 17-25
1632	<b>P-END</b>	End learn (part) programming	▶ Seite 16-85
1634	<b>ENTDAT</b>	Enter workpiece in workpiece catalog	▶ Seite 17-10
1635	<b>DELETECNC</b>	Delete workpiece	▶ Seite 17-12
1639	<b>PROG</b>	Start learn (part) programming	▶ Seite 16-13
1640	<b>CNCRUN</b>	Start CNC run	▶ Seite 18-3
1641	<b>DATLIS</b>	List control data	▶ Seite 17-28

<b>DI Number</b>	<b>Abbrev.</b>	<b>Function</b>	<b>Page</b>
1642	<b>DATCOR</b>	Correct data	▶ Seite 17-31
1643	<b>CNCLIN</b>	Copy workpiece	▶ Seite 17-18
1644		Batch measurement	▶ Seite 18-8
1645	<b>CNCMOD</b>	Modify workpiece	▶ Seite 17-17
1646	<b>PCMTEST</b>	PCM test run	Opt. LX 9
1647	<b>PCMGEN</b>	PCM generation run	Opt. LX 9
1649		AUTO CNC start	Opt. LX 18
1650	<b>LISCAT</b>	List workpiece catalog to printer	▶ Seite 17-5
1651		Initialize graphics software	▶ Seite 5-48
1652		Output graphics (paper change)	▶ Seite 5-49
1661	<b>CONMODE</b>	Define control mode	▶ Seite 6-10
1662	<b>OUTPMOD</b>	Define the print format	▶ Seite 5-12
1663	<b>NAMES</b>	Switch name allocation on/off	▶ Seite 5-9
1664	<b>WARNLI</b>	Set a warning limit	▶ Seite 14-13
1665	<b>REC DEF</b>	Define scope of record	▶ Seite 5-14
1666	<b>PCMEDIT</b>	PCM edit mode	Opt. LX 9
1667		Define record output format	▶ Seite 5-17
1668	<b>AUTORUNDEF</b>	Set up/change one button mode	Opt. LX 5
1669	<b>AUTORUNON</b>	Activate one button mode	Opt. LX 5
1670	<b>RESTORE</b>	Restore old status	▶ Seite 6-7
1671	<b>PCMMOD</b>	PCM run mode	Opt. LX 9
1672	<b>FOCPRERUN</b>	FOCUS: Prerun	Opt. LX 17
1673	<b>FOCDIALDEF</b>	FOCUS: Features / graphics assignment	Opt. LX 17
1674	<b>PRINTMAN</b>	Administration of output devices	▶ Seite 5-50
1675	<b>FEED or NP</b>	Page feed in record	▶ Seite 5-19
1676	<b>TEXT</b>	Comments in measurement record	▶ Seite 5-33
1677	<b>BTEXT</b>	Comments on screen	▶ Seite 5-35
1678	<b>CPNTXT</b>	Comments on alphanumeric control panel	▶ Seite 5-37
1679		Comment line in control data	▶ Seite 16-28
1680	<b>FIXPLA</b>	Select reference plane	▶ Seite 10-50
1681	<b>SIGMA</b>	Mating size (Sigma factor)	▶ Seite 10-49
1682	<b>ANGDMS</b>	Output in degrees/minutes/seconds	▶ Seite 13-2
1683	<b>SAVEREC</b>	Save records	▶ Seite 5-41
1684	<b>RECOUTP</b>	Save, output and delete records	▶ Seite 5-42

<b>DI Number</b>	<b>Abbrev.</b>	<b>Function</b>	<b>Page</b>
1685	<b>SYSCOM</b>	Start customer programs	➤ Seite 3-44
1686	<b>SYSBEF2</b>	Start customer programs	➤ Seite 3-44
1687	<b>VARREC</b>	Variable measurement record	Opt. LX 1
1689	<b>PRINTSPOOL</b>	Print status with spooled printers	➤ Seite 5-52
1690	<b>RES</b>	Set record address counter to any address	➤ Seite 6-8
1692		Define language, unit of measurement and decimal places	3 - 46 ➤ Seite 5-16
1693		Address definition mode for EXCALL NP Termin line	Opt. LX 9
1694	<b>PRGCORR</b>	Correction of learn program during programming	➤ Seite 16-17
1698		Change operator name	➤ Seite 5-45
1699		FOCUS: Graphic result display (ERGANZ)	Opt. LX 17
1701	<b>ZEROPT</b>	Zero point	➤ Seite 9-15
1702	<b>TRPLANE</b>	Transformation plane	➤ Seite 9-7
1703	<b>TR0+1</b>	Rotate around zero point and one element	➤ Seite 9-24
1705	<b>TRDIS</b>	Rotate to distance	➤ Seite 9-29
1706	<b>TRSPACE</b>	Transformation space	➤ Seite 9-4
1707	<b>AXISCHA</b>	Select space axis	➤ Seite 9-23
1708	<b>WS-&gt;WPOS</b>	Store W-position in computer	➤ Seite 16-9
1709	<b>TRANGLE</b>	Rerotate about an angle (mode with DI 1719)	➤ Seite 9-25
1710	<b>WPTCAT</b>	Store/delete W position	➤ Seite 16-7
1711	<b>AXISSEL</b>	Rename workpiece axes / free axis selection	➤ Seite 9-33
1712	<b>WPFCAT</b>	Read in W-position	➤ Seite 16-10
1713	<b>WL WPC</b>	Form workpiece coordinate system from control coordinate system	➤ Seite 9-31
1719	<b>MOD1709</b>	Define mode for WP reference axis	➤ Seite 9-27
1720		Relative axis exchange	➤ Seite 9-36
1722	<b>BASISDIS</b>	Displace zero point into a theoretical plane	➤ Seite 9-19
1723	<b>DISPLACE</b>	Displace zero point by a defined value	➤ Seite 9-18
1731		X coordinate zero point	➤ Seite 9-17
1732		Y coordinate zero point	➤ Seite 9-17
1733		Z coordinate zero point	➤ Seite 9-17
1734		3D transformation with selectable axis	➤ Seite 9-10
1735		2D transformation with selectable axis	➤ Seite 9-10
1739		Enter nominal vector (DMIS postprocessor)	➤ Seite 9-10

<b>DI Number</b>	<b>Abbrev.</b>	<b>Function</b>	<b>Page</b>
1740		Alignment of nominals	► Seite 9-10
1750		Twin column: linking	Opt. LX 11
1751	<b>TWCROT</b>	Twin column: Calculate rotation	Opt. LX 11
1752	<b>TWC SURFACE</b>	Twin column: Save surface	Opt. LX 11
1753	<b>TWCLINE</b>	Twin column: Save line	Opt. LX 11
1754	<b>TWCSPERE</b>	Twin column: Save sphere	Opt. LX 11
1755	<b>TWCDELTR</b>	Twin column: Delete translation	Opt. LX 11
1756	<b>TWCACTIV</b>	Twin column: Activate link	Opt. LX 11
1757	<b>TWCTRANS</b>	Twin column: Calculate translation	Opt. LX 11
1758		Twin column: Initialization complete (caution)	Opt. LX 11
1759	<b>TWCLIST</b>	Twin column: List transformation system	Opt. LX 11
1769	<b>WPCPOL</b>	W-position displacement, polar	► Seite 16-66
1771	<b>WPDCCAR</b>	W-position displacement, cartesian	► Seite 16-66
1781		Result output for 3D elements	Opt. LX 6
1802		Generate UMESS 300 control data lines in PROG	Opt. LX 4
2100	<b>CADLINK</b>	Call CADLINK	Opt. LX 7
2300		Call GON	Opt. GON
2600	<b>STS</b>	CMM multisphere test standard (MSTS)	Opt. LX 15
2605	<b>TSTFILES</b>	CMM MSTS: Parameter input	Opt. LX 15
2610	<b>STSGEN</b>	CMM MSTS: CNC generation	Opt. LX 15
2620	<b>STSEVAL</b>	CMM MSTS: Evaluation	Opt. LX 15
2700	<b>KUM</b>	Call KUM	Opt. KUM
2800	<b>PIPE</b>	Call pipe measurement program	Opt. LX 12
2900	<b>SAM</b>	Call SAM	Opt. SAM NV
2950	<b>SPC</b>	Call SAM-SPC	Opt. SAM NV
2951	<b>SPCTRA</b>	SAM data transfer	Opt. SAM NV
2952		Fetch measuring run data from SAM with PCM	Opt. SAM NV
2990		SAM-Daten Update ab Rev. 7.0 auf Rev 7.5 Update of SAM data to Rev. 7.5 from Rev. >/=7.0	Opt. SAM NV
3000	<b>ACE</b>	Call ACE	Opt. ACE
3001	<b>PRBNO</b>	ACE: Probe change	Opt. ACE
3002	<b>I-POS</b>	ACE: Intermediate position	Opt. ACE
3003	<b>PROBING</b>	ACE: Probing	Opt. ACE
3004	<b>MACRO</b>	ACE: Macro	Opt. ACE

<b>DI Number</b>	<b>Abbrev.</b>	<b>Function</b>	<b>Page</b>
3005	<b>DSEMODE</b>	ACE: DSE mode	Opt. ACE
3010	<b>RES 1LINE</b>	ACE: Reserve one control data line	Opt. ACE
3011	<b>RES NLINE</b>	ACE: Reserve n control data lines	Opt. ACE
3012		GON: Gear measurement	Opt. GON
3013		GON: Gear new input	Opt. GON
3014		GON: Subsequent evaluation	Opt. GON
3016		GON: Brief input	Opt. GON
3022		GON: Measurement	Opt. GON
3051		GON: Definition of standards	Opt. GON
3052		GON: Definition of graphic formats	Opt. GON
3053		GON: Data administration	Opt. GON
3054		GON: Manager	Opt. GON
3055		GON: Data output	Opt. GON
3056	<b>CHANCE</b>	ACE: Disperse data	Opt. ACE
3060		Activate measurement counter for manual CMMs	
3061		Change display coordinates for manual CMMs	
3099	<b>UMESS</b>	ACE off / UMESS on	Opt. ACE
3201	<b>CNCCOTUX</b>	Convert control data from UMESS 300	Opt. LX 4 N/V
3202		Initialize record header for <DI 3201>	Opt. LX 4 N/V
3301	<b>CNCCOT300</b>	Convert control data to UMESS 300 (old)	Opt. LX 4 N/V
3452	<b>FETCHASCII</b>	DATAKOM: Receive file	
3453	<b>ASCIISEND</b>	DATAKOM: Send file	
3457	<b>DACCOM-MAND</b>	DATAKOM: Command input	
3459	<b>DACPATHDEF</b>	DATAKOM: Abbreviation definition	
3460	<b>FETCNC</b>	DATAKOM: Fetch CNC runs	
3461	<b>SENDCNC</b>	DATAKOM: Send CNC runs	
3469	<b>ESNCREC</b>	DATAKOM: Send current measurement record	
3470	<b>DOPSTART</b>	DATAKOM: Offline start	Opt. LX 11
3472		DATAKOM: Remote control	
3499	<b>DACTOTDEF</b>	DATAKOM: LAN preassignment	
3500	<b>SAVE</b>	Save/externally store CNC programs	➤ Seite 4-3
3510		Copy CMM command blocks to intermediate storage	➤ Seite 4-14

<b>DI Number</b>	<b>Abbrev.</b>	<b>Function</b>	<b>Page</b>
3511		Restore KUM command blocks from intermediate storage	▶ Seite 4-14
3800	<b>KAM</b>	Call KAM	Opt. KAM
3801	<b>VDAKUM</b>	VDA data => KUM (nominal data)	Opt. KUM
3802	<b>KUMVDA</b>	KUM => VDA (measured data)	Opt. KUM
3803	<b>NOMMEA</b>	Measurement according to nominals	Opt. KUM
3811	<b>KAMMACRO</b>	Macro functions for KAM	Opt. KAM
3840		Save record for columns 1 and 2 to file	Opt. LX 11
3841		Create a double record (for wide paper only)	Opt. LX 11
3870	<b>FCC</b>	Fast contour control	Opt. KUM
4500		SAM reporter	
6501		Semiautomatic probe calibration	▶ Seite 7-17
6502		Manual probe calibration	▶ Seite 7-29
6504		Delete probe data	▶ Seite 8-10
6505		Set probe data to zero	▶ Seite 8-9
6506		Specify reference probe	▶ Seite 7-15
6507		Define calibration mode	▶ Seite 7-10
6511		Temperature compensation by input	▶ Seite 6-22
6512		Define temperature-sensitive probe	
6513		Define temperature limit	▶ Seite 6-24
6514		Check temperature limit	▶ Seite 6-26
6515		Temperature record	▶ Seite 6-27
6520	<b>PRB BEND</b>	Determine bend parameters for clamped probe head	▶ Seite 7-36



# Table of contents

<b>About these operating instructions</b> .....	<b>3</b>
Typographical conventions .....	3
Characters and symbols .....	4
Chapter overview .....	5
<b>Direct input functions</b> .....	<b>6</b>

## **Chapter1 Introduction**

<b>Scope of the UMESS user manual</b> .....	<b>1-2</b>
<b>How to use the operating instructions</b> .....	<b>1-3</b>
<b>Hardware</b> .....	<b>1-5</b>

## **Chapter2 Starting, operating and ending Measuring**

**SW**

<b>General comments on windowing</b> .....	<b>2-2</b>
<b>Prerequisites</b> .....	<b>2-3</b>
<b>Switching on the measuring machine and computer</b> . . . .	<b>2-4</b>
Differences .....	2-4
KDE user interface .....	2-5
<b>Reference point travel</b> .....	<b>2-7</b>
Dialog window .....	2-7
Reference point travel .....	2-7
Procedure .....	2-8
Limit position .....	2-9
UMESS without CMM .....	2-9
<b>Login procedure</b> .....	<b>2-10</b>
<b>Keyboard</b> .....	<b>2-11</b>
Function .....	2-11
Special keys .....	2-11

<b>Mouse functions</b> .....	<b>2-15</b>
Mouse .....	2-15
Mouse pointer .....	2-15
<b>Function calls</b> .....	<b>2-16</b>
Explanation of illustration .....	2-16
Function call via a direct input .....	2-16
<b>Faults (Break)</b> .....	<b>2-18</b>
<b>End of operation</b> .....	<b>2-20</b>

## **Chapter3 Description of the windows**

<b>Working with windows</b> .....	<b>3-2</b>
Activating windows .....	3-2
Moving windows .....	3-2
Shrinking the window to an icon .....	3-2
Modifying the window size .....	3-3
Scrolling the contents of the window .....	3-4
Window menu .....	3-4
<b>UMESS main menu</b> .....	<b>3-6</b>
Functions of the UMESS main menu .....	3-6
Structure of the UMESS main menu .....	3-8
<b>Calling UMESS functions using menus</b> .....	<b>3-10</b>
Using the mouse .....	3-10
Using the keyboard .....	3-11
Using the standard control panel .....	3-11
Overview of all menus .....	3-12
<b>Pictograms in the UMESS main menu</b> .....	<b>3-23</b>
Calling UMESS functions via pictograms .....	3-23
Selecting another pictogram page .....	3-25
Editing a pictogram page .....	3-25
Utilities for the pictogram pages .....	3-28
Reinitializing a window .....	3-32
<b>Setting colors and fonts</b> .....	<b>3-33</b>

Setting colors .....	3-33
Setting fonts .....	3-34
<b>Other windows in UMESS .....</b>	<b>3-36</b>
Printer (record) window .....	3-36
Plotter window .....	3-37
Dialog window .....	3-38
UMESS dialog window .....	3-40
<b>Activating/deactivating the UMESS main menu .....</b>	<b>3-41</b>
<b>Changing the language &lt;DI 1692&gt; .....</b>	<b>3-42</b>
<b>Starting system programs &lt;DI 1685/1686&gt; .....</b>	<b>3-44</b>

## **Chapter4 Data backup UNIX/LINUX**

<b>General information on data backup UNIX .....</b>	<b>4-2</b>	
<b>Backing up and restoring CNC programs &lt;DI 3500&gt; ....</b>	<b>4-3</b>	
Intermediate storage .....	4-3	
Dialog page for data backup .....	4-4	
Clearing the intermediate store .....	4-5	
Backup to/restoration from intermediate storage .....	4-6	
Copying the contents of the intermediate store to a backup medium	4-9	
Copying data from the backup medium to the intermediate store ..	4-11	
Converting control data to the ASCII or internal format .....	4-13	
Backup and restoration of all workpiece-independent KUM data with	<DI 3510> and <DI 3511> .....	4-14
<b>Backup and restoration of user data with CZ Utilities ..</b>	<b>4-16</b>	
Starting CZ Utilities for data backup .....	4-16	
Backup of User Data .....	4-18	
Restoring user data .....	4-20	
<b>Executing and restoring a full backup .....</b>	<b>4-21</b>	
Single User mode .....	4-21	
Executing a full backup .....	4-22	
Restoring a full backup .....	4-22	

Data backup modes LINUX .....	4-23
-------------------------------	------

## Chapter5 Output of results

<b>Basic Principles .....</b>	<b>5-2</b>
Components of the measurement record .....	5-2
Variants of the record output .....	5-2
Display of results in the measurement record .....	5-3
<b>Identification of results .....</b>	<b>5-8</b>
Allocating addresses .....	5-8
Input of identifications .....	5-9
Allocating names .....	5-9
<b>Output mode &lt;DI 1662&gt; .....</b>	<b>5-12</b>
Defining the record output medium <DI 1614 /1615> .....	5-12
Defining the scope of the record <DI 1665> .....	5-14
Defining the language, unit of measurement and decimal places <DI 1692> .....	5-16
Defining the print format <DI 1667> .....	5-17
Page feed in the record <DI 1675> .....	5-19
Result output on alphanumeric control panel .....	5-19
<b>Header .....</b>	<b>5-21</b>
Default record header and variable record header I .....	5-21
Modification of variable header I <DI 1612> .....	5-22
Calling the default header and variable header I <DI 1610> .....	5-24
Call des Variablen Protokollkopfes II <DAW 1611> .....	5-27
<b>Comment input .....</b>	<b>5-33</b>
Comments in the measurement record <DI 1676> .....	5-33
Screen display of comments <DI 1677> .....	5-35
Comments on the alphanumeric control panel <DI 1678> .....	5-37
<b>Time function &lt;DI 1618&gt; .....</b>	<b>5-38</b>
<b>Repetition record &lt;DI 1613&gt; .....</b>	<b>5-40</b>
<b>Saving, outputting and deleting records .....</b>	<b>5-41</b>
Saving records with a workpiece number or code <DI 1683> .....	5-41

Saving, outputting and deleting records <DI 1684> . . . . .	5-42
Printing the last 10 measurement records <DI 1604> . . . . .	5-43
<b>Changing the user name &lt;DI 1698&gt; . . . . .</b>	<b>5-45</b>
<b>Graphic output . . . . .</b>	<b>5-46</b>
Setting the mode for graphic devices <DI 1625> . . . . .	5-47
Initializing the graphic software <DI 1651> . . . . .	5-48
Output of graphics <DI 1652> . . . . .	5-49
<b>Printing and plotting in a network . . . . .</b>	<b>5-50</b>
Administration of output devices <DI 1674> . . . . .	5-50
Status with spooled printers <DI 1689> . . . . .	5-52

## **Chapter6 Preparations for a measuring run**

<b>Reference point travel &lt;DI 1570&gt; . . . . .</b>	<b>6-2</b>
<b>Linear offset correction &lt;DI 1572&gt; . . . . .</b>	<b>6-4</b>
<b>Setting the address counter . . . . .</b>	<b>6-7</b>
Setting the initial status <DI 1608> . . . . .	6-7
Producing the old status <DI 1670> . . . . .	6-7
Setting the address counter to a random address <DI 1690> . . . . .	6-8
<b>Defining the control mode &lt;DI 1661&gt; . . . . .</b>	<b>6-10</b>
Probing parameters <PROBE P> . . . . .	6-11
Machine parameters <MACHIN.P> . . . . .	6-13
Decisions <DECISION> . . . . .	6-16
<b>Setting the operating mode for the measuring probe head &lt;DI 1502&gt; . . . . .</b>	<b>6-18</b>
Adapting the probing behavior <DI 1574> . . . . .	6-20
<b>Influence, correction and monitoring of temperature changes 6-21</b>	
Influence . . . . .	6-21
Temperature compensation via input <DI 6511> . . . . .	6-22
Temperature monitoring <DI 6513> . . . . .	6-24
Temperature check with <DI 6514> . . . . .	6-26
Temperature record with <DI 6515> . . . . .	6-27

<b>Position of probe rack</b> .....	<b>6-28</b>
Magazine mode <DI 1556> .....	6-29
Defining the probe holder positions <DI 1557> .....	6-32
<b>System information &lt;DI 1617&gt;</b> .....	<b>6-36</b>
<b>Initializing the machine &lt;DI 1590&gt;</b> .....	<b>6-37</b>

## **Chapter7 Probe calibration**

<b>General information</b> .....	<b>7-2</b>
Terms .....	7-2
Types of probe calibration .....	7-5
General procedure .....	7-5
Accuracy of probe calibration .....	7-6
Permissible temperature range .....	7-7
<b>Preparing for probe calibration</b> .....	<b>7-10</b>
Defining the calibration mode <DI 6507> .....	7-10
Specifying the reference probe <DI 6506> .....	7-15
<b>Semiautomatic probe calibration</b> .....	<b>7-17</b>
Overview .....	7-17
Semiautomatic probe calibration with <DI 6501> .....	7-17
Semiautomatic probe calibration with <DI 15228> (tensor calibration) .....	7-19
Tensor calibration: Full calibration or recalibration .....	7-25
Inclined probes during semiautomatic probe calibration .....	7-27
<b>Manual probe calibration &lt;DI 6502&gt;</b> .....	<b>7-29</b>
<b>CNC probe calibration</b> .....	<b>7-31</b>
<b>Calibrating disk and cylinder probes</b> .....	<b>7-32</b>
<b>Recalibration with reference standards</b> .....	<b>7-33</b>
<b>Probe bend compensation</b> .....	<b>7-34</b>
General information .....	7-34
Determining bend parameters for the "clamped" probe head mode <DI 6520> .....	7-36

Output and deletion of bend parameters . . . . .	7-44
Determining bend parameters for unclamped scanning <DI 1184> . . . . .	7-46
Measuring with compensation of the probe bend <DI 1186> . . . . .	7-47
<b>Checking the calibration at regular intervals &lt;DI 1559&gt;</b>	<b>7-49</b>

## **Chapter8 Administration of probe data/probe change**

<b>Terms . . . . .</b>	<b>8-2</b>
<b>General . . . . .</b>	<b>8-4</b>
<b>Output of probe data &lt;DI 1624&gt; . . . . .</b>	<b>8-6</b>
<b>Modifying probe data &lt;DI 1627&gt; . . . . .</b>	<b>8-7</b>
<b>Deleting and resetting probe data . . . . .</b>	<b>8-9</b>
Resetting probe data (to zero) <DI 6505> . . . . .	8-9
Deleting probe data <DI 6504> . . . . .	8-10
<b>Changing the combination &lt;DI 1601&gt; . . . . .</b>	<b>8-11</b>
<b>Changing probes . . . . .</b>	<b>8-12</b>
Removing probes manually <DI 1554> . . . . .	8-12
Inserting probes manually <DI 1555> . . . . .	8-15
Automatic probe change <DI 1553> . . . . .	8-17

## **Chapter9 Mathematical alignment**

<b>Coordinate systems . . . . .</b>	<b>9-2</b>
<b>Aligning the workpiece parallel to the machine coordinates</b>	<b>9-3</b>
Transformation space <DI 1706> . . . . .	9-4
Transformation plane <DI 1702> . . . . .	9-7
Transformation with selectable coordinate axis . . . . .	9-10
<b>Parallel displacement of the workpiece coordinate system . . . . .</b>	<b>9-15</b>
Zeroing an element <DI 1701> . . . . .	9-15
Zeroing a coordinate <DI 1731, 1732, 1733> . . . . .	9-17
Displacing the zero point by a defined value <DI 1723> . . . . .	9-18

Displacing the zero point into a theoretical reference plane <DI 1722>  
9-19

**Rotating the workpiece coordinate system . . . . . 9-23**

Selecting the space axis <DI 1707> . . . . . 9-23

Rotation about the zero point and one element <DI 1703> . . . . 9-24

Rerotating by an angle <DI 1709> . . . . . 9-25

Defining the mode for the WP reference axis <DI 1719> . . . . . 9-27

Rotating to distance <DI 1705> . . . . . 9-29

**Forming a workpiece coordinate system from a control  
coordinate system <DI 1713> . . . . . 9-31**

**Renaming the workpiece axes . . . . . 9-33**

Free axis selection <DI 1711> . . . . . 9-33

Relative axis selection <DI 1720> . . . . . 9-36

**Recall of an element or a coordinate system <DI 1301> 9-37**

## **Chapter10 Measuring**

**Procedure . . . . . 10-2**

**Probing . . . . . 10-3**

Probing strategies . . . . . 10-3

Probing possibilities . . . . . 10-5

Switching on the intermediate result display <DI 1188> . . . . . 10-8

Simplified termination of probings,  
Warning limit input < DI 1188> . . . . . 10-10

Probing correction <DI 1187> . . . . . 10-13

Correction of probing errors . . . . . 10-15

Self-centering probing (for the measuring probe head only) . . . 10-16

Changing the allocation of joystick deflection to travel movements  
<DI 1509> . . . . . 10-18

Travel in the workpiece or control coordinate system <DI 1506> . . .

10-19

Displaying workpiece coordinates <DI 1507> <DI 15250> . . . . 10-19

**Creating/evaluating point collection files . . . . . 10-21**

Collecting points in a file <DI 1100> . . . . . 10-21

File evaluation . . . . . 10-22



Data transfer in VDA format <DI 1166> . . . . .	10-26
Finding kink points <DI 1189> . . . . .	10-27
<b>Recalling results . . . . .</b>	<b>10-29</b>
Recall of an address <DI 1301> . . . . .	10-29
Recall of several elements . . . . .	10-32
<b>Travel commands . . . . .</b>	<b>10-34</b>
Positioning to workpiece coordinates <DI 1511> . . . . .	10-37
Positioning to a result <DI 1513> . . . . .	10-38
Positioning to a normal vector <DI 1514> . . . . .	10-40
Travel from the current position in fixed steps <DI 1515> . . . . .	10-41
Travel from a probing position in fixed steps <DI 1516> . . . . .	10-43
<b>Additional information . . . . .</b>	<b>10-45</b>
Extreme values <DI 1460> . . . . .	10-45
Form error <DI 1449> . . . . .	10-46
Supplementary coordinates <DI 1262> . . . . .	10-47
Mating size (sigma factor) <DI 1681> . . . . .	10-48
Selecting the reference plane <DI 1680> . . . . .	10-50
<b>Interpretation of the measurement results . . . . .</b>	<b>10-53</b>
Projected angles . . . . .	10-53
Dispersion (standard deviation) . . . . .	10-55
"No result" function . . . . .	10-55

## Chapter11 Geometric elements

<b>General . . . . .</b>	<b>11-2</b>
Input and dialog window for N point programs . . . . .	11-3
Macro selection . . . . .	11-3
Entering the inner/outer code <DI 1179> . . . . .	11-5
<b>POINT &lt;DI 1101&gt; . . . . .</b>	<b>11-6</b>
<b>CIRCLE &lt;DI 1104&gt; . . . . .</b>	<b>11-9</b>
Measuring a circle manually . . . . .	11-9
Measuring a circle semiautomatically . . . . .	11-11
Scanning a circle with VAST . . . . .	11-12
4-point circle <DI 1174> . . . . .	11-17

<b>ELLIPSE &lt;DI 1108&gt;</b> .....	<b>11-19</b>
<b>LINE &lt;DI 1102&gt;</b> .....	<b>11-22</b>
<b>SURFACE &lt;DI 1103&gt;</b> .....	<b>11-27</b>
Measuring a surface manually .....	11-27
Measuring a surface semiautomatically .....	11-29
Scanning a surface with VAST .....	11-31
<b>CYLINDER &lt;DI 1106&gt;</b> .....	<b>11-36</b>
<b>CONE &lt;DI 1107&gt;</b> .....	<b>11-41</b>
<b>TORUS &lt;DI 1109&gt;</b> .....	<b>11-46</b>
<b>SPHERE &lt;DI 1105&gt;</b> .....	<b>11-49</b>
<b>Circle segment &lt;DI 1114&gt;</b> .....	<b>11-53</b>
<b>3D circle &lt;DI 1154&gt;</b> .....	<b>11-58</b>
<b>Theoretical elements</b> .....	<b>11-61</b>
<b>Flatness macro &lt;DI 1169&gt;</b> .....	<b>11-63</b>

## **Chapter12 Linking results**

<b>Intersections</b> .....	<b>12-2</b>
Plane intersections <DI 1218> .....	12-2
Intersection point of axes in space <DI 1215> .....	12-7
Surface sections <DI 1219> .....	12-9
<b>Perpendicular calculations</b> .....	<b>12-15</b>
Perpendicular cylinder <DI 1285> .....	12-15
Perpendicular distance <DI 1286> .....	12-17
Perpendicular / Perpendicular distance <DI 1272> .....	12-19
<b>Distance in cartesian coordinates &lt;DI 1202&gt;</b> .....	<b>12-20</b>
<b>Symmetry elements &lt;DI 1206&gt;</b> .....	<b>12-22</b>
<b>Mean value calculation &lt;DI 1345&gt;</b> .....	<b>12-25</b>
<b>Formula calculation &lt;DI 1379&gt;</b> .....	<b>12-27</b>
<b>Pitch measurements &lt;DI 1310&gt;</b> .....	<b>12-30</b>

<b>Determining the minimum and maximum of measurement results &lt;DI 1341&gt; &lt;DI 1343&gt; . . . . .</b>	<b>12-40</b>
<b>Generating a plane by linking &lt;DI 1265&gt; . . . . .</b>	<b>12-42</b>
<b>Generating a point by projecting from point to line &lt;DI 1266&gt; 12-45</b>	

## **Chapter13 Conversion of results**

<b>Conversion of results . . . . .</b>	<b>13-2</b>
Angle output in degrees, minutes and seconds <DI 1682> . . . . .	13-2
Calculation of the rotation and tilt angle <DI 1204> . . . . .	13-2
Changing the reference axis and direction of rotation <DI 1251> . . . . .	13-5
<b>Calculation of polar distances . . . . .</b>	<b>13-7</b>
Polar distance in one plane <DI 1203> . . . . .	13-7
Space diagonal <DI 1261> . . . . .	13-9
<b>Penetration point &lt;DI 1217&gt; . . . . .</b>	<b>13-11</b>
<b>Additional cone program &lt;DI 1243&gt; . . . . .</b>	<b>13-13</b>
<b>Cone angle correction &lt;DI 1144&gt; . . . . .</b>	<b>13-15</b>

## **Chapter14 Dimensional, form and position tolerances**

<b>Dimensional tolerances . . . . .</b>	<b>14-2</b>
Procedure . . . . .	14-2
Nominal-actual mode <DI 1454> . . . . .	14-2
Nominal input <DI 1459> (old 1452) . . . . .	14-8
Setting a warning limit <DI 1664> . . . . .	14-13
Interpretation of results . . . . .	14-14
Output of deviations referenced to the tolerance center . . . . .	14-16
<b>Form tolerances . . . . .</b>	<b>14-18</b>
Straightness <DI 1401> . . . . .	14-19
Flatness <DI 1402>, with reference length <DI 1472> . . . . .	14-21
Roundness <DI 1403> . . . . .	14-26
Cylindricity <DI 1404> . . . . .	14-28

<b>Position tolerances</b> .....	<b>14-30</b>
Parallelism <DI 1415> .....	14-31
Angularity (slope) <DI 1435> .....	14-38
Perpendicularity with MMC <DI 1425> .....	14-41
Position with MMC <DI 1407> .....	14-45
Symmetry <DI 1410> .....	14-49
Runout <DI 1445> .....	14-52
Concentricity with MMC <DI 1408> .....	14-55
Coaxiality with MMC <DI 1409> .....	14-57
<b>Superposition of form and position deviations</b> .....	<b>14-60</b>
Min-max flatness <DI 1110/1111/1140> .....	14-60
Min-max roundness <DI 1112/1113/1141> .....	14-62
<b>Deleting outliers &lt;DI 1181&gt;</b> .....	<b>14-66</b>
<b>Filtering points &lt;DI 1185&gt;</b> .....	<b>14-69</b>

## **Chapter15 Rotary table operation**

<b>Procedure for measuring with a computer controlled rotary table</b> .....	<b>15-2</b>
<b>Preparations</b> .....	<b>15-3</b>
<b>Positioning commands</b> .....	<b>15-4</b>
Positioning with the computer or joystick .....	15-4
Rotating the rotary table to an angular position <DI 1521> .....	15-4
Rotating the rotary table by an angular step <DI 1522> .....	15-7
Rotating the rotary table by a scale division <DI 1523> .....	15-8
Aligning the rotary table parallel to the machine coordinates <DI 1524> .....	15-9
Traveling to the rotary table reference point <DI 1570> .....	15-10
Setting the rotary table position to zero <DI 1520> .....	15-10
<b>Rotary table measurement mode</b> .....	<b>15-11</b>
Procedure .....	15-11
Defining the rotary table axis .....	15-12
Storing, reading in and deactivating the rotary table axis <DI 1568> .....	15-14

Displaying the rotary table axis .....	15-16
Coupled rotation/uncoupling of workpiece/control coordinate system <DI 1566> (<DI 1567>) .....	15-19

## **Chapter16 Learn programming**

<b>General .....</b>	<b>16-2</b>
<b>Procedure for learn programming .....</b>	<b>16-5</b>
<b>Control coordinate system .....</b>	<b>16-6</b>
Defining and storing the control coordinate system .....	16-6
Storing the W-position/Deleting the W-position <DI 1710> .....	16-7
Storing the W-position in the computer <DI 1708> .....	16-9
Reading in the W-position <DI 1712> .....	16-10
W-position catalog .....	16-11
<b>Starting learn programming &lt;DI 1639&gt; .....</b>	<b>16-13</b>
Learn programming a new workpiece .....	16-13
Continuing the learn programming of an existing workpiece ..	16-14
<b>Execution of learn programming .....</b>	<b>16-16</b>
Procedure .....	16-16
Screen display during learn programming .....	16-17
Correction during learn programming <DI 1032> and <DI 1694> .....	16-17
Program calls .....	16-20
Probing, probing parameters, machine parameters .....	16-20
Programmable stop <DI 1096> .....	16-21
Probe head mode <DI 1551> .....	16-24
Computer controlled manually measured sections <DI 1077> ..	16-25
Comment line in the control data <DI 1679> .....	16-28
Reserve address <DI 1456> .....	16-29
Strategies for time-optimized programs .....	16-29
<b>Travel paths and intermediate positions .....</b>	<b>16-30</b>
Overview .....	16-30
Intermediate position <I-Pos> in the W-position system .....	16-31
Fine positioning in the workpiece coordinate system .....	16-31

Continuation after a missing bore <DI 1080> . . . . .	16-32
Bore element <DI 1081> . . . . .	16-34
<b>Generating programs . . . . .</b>	<b>16-36</b>
Overview . . . . .	16-36
Loops <DI 1051> . . . . .	16-36
Conditional branchings and jumps <DI 1050> . . . . .	16-44
Formulating conditions for loops and branchings. . . . .	16-49
Control data of loops and branchings . . . . .	16-58
Application example for loops and branchings . . . . .	16-64
W-position displacement <DI 1769, DI 1771> . . . . .	16-66
EXCALL workpiece jump . . . . .	16-71
CNC macro mode . . . . .	16-77
Creating a CNC macro . . . . .	16-78
Copying a macro to a learn program <DI 1079> . . . . .	16-81
<b>Terminating learn programming &lt;DI 1632&gt; . . . . .</b>	<b>16-85</b>

## **Chapter17 Control data modification and management**

<b>Workpiece catalog . . . . .</b>	<b>17-5</b>
Listing the workpiece catalog <DI 1630, 1650> . . . . .	17-5
Entering a workpiece in the workpiece catalog <DI 1634> . . . . .	17-10
Deleting workpieces <DI 1635> . . . . .	17-12
Workpiece information . . . . .	17-15
Modifying workpiece attributes <DI 1645> . . . . .	17-17
Copying workpieces <DI 1643> . . . . .	17-18
Managing workpiece catalogs <DI 1630> . . . . .	17-19
Changing or deleting a password in the workpiece catalog . . . . .	17-21
Defining the output columns of the catalog . . . . .	17-22
Changing the control data catalog . . . . .	17-23
Creating a new control data catalog . . . . .	17-25
Modifying or deleting a control data catalog . . . . .	17-26
<b>Editing control data . . . . .</b>	<b>17-28</b>
Listing control data <DI 1641> . . . . .	17-28
Interpretation of the control data . . . . .	17-29
Correcting control data <DI 1642> . . . . .	17-31

Selecting a control data line <SELECT L> . . . . .	17-35
Modifying a control data line <MODIFY> . . . . .	17-35
Masking a control data line <MASK> . . . . .	17-37
Unmasking a control data line with <DEMASK> . . . . .	17-38
Inserting additional control data lines with <INSERT> . . . . .	17-39
Copying control data lines with <COPY> . . . . .	17-40
Moving control data lines <MOVE> . . . . .	17-42
Deleting control data lines <DELETE> . . . . .	17-43
Converting control data <CONVERS> . . . . .	17-44
Softkeys for special functions <SPEC FCT> . . . . .	17-48
Adjusting control data addresses <AUTO-ADR>, <MAN-ADR> .	17-49
Searching for control data lines < FUNCT ->, FUNCT <-, CHAR. ->, CHAR. <-> . . . . .	17-51
Systematically changing control data coordinates <FORMULA>	17-53
Automatic nominal value adjustment <NOM CONV> . . . . .	17-54
Copying control data lines from other workpieces <MIX> . . . .	17-55
Terminating the control data correction <TERMIN> . . . . .	17-58

## Chapter18 CNC run

<b>Procedure . . . . .</b>	<b>18-2</b>
<b>Starting a CNC run for a single workpiece &lt;DI 1640&gt; . .</b>	<b>18-3</b>
<b>Starting a CNC run for multiple workpieces . . . . .</b>	<b>18-5</b>
Overview . . . . .	18-5
Compiling a batch measurement with EXCALL . . . . .	18-6
Batch measurement with <DI 1644> . . . . .	18-8
<b>Interrupting and continuing a CNC run . . . . .</b>	<b>18-11</b>
Interruption by the operator . . . . .	18-11
Function call during the stop phase . . . . .	18-13
Interruption due to malfunction . . . . .	18-14
User guidance in manual sections . . . . .	18-16
<b>CNC debugger &lt;DI 1070&gt; . . . . .</b>	<b>18-17</b>
<b>Determining the probing direction for single points of a CNC run &lt;DI 1178&gt; . . . . .</b>	<b>18-21</b>

## Chapter19 Scanning

<b>General</b> .....	<b>19-2</b>
<b>Preparations</b> .....	<b>19-3</b>
Selecting the scanning method .....	19-3
Preparations for measuring probe heads .....	19-5
Defining the scanning mode <DI 1530> .....	19-6
Transferring the scanning mode .....	19-8
Listing the scanning modes <MOD TOT> .....	19-9
<b>Scanning measuring run</b> .....	<b>19-10</b>
Branching of dialog windows .....	19-10
Scanning with UMESS .....	19-11
Scanning with KUM .....	19-13
Scanning with HOLOS .....	19-14
<b>Details on the scanning mode</b> .....	<b>19-15</b>
Branching of dialog windows .....	19-15
Scanning in the known contour mode .....	19-16
Scanning in the unknown contour mode .....	19-19
Scanning in the known contour clamped mode .....	19-21
<b>Explanation of the scanning parameters</b> .....	<b>19-25</b>
Mode of operation .....	19-25
Path modes .....	19-25
Scanning speed .....	19-28
Intermediate position during scanning .....	19-28
Point density .....	19-30
Reclamping .....	19-33
Target code/target window .....	19-35
Overlapping mode <DI 1176> .....	19-37
<b>Explanation of the scanning measuring run</b> .....	<b>19-39</b>
Scanning a known contour .....	19-39
Scanning unknown contours .....	19-42
Scanning unknown contours, clamped .....	19-44
Scanning an unknown contour manually .....	19-61
Scanning contour lines .....	19-68



**Learn programming ..... 19-70**



# Chapter

# 1

## Introduction


---

### **This chapter contains:**

Scope of the UMESS user manual . . . . .	1-2
How to use the operating instructions . . . . .	1-3
Hardware. . . . .	1-5

## Scope of the UMESS user manual

This manual describes the standard UMESS software. This comprehensive software package for measuring regular geometric elements offers the following options:



- Probe calibration,
- Mathematical alignment of the test objects,
- Measurement of all standard geometric elements by probing single points, self-centering probing and scanning,
- Mathematical measurement of all elements which cannot be probed by linking elements,
- Recall of previously measured elements for further evaluations and linkage (constructions) including transformation to new coordinate systems.
- Evaluation of all form and position tolerances,
- Flexible record structure,
- CNC programming of measuring runs,
- Use of a rotary table as the fourth axis.

### Additional programs

Furthermore, UMESS provides the basis for all UMESS options and a number of special software packages, e.g. KUM, PROVACS, SAM, GON etc. Separate manuals are available for these programs.


### Hardware

You will also find additional specific software functions in the corresponding hardware user manuals e.g.



- ; if you work with the FC production measuring center;
- if you have a Dynalog control panel;
- if your coordinate measuring machine has a DSE or RDS articulating probe holder;
- if you work with a duplex CMM.

# How to use the operating instructions

- Prerequisites** In writing this manual, we have taken into consideration the fact that you are a qualified technician in the field of metrology and have attended our UMESS training program. You will therefore normally be using it as a reference work. We have, however, also designed this manual so that untrained operators can use it to familiarize themselves with UMESS.
- Revision information** Any new revision subsequently delivered will be accompanied by a revision information which can be printed out using CZ Utilities.
- Please follow the instructions contained therein, since the dialogs may also have changed for some functions.
- Organization** The table of contents, glossary, list of direct input functions and cross references in the text should help you find what you're looking for immediately.
- The main chapters are arranged in the sequence of the procedure usually followed when working with coordinate measuring machines (see flow chart on next page).
- Subsections**
- The subdivision of these main chapters can be found in the table of contents.
  - A separate subchapter is normally provided for each function. Each subchapter contains the following information if required:
    - Effect of the function,
    - Applications, preparation and handling,
    - Function call (invocation),
    - Input mask or dialog,
    - Necessary and/or possible inputs,
    - Control data coding,
    - Examples.



## Hardware



The following hardware is required to use UMESS:

- A coordinate measuring machine with an 8-bit or 16-bit control: equipped with a trigger or measuring probe head, with or without rotary table, possibly with other accessories (e.g. probe changer).
- Computer





# Chapter

# 2


## Starting, operating and ending Measuring SW

---

### **This chapter contains:**

General comments on windowing . . . . .	2-2
Prerequisites . . . . .	2-3
Switching on the measuring machine and computer . . . . .	2-4
Reference point travel . . . . .	2-7
Login procedure. . . . .	2-10
Keyboard. . . . .	2-11
Mouse functions . . . . .	2-15
Function calls. . . . .	2-16
Faults (Break). . . . .	2-18
End of operation . . . . .	2-20

## General comments on windowing




.The measuring programs and the corresponding options all employ a windows user interface.

This means that several windows in which the dialog with the computer and the output of the peripheral devices are displayed are automatically opened on your screen.

## Prerequisites

Die UX-Meßprogramme werden auf Rechnern des Typs HP 9000 Serie 700 oder Serie B unter dem Betriebssystem HP-UX eingesetzt. Rechner und Peripherie müssen elektrisch zusammengeschlossen und, wenn Sie nicht an einer MFT-Station gerätefern arbeiten, mit dem Steuerschrank des Meßgerätes verbunden sein.

The computer and peripheral devices must be connected together electrically and, if you are not working on an ACE station, linked with the control cabinet of the measuring machine.




The CMM computer is linked to the ACE station via the LAN.

The DATACOM option can be used to exchange measuring data and CNC runs.

## Switching on the measuring machine and computer

### Differences


The actual operation and appearance of control and display elements may vary for individual control types.



Turn the main switch clockwise to position "I":

- The MAINS ON pilot lamps come on
- The computer cabinet with the computer units is now ready for operation


For more information in the indicator panel: see the pertaining hardware operator's manual.



- **Turn keylock switch clockwise to position "I":**  
The control pilot lamps come on.
- **Turn keylock switch further to the START position and hold it there approx. 2 sec. until the air bearings are activated:**  
The DRIVES pilot lamps and all other signal lamps for monitoring the voltage come on.
- **Switch on the computer and monitor and wait for the automatic start of the operating system**

## KDE user interface

The UNIX/LINUX operating system boot procedure stops at the LOGIN window of the KDE user interface and waits for the input of a user name.




Welcome to Linux on [zo 01q 99z]

**ZEISS**

login

Password

Session Type:



Welcome to kmg01s1

Please enter your user name

**ZEISS**

User: ut16

Enter the user name 'ut16'.

Password

If you have a password, enter it here. In any case confirm with <Enter>.

The LINUX operating system now starts the KDE user interface.

Start UMESS

**Start UMESS by clicking on the button for UMESS single-column or duplex operation.**

### NOTE

Duplex operating mode:  
Start column 2 first, and then column 1.  
Wait until all windows have appeared.

If necessary, adjust the size and arrangement of the windows to suit your requirements.

# Reference point travel

## Dialog window

After UMESS starts, the dialog window will display either the **<Reference point travel>** input mask or the query **<Without CMM?>**

### NOTE

Exception: If the measuring machine is left on after the last UMESS end, you can log on again immediately.

## Reference point travel

The reference point travel (also called zero point travel or homing run) brings the counter readings of the three machine axes to a defined initial status. If a rotary table is connected to your CMM, it will also move to its reference point position.

For DSE, RDS and FC, please refer to the pertaining hardware operator's manual.



### Caution: Risk of crushing and collision!

.Prior to the reference point travel, position the probe head so that the machine zero point later traveled to (in the upper rear left corner) can be reached without a collision.

The probe head first moves to the mechanical limit position in the Z axis, and then in the X and Y axes.



### Caution: Risk of injury!

If a rotary table is connected, it will also move to its reference point. Be careful: Any workpieces clamped on the table may cause a hazard if turned along with the table.

Dialog													
<p>Reference point travel</p> <p>X, Y, Z, RT <input checked="" type="checkbox"/> only RT <input type="checkbox"/></p> <p><input checked="" type="checkbox"/> D</p> <p style="margin-left: 100px;">X <input style="width: 80px;" type="text" value="30.0000"/> Y <input style="width: 80px;" type="text" value="-30.0000"/> Z <input style="width: 80px;" type="text" value="-30.0000"/></p> <p style="margin-left: 100px;">RT <input style="width: 100px;" type="text" value="0/0/0.0"/></p>													
* YES				NO *								TERMIN	
BACK				PRE MENU								INFO	

### Procedure

If necessary, change the (machine) coordinate values offered in the dialog window. The probe head will move to the position entered following the reference point travel.

**TERMIN**

The dialog window then closes and the message **CAUTION: CMM zero point travel** appears on the screen. The probe head first moves to the mechanical limit position in the Z axis, and then in the X and Y axes.



## Limit position

On reaching the mechanical limit positions, the probe head automatically moves away from this zero point by a distance corresponding to the value entered in all axes.

### NOTE

If the CMM does not move away from the zero point, you can cancel operation with **<CANCEL>**.

Check whether X, Y and Z have the correct sign and are within the measuring volume.

If the reference point is not valid (message on screen), call this function again by entering **<DI 1570>**.

### NOTE

If the **<Reference point travel>** dialog window automatically appears after switching on the CMM, the dialog window must not be closed with **<PRE MENU>** or **<BACK>**.

## UMESS without CMM

The inquiry **Without CMM?** shows that the measuring machine was switched off during the system start or that the electrical connections have been interrupted.

YES

continues the start process with a logon. In this case, you can use UMESS without a coordinate measuring machine.

NO

leads to the prompt to switch on the measuring machine and/or check the connections.

## Login procedure

The screenshot shows a dialog box with the following elements:

- Title bar: Dialog
- Text: Measuring software start
- Prompt: Please enter user name
- Input field: Mueller
- Buttons at the bottom: \* YES, NO, \*, and TERMIN
- Additional buttons: INFO

### Operator name

Following the reference point travel, after **Without CMM = <YES>** or following a start without switching off the control cabinet in-between, the dialog window will request you to log in as a user. Type in your user name and confirm it with **<Enter>**.

UMESS is now ready for operation.

### Restore


Then, if necessary, save the results from the last UMESS session with **<DI 1670>** before continuing on (▶ „Producing the old status <DI 1670>“ on page 6-7).

# Keyboard

## Function

With the computer keyboard

- you can type in data and transfer it to the computer,
- control the cursor (to mark the position where the following text should be entered) and
- scroll the contents of the screen memory into the visible zone.



## Special keys

In addition to the usual letters, numbers and characters, the keyboard also has a few special keys:

### Program control keys

Key	Function
<Tab>	Changeover between upper/lower row of softkeys
<Enter>	Terminate input / continue to next input field
<Break>	Terminate UMESS in case of malfunction ▶ „Faults (Break)“ on page 2-18

**Cursor control keys**

Key	Function
<↑>	Return to the previous input field
<↓>	Continue to the next input field
<→>	Move the cursor one place to the right
<←>	Move the cursor one place to the left
<Shift> <↑>	Scroll the screen contents upwards
<Shift> <↓>	Scroll the screen contents downwards
<Back space>	Move the cursor one place to the left; cf. ► „Pictograms in the UMESS main menu“ on page 3-23


**Keys for text input and processing**

Key	Function
<Insert>	Insert characters to the left of the cursor: First activation: Insert mode ON, (indicated by <b>IC</b> ) Second activation: Insert mode OFF
<Delete>	Delete one character at the current cursor position
<Shift> <Insert>	Insert a line (not activated in UMESS)
<Shift> <Delete>	Delete a line (not activated in UMESS)
<Home>	Jump to beginning of text (not activated in UMESS)
<End>	Jump to end of text (not activated in UMESS)
<Page Up>	Move forward one page
<Page Down>	Move back one page


### Softkeys

Keys <F1> to <F8> are command input keys, i.e. softkeys with a changing function assignment.

The 16 rectangular fields highlighted at the top of the screen show the current assignment of the softkeys.




The asterisk (\*) in the center shows which softkey line is currently activated. In its initial status the asterisk appears in the upper line. If you press the <Tab> key, the asterisk then shifts to the lower line. Now you can activate any key in the lower line.




### Shift keys

Keys <F9> to <F12> are shift keys for certain window functions in the UMESS main menu.



Changes between the different "pictogram page" (icon bar) levels



Changes between the pulldown menu and the list and message window

**F 11**

Changes between UMESS main menu and record window.

**F 12**

Changes between UMESS main menu and direct input window.


## Mouse functions

The mouse is a small device for controlling the cursor (mouse pointer) on the screen as a supplement to the computer keyboard.

You can use the mouse to:

- activate and manipulate windows
- call functions
- activate input fields

### Mouse



### Mouse pointer

You can control the movement of the mouse pointer (cursor) on the screen with the mouse. The cursor is represented on the screen by an "X" or an arrow. When you move the mouse on the mouse pad, the cursor moves in the same way on the screen.

The mouse has either two or three buttons. If it has three buttons, the one in the middle has no function.

You may have to press the left button, the right button or both buttons, depending on the function required.

## Function calls

### Explanation of illustration

#### 3 options


You can normally activate functions in one of three different ways:

- Using direct input <DI> numbers or shortcuts,
- Via pulldown menus,
- via a "pictogram" (icon).

#### Type of display

The operating instructions explain three ways of calling or invoking each function:

(Example shown here: Extent of record)




<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1624	Probe	
CONFLIS	Data	
a31	List	

### Function call via a direct input

#### Function

A direct input <DI> is the direct call of a function without using a pull-down menu.




You can use and operate the measuring programs and their corresponding options via "windowing".

In other words, several windows in which the dialog with the computer and the output of the peripheral devices are displayed automatically open on your your screen.

You have three options:

- Enter the corresponding DI number.
- Enter the function abbreviation (not provided for all functions).
- Enter the abbreviation from UMESS 300 (not provided for all functions).

(e.g.: **Adr.Prog.57** from UMESS 300 is entered as **a57**.)



You can use key <F12> to change back and forth between the UMESS main menu and the Direct Input window.

Type in the number or the abbreviation in the **Direct input** input field and confirm with <Enter>.



**Previous**

The input window is closed, no UMESS function is activated.

## Faults (Break)

### Application

Incorrect or inadvertent activation of keys, incorrect programming, collisions and other operating errors may lead to a UMESS crash.

Information on how to eliminate the error normally appears on the screen

**Pause  
Break**

If these measures are not successful or the error or fault which occurred can not be remedied by the software, press the **<Break>**.key once.

This restarts the measuring software (and takes several seconds).


If you press **<Break>** a second time, UMESS is interrupted and must be restarted.

### Prerequisite

The **<Break>** key functions only if one of the following windows is active:

- UMESS main menu,
- Record window or
- Direct Input window

Click on **<Yes>** with the mouse or press the **<Enter>** key to restart UMESS.



### NOTE

Special feature of the Dynalog control panel:  
Press the **<Break>** key two or three times immediately after acknowledging the warning window so make sure that UMESS is really interrupted. Then restart UMESS by clicking on the icon symbol. This is necessary to ensure that all UMESS windows are displayed correctly on the Dynalog.

### Restore

Subsequently or, if need be, beforehand, save the results from the last UMESS session with **<DI 1670>** (► „Producing the old status <DI 1670>“ on page 6-7).


Faults in the CNC run (▶ „*Interruption due to malfunction*“ on page 18-14).


## End of operation

### Procedure

To terminate system operation, proceed as follows:

- Terminate all running operations and save any data which may be required later,
- Clear probe,
- Quit UMESS,



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1003	Probe	
END	UMESS End	

### Start shutdown

Start the shutdown procedure by:

- 1 Selecting the KDE system button
  - Select **<Logoff>**
  - Click on **<End KDE>**
  - Click on **<Shutdown>** in the **KDE User Login** window
  - Select the **<Shutdown>** function.

The operating system is now shut down.

or

- 2 Click on the logoff icon on the front panel.
  - Further procedure: See point 1

### Last message

Once the LINUX system has been stopped, the following message will be displayed:

#### **<Shutdown>**

Now you can switch your measuring system off, i.e.

- Switch off the computer
- Turn the keyswitch and the main switch on the control cabinet to **0**

# Chapter

# 3

## Description of the windows

---

### **This chapter contains:**

Working with windows . . . . .	3-2
UMESS main menu . . . . .	3-6
Calling UMESS functions using menus . . . . .	3-10
Pictograms in the UMESS main menu. . . . .	3-23
Setting colors and fonts . . . . .	3-33
Other windows in UMESS . . . . .	3-36
Activating/deactivating the UMESS main menu . . . . .	3-41
Changing the language <DI 1692> . . . . .	3-42
Starting system programs <DI 1685/1686> . . . . .	3-44

## Working with windows

### Activating windows

#### Mouse pointer

You can activate a window by placing the mouse pointer inside it (the pointer appears as an "X") and clicking once. After the mouse pointer enters a window, its appearance will change to an "I" or another character.


#### Frame color

Once a window has been activated, its frame changes color and it is moved to the front. Keyboard inputs appear in the command line of the activated window.

### Moving windows

#### Upper edge of window

Click on the frame field at the upper edge of the window with the left mouse button and hold the button down.



The shape of the mouse pointer now changes to a "+"; a frame indicates the current position of the window.


#### Moving the mouse

You can now change the position of the window dragging the mouse and then letting go of the left mouse button.

### Shrinking the window to an icon

#### Minimize button

If you do not require need a certain window or your screen is simply overcrowded with open windows, you can shrink individual windows to an icon. Just click on the Minimize button in the upper right hand corner of the frame with the left mouse button

**Icon**

The window is then displayed as an icon on the left-hand margin of the screen. You can move it by clicking on it with the left mouse button and holding the button down. The icon can then be moved to another location by dragging the mouse pointer and positioned there by letting go of the button again.

**Restoring the window**

You can restore the icon to window size by clicking on it briefly two times with the left mouse button. The window then reappears in the position where it was before it was shrunk.

## Modifying the window size

**Clicking on the frame**


You can change the size of a window by clicking on any point of its frame with the left mouse button and keeping the button pressed. The point where you click on the frame determines the direction in which you can enlarge or reduce the size of its frame. If, for example, you click on its right border, you can change the shape of the frame by shifting its right border laterally. If you want to adjust both the height and the width of the window simultaneously, click on a corner of the frame.

### Scrolling the contents of the window

#### Moving the scroll bar

If you would like to scroll the contents of a window vertically, many windows have a scroll bar along on their right-hand border.


If you keep the mouse button pressed while moving the cursor up and down, the text section shown in the window will change correspondingly.



### Window menu

#### System menu

Each window has a system menu in which you can select various functions concerning that window. To open this menu, click on the menu field in the upper left-hand corner of the frame with the left mouse button and hold it down.



#### Activating a function

The lines are highlighted by moving the mouse pointer up and down the system menu. The highlighted function will be executed as soon as you let go of the mouse button.



<b>Resize</b>	Selecting <b>&lt;Resize&gt;</b> reverses any change you have made via the system menu. I.e. you thus <i>restore</i> the previous condition of the window.
<b>Move</b>	If you select <b>&lt;Move&gt;</b> and release the button, a frame appears which can then be moved around on the screen. The coordinates of the frame in reference to the upper left-hand corner of the frame are displayed in the center of the screen. The new position of the window can be set by pressing the left mouse button once.
<b>Iconify</b>	The window can be shrunk to an icon with <b>&lt;Iconify&gt;</b> .
<b>Maximize</b>	<b>&lt;Maximize&gt;</b> enlarges the window to full screen size.
<b>Close</b>	<b>&lt;Close&gt;</b> closes the window.


**NOTE**

This command must not be used in a UMESS window, since it would cause errors in or termination of UMESS.

## UMESS main menu

### Functions of the UMESS main menu

- Operation** The UMESS main menu enables you to operate the UMESS program system in via windows (windowing). You can invoke all UMESS functions by selecting them from Pull-Down-Menus, via "pictograms" (icons) or by entering a direct input number **<DI no.>** (► „Function calls“ on page 2-16).
- Menu levels** The menus are combined under a main menu with two submenu levels. You can use these menus to select and activate the required UMESS function in plain text.
- Pictogram (icon) pages** The UMESS main menu contains 64 pictograms (icons) arranged in 4 "pictogram pages" (double icon bars). You can put these pages together to meet your own special requirements.



### You can use the UMESS main menu to...

- call UMESS functions via menus (▶ „Calling UMESS functions using menus“ on page 3-10)
- call UMESS functions via pictograms (▶ „Pictograms in the UMESS main menu“ on page 3-23)
- call UMESS functions via DI numbers (▶ „Function calls“ on page 2-16)
- select pictogram pages (▶ „Pictograms in the UMESS main menu“ on page 3-23)
- put together your own pictogram pages (▶ „Editing a pictogram page“ on page 3-25)
- set type fonts and colors (▶ „Setting colors and fonts“ on page 3-33)
- operate UMESS in other languages (▶ „Changing the language <DI 1692>“ on page 3-42)
- change options (KUM, SAM, etc.) (▶ „Options“ menu“ on page 3-21)

#### Procedure

The UMESS main menu determines the DI no. for a selected UMESS function and passes it on to the UMESS program system, thus activating the corresponding UMESS function.


#### Mouse operation

Since the UMESS main menu is a graphic user interface, the easiest way to operate it is via the mouse. All you have to do to activate a function is place the mouse pointer on a pictogram or menu item and then click on it *once* with the left mouse button.

#### Keyboard operation

You can also operate the UMESS main menu without a mouse using the computer keyboard or from the control console.

## Structure of the UMESS main menu



### Active function

As long as a function is activated in the UMESS pictogram system, the DI no. of the active function is displayed along with the message "**Job being processed**" (see illustration above). No changes in the UMESS main menu, e.g. selection of pictogram pages or other UMESS functions, can be performed during this time.

### Dialog window

A dialog window is automatically opened for UMESS functions requiring further inputs. (► „Dialog window“ on page 3-38) The dialog window must be closed with **<TERMIN>** after concluding all inputs so that the corresponding UMESS functions can be executed.

### Shuffle up


User activities may cause the dialog window to be positioned in the background. In order to be able to make inputs, the dialog window must be placed in the foreground with **<Shuffle up>**.

**3 options**

You can operate the UMESS main menu in three different ways, i.e.:

- using the mouse,
- using the computer keyboard,
- using the control panel.

## Calling UMESS functions using menus



### Menu organization

Using the menu, you can call all UMESS functions either with the mouse or by via keyboard inputs. The submenus are arranged maximally 2 levels below the main menu. (in the form of Pull-Down-Menus).

### Labeling

▶

The individual menu items are marked in the submenus as follows:  
a submenu follows (see figure: change ▶).

...

a function is called which requires inputs in a corresponding dialog window (▶ „Other windows in UMESS“ on page 3-36) (see figure: **automatically...**). You can also cancel the function called using the corresponding dialog window.

### (Text only)

The function is executed immediately. No window opens and there is no possibility to cancel the function (see figure: **UMESS End**).

## Using the mouse

If you click on one of the options in the main menu (Probe/Coord./Elements etc.) *once* with the left mouse button (click directly on the text), you will reach the first submenu level.


If you are in the first submenu level and click on a menu item *once* with the left mouse button, you will either activate the corresponding function or branch to the second submenu. If you click on a menu

item once with the left mouse button in the second submenu level, you will activate the corresponding function.

**NOTE**

You can search for a menu item throughout the entire menu by positioning the mouse pointer on a menu item in the main menu, pressing the left mouse button and keeping it pressed. As long as you keep the left mouse button pressed, you can move the mouse pointer back and forth through all menus. Once you find the required menu item, you can activate it by positioning the pointer directly on top and letting go of the left mouse button.


**Using the keyboard**



In the main menu, one letter of each option is underlined. If you press the hold the **<Alt>** key and enter the underlined letter, you will reach the corresponding first submenu level.



You can also move back and forth between the pictogram pages and the UMESS main menu by pressing key **<F10>**. If you have selected the UMESS main menu, you can move from one menu item to another within the UMESS main menu using the **<->** and **<=>** cursor keys. Using the **<↓>** **<↑>** cursor keys, you can then branch from the UMESS main menu to the first submenu level of the menu item concerned.




In the submenu, the cursor bar is positioned on the top menu item. You can move the cursor bar up and down using the cursor keys **<↓>****<↑>**.



You can move to the second submenu level by pressing **<Enter>** or the **<->** cursor key. You can return to the first submenu level by pressing the **<=>** cursor key. You can activate the function corresponding to the selected menu item by pressing **<Enter>**.

**Using the standard control panel**



You can move back and forth between the pictogram page and the UMESS main menu with softkey **<F10>**. If you have selected the UMESS main menu, you can move from one option to another with the **<->** and **<=>** cursor keys. Using the **<↓>** **<↑>** cursor keys, you can branch from the UMESS main menu to the first submenu level of the menu item concerned.

In the submenu, the cursor bar is positioned on the top menu item; using the <↓><↑> cursor keys, you can move the cursor bar up and down. You reach the second submenu level by pressing <Return> or the <→> cursor key. You can return to the first submenu level with the <←> cursor key.

Pressing <Return> activates the UMESS function of the selected menu item.

### Overview of all menus

#### Overview

The following text provides a complete overview of all menus, i.e. each menu item is listed along with its corresponding first and second submenu levels.

#### Chapters

The menus contain cross references to the chapters of the operating instructions where the corresponding information is located, for example:

▶ „Overview of all menus“ on page 3-12).


If not specified otherwise, the chapter referred to is always a chapter of the UMESS operating instructions.

#### Dis


The <DI No.> for each menu item is specified as a cross reference to the item (▶ „Function calls“ on page 2-16).



**Menü „Taster“**




**"Coordinate system" menu**



**"Geometric elements" menu**

<b>Element</b>		<b>CMM</b>	<b>CNC</b>	<b>Eval</b>	<b>Record</b>	<b>Service</b>	<b>Option</b>	<b>Help</b>
Geometric elements	Circle...							<b>1104</b> > page 11-9
	Cylinder...							<b>1106</b> > page 11-36
	Surface...							<b>1103</b> > page 11-27
	Line...							<b>1102</b> > page 11-22
	Cone...							<b>1107</b> > page 11-41
	Sphere...							<b>1105</b> > page 11-49
	Ellipse...							<b>1108</b> > page 11-19
	Torus...							<b>1109</b> > page 11-46
	Transfer macro...							<b>1079</b> > page 16-81 > and Opt.10
	Recall...							<b>1301</b> > page 9-37 > page 10-29
Car body	Space point...							<b>1120</b> Opt.6
	3D point mode...							<b>1121</b> Opt.6
	Edge point							<b>1220</b> Opt.6
	Corner point							<b>1216</b> Opt.6
	Parabola edge point...							<b>1173</b> Opt.6
Data acquisition	Collect points in file...							<b>1100</b> > page 10-21
	Points to VDA...							<b>1166</b> > page 10-26
	Fixed plane...							<b>1680</b> > page 10-50
	Probing correction...							<b>1187</b> > page 10-13
	Cone correction...							<b>1144</b> > page 13-15
	Sigma displacement...							<b>1681</b> > page 10-48
	Filter...							<b>1185</b> > page 14-69
	Outlier elimination...							<b>1181</b> > page 14-66
Special elements	Point...							<b>1101</b> > page 11-6
	Circle segment...							<b>1114</b> > page 11-53
	MCC and MIC							<b>1180</b> Opt.3
	Min/Max round...							<b>1141</b> > page 14-62
	Min/max Flat...							<b>1140</b> > page 14-60
	Min calculation...							<b>1341</b> > page 12-40
	Max calculation...							<b>1343</b> > page 12-40
Macros	Bore element...							<b>1081</b> > page 16-34
	4Pt circle							<b>1174</b> > page 11-17

"Coordinate measuring machine" menu




**"Automatic runs (CNC)" menu**

<b>CNC</b> Eval Record Service Option Help	
	<b>DI</b>
Start CNC	CNC run... <b>1640</b> > page 18-3
	STEP mode... <b>1070</b> > page 18-17
	Run macro... <b>1644</b> > page 18-8
	by remote computer... <b>1013</b> Opt.11
	Set up one button mode... <b>1668</b> Opt.5
	Activate one button mode... <b>1669</b> Opt.5
	AUTO CNC... <b>1649</b> Opt.18
Intermediate position	<b>1510</b> > page 16-31
PROG	Start... <b>1639</b> > page 16-13
	Jumps... <b>1050</b> > page 16-44
	Loops... <b>1051</b> > page 16-36
	Stop with DI... <b>1096</b> > page 16-21
	manual measuring section... <b>1077</b> > page 16-25
	Continue with problems... <b>1080</b> > page 16-32
	Correction <b>1032</b> > page 16-17
	End... <b>1632</b> > page 16-85
Control data	correct... <b>1642</b> > page 17-31
	list... <b>1641</b> > page 17-28
	convert CMS->LX... <b>3201</b> Opt.4
	convert LX->CMS... <b>3301</b> Opt.4
Workpiece administration	copy... <b>1643</b> > page 17-18
	delete... <b>1635</b> > page 17-12
	enter... <b>1634</b> > page 17-10
	Catalog... <b>1630</b> > page 17-1
	Modify catalog... <b>1645</b> > page 17-17
	Catalog on printer... <b>1650</b> > page 17-5
PCM	PCM Edit on/off... <b>1666</b> Opt.9
	PCM Run mode... <b>1671</b> Opt.10
	PCM Test run... <b>1646</b> Opt.9
	PCM generation run... <b>1647</b> Opt.10
FOCUS	Change of safety plane... <b>1041</b> Opt.17
	Start of group... <b>1042</b> Opt.17
	End of group... <b>1043</b> Opt.17
	Programming dialog... <b>1040</b> Opt.17
	Assignment of table to graphics... <b>1673</b> Opt.17
	Pretravel... <b>1672</b> Opt.17


**"Evaluation" menu**

<b>Eval</b>		<b>Record</b>	<b>Service</b>	<b>Option</b>	<b>Help</b>	
Form	Straightness...				<b>1401</b> > page 14-19	
	Flatness...				<b>1402</b> > page 14-21	
	Flatness/Length...				<b>1472</b> > page 14-21	
	Roundness...				<b>1403</b> > page 14-26	
	Cylinder form...				<b>1404</b> > page 14-28	
	Form dev. ...				<b>1449</b> > page 10-46	
	GDT plot...				<b>1470</b> Opt.2	
	Fast plot...				<b>1461</b>	
	Position	Position...				<b>1407</b> > page 14-45
		Concentricity...				<b>1408</b> > page 14-55
Coaxiality...				<b>1409</b> > page 14-57		
Symmetry...				<b>1410</b> > page 14-49		
Parallelism...				<b>1415</b> > page 14-31		
Perpendicularity...				<b>1425</b> > page 14-41		
Angularity...				<b>1435</b> > page 14-38		
Run...				<b>1445</b> > page 14-52		
2D Bore pattern best fit...				<b>1159</b> Opt.2		
Distance	cartesian				<b>1202</b> > page 12-20	
	polar 2D				<b>1203</b> > page 13-7	
	polar 3D				<b>1261</b> > page 13-9	
	Perpendicular				<b>1286</b> > page 12-22	
	Perpendicular cylinder				<b>1285</b> > page 12-22	
Inters.	Inters.				<b>1218</b> > page 12-2	
	2 Axes 3D				<b>1215</b> > page 12-7	
	Penetration point S/A				<b>1217</b> > page 13-11	
	Convex surface intersections				<b>1219</b> > page 12-9	
Symmetry element Formula... Mean value...					<b>1206</b> > page 12-22	
					<b>1379</b> > page 12-27	
					<b>1345</b> > page 12-25	
Angle	Angle				<b>1204</b> > page 13-2	
	Output Deg/Min/Sec				<b>1682</b> > page 13-2	
	Conversion...				<b>1251</b> > page 13-5	
Additions	Additional cone...				<b>1243</b> > page 13-13	
	XYZ supplement				<b>1262</b> > page 10-47	
	Extreme values...				<b>1460</b> > page 10-45	
	Circular pitch...				<b>1311</b> > page 12-30	
	Linear pitch...				<b>1312</b> > page 12-30	
	Kink recognition...				<b>1189</b> > page 10-27	
	Write intermediate file...				<b>1303</b> Double-column	
	Read intermediate file...				<b>1304</b> license	

**"Record" menu**



**"Utilities" menu**






"Options" menu

Option	Help	DI	
SAM	SAM Data transfer...	2951	SAM
	SAM...	2900	SAM
	SPC...	2950	SAM
MFT	I-Position...	3002	MFT
	Probing...	3003	MFT
	1 Reserve control data line	3010	MFT
	reserve n CNC lines...	3011	MFT
	DSE mode ACE...	3005	MFT
	Select probe...	3001	MFT
	Travel path plot...	3030	MFT
	ACE ON	3000	MFT
UMESS (ACE OFF)	3099	MFT	
KUM...		2700	KUM
ROM...		2800	Opt.12
GON...		2300	GON
KAM...		3800	MFT
CAD LINK...		2000	Opt.7
CMM ball plate...		2600	Opt.15

### "Help" menu



## Pictograms in the UMESS main menu

### Calling UMESS functions via pictograms



Pictograms are icons with graphic symbols to which a specific UMESS function has been assigned. The UMESS main menu features 64 pictograms in 4 "pictogram pages".

#### Preassignment

The UMESS main menu (file DTableFile) contains four pictogram pages which are preassigned to specific job categories: **Prepare, Measure, CNC/PROG** and **0000**, whereby the last category is a blank page for your own individual entries. You can store further pictogram pages and read them in with the functions listed under **<Service>** **<Pictogram pages>**.

#### Long-term setting

The pictogram pages displayed the last time UMESS was terminated will be displayed again after UMESS is restarted, provided that they had been stored once in this form (► „Editing a pictogram page“ on page 3-25 Storing pictogram pages). This long-term setting thus ensures that the pictogram pages you worked with during your last UMESS session will appear unchanged the next time you work with them, e.g. on the next day.


### Using the mouse

If you position the mouse pointer on a pictogram, the corresponding direct input number (DI no.) and title (name of the UMESS function in plain text) will be displayed above the pictogram page immediately.

You can then activate the corresponding UMESS function by clicking on the left mouse button *once*. The DI no. of the active UMESS function is then displayed along with the message "**Job being processed**".


#### NOTE

Do **not** execute a double-click. The second click would activate the function a second time, thus constituting an illegal action. If you try to activate two UMESS functions simultaneously, the following window will open when you activate the second function:



To continue you must acknowledge the information by clicking on the **<OK>** button once with the left mouse button or pressing the **<Enter>** key.


### Using the computer keyboard



The area of the UMESS main menu where you are currently located is marked by a thick border. I.e. the bolder border indicates which of the keyboard.

Using softkey **<F10>** you can switch back and forth between the UMESS main menu and the pictogram page. Using the **<Tab>** keys you can switch back and forth between the list and message window, the pictogram page and individual pictograms. Within the pictogram page, you can use the cursor keys (**<→>**, **<↓>**, **<←>**, **<↑>**) to jump from one pictogram to another. Using **<Enter>** you can then activate the UMESS function corresponding to the selected pictogram.

### Using the standard control panels




If horizontal display of the pictogram page is set (▶ „Editing a pictogram page“ on page 3-25), each pictogram page comprises two rows containing 8 pictograms each. Using softkeys **<F1>** to **<F8>**, you can activate one of the UMESS functions in the top row of pictograms at a time. Using **<Shift>+<F1>** to **<Shift>+<F8>** you can activate any of the UMESS functions in the bottom row of pictograms one-at-a-time.

From the standard control panel, you can also select and activate UMESS functions within the pictogram page by using the cursor keys and the **<Return>** key in the same way as with the computer keyboard.

## Selecting another pictogram page

### Using the mouse

If you click on one of the four index tabs to the right of the pictogram page **once** with the left mouse button, the corresponding pictogram page will be displayed.




### Using the computer keyboard

You can switch to the next pictogram page by pressing softkey <F9>.

### Using the standard control panels

You can switch to the next pictogram page by pressing softkey <F9>.




## Editing a pictogram page

With the UMESS main menu, you can custom design the user interface to meet your own requirements.

You can design the pictogram pages according to the jobs you most often require and store them as a file. You can also label the index tabs for selecting the pictogram pages and store multiple files.

The stored file activated last will be displayed again following the next system start.




### Saving a menu item as a pictogram

You can create pictograms from any menu items which are not marked with a triangle and which are UMESS functions and save them in one of the four pictogram pages.

To fetch a menu item (i.e. a UMESS function) from the Pull-Down-Menu and save it as a pictogram, you must find the corresponding menu item. To do this, place the mouse pointer on a menu item in the main menu, press the *left* mouse button and keep it pressed. The corresponding first submenu will then be displayed. Then drag the mouse pointer through the menus until you have reached the required menu item. Now press the right mouse button as well and, keeping both buttons pressed, drag the pointer out of the menu. Let go of both mouse buttons. The mouse pointer then changes shape to an envelope symbol and the menu is closed.

#### Selection

#### Procedure



Position the envelope symbol on the pictogram which you want to change (overwrite) and click once with the *right* mouse button. The envelope symbol is then closed and the graphic symbol appears. You have now stored the menu item as a pictogram on the pictogram page. If no graphic symbol is available for the selected menu item, the DI no. will be displayed instead.

### Copying pictograms


You can copy pictograms and save them on the same pictogram page or on another one.

#### Procedure

Position the mouse pointer on the required pictogram. Then press the right mouse button, hold it down and drag the mouse pointer out of the pictogram. The mouse pointer then changes to an envelope symbol.

#### Envelope symbol

Using the envelope pointer, you can select another pictogram page via the index tabs located to the right of the pictogram page. To do this, click on the corresponding index tab once with the *left* mouse button.



Position the envelope symbol on the pictogram which you want to change (overwrite) and click once with the *right* mouse button. The envelope symbol is then closed and the graphic symbol appears. You have copied the pictogram and saved it on another pictogram page.

### Editing pictogram pages with the "Direct input" window

You can copy texts or numbers you have written to the **Direct input** window to the current pictogram page or to one of the four index tabs.

#### Procedure

Your pictogram will function properly if you copy a valid **<DI No.>** or a valid text abbreviation from the **Direct input** window to a pictogram. If a graphic symbol is available for the **<DI No.>**, it will automatically be displayed when the pictogram is transferred to the pictogram page. If no graphic symbol is available, the **<DI No.>** will be displayed in the pictogram.



Press softkey **<F12>** to open the **Direct input** window. For more details on the **Direct input** window ([▶ „Function calls“ on page 2-16](#)).

**Procedure**

You can enter up to eight characters in the input field of the **Direct input** window.


To transfer your input from the input field to a pictogram page, position the mouse pointer on the input field, press the *right* mouse button and keep it pressed. If you then drag the mouse pointer out of the **Direct input** window, its shape will change to an envelope symbol. Position the envelope symbol on the pictogram or index tab you want to overwrite and click once with the *right* mouse button; the text from the input window will then be entered in the pictogram or index tab. If a graphic symbol is available for an entered **<DI No.>**, it will be displayed in the pictogram.

**Deleting a pictogram**

You can delete a pictogram by copying a blank pictogram onto the one to be deleted.


**DI 0000**

If no blank pictogram is available, you can open the **Direct input** window with softkey **<F12>** and copy the four zeroes **0000** from there to the pictogram page using the *right* mouse button.

**Trash can**

If you make a mistake while copying a pictogram you can also *throw it away* into the "trash can". A trash can icon is located in the bottom right corner of the UMESS main menu. If you place the envelope-shaped mouse pointer on the trash can icon and click on the *right* mouse button, this will cancel the copy process.

### Utilities for the pictogram pages



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
	Service	
	Pictogram pages	

**NOTE**

In the <**Pictogram pages**> utility you can select the following functions:

**Display**

Display the pictogram pages

**switch to Backgr**

or mask them.

**store...**

See below for description.

**read...**

See below for description.

**horizontal**

The pictogram pages can either be displayed horizontally with **16 pictograms**,

**vertical**

or vertically with **12 pictograms**.

**small**

Depending on the size of your monitor, you can select a *small*, *mean* (average) or *large* display of the UMESS main menu and record window.

**mean**


**large**

**Dynalog control panel:** To display the complete UMESS main menu on the monitor, you must set the display to *small*, since the display can not show any other resolution.

### Saving pictogram pages

**Function call**


After editing the pictogram pages, you can save this status in a file.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
	Service	
	Pictogram pages	
	store...	



The **Store pictogram pages** window is displayed with the function call.



### Softkeys

#### Speichern

When this function is selected, the cursor is automatically positioned in the **Select** data box and you can enter a name directly or select a name which already exists from the **Files** display box.

All four pictogram pages are saved in a single file.

#### NOTE

The default assignment for the pictogram pages is saved in the **DTableFile**. Avoid overwriting this file wherever possible.

#### Filter

This function can help you find a specific filename more quickly. Enter a selection restriction in the **File Filter** box. When the **<Filter>** is pressed, only those files which meet the criteria entered will be listed in the **Files** display box.

#### Previous

You must press this button after saving files or to quit this screen page without making any changes.


### Read-in of pictogram pages

**Function call**

You can call (read-in) and display the files saved with your personal pictogram pages in the UMESS main menu.



The **Read pictogram pages** window is displayed when the function is called.



**Softkeys**



When this function is called, the cursor is automatically positioned in the **Select** data box and you can enter a name directly or select a name which already exists from the **Files** display box using the mouse.

**NOTE**

The default assignment of the pictogram pages is saved to the **DTableFile**.



This function can help you find a specific filename more quickly. Enter a restriction in the **File Filter** data box. When the **<Filter>** button is pressed, only those files which correspond to the criteria entered are displayed in the **Files** display box.



You must press this button after saving the files or to exit this screen without making any changes.

**Pictogram pages after starting UMESS**


**Long-term setting**

The pictogram pages you stored or read-in last will be displayed again when UMESS is restarted. This means that you will find the pictogram pages you worked with the last time exactly the way you left them, e.g. when starting work the next day.

**Reinitializing a window**

**Function call**

This function is used only in connection with the window display on the **Dynalog control panel**:



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
	Service	
	General	
	Window init	

**Window init**


This function is used to refresh the window (see also the Dynalog manual).

# Setting colors and fonts

## Setting colors

**Function call**

With the <Colors> program function you can temporarily set different colors for the foreground and background of the UMESS main menu.



<u>Dl</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
	Service	
	Colors...	

You can select the color of your choice from the **Colors** selection box with the mouse. Use the right-hand scroll bar to browse through the entire range of colors available.

-
Color selection

Colors

aquamarine  
 medium aquamarine  
 black  
 blue

Default

Selection

Background

Foreground

Previous

Help

**NOTE**

The color and font settings remain effective only until UMESS is terminated. The default settings will always be reactivated following the next restart of UMESS.

**Softkeys**

**Background**

The color selected is used as the background color.

**Foreground**

The color selected is used as the foreground color for the fonts.

**Default**

The default setting with a gray background and a white font is reactivated.




**Previous**

Temporarily saves settings and closes input window.

**Setting fonts**

**Function call**

With the **<Fonts>** program function, you can temporarily set different fonts and font sizes for the UMESS main menu, record, help texts, status texts and list window.



### Softkeys

**NOTE**

First use the mouse to select the texts to which the change should apply on the right side. Then the font must be selected from the pick-list on the left.

**Default**

The default setting for the fonts is reactivated and displayed.

**OK**

The font selected is accepted and displayed immediately.

**Previous**

Temporarily saves settings and closes the input window.

**NOTE**

The color and font settings remain effective only until UMESS is ended. The default settings are always reactivated the next time UMESS is started.

## Other windows in UMESS

### Printer (record) window

All of the data output by the program (e.g. measurement records, probe data, control data) are displayed in the printer window.

#### Inputs

No inputs can be made to the printer window.

#### Start

The printer window is automatically displayed when you start UMESS.

#### Example of a printer window

Record										
=====										
MEASURING RECORD					ZEISS UMESS					
WORKPIECE NAME					MANUAL MEASUREMENT					
=====										
DRAWING NUMBER		ORDER NUMBER			SUPPLIER/CUSTOMER			OPERATION		
638596-4589-54		1457-5834-5648			Zeiss			0100		
OPERATOR		DATE		PART NUMBER						
Mueller		01/07/98		546						
=====										
ADR	REC	TASK	IDF	SY	ACTUAL	NOMINAL	U.TOL	L.TOL	DEV	EXC
=====										
1		SURFACE		Z	-259.082					
		X/Z		W1	0.004					
		Y/Z		W2	-0.008					
		8P S/MIN/MAX			.043		(7)	-.071	(8)	.028
2		ROTATE SPACE		W	-.009					
3		ZEROP		Z	-259.082					

#### Description of record output

► „Output of results“ on page 5-1



### Plotter window

All of the graphics output by the program (e.g. roundness plot, KUM representation) are displayed in the plotter window.


**Inputs**

No inputs can be made to the plotter window.

**Start**

The plotter window automatically opens in its default position when UMESS is started.

**Example of a plotter window**



**Description of plot output**

See operator's manual for Option 2.

## Dialog window


**Application**

After the function call, UMESS usually needs more information to execute the function. The program prompts input of this information via the dialog window(s).

**Explanation**

Where necessary, this UMESS operator's manual documents the dialog windows as they appear after the function call.

**Example of a dialog window**



## Procedure

### Data box

The data box where the next input is required is highlighted. In some cases it will be preassigned with a suitable default value.

- Typing an input into the box deletes the preassigned default value.
- If you move the cursor to the right with the cursor key before typing your entry, the contents of the box remain intact and can then be modified.
- Pressing **<Backspace>** (several times) causes the original contents of the box to appear again.

### Line mark

The line mark indicates which values are allowed in the given box:

- c** Any character, upper case or lower case is possible. Example: **Housing 1**.
- C** Any upper case character possible; lower case **not** possible. Example: **WST 57**.
- Y** YES/NO box, i.e. accept with **<YES>** or reject with **<NO>**. In the dialog window above **Paper start manual** and **or autom.** are yes/no boxes. **<YES>** normally enters an asterisk **\***.
- I** Integers (whole-number values). Examples: **1, 204, -5**.
- D** Integers or decimal numbers. Examples: **1.56, .50, -1004.25, 7**.
- W** Angle.

### Inputs

Type in new value or accept default value and confirm with **<Enter>**. If the input is correct, the next data box will be highlighted. If the input is wrong, the program will prompt a correction. Work through all data boxes in this manner. If only individual boxes have to be changed, move to these boxes using the  $\vee$  and  $\wedge$  cursor keys.

### Inch

The line mark also has an I for inch inputs.

### Softkeys

Quit or cancel the dialog window with one of the softkeys.

The following generally applies:

**TERMIN**

Starts the function with the values entered or opens additional dialog windows if necessary.

**EXECUTE**

Starts a function without exiting the dialog window.

**BACK**

**PRE MENU**

**CANCEL**

These three softkeys can all be used to exit the mask without starting the function.

**REPEAT**

Checks the values entered.

**INFO**

You can call any further information available using this softkey.

### Special features

Exceptions and special features are explained in the section of the manual containing the corresponding functional description.

### UMESS dialog window


### Application

This window is used to display the bootfile when booting UMESS. Several system messages are also logged here during operation of UMESS.

# Activating/deactivating the UMESS main menu

**Application** You can switch off the UMESS main menu graphic user interface to enable control of UMESS via the dialog window. This enables you to enter direct input numbers and actuate softkeys in the dialog windows.

**Operation** You can deactivate the UMESS main menu by entering **<DI No.> -18** and acknowledging with **<Enter>** in the **Direct input** window.



**Dialog window** When you deactivate the UMESS main menu, the **Meas. software Main functions** dialog window for entering direct input numbers is displayed and activated.


Although the UMESS main menu and **Direct input** window are still displayed on the screen, they are off-line.

**Reactivation** You can reactivate the UMESS main menu by entering **<DI No.> -17** in the **Direct data box** of the **Meas. software Main functions** window and acknowledging with **<Enter>**.

## Changing the language <DI 1692>

### Application

If several languages are stored in the language file on your computer, you can change the UMESS main menu, dialogs and records to one of these languages.



Dialog			
Modify mode			
	Dialog	Record	
<input type="checkbox"/> C	Language code	<input type="checkbox"/> D	<input type="checkbox"/> D
	Number of decimal places	<input type="text" value="4"/>	<input type="text" value="4"/>
	Unit of measurement	<input type="text" value="mm"/>	<input type="text" value="*"/>
	or inch	<input type="text"/>	<input type="text"/>
	Time output	<input type="text" value="German"/>	<input type="text" value="*"/>
	or American	<input type="text"/>	<input type="text"/>
* YES NO		*	TERMIN
BACK			INFO

### Language abbreviations

**D** = German, **A** = English, **E** = Spanish, **H** = Dutch, **F** = French, **I** = Italian, **P** = Portuguese, **S** = Swedish

Enter the abbreviation of the language you require and confirm with <TERMIN>.

### NOTE

The function call initially changes languages only in the dialog and the record window.

To use the UMESS main menu in the other language, you must first end the current measuring program session with (<UMESS End>) and then restart UMESS.

For a description of the other functions in the dialog window: ➤ „Output of results“ on page 5-1

**NOTE**

If the message: **File not found** appears when you select a language, then the language selected has not been released on your computer. Exit the dialog page with **<BACK>**.

**Pictogram pages in the other language****Index tabs**

The labeling of the four index tabs for selecting the pictogram pages and the pictogram pages themselves do not change when the other language is selected. If you would like to change the corresponding pictogram pages and index tabs to the other language, you must manually read them in accordingly. (➤ „Utilities for the pictogram pages“ on page 3-28).

**Filename**



The filename begins with the abbreviation of its corresponding language and has the suffix **TableFile**.

Example for English pictogram pages: **ATableFile**

## Starting system programs <DI 1685/1686>

### Application



In individual cases it may be necessary to utilize customized command files or programs you yourself have created in addition to the measuring SW provided by Carl Zeiss. The programmable <DI 1685> and <1686> can be used to start such "learn" or "part" programs:





**Special feature**

<DI 1685> is intended for dialog-oriented customized programs. If the screen is enabled for dialogs, the <STOP> or <CANCEL> softkeys are no longer available during the CNC run. The CNC mode must therefore be interrupted.



**Special feature**

<DI 1686> makes it possible to start programs which do not require a dialog. The screen is not enabled for dialogs so that the CNC mode does not have to be interrupted.

### Data boxes

Input of a run string comprising max. 72 characters.

Execution and return to UMESS.

**TERMIN**

### Path

A path to the customer programs must be defined, e.g.:  
**/opt/zeiss/tool** or another path to personal program directories.

### Types of program

You can use shell scripts, Fortran or C programs. Parameter transfer is usually performed as for the start, i.e. from the shell level.

### Parameters

Return of the parameters:

- from the shell script with the command **CZ\_return**.
- from a C program with the command **exit()**.
- from a Fortran program with the subroutine **ftn\_exit()**.
- The parameters must be transferred in the run string.
- An integer\*2 type error variable and an error string with a length of 80 characters are provided as return parameters.
- If an error is transferred, a CNC run may be canceled. If an error string is set, it will be output to (and displayed on) the screen.

**NOTE**

# Chapter

# 4

## Data backup UNIX/LINUX

---

### **This chapter contains:**

- ▶ „General information on data backup UNIX“ on page 4-2
- ▶ „Backing up and restoring CNC programs <DI 3500>“ on page 4-3
- ▶ „Backup and restoration of user data with CZ Utilities“ on page 4-16
- ▶ „Executing and restoring a full backup“ on page 4-21
- ▶ „Data backup modes LINUX“ on page 4-23

## General information on data backup UNIX

### Loss of data

Operating errors (unintentional deletion) or exceptional disk faults may result in a loss of CNC programs, control data, performance modes (standards), probe data etc. or even the entire software revision.

In such cases, all of your valuable data may under certain circumstances be lost if you have not run a data backup.



### IMPORTANT!

If no system administrator is responsible for data backups of your system, every user is responsible for performing regular and timely backups of his own data!

### The data backup can be performed in various ways:

#### <DI 3500>

In UMESS you can save CNC runs using <DI 3500> and KUM data using <DI 3510> to disk or DAT tape.

#### User data backup

User data can be saved to DAT tape (DDS) using CZ Utilities.

#### Full backup

Using the UNIX system with SAM, the entire hard disk can be saved to DAT tape (DDS).

#### Network

A data backup can be automated by your system administrator via the network.

### Reconstruction

The following backup procedure is recommended to enable reconstruction in cases involving the loss of very small amounts of data:

#### Full backup and user data backup

Backup of all data to DAT tape (DDS):

Between once a week and once a month, depending on the amount of new or changed data => using CZ Utilities (> „Backup and restoration of user data with CZ Utilities“ on page 4-16).

*Use at least two different DAT tapes alternately.*

#### <DI 3500>

Control data and KUM workpieces:

On date of creation or change => via <DI 3500> (> „Backing up and restoring CNC programs <DI 3500>“ on page 4-3).

*As with the DAT tapes, you should alternate diskettes here as well.*

#### Before the update

We strongly recommend backing up important UMESS data prior to every new installation or update of measuring software!

# Backing up and restoring CNC programs <DI 3500>


## Intermediate storage

- Application** With this function you can copy UMESS and KUM workpieces from the workpiece catalog to a backup medium via an intermediate or temporary store. Furthermore, this function ensures that workpieces from other systems, e.g. UMESS 1000 can also be used in UMESS UX.
- KUM data** KUM command blocks can be copied to the intermediate store via <DI 3510> and restored with <DI 3511>.


## Application examples

- Backup** For backup of new or modified measuring runs, preferably every day and in duplicate. In this way, you also back up those workpieces which have been added or modified since the last full data backup .
- External storage** If the workpiece catalog is full, you can swap-out CNC programs you no longer need to external storage, from where they can also be retrieved.
- Transport** Used to send or transport CNC programs, or to load runs sent on a backup medium.
- Other** You can also copy workpiece files and other files outside of UMESS to and from backup media using UNIX commands.
- Directory** The following directory is used for intermediate storage on the hard disk: **/var/opt/zeiss/CZ\_BACKUP\_SCR**.

Principle of external data storage with <DI 3500> (backup):




Principle of restoring data with <DI 3500>:




### Dialog page for data backup

**Function call**

You must always start all operations involving the external storage and retrieval of workpieces or any conversion required between the internal and ASCII format from the <Data backup/Administration> dialog window.





**Function selection**

Function selection can not be performed with the mouse, but only via the keyboard. Only the softkeys in the dialog window can be operated with the mouse.

**Softkeys**



Select/reject the appropriate function with these softkeys. (<YES> = entry of \*)



Selection of individual boxes is also possible with the ^ and v cursor keys.



This key is used to confirm execution of the selected function.



After finishing all copying procedures, you can close the dialog window with one of these two keys.



**Clearing the intermediate store**

**Application**

The intermediate store must be cleared

- if you want to create a new backup or
- to prepare for data restoration from a backup medium.

**Function call** Select the function required with the <YES/NO> keys and confirm with <TERMIN>.

### Backup to/restoration from intermediate storage

**Application** With the procedure described below you can

- copy (back up) CNC runs or KUM workpieces intended for backup to intermediate storage,
- copy (restore) workpieces from intermediate storage to the workpiece catalog,
- define the size of the intermediate store (depending on the backup medium used),
- list the contents of the intermediate store.

Dialog

B A C K U P

Save ?       Restore ?

Meas data - save too ?        
 Deviations - save too ?     

UMESS CNC run ?        
     WP-Code        
     or workpiece name     

or KUM workpiece ?        
     from workpiece no.        
     to workpiece no.     

* YES	NO	UMES-CAT	*		REPEAT	TERMIN
BACK	PRE MENU	I STORE		TAPE-LEN		INFO



### Softkeys

**\* YES**

Task selection (<\* **YES**> = enter \*).

**NO**

**UMES-CAT**

Outputs workpiece catalog to screen (see also ➤ „Control data modification and management“ on page 17-1).

**REPEAT**

Used to complete missing entries (e.g. workpiece names).

**TERMIN**

Closes the dialog window and causes the workpiece entered to be copied in the specified direction. Then the dialog window reappears.

If when **Restore = \*** the workpiece specified already or still exists in the workpiece catalog, the program will request a new workpiece name. In this way you have the option of duplicating UMESS workpieces in the workpiece catalog.

**BACK**

Return to the <**Data backup / Administration**>.

**PRE MENU**

**I STORE**


Lists current contents of intermediate store on screen specifying the workpiece number, workpiece name, file name, date of backup and type of data.

The following data type codes are used:

- A** ASCII format.
- B** Internal format.
- U** Faulty conversion (e.g. insufficient temporary storage space).

**TAPE LEN**

In the dialog window <**SELECTION of tape length or storage medium**> specify the length or type of backup medium used (select <\* **YES**>/<**NO**>, confirm with <**TERMIN**>). Based on this information, the program calculates the size of the intermediate or buffer store.



**Please note**

The intermediate or temporary store will accept as many workpieces as a type of the specified length can store. Once this capacity is exceeded, the a message will appear stating **the workpiece concerned is not transferred to the intermediate storage**. If this case, clear the intermediate store by copying the data to a backup medium or using the appropriate function call (> „Clearing the intermediate store“ on page 4-5).

**Data boxes**

- Save?** Used to copy from workpiece catalog to intermediate (buffer) store.
- Restore?** Used to copy to the workpiece catalog from the intermediate store.
- Meas data - save too?** Concerns KUM, cf. applicable operating instructions. Input does not apply with **Restore**.
- Deviations - save too?** Concerns KUM, cf. applicable operating instructions. Input does not apply with **Restore**.
- UMESS CNC run?** Used to copy CNC programs. The workpieces to be copied must be specified by workpiece name or number (as usual for the workpiece catalog). If a CNC program contains KUM calls, the workpiece-specific KUM data will also be backed up.
- KUM workpiece?** Used to copy KUM programs. The workpieces to be copied must be specified via their numbers (cf. KUM operating instructions).

**Procedure**

- Tape length** If you work with various backup media or are creating the intermediate store for the first time: Specify the tape length (<**TAPE LEN**> soft key).
- Copying direction** Select the desired copying direction:
  - From workpiece catalog to intermediate storage (backup):  
**Save = \***.
  - From intermediate storage to workpiece catalog (restoration):  
**Restore = \***.
- KUM data** KUM users: also specify the data to be saved where applicable (measured data, deviations).
- Workpiece** Specify the workpieces to be copied. Start copying with <**TERMIN**>. In KUM several workpieces can be copied if they have consecutive numbers. This also applies to UMESS if you make entries in the form e.g. **1-2** or **110-119** (i.e. the numbers of the first and last workpieces separated by a hyphen without blanks).
- List intermediate storage** If required, list the contents of the intermediate storage with the <**STORE**> softkey.

**NOTE**

The intermediate store is located on the hard drive in the directory **/var/opt/zeiss/CZ\_BACKUP\_SCR**.  
 If a serious malfunction (disk crash) occurs, the data stored here is just as much in danger of being destroyed as the other UMESS and KUM control data. You only have a true backup after copying the data buffered in the intermediate store to a backup medium.  
 Only a backup of the complete data stock (full backup) also includes the contents of the intermediate store.

**Copying the contents of the intermediate store to a backup medium**


- Application** Using the dialog window described below, you can copy the entire contents of the intermediate store to a backup medium.

**Procedure**

- Backup medium** Insert a backup medium of the size you specified with <**TAPE LEN**> (> „Backup to/restoration from intermediate storage“ on page 4-6), in the drive.

**Selection function**

Call dialog window (▶ „Dialog page for data backup“ on page 4-4) and select **<copy files from intermediate storage to backup medium>**.



**Code**

Enter the code corresponding to your backup medium and confirm with **<TERMIN>**.

The following warning is then displayed:

**The data on tape/diskette will be overwritten!**

**Verification inquiry**

**Is the tape/diskette inserted and the write protect removed?**

Acknowledge with **<YES>** or cancel with **<NO>**.

**Background processes**

The following functions are then run automatically:

- The contents of the intermediate or buffer store are copied to the backup medium in **tar** format.  
All UMESS and KUM data copied are displayed in the UMESS dialog window as a background process. A catalog file with the name **SAVE\_INFO\_\_\_K** is also copied.
- The previous contents of the backup medium are lost!
- If an error occurs during the copy procedure, this will be documented accordingly in the UMESS dialog window.

- The intermediate store is cleared automatically!
- The **<Data backup/Administration>** dialog window is then displayed.

**Check**

If necessary, list the contents of the backup medium outside of UMESS using the UNIX command (**tar tvf /dev/dat** or **tar tvf /dev/rdisk/floppy** depending on the medium used).

### Copying data from the backup medium to the intermediate store

**Application**

The procedure described below is used to copy the entire contents of a backup medium to the empty intermediate (i.e. buffer) store.

**Prerequisite**

This function can be used only for backup media to which data has been written via **<DI 3500>** or using the previous KUM backup program (SKUMS). The data stored on the backup medium may also be in ASCII format, e.g. if it was backed up from UMESS 1000.

#### **Procedure**

**Prerequisite**


Clear the intermediate store (▶ „*Clearing the intermediate store*“ on page 4-5).

**Backup medium**

Insert backup medium in drive.

**Select function**

Call dialog window (▶ „*Dialog page for data backup*“ on page 4-4) and select (check) **<copy files from backup medium to intermediate storage>**.



**Note** You do not have to enter the length of the tape.  
**Code** Enter the code matching your backup medium and confirm with **<TERMIN>**.

The following message is then displayed:

**Copy from tape/diskette to intermediate storage!**

**Verification inquiry** **Has the tape/diskette been inserted?**  
 acknowledge with **<YES>** or cancel with **<NO>**.

**Background processes** The following functions then run automatically:

- All UMESS and KUM data copied are displayed in the UMESS dialog window in the background.
- If an error occurs during the copying procedure, this will be documented in the UMESS dialog window.
- The **<Data backup/Administration>** window will then be displayed.

**Restore** Now you can copy the workpieces from the intermediate store to the workpiece catalog (*> „Backup to/restoration from intermediate storage“ on page 4-6*);

Convert ASCII data to the internal format beforehand (▶ „Converting control data to the ASCII or internal format“ on page 4-13).

## Converting control data to the ASCII or internal format

### Prerequisites

In principle you can also use workpieces in UMESS/KUM UX which you have created with a compatible system, e.g. UMESS/KUM 1000, and vice versa.

### Please note

- Conversion is a very time consuming process. For this reason, you should start a conversion only if you are really sure that you need it for the other system (with the target format).
- ASCII data require roughly twice as much storage space as data in the internal format. The storage space available in the buffer store may therefore be insufficient for this format. Two options:
  - Start the conversion as described below and wait for the screen display **Disk full**. Use <I STORE> to check which data has been and which has not been processed. (▶ „Backup to/restoration from intermediate storage“ on page 4-6). Then repeat the conversion process for workpieces of data types **B** and **U**.
  - Always convert and transfer workpieces as described below.

### Procedure

#### From system A (e.g. UMESS 1000):

#### Intermediate storage

Clear the intermediate store if necessary: (▶ „Clearing the intermediate store“ on page 4-5).

#### Copy workpiece

Copy workpiece(s) to the intermediate store: (▶ „Backup to/restoration from intermediate storage“ on page 4-6).

#### Convert format

Convert workpiece files from the internal format to the ASCII format:  
The conversion affects all workpieces located in the intermediate store.

#### Backup medium

Transfer ASCII data from intermediate store to backup medium: (▶ „Copying the contents of the intermediate store to a backup medium“ on page 4-9) For the correct procedure and input, refer to the operating instructions for the system concerned.

#### From system B (e.g. UMESS UX):

#### Backup medium

Transfer contents of backup medium to the intermediate store: (▶ „Copying data from the backup medium to the intermediate store“ on page 4-11)

**Convert format**

Convert the workpiece files from ASCII format to the internal format.  
The conversion affects all workpieces in the intermediate store.

**Copy workpiece**

Transfers workpieces from the intermediate store to the workpiece catalog: (> „Backup to/restoration from intermediate storage“ on page 4-6)

Perform any adjustments required.


**Backup and restoration of all workpiece-independent KUM data with <DI 3510> and <DI 3511>**

**Application**

CNC runs and the corresponding KUM data are saved with <DI 3500>. The workpiece-independent performance modes and performance mode command blocks can be copied to the intermediate store and converted to ASCII format with <DI 3510>.

**<DI 3510>**

**Backup to intermediate storage**




<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
3510		

During the backup, all relevant performance modes and performance mode blocks are automatically taken into account and converted to ASCII format. The files included in the backup are then displayed in the list and message window.

**<DI 3511>**


**Restoring from intermediate storage**



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
3511		

KUM workpieces with relevant performance mode data may be located in the intermediate store. During restoration, you must check to determine whether any performance mode data is located there. You can decide in a dialog whether or not you want to restore the existing performance mode data.





**IMPORTANT!**

If you decide to restore the performance mode data, all of the performance mode data in the intermediate store will be restored. Any performance mode data which may be stored in your computer will then be overwritten!

Then all the performance mode data located in the intermediate store will be deleted. This ensures that a performance mode which has been restored and can be reused will not have to be restored repeatedly. Apart from CNC runs, only workpiece-dependent KUM data is now still located in the intermediate store.

Even the performance modes for those KUM workpieces which have not yet been restored are now already located in your computer.

## Backup and restoration of user data with CZ Utilities

**Application** Backup of important UMESS data is very easy with CZ Utilities.


*No special knowledge of the operating system is required.*

**Local or LAN** You can back up the data either locally or via LAN (local area network). When performing data backups via LAN, you must always start CZ Utilities on the computer where the backup drive is located (tape cartridge or DAT).

### Starting CZ Utilities for data backup

**Workspace menu** The background on which all windows are displayed is referred to as the workspace. If you click anywhere on this workspace, the Workspace menu will open.


**CZ menu** Here you will find the CZ menu. If you keep the mouse button pressed and then "drag" the pointer to the CZ menu, you can start CZ Utilities by positioning the pointer on this option and then letting go of the button.



**Data backup** The data backup can be started more directly with **Workspace Menu -> CZ Menu -> Backup**. However, you can not change to the **root** superuser.

**CZ-Utilities -> SAM**

When CZ-Utilities is called, the program branches to the **System Administration Manager (SAM)** and first asks which **user** you would like to use the function for.



The default user is **ut16**. Press softkey **<F4>** until the **root** user is displayed.

**SAM**

Within SAM you must call the following menus by double-clicking to reach the user data backup:

- **CZ\_UTILITIES**
  - **CZ\_DATASAVE**
  - **SAVE\_CZ\_USERDATA**
- or
- **RESTORE\_CZ\_USERDATA**

## Backup of User Data

Function call

See ► „Starting CZ Utilities for data backup“ on page 4-16

CZ-UTILITY							
<pre> ***** ** **  CZ Utilities 8.3.0 - Data backup (CZ user data)  ** ** *****           </pre>							
Input  Data backup medium							
1      DAT (DDS)							
2      Optical Disk (MO)							
Selection: <input type="text" value="1"/>							
Back	End			CZ-UTILITY	Help		

**Backup medium**

Select the medium you want to use for the backup by entering the appropriate code no.


**Computer name**

You will then be prompted to enter the computer from where the backup should be made. The local computer from where the data backup was started will always be offered as the default value. You can confirm this selection with **<Enter>**.

**Data list**

A list of all data to be backed up will then be created. You can print this list or edit it as required.

Starting a backup



**NOTE**

You will then be prompted to insert a tape cartridge in the matching drive. Wait until the loading procedure for the tape cartridge has been completed (i.e. until the 'Busy' lamp on the drive goes out) and start the data backup by pressing the **<Enter>** key. If the capacity of the tape cartridge is insufficient for a full backup, you will be prompted to insert an additional tape cartridge.

## Restoring user data

Function call

See ► „Starting CZ Utilities for data backup“ on page 4-16

CZ-UTILITY							
<pre> ***** **                               ** **      CZ Utilities 8.3.0 - Restore      ** **                               ** *****           </pre>							
<p>Input    Data backup medium</p>							
<p>      1        DAT (DDS)</p>							
<p>      2        Optical Disk (MO)</p>							
<p>Selection: <input type="text" value="1"/></p>							
Back	End			CZ-UTILITY	Help		

### Backup medium

Select the medium you want to use for the backup by entering the code number.

### Starting the restore process

You will now be prompted to insert a tape cartridge in the corresponding drive. Wait until the loading process for the tape cassette has been completed (i.e. until the 'Busy' lamp on the drive has switched off) and start the restoration by pressing the **<Enter>** key.

## Executing and restoring a full backup

### Application

All of the data on the hard disk can be backed up to the DAT tape.

#### NOTE

To do this you must be familiar with the operating system! Be very careful with all inputs and avoid typographical errors!

### Full backup using CZ Utilities

A full backup can be created using CZ Utilities, however, this is **not recommended**. Many background processes are still running in UNIX while CZ Utilities are being executed. For this reason, certain files may not be included in the backup.

## Single User mode

### Application

A full backup should be executed or restored only in the Single User mode. This ensures that the operating system does not have any further actions running in the background mode.

### If the computer is switched off:

Switch the computer on and immediately press the **<Esc>** key several times. The Boot Administrator will then start. Enter the following commands:

```
BOOT_ADMIN> boot scsi.6.0 isl
```

```
ISL> hpux -is boot
```

UNIX will then boot a minimum system and display the following message:

**WARNING: YOU ARE SUPERUSER !!**

### If the computer is switched on:

- Terminate UMESS and any other applications.
- Open a system window ("New window").
- Log in as superuser with the command: **su**
- Set the computer to runlevel 1 **init 1**
- **Welcome to HP-UX ...**  
**Console Login:**  
Enter: **root**

UNIX displays the following message:

**WARNING: YOU ARE SUPERUSER !!**

### Second hard disk

If a second hard disk is installed in the computer, it must also be mounted with: **mount -a**

## Executing a full backup

<b>Application</b>	A full backup should be created in the <b>Single User mode</b> .
<b>Function call</b>	<b>/etc/fbackup -v -n -0 -f /dev/dat -i /(-0 = -zero)</b>
<b>Duration</b>	30 - 60 minutes, depending on the amount of data stored. The files backed up will be displayed on the monitor.
<b>2. DAT tape</b>	If the amount of data on the hard disk exceeds the capacity of the DAT tape, the backup process will be halted with the following message:  <b>fbackup(xxxx): hit return when volume 2 is ready on /dev/dat?</b>  Insert a second DAT tape and press <b>&lt;Enter&gt;</b>
<b>SAM</b>	A full backup can also be executed in the System Administration Manager (SAM). To do this, call <b>sam</b> in the single user mode.
<b>Restarting the software</b>	<b>shutdown -r 0</b>

## Restoring a full backup

<b>Application</b>	A full backup should be restored only in the Single User mode.
<b>Function call</b>	<b>/etc/frecover -xov -f /dev/dat -i /</b>
<b>Duration</b>	30 - 60 minutes, depending on the amount of data. The restored files are displayed on the monitor.
<b>DAT tape</b>	If more than one DAT tape was required to create the full backup, the following message will be displayed during the restoration process:  <b>fbackup(xxxx): tape drive error during fastsearch mark positioning</b>  <b>fbackup(xxxx): Volume 1 completed</b>  <b>fbackup(xxxx): Press return when next volume is ready on /dev/dat:</b>  Insert the next DAT tape and press <b>&lt;Enter&gt;</b> .
<b>Partial restoration</b>	Individual files or directories can also be restored with the following command:  <b>/etc/frecover -xov -f /dev/dat -i /directory/Filename</b>
<b>Restarting the software</b>	<b>shutdown -r 0</b>



## Data backup modes LINUX

The following data backup modes can be selected via **KDE system button** → **CZ\_Uutilities** → **CZ\_Datasave**:

- **CZ\_Fullbackup** → backs up entire hard disk.
  - Format: tar
  - Medium: DAT drive
  - Remote data backup between: **LINUX → LINUX**  
**LINUX → HPUX 10.20**
- **Save\_CZ\_Userdata** → performs backup acc. to backup list.
 

The backup list can be edited by the user.

  - Format: tar
  - Medium: DAT drive
  - Remote data backup between: **LINUX → LINUX**  
**LINUX → HPUX 10.20**
- **Restore\_CZ\_Userdata** → restores user data backup to hard disk.
  - Format: tar
  - Medium: DAT drive
  - Remote data backup between: **LINUX → LINUX**  
**LINUX → HPUX 10.20**
- **CZ\_SAM\_ASCII\_Data** → backs up SAM data **\*.SAM** and **\*.ERR** to the local directory **/home/zeiss/UF**.
  - Format: tar
  - Medium: DAT drive, floppy
  - Remote data backup between: **LINUX → LINUX**  
**LINUX → HPUX 10.20**



# Chapter

# 5

## Output of results

---

### **This chapter contains:**

Basic Principles. . . . .	5-2
Identification of results. . . . .	5-8
Output mode <DI 1662>. . . . .	5-12
Header. . . . .	5-21
Comment input. . . . .	5-33
Time function <DI 1618>. . . . .	5-38
Repetition record <DI 1613>. . . . .	5-40
Saving, outputting and deleting records. . . . .	5-41
Changing the user name <DI 1698>. . . . .	5-45
Graphic output . . . . .	5-46
Printing and plotting in a network . . . . .	5-50

## Basic Principles

### Components of the measurement record

#### Organization

A measurement record comprises the following:

- **Texts**  
entered using the **<TEXT>** function (**<DI 1676>** ► „Comments in the measurement record <DI 1676>“ on page 5-33).
- **Results**  
subdivided into
  - results with nominal capability  
(results from measurements, conversions or linkings (constructions) for which a nominal-actual or variance comparison can be executed, e.g. **<CIRCLE>**, **<GDT-ROUND>**, **<INTERSECTION>** etc., ► „Dimensional, form and position tolerances“ on page 14-1) and
  - results without nominal capability  
(results from functions which influence the coordinate systems, e.g. **<ROTATE SPACE>**, **<ROTATE PLANE>**, **<ZERO POINT>** No nominal can be specified for these results).
- **Graphics**  
created e.g. with the GDT plot function **<DI 1470>** (see Option 2, ► „Graphic output“ on page 5-46).

### Variants of the record output

#### Extent of record

The format of the record can be defined with **<DI 1665>** (► „Defining the scope of the record <DI 1665>“ on page 5-14) and **<DI 1667>** (► „Defining the print format <DI 1667>“ on page 5-17).

#### Output device

Output to the printer is activated/deactivated with **<DI 1614>** and **<DI 1615>** (► „Defining the record output medium <DI 1614 /1615>“ on page 5-12).

#### Additional output

The measurement record is output to the selected output device and at the same time stored on the hard drive.

It can be output again either with **<DI 1613>** (repetition record, ► „Repetition record <DI 1613>“ on page 5-40) or, if it has been stored with **<DI 1683>** (► „Saving, outputting and deleting records“ on page 5-41), via **<DI 1684>**.

## Display of results in the measurement record

### Possibilities

The measurement record can be shown in two different ways. It can be set with **<DI 1667>** (► „Defining the print format <DI 1667>“ on page 5-17).

### Example

#### Default record

```

=====
ADR|REC |TASK| IDF |SY| ACTUAL | NOMINAL | U.TOL | L.TOL | DEV | EXC
=====
BORE_1
 1      CIRCLE I  M22  X   13.4045   13.5000   0.1000  -0.1000  -0.0955  ----
                M25  Y   45.1076   45.0000   0.1000  -0.1000  -0.1076  0.0076
                M12  D   10.0328   10.0000   0.1000  -0.1000   0.0328  ++
 8P S/MIN/MAX                0.5960   (5)    -0.3640  (1)    0.312

```

### Feature

A max. of 5 characters can be entered in the identification box.

### Example

#### Extended record output

```


=====
ADR|  NAMES / IDF |SY| ACT VAL| NOM VAL| U.TOL | L.TOL | DEV | MAG
=====
 1 CIRCLE_0001      CIRCLE I
  X_00000045      X   13.4045   13.5000   0.1000  -0.1000  -0.0955  ----
  Y_00000055      Y   45.1076   45.0000   0.1000  -0.1000  -0.1076  0.0076
  D_00000050      D   10.0328   10.0000   0.1000  -0.1000   0.0328  ++
 8P S/MIN/MAX                0.5960   (5)    -0.3640  (1)    0.312

```

### Feature

A max. of 10 characters can be entered in the identification box.

Explanation of element output



Explanation of abbreviations in the measurement record

Abbreviation	Meaning
DEV	Deviation from nominal value
ADR	Current address
TASK	Measuring task
IDF	Freely selectable identification

<b>Abbreviation</b>	<b>Meaning</b>
<b>DIN-</b>	Evaluation acc. to DIN 7184
<b>PLA</b>	Plane
<b>LINE</b>	Line
<b>COA</b>	Coaxiality
<b>CON</b>	Concentricity
<b>RUN</b>	Radial/axial runout
<b>ANG</b>	Angularity
<b>PAR</b>	Parallelism
<b>POS</b>	Position
<b>PER</b>	Perpendicularity
<b>RND</b>	Roundness
<b>SYM</b>	Symmetry
<b>CYL</b>	Cylindricity
<b>(M) A (M)</b>	Calculation with maximum material condition
<b>DIST</b>	Distance
<b>ROTATE PLANE</b>	2D alignment to 1 projected angle
<b>ROTATE SPACE</b>	3D alignment to 2 projected angles
<b>ELLIP O/I</b>	Outer/inner ellipse
<b>U.TOL/L.TOL</b>	Upper/lower tolerance
<b>MIN PLANE</b>	Minimum plane from DI 1140
<b>MAX PLANE</b>	Maximum plane from DI 1140
<b>RES.</b>	Result of conversion with formula DI 1379
<b>Formplot</b>	GDT plot with DI 1470 or fast plot with DI 1461
<b>t-NOM</b>	Entered form deviation
<b>t-ACT</b>	Measured form deviation
<b>STD DEV</b>	Standard deviation
<b>MAGNIFICAT.</b>	Entered magnification
<b>V-MAX</b>	Maximum scanning speed
<b>PROBE DIA</b>	Probe diameter in mm
<b>ACTUAL</b>	Measured value
<b>NO RESULT</b>	No result can be calculated
<b>CONE O/I</b>	Outer/inner cone
<b>CONE DIA</b>	Cone diameter at given height
<b>CON CO</b>	Cone coordinates at given diameter
<b>CIRCLE O/I</b>	Outer/inner circle
<b>CIR SE</b>	Circle segment with DI 1114
<b>PERP DIST</b>	Perpendicular distance output with DI 1286

## Output of results

Abbreviation	Meaning
PERP CYL	Perpendicular distance output with DI 1285
MEAN	Arithmetical mean
NOMINAL	Nominal dimension in the drawing
ZEROPT	Coordinates of the last address are set to zero
..P S/MIN/MAX	Number of measured points Standard deviation/minimum/maximum value Element referring to best fit element
3D POINT	3D point
RADMES	Radius measurement with DI 1114
REC *	Recall of an element <b>without</b> coordinate transformation
REC !	Recall of an element <b>with</b> coordinate transformation
MIN-R	Min radius from DI 1141
MAX-R	Max radius from DI 1141
3D POLAR	3D polar = 3D polar distance with DI 1261
S-G FF	Intersection line from two surfaces
I-PT FG FZ GG KF KG KK KZ	Intersection point from surface and line surface and cylinder axis line and line circle and surface circle and line circle and circle circle and cylinder axis
SYM- A F P	Symmetry Axis Surface Point
SY X Y Z D R W1 W2 WK RD WX WY WZ t tD tX tY tZ	Symbols: Axes, diameter, radius, Plane angles W1 and W2, cone angle, Length and direction of the 3D diagonals, Form and position deviation acc. to DIN 7184
PART NO	Current part number of workpiece measured



<b>Abbreviation</b>	<b>Meaning</b>
<b>PITCH</b>	Pitch measurement with DI 1310
<b>p</b>	Distance between elements
<b>pk</b>	Distance to first element
<b>fp</b>	Individual pitch error
<b>Fp</b>	Cumulative pitch error
<b>fu</b>	Distance between adjacent pitches
<b>Fr</b>	Radial runout
<b>POS</b>	Nominal position
<b>EXC +/-</b>	Tolerance exceeded or degree of utilization 25% tolerance utilization more or less
<b>EDGE PT</b>	Edge point
<b>W-NAME</b>	Name of workpiece measured
<b>CYL O/I</b>	Outer/inner cylinder

## Identification of results

### Organization

Results must be clearly identified in the record to simplify name allocation and subsequent retrieval.

This can be done by:

- **Address**  
allocating addresses (▶ „Allocating addresses“ on page 5-8)
- **Identification**  
entering identifications (▶ „Input of identifications“ on page 5-9)
- **Name**  
allocating names (▶ „Allocating names“ on page 5-9)

### Allocating addresses

#### Address allocation

An address is automatically allocated to every result. This is a consecutive number under which the result is stored in the internal record.

#### Counting

The address of a result is determined by the address counter, which is set to 1 following the start of UMESS and incremented by 1 for every result.

#### Address counter

The following functions influence the address counter:

- **<DI 1608>**; set to initial status (▶ „Setting the initial status <DI 1608>“ on page 6-7) The address counter is set to 1.
- **<DI 1610>**; call up record header (▶ „Calling the default header and variable header I <DI 1610>“ on page 5-24) The address counter is set to 1.
- **<DI 1690>**; set address counter (▶ „Setting the address counter to a random address <DI 1690>“ on page 6-8) The address counter can be set to any value.

#### NOTE

Each address can exist only once in the internal record. If the address counter is reset, all previous results will be overwritten.

## Input of identifications

### Application

A remark can be entered for every measured value with a nominal-actual (variance) comparison (► „Dimensional, form and position tolerances“ on page 14-1). However, this remark is used only for relating the measurement results to the drawing dimensions etc.

### Options

The identification box may have either 5 characters as for the default record or 10 characters as for the extended record. It is set with <DI 1667> (► „Defining the print format <DI 1667>“ on page 5-17).

## Allocating names

### Application

If the name allocation is activated, a name is assigned to each result which has *nominal capability*. The same applies to the following functions with which coordinate transformations are executed:


- Zero point <DI 1701>
- Rotate plane <DI 1702>
- Rotate zero point + 1 element <DI 1703>
- Rerotate about an angle <DI 1704> and <DI 1709>
- Rotate to distance <DI 1705>
- Rotate space <DI 1706>
- Change space axis <DI 1707>
- Free axis selection <DI 1711>
- W-position according to workpiece system <DI 1713>
- Basic displacement <DI 1722>
- Zero point displacement <DI 1723>.


### Activating/deactivating name allocation

<DI 1663>

### Long-term mode

The setting selected is a long-term mode. I.e. the setting selected here is retained even after the computer is switched off.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1663	Record	
NAMES	Mode	
	Name allocation on/off...	

Dialog

Element name selection

Name allocation activated

YES NO \* TERMIN

BACK INFO

**YES**

These buttons activate/deactivate the name allocation.

**NO**

**TERMIN**

Press **<TERMIN>** to close dialog window.

### Input functions

If the name allocation function is activated, then

- a result name is output to the measurement record,
- a **result name** is prompted for functions with dialog input,
- a default value is offered in the result name box for functions with input via dialog boxes.

### Default names

The computer offers a default name which can be changed by the user.

### Allocation rules

The following rules must be observed when allocating names:

- Maximum length: default 10 characters. Can be changed to 24 characters with **<DI 1667>** (**>** „Defining the print format **<DI 1667>**“ on page 5-17).
- Permissible characters: **A - Z** (upper case), **0 - 9**, underline ("\_").
- The first character must be a letter.

- The last character must not be an underline.
- The names must be unambiguous, i.e. each name may appear only once per measuring run.

**Preassignment**

A standard indexed name (for example **CIRCLE\_1**) is always offered as the default entry. The index is increased each time the same element is called again.

**(CIRCLE\_2 -> CIRCLE\_3 -> CIRCLE\_4 -> . . . -> CIRCLE\_n)**

**Subsequent calls**

If the preassignment (default name) is not accepted, but overwritten with another name, this name will then always be offered during subsequent calls of the same function with an increased index.

**Prerequisite:** The name ends with a digit.


**Example**

The **<CIRCLE>** function is called. The preassignment **CIRCLE\_1** is not accepted. The user enters **BORE\_10**. In this case **BORE\_11** will be offered as the preassigned or default value the next time the **<CIRCLE>** function is called.

**NOTE**

- If you use your own result names, they must be entered in upper case letters.
- The result name index must not exceed the value 32767 (e.g. **CIRCLE\_32767**).
- With the alphanumeric control panel, the "\_" character can be entered by keying in **<CTRL> + <->**.
- *Indexed names must* be preassigned to functions in which several addresses are output to the measurement record. Examples: Extreme values, form deviation and pitch.
- Loops in CNC programs: Starting with the second loop, an additional index is appended to each result name. This prevents results with different addresses from being assigned the same name.
- Examples: **CIRCLE\_5 -> CIRCLE\_5\_1**  
**LINE -> LINE\_1**
- Results can be recalled or linked by entering the name.
- The name allocation is activated with **<DI 1663>**.

## Output mode <DI 1662>



### Scope of functions

The following measurement record output parameters can be defined with the output mode:

### Softkeys

**REC DEF**

Scope of record (▶ „Defining the scope of the record <DI 1665>“ on page 5-14)

**REC OUTP**

Record format, with output to printer (▶ „Defining the print format <DI 1667>“ on page 5-17)

**GRPH MOD**

Graphics mode (▶ „Graphic output“ on page 5-46)

**LANGUAGE**

Language, unit of measurement and number of decimal places (▶ „Defining the language, unit of measurement and decimal places <DI 1692>“ on page 5-16)

**DEC PLAC**

**TERMINAL**

Record output medium (▶ „Defining the record output medium <DI 1614 /1615>“ on page 5-12)

**PRINTER**

### Alternative call

All of the functions listed above can be called centrally using <DI 1662> and the appropriate softkey, by using their own specific DI number, or from the Pull-Down-Menu.

## Defining the record output medium <DI 1614 /1615>

### Printer/screen


The measurement record is always output to the screen. It can also be additionally output to the printer.


The output device can be defined in one of two ways:

- By initializing the record output. Explanation (▶ „Defining the print format <DI 1667>“ on page 5-17).


- By selecting the output device directly.


#### Activating output to the printer



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1614 PRINT	Record Mode Printer output...	

#### Deactivating output to the printer



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1615 TERMINAL	Record Mode Screen output...	

#### NOTE

The output device selection is stored in a long-term file. This means that the output medium selection will be retained even after the computer is switched off. This setting can be changed again only by calling the corresponding function.

## Defining the scope of the record <DI 1665>

**Function**

The scope of the measurement record can be defined using <DI 1665>.

Dialog

Definition of record contents

Output  Y

all

or results with nominals

or lines with nominals

or results with tol. utilisation

or lines with tol. utilisation

Selected dispersion output

Dispersion output for all elements

Output with dispersion value S >

Suppress text output


Suppress help and mode information\*

Printer

Terminal

\* YES NO \* TERMIN

BACK INFO



DI	Pull-Down-Menu	Pictogram
1665	Record	
REC DEF	Mode	
a57	Extent of record...	

**Documentation**

The mode set is documented in the measurement record according to the input.

Exception: The box for suppressing the mode information has been selected.

**Data boxes**

all

The entire measurement record is output.

or results with nominals  
or lines with nominals

The measurement result is output only if the nominals have been defined.



<b>or results with tol. utilisation or lines with tol. utilisation</b>	The measurement result is output only if a certain percentage of the entered tolerance range has been utilized or exceeded. Enter the tolerance utilization from which a result is to be output
<b>Dispersion output for all elements</b>	The dispersion output can be preselected.
<b>Output with dispersion value S &gt;</b>	The dispersion is output only if the limit entered in the next box has been exceeded. The average point dispersion, smallest value (MIN) and largest value (MAX) are output.
<b>Suppress text output</b>	Suppression of all texts which have been entered with <TEXT>.
<b>Suppress help and mode information</b>	Suppression of texts on the stored output mode.



**Data boxes****Language code**

Abbreviations used:

**D** = German**A** = English**E** = Spanish**H** = Dutch**F** = French**I** = Italian**P** = Portugese**S** = Swedish

Either accept the default code or overwrite and confirm with **<Enter>**.

**Number of decimal places**

Enter the number of decimal places (0 to 5) required and confirm with **<Enter>**.

**Unit of measurement**

**Inches** or **mm** can be selected with **<YES>/<NO>**.

**Time output format**

German = DD.MM.YYYY

American = MM/DD/YY


The time output is linked with the language setting. If for example English is selected, the time will be output in the American format.

**Defining the print format <DI 1667>****Function**

You can use the **<REC OUTP>** function as an alternative to **<DI 1614>** and **<DI 1615>** to select the output device for the measurement record (► „Defining the record output medium <DI 1614 /1615>“ on page 5-12).

**Long-term mode**

The setting selected is retained until changed.



Dialog			
Initialization of record output			
<input checked="" type="checkbox"/> Y	Output device	Terminal	<input checked="" type="checkbox"/> *
	or printer		<input type="checkbox"/>
	Characs / Line	Number	<input type="text" value="80"/>
	Lines / Page	Number	<input type="text" value="60"/>
Record			
	Perf.mod		<input type="checkbox"/>
	Extended output	10 char's	<input checked="" type="checkbox"/> *
		24 Charact	<input type="checkbox"/>
	Record output backup 10		<input type="checkbox"/>
<input type="checkbox"/> * YES	<input type="checkbox"/> NO	<input type="checkbox"/>	<input type="checkbox"/>
<input type="checkbox"/> * REPEAT	<input type="checkbox"/> TERMIN	<input type="checkbox"/>	<input type="checkbox"/>
<input type="checkbox"/> BACK	<input type="checkbox"/> PRE MENU	<input type="checkbox"/>	<input type="checkbox"/>
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/> CALCUL	<input type="checkbox"/> INFO

**Data boxes**

**Output device**

Printer and screen data output can be selected with <YES> and <NO>.

**Characs/Line**

Input option: 80 to 132 characters per line. Default value: 80

**Lines/Page**

Input option: 10 to 120 lines per page. Default value: 60

**Record Perf.mod**

– **Standard**

Output of the normal record. A maximum of 5 characters can be entered for the identification box and a maximum of 10 characters for the name allocation box.

– **Extended output 10 char's**

- The result name may have up to 10 characters. It is located in the same line as the address and the element name.
- The identification may have up to 10 characters (default 5 characters). It is located below the result name.

– **Extended output 24 Charact**

The result name may have up to 24 characters. (Examples ▶ „Display of results in the measurement record“ on page 5-3.)


**Record output backup  
10**

If this function is selected, the last 10 measurement records will automatically be saved to the directory **/home/zeiss/UF**. The printout can be started with **<DI 1604>** (▶ „Printing the last 10 measurement records <DI 1604>“ on page 5-43).

**Page feed in the record <DI 1675>**


**Function**

You can invoke or program a page feed with **<DI 1675>**.




<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1675	Record	
NP or FEED	Layout	
a617	Page feed...	

**Result output on alphanumeric control panel**




The result is not output to the alphanumeric control panel as a standard feature. It is, however, possible to display coordinate transformations and measured results on the alphanumeric control panel in a single line and without nominals.

**Activating the alpha  
control panel output**



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
.34		
REC ON		

Deactivating the alpha control panel output



# Header

## Application

Before starting a measuring run, you can attach a header to the corresponding record for documentation purposes. This header contains information on the allocation of measuring results to the test object, the operator, the department, the customer etc. The following functions are required to create or output a record header:

- **<DI 1612>** to select between the default record header and variable record header I.
- **<DI 1610>** to call and output the default record header and variable record header I.
- **<DI 1611>** to call and output variable record header II.

## Default record header and variable record header I

### Layout of the default header

```

=====
                                MEASURING RECORDZEISS  UMESS
=====
WORKPIECE NAME                                MANUAL MEASUREMENT
=====
DRAWING NUMBER | ORDER NUMBER | SUPPLIER/CUSTOMER | OPERATION
638596-4589-54 | 1457-5834-5648 | Zeiss           | 0100

OPERATOR | DATE | PART NUMBER |
Mueller | 11/30/98 | 45      |

=====
ADR|REC|TASK|IDF|SY|ACTUAL|NOMINAL|U.TOL|L.TOL|DEV|EXC
=====

```

### Features

- Included in UMESS as a default feature.
- Form can not be altered.
- Data boxes can be filled in.

Structure of variable header I

```

=====
                                MEASURING RECORD ZEISS  UMESS
1      Any
2
3      text
4
5      from
6
7      line 1 to
8
9      line 9

WORKPIECE NAMEMANUAL MEASUREMENT
=====
DRAWING NUMBER | ORDER NUMBER | SOFTWARE | MEASURING DEVICE
638596-4589-54 | 1457-5834-5648 | UNIX | CMM

OPERATOR | DATE | PART NUMBER | CUSTOMER | COMMENT
Mueller | 07.01.1998 | 45 | |

=====
ADR|REC|TASK|IDF|SY|ACTUAL|NOMINAL|U.TOL|L.TOL|DEV|EXC
=====

```

Features

- A maximum of 9 permanently stored text lines.
- The number and names of columns can be changed. (This does not apply to the **OPERATOR**, **DATE** and **PART NUMBER** columns).
- Produced with **<DI 1612>** (► „Modification of variable header I <DI 1612>“ on page 5-22).


**Modification of variable header I <DI 1612>**


Application

The type of header required can be selected with this function.

Options

- Input or modification of text lines and column labels
- Initialization of header. If variable header I is deleted, the default header will be set.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1612	Record	
MODREC	Record head	
a58	modify...	



Dialog

Modification of record head

PERF MOD \* TEXTLINE COLUMN

PRE MENU INFO

### Softkeys

#### STANDARD

Initializes the protocol header.

- Activates the default header.
- Deletes all text lines previously entered.
- Resets modifications of column identifications.
- All header inputs are deleted. The operator name can be changed by logging in again in UMESS or by entering **<DI 1698>**.
- Returns to main menu without outputting the header.

#### TEXTLINE

Text lines 1 to 9 can be entered or edited. Following termination with **<TERMIN>** the system returns to the main functions.

#### COLUMN

The length, identifications and number of the columns can be changed. (This does not apply to the **OPERATOR**, **DATE** and **PART NUMBER** columns).

If the first character of a column is an asterisk (\*), the column is automatically requested with each CNC start.

Note that the columns are separated by a vertical line (|).

### NOTE

Note for CNC mode

You must define the header before starting the learn (part) programming, since the number of control lines required varies according to the layout.




### Calling the default header and variable header I <DI 1610>

#### This function

- enables you to input the information which is to appear in the header;
- prints the header;
- deletes all alignment angles and zero points and sets the address counter to **1**.
- Previous measurement results are lost, the initial status is set.
- The axis identifications set with <DI 1711> are *not* deleted.

**Application**

The header is normally invoked at the beginning of a new measuring run or CNC program.



Accepts all data from the last input. Only columns marked with an asterisk (\*) are requested in a separate dialog window.

**SET PRINTER TO TOP OF PAGE! (RETURN)**

If record output to the printer is selected and the printer is being operated in the direct mode, you will be prompted to set the printer to the top of the page.

## Output of results

**YES**

The program will then prompt you to fill in all of the header columns except for **OPERATOR** and **DATE**.

Record head				Input			
=====							
MEASURING RECORD ZEISS UMESS							
@ WORKPIECE NAME				CNC RUN			
=====							
DRAWING NUMBER	ORDER NUMBER	SUPPLIER/CUSTOMER	OPERATION				
652485-2548	124576-6548-54	KMG	0100				
OPERATOR	DATE	*PART NUMBER					
Mueller	12/02/98	11					
				*			
					TERMIN		
PRE MENU							
					INFO		

**TERMIN**

End of input and return to previous menu.

**SET PRINTER TO TOP OF PAGE! (RETURN)**

If record output to the printer is selected and the printer is being operated in the direct mode, you will be prompted to set the printer to the top of the page

**SYSTEM INITIALIZED**

Displayed as information in the list and message window.


## Call des Variablen Protokollkopfes II <DAW 1611>

### Definition

You can arrange the layout of variable header II with a max. of 65 lines of texts and data boxes.

### NOTE

Restriction: The **operator**, **date**, **workpiece name** and **part number** boxes must be included in the layout.



Dialog											
VARIABLE RECORD HEAD MAIN FUNCTION											
<input type="checkbox"/>	C	NAME VARIABLE RECORD HEAD	<input type="text" value="EXAMPLE"/>								
ADDITIONAL INFORMATION			<input type="text" value="with parameters"/>								
* YES				NO				COPY		*	
EDIT				CATALOG		PRINT		EXECUTE			
BACK		PRE MENU				DELETE		LABELS		ENTER	INFO

### Softkeys

**CATALOG**

A list of the available header files is displayed. The file required can be selected using the **<YES>/<NO>** keys.

**COPY**

To copy an existing header file:

Enter the name of the header file you want to copy, press **<COPY>** and enter the new name of the file.

### NOTE

A new header file can be created by copying and then editing an existing file.

**EDIT**

Calls the text editor to edit an existing header file.

**LABELS**

Used to enter or edit the labels of user parameters in the database.

**DELETE**

Deletes a header. A file thus selected will be deleted from the hard disk only following a confirmation inquiry.

**PRINT**

Outputs the header currently selected without prompting inputs to the data boxes. The header is created with data from the database. The initial system is activated.

**EXECUTE**

Inputs and outputs the header currently selected. The initial system is activated.


**ENTER**

Enters and saves data in the database. No printout is performed.

### Labels

The parameters stored are displayed after calling **<LABELS>**.

User parameters can be edited here:




1) output only

2) only assigned in **PROG** or **CNC**


#### NOTE

After calling the **<EDIT>** or **<LABELS>** softkeys, the editors must be terminated by selecting **File** → **Termin** from the Pull-Down-Menu.


## Defining the boxes for output



Alternative:



## Defining the boxes for input and output



Possible operating modes:

- 0 = no input (corresponds to [ ])
- 1 = manual
- 2 = programming mode
- 3 = CNC run, input from database
- 4 = man CNC, input from control data

## Parameters

The labels and contents of data boxes can be defined by parameters:



- System parameters (H1 - H14)
- Technical parameters (T1 - T3)
- User parameters (U1 - U99)

H and T parameters are system and technical parameters which are always provided in updated form. Since they are also used in other UMESS programs, they should not be changed.

In contrast to the above, U parameters can be used as required. They are also session-specific, i.e. must be redefined for each session.

#### Line length

Data boxes may be defined only up to the 77th character in each line. A box may have a maximum of 69 characters.

#### Tab stops

Tabs are not allowed.

#### Data boxes

If an data box has op. mode code 3 or 4 or an output box has [ ], the output value will be taken from the current data base. In all other cases, the output value is taken from the control data.

#### Control data

The complete record header is stored in the control data and output depending on the value of column SC2. If a definition file is missing, it will automatically be created in the CNC run and entered in the catalog. A record header with the same contents can thus be selected either manually or during PROG.

If the creation of a definition file is prevented, the lowest value position in column SC2 must be changed to **0**.

#### Interpretation of the codes in column SC2

- |           |   |
|-----------|---|
| 0         | Control data from old version (corresponds to the value 6)  |
| bit 0 = 1 | The record head is updated in the CNC mode and entered in the catalog if required.  |
| bit 1 = 1 | Input in the database.  |
| bit 2 = 1 | Output in record with values from database or control data.   |
| bit 3 = 1 | Read in " <b>TEMPFILE___SNB</b> " file from <b>/home/zeiss/UC</b> (special case for DNC mode, can not be created using PROG). |

Example

Header edited

```

=====
=
[$U1 ]
=====
=

[$H1 ] : {123H1 } [$U10 ]: {1234U10:3}

DRAWING : [DU1 ] from[H2 ]

DETAIL : [DU2 ] PART NUMBER: {13H3 }

WORKPIECE NAME: {123H4 }

SUPPLIER : [DU3 ]
          [DU4 ]

-----
-
[$T3 ] : [T3 ]

                                     INSP.DATE : {OOH2 }
                                     TIME : {OOH12 }
    
```

Header output

```

=====
Content of Userparameter U1
=====

OPERATOR : Mueller Serial No. : 001

DRAWING : Contents of User parameter U1 DATE 02/04/1998

DETAIL : Contents of User parameter U2 PART NUMBER : 25

WORKPIECE NAME: TEST

SUPPLIER : Contents of User parameter U3
          Contents of User parameter U4

-----

PROBECONFIGURATION : 17

                                     INSP.DATE : 02/04/1998
                                     TIME: 13:15:20


=====
ADR| NAME / IDF |SY| ACT VAL|NOM VAL| U.TOL | L.TOL | DEV | MAG
=====
    
```


# Comment input

## Comments in the measurement record <DI 1676>

**Application**

Any number of texts can be printed in the measurement record with this function.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1676	Record Layout Text...	

Dialog

Text input

@ This is a text

		< - >	< + >
--	--	-------	-------

\*

		EXECUTE	TERMIN
--	--	---------	--------

	PRE MENU		
--	----------	--	--

			INFO
--	--	--	------



The last 10 text inputs remain stored. They can be recalled to the data box and output using the **< + >** / **< - >** keys.



The text entered is printed. The dialog window remains open and more texts can be entered.



Pressing **<TERMIN>** or **<Enter>** causes the text to be printed and closes the dialog window.

### NOTE

- Maximum of 77 characters per line.
- Actuals from measurement results can be inserted in the following form:  
... **#SY(ADR)#** ...  
**SY** = symbol of measured value to be output,  
**(ADR)** = address of measured value to be output. The field reserved for output can be enlarged by blanks after ADR.  
Example:  
**Diameter of bore = #D(15)# mm**
- The **<Insert>** and **<Delete>** simplify text processing.
- The texts are printed left-justified.



### NOTE

This function can not be used to enter screen notes during a CNC measuring run. (► „Screen display of comments <DI 1677>“ on page 5-35).

## Screen display of comments <DI 1677>

### Application

You can use this function to enter notes for the user. These notes will be displayed on the screen during the CNC measuring run.



The last 10 text inputs remain stored. They can be recalled to the data box for display and output using the < + > / < - > keys.



The text entered is printed. The dialog window remains open and more texts can be entered.




Pressing <TERMIN> or <Enter> prints the text entry and closes the dialog window.


### NOTE

- Maximum of 77 characters per line.
- Actuals from measurement results can be inserted in the text in the following form:  
... **#SY(ADR)#** ...  
**SY** = symbol of measured value to be output,  
**(ADR)** = address of measured value to be output. The field reserved for the output can be enlarged by adding blanks after ADR.  
Example:  
**Diameter of bore = #D(15)# mm**
- The **<Insert>** and **<Delete>** keys facilitate text processing.
- The texts are printed left-justified.


## Comments on the alphanumeric control panel <DI 1678>



Notes for the user can be entered with this function. These notes are displayed both on the monitor screen and in the second dialog line of the control panel during the CNC measuring run.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1678	Record	
CPNXT	Layout	
	Notes CP...	




For information on applicaiton, see ► „Screen display of comments <DI 1677>“ on page 5-35.

# Time function <DI 1618>

**Application** The following will be output if you enter <DI 1618> in the measurement record:

- the current time or
- the time which has elapsed since the last time the given function was called (relative time).

This makes it possible to determine the amount of time required to perform specific measurement tasks and output this information directly to the measurement record.



The screenshot shows a 'Dialog' window titled 'Time function'. It features a checkbox labeled 'Relative time ?' with a 'Y' in a small box to its left. At the bottom of the dialog, there are two rows of buttons. The first row contains buttons for 'YES', 'NO', and two empty boxes. The second row contains two empty boxes, a 'CANCEL' button, and two more empty boxes. A '\*' symbol is positioned between the two rows of buttons.



**YES**

The time which has passed since the last time this function was called is output.

The current time will automatically be displayed the first time this function is called after the system is switched on.

**NO**

The current time is output.

Multitasking of the control and evaluation functions may result in a time lag between the printed time (=end of evaluation) and the machine standstill time (=end of control).


**NOTE**


This situation can be remedied via synchronization, e.g. by running offset adjustment  $x=y=z=0$  prior to PROG End.

## Repetition record <DI 1613>

### Application

When this function is called, the measurement record of the last measuring run stored will be output to the printer or screen.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1613	Record Output repeat current record...	

### Extent

The extent of record settings from <DI 1665> also apply to the repetition record.

### Function

The record of the last measuring run is retained even after the computer has been switched off and can be output as a repeat record.

### Reset of address counter

The following functions reset the address counter to 1:

- Call of record header <DI 1610>
- Setting the initial status <DI 1608>

NOnce one of these functions has been called, the record of the previous measuring run can *no longer* be printed out.

## Saving, outputting and deleting records


### Saving records with a workpiece number or code <DI 1683>

#### Application

When this function is called, the current record will be saved to the **/home/zeiss/UF** directory of the hard disk in ASCII format.

#### Extent

The settings of <DI 1665> restricting the extent of the record have no influence. All of the data is always saved.



#### Filename

The filename has the following syntax:

PD\_xxx\_yyyy\_B

#### xxx

is the workpiece code (number or first 3 characters) from the control data catalog (only for the CNC or PROG mode).

#### yyyyy

is the part number from the header

#### Example

**PD\_15\_3\_\_B** is the record of workpiece no. 15 in the control data catalog with part no. 3.

#### NOTE

If this function is called in the manual mode (without **PROG**), the workpiece number will be assigned with zeros.

If a backup is required only for a specific measuring run, you must first set the initial status by entering <DI 1608> (set initial status) or <DI 1610> (call record head).



## Saving, outputting and deleting records <DI 1684>

**Application**

You can save records in ASCII format under a single file name in the **/home/zeiss/UF** directory of the hard drive by entering **<DAW 1684>**. Saved records can also be output or deleted.

**Extent**

The settings from **<DI 1665>** for restricting the extent of the record have no influence here. All of the data is always saved.



**Softkeys**



The names of all records stored are output in the list and message windows on the screen.

A preselection can be made by entering a suitable abbreviation, e.g. **HOU\***

- File name** If you want to store a current record, read or delete a stored record, the correct filename must be specified here.
- Name conventions** The filename must comprise max. 13 characters + **B**, i.e. its first character must be a letter. Special characters, e.g.. "/" are not allowed.
- Continuous saving** If records are to be saved automatically without overwriting previous records during the CNC run, additional placeholders or blank spaces must be inserted in the filename for the part number.

Example: **GEH\_\_ [H3 ]\_\_ B**

At least one blank is required inside the brackets. Blank spaces outside of the brackets must be filled in with "\_" (underlines).


During the CNC run, the space reserved in **[H3 ]** is replaced by the part number (**GEH\_\_001\_\_B**).

**Task: Write, read or delete**

- **Write**  
Saves the current record under the filename specified.
- **Read**  
Reads the record stored under the filename to the current measurement record. The record is then output.  
Once this has been done the repetition record <DI 1613> can no longer be called up, since the record file has been overwritten.
- **Delete**  
Deletes the record with the specified filename.

### Printing the last 10 measurement records <DI 1604>

- Application** This function is used to list and print the last 10 measurement records.  
The measurement records are saved under the name **PR\_LAST\_xx\_ssB** in the **/home/zeiss/UF** directory of the hard disk, where **xx** here stands for the consecutive number and **ss** denotes the session number.






**Important**

This function also internally executes <DI 1608> and therefore resets to the initial status. This is necessary to ensure that the latest record has been closed and saved.

**Procedure**

The records are displayed in a list window, where they can be selected with the mouse and printed.




## Changing the user name <DI 1698>

**Application**

With this function, you can change the user name entered while a measuring run is in progress.

**CNC run**

If this function is started during a CNC run, the CNC run will be halted until it has been completed.



-
Dialog
□ □

c Please enter user name
 Maier

* YES	NO		

\*

			TERMIN
			INFO

## Graphic output

### Procedure

Proceed as follows to print or plot a graphic display (e.g. form plot) on the printer or plotter:

#### 1. Select graphic device

First select the required output device with **<DI 1625>** (► „Setting the mode for graphic devices <DI 1625>“ on page 5-47 or Option 2).

#### 2. Create form plot

You can create a form plot using **<DI 1470>** or a fast plot using **<DI 1461>**. (Option 2)

#### 3. Start printout


The "Paper change" function is started with **<DI 1652>** (► „Output of graphics <DI 1652>“ on page 5-49). Only then will the graphic information be fed to the printer or plotter.



## Setting the mode for graphic devices <DI 1625>

### Application

With this function you specify the device where the graphic displays should be output (see UMESS Options 1 and 2, KUM).



Dialog									
<input type="checkbox"/>	Graphic devices - Mode setting initialize, list, configure, select								
			INIT	LIST	*	CONFIG	SELECT		
BACK									INFO

**Softkeys**

**INIT**

The graphic system and all other devices selected (see **<SELECT>** softkey) are initialized; the device status is output to the record. **<DI 1651>** contains the same function, however, without a message output (➤ „Initializing the graphic software **<DI 1651>**“ on page 5-48).

**LIST**

The current configuration is output to the record.

**CONFIG**

With this function you can change the size and position of the frame in the device box Xmin, Xmax, Ymin, Ymax.

**SELECT**

The devices where graphic output is to be performed must be selected here.

**True-to-scale representation**

**NOTE**


If you activate several different devices:  
The true-to-scale representation is always referenced to the activated device with the lowest device number. If the height-width ratio of the other activated devices differs from the one referred to, the graphics printed or plotted on them will appear distorted or partially cut off.

**Initializing the graphic software <DI 1651>**

**Application**

The graphic software and all devices selected (➤ „Setting the mode for graphic devices **<DI 1625>**“ on page 5-47) must be set to a defined initial status during the system start or after a fault.

This initial status can also be produced by entering **<DI 1625>** and pressing the **<INIT>** softkey (➤ „Setting the mode for graphic devices **<DI 1625>**“ on page 5-47).




<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1651		


**NOTE**

You can use this function to delete buffered graphic files during operation if the graphic output function is to be canceled.

### Output of graphics <DI 1652>

In order to output the graphic file to your plotter or graphic printer, you must first initiate the "Paper change" function by calling <DI 1652>.




<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1652	Record Plot Paper change	

## Printing and plotting in a network

### Administration of output devices <DI 1674>

#### Application

Networked computers can share a remote printer.




#### Possible operating modes

- **Unspooled mode**  
A printer is used by only one computer.
- **Spooled mode**  
A remote printer is shared by several computers via the network. The print jobs are buffered in a queue and processed by the printer in the order in which they arrive.

**Function**

If several printers can be accessed within a network, you can change printers by entering **<DI 1674>**.



Dialog

Printer device administration

Active Device

Y	*	Printer (Epson LQ) spooled
<input type="checkbox"/>	<input type="checkbox"/>	Printer (Epson LQ) direct connection
<input type="checkbox"/>	<input type="checkbox"/>	Laserjet 3 / 4 (print/plot) spooled (pltlj)
<input type="checkbox"/>	<input type="checkbox"/>	Printer (Ruggedwriter/HP2932A) spooled (rlp)
<input type="checkbox"/>	<input type="checkbox"/>	Deskjet (print/plot) spooled (net1600c)
<input type="checkbox"/>	<input type="checkbox"/>	
<input type="checkbox"/>	<input type="checkbox"/>	
<input type="checkbox"/>	<input type="checkbox"/>	
<input type="checkbox"/>	<input type="checkbox"/>	
<input type="checkbox"/>	<input type="checkbox"/>	
<input type="checkbox"/>	<input type="checkbox"/>	

\* YES

NO

\*

TERMIN

BACK

INFO

**Active**


The device to be used for record output must be selected with the **<YES>/<NO>** keys.

The selection made can be stored as a long-term file by confirming with **<TERMIN>**.

### Status with spooled printers <DI 1689>

**Application**

In the spool mode printing starts by canceling the connection to the printer (e.g. switchover to the screen) or according to other criteria selectable via <DI 1689>.



Dialog

Status with spooled printers

Output:

Y to  Page(s)  \*

with record head

with CNC start

with CNC end

with device change

Header information

PRINT with LOGO

Text for header information

\* YES

NO

\*

TERMIN

BACK

INFO

**NOTE**

When printing single pages, it is advisable to include header information (sender) in the record.

# Chapter 6

## Preparations for a measuring run

---

### **This chapter contains:**

Reference point travel <DI 1570> . . . . .	6-2
Linear offset correction <DI 1572> . . . . .	6-4
Setting the address counter . . . . .	6-7
Defining the control mode <DI 1661> . . . . .	6-10
Setting the operating mode for the measuring probe head <DI 1502> 6-18	
Influence, correction and monitoring of temperature changes . . .	6-21
Position of probe rack . . . . .	6-28
System information <DI 1617> . . . . .	6-36
Initializing the machine <DI 1590> . . . . .	6-37

## Reference point travel <DI 1570>

### Application

The zero point of the machine coordinate system must be defined exactly for all coordinate measuring machines.

The zero point of the machine coordinate system is assigned to the mechanical limit position of the individual axes by a reference point or zero point travel (homing run). If a rotary table is connected, it can also be rotated to its reference position.



### Important

Before executing the reference point travel, position the probe head so that the machine zero point subsequently to be traveled to (upper rear left-hand corner) can be reached without a collision.

The probe head first moves to the mechanical limit position in the Z axis, and then in the X and Y axes.




### Danger


If a rotary table is connected, it will be positioned to its reference point. Be careful if workpieces are clamped to the table (danger of collision).

### Function call

The reference point travel is called by

- switching on the CMM and starting UMESS
- calling <DI 1570>



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1570	CMM	
RERPT	Travel commands	
	Reference point travel...	



Dialog									
Ref. point travel									
X, Y, Z, RT * <input type="checkbox"/> only RT <input type="checkbox"/>									
<input type="checkbox"/> D	X	<input type="text" value="30.0000"/>	Y	<input type="text" value="-30.0000"/>	Z	<input type="text" value="-30.0000"/>			
	RT	<input type="text" value="0/0/0.0"/>							
* YES		NO				*		TERMIN	
BACK		PRE MENU						INFO	

**Procedure**

After reaching the mechanical limit position, the probe head automatically travels in all axes from this zero point. The amount or distance to be traveled can be entered in the lower data boxes.

**TERMIN**

This key terminates the dialog window. The following message appears on the screen: **Caution! CMM zero point travel!**

The probe head first travels to the mechanical limit position in the Z axis and then in the X and Y axes.

**Limit position**

After reaching the mechanical limit position, the probe head automatically moves away from this zero point by the value entered in all axes.

**NOTE**

If the <Reference point travel> dialog window automatically appears after the machine is switched on, the dialog window must not be terminated with <PRE MENU> or <BACK>.


**NOTE**


If the machine does not travel away from the zero point, you can cancel by pressing <CANCEL>. Check to make sure that X, Y and Z have the correct +/- sign and lie within the measuring volume. If the reference point is not valid (message on screen) call this function again.


# Linear offset correction <DI 1572>

**Application** After a reference point travel, the W-position and the axis position of the rotary table may no longer mathematically correspond to the previous positions. Since the CMM zero point is defined via the limit switch, a linear offset then results. This offset can be measured using a master sphere and then corrected mathematically.

- Prerequisites**
- Calibrated probe
  - The position of the calibration sphere must have been defined before the reference point travel.



DI	Pull-Down-Menu	Pictogram
1572	CMM	
OFFSET	RT 05	
a73	Drift correction...	



Linear offset

Y Please select function

REF MAN	REF AUTO	REF_NO.	OFF_TEST	*	OFF MAN	OFF AUTO	OFF_NO.	TERMIN
	PRE MENU		DIA_TEST		OFF_ZERO			INFO

### Procedure

- Create a reference to the workpiece system by performing a reference measurement on the calibration sphere.
- Reference point travel.
- Measure the position of the calibration sphere again with a calibrated probe.
- If you have defined a control point: Sie einen Kontrollpunkt festgelegt haben: Probe the control point.

### Softkeys

<b>REF MAN</b>	The reference position of the sphere is measured manually.
<b>REF AUTO</b>	The reference position of the sphere is measured automatically. This is done by probing once in the direction of the shaft. A subprogram then roughly determines the position of the sphere and measures it again with the points generated for this purpose (function not implemented for laser).
<b>REF_NO.</b>	The reference position is displayed; no change is possible.
<b>OFF_TEST</b>	An offset test is performed.
<b>OFF MAN</b>	The offset is measured manually.
<b>OFF AUTO</b>	The offset is measured automatically (similarly to <b>REF AUTO</b> ). If the probing is inaccurate, the computer assumes that the probe is at an inclined angle and the vector is displayed. A correction may be entered (e.g. 0, 0, -1 for a probe oriented in the -Z direction).
<b>OFF NO.</b>	The offset is displayed and can be changed as required.
<b>OFF_ZERO</b>	Resets the offset to zero.
<b>DIA_TEST</b>	The parameters for the temperature compensation of the rotary table can be entered.

Dialog			
Parameters for temperature compensation rotary table			
<input type="checkbox"/> D	Temperature difference CMM	<input type="text" value="1.00"/>	Deg C
	Temperature difference air	<input type="text" value="1.00"/>	Deg C
	Time difference	<input type="text" value="15"/>	Minutes
	Return code	<input type="text" value="1"/>	
		*	<input type="text" value="TERMIN"/>
<input type="text" value="BACK"/>			<input type="text" value="INFO"/>

**NOTE**

The following functions can be programmed:

- REF MAN
- OFF MAN
- REF AUTO
- OFF AUTO

The user must program all positions. The intermediate positions are stored in the W-position system and the probings in the workpiece system.

The user only has to enter the start position, which is then stored in the workpiece system. The normal determined is also stored.


## Setting the address counter

### Setting the initial status <DI 1608>

#### Application

All results and alignments of a previous measuring run are erased with this function. It should be started before every new measuring run. The following then takes place:

- The address counter is set to 1.
- The alignment angles and zero points of the workpiece coordinate system are deleted.
- **FIXED PLANE** is set to automatic ("0") (► „Selecting the reference plane <DI 1680>“ on page 10-50).
- The rotary table rotation and workpiece coordinate system are separated from one another.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1608	Coord	
INITSTATUS	Preparation	
a11	Initial status	

#### Display

The list and message window displays the following message:

#### **SYSTEM INITIALIZED**

#### **NOTE**

- The free axis selection, sigma displacement and **PRB MOD** are *not* deleted.
- During learn (part) programming, the control data are stored in machine coordinates if **W-POS** is called following the initial status.

### Producing the old status <DI 1670>


#### Application


The address counter is reset to 1 after the computer boots up and UMESS is started. The results of the previous measurement run are overwritten by new measurement results.

<DI 1670> sets the address counter to the position where it was before the system was switched off.

## Preparations for a measuring run

Measurement results or programming steps can be "saved" or "salvaged" following a system crash. If a rotary table is coupled, this status is retained.




<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1670 RESTORE	Service General Old status	


**NOTE** This function can be called immediately after starting UMESS.


### Setting the address counter to a random address <DI 1690>

**Application** With <DI 1690> the address counter of the measurement record can be set to any number required.

**Example** Addresses with faulty measurements can be overwritten by resetting the address counter.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1690 RES a29	Record Address counter...	



**Procedure**

Enter the address required and confirm with **<Enter>**.

**NOTE**


A control data line will be generated if the function is called in the PROG mode. If this is not required, the control data line can be deleted with **<DI 1032>**.


# Defining the control mode <DI 1661>

**Types of parameters**

The CMM control can be influenced by three groups of parameters:

- Probing parameters > „Probing parameters <PROBE P>“ on page 6-11
- Machine parameters > „Machine parameters <MACHIN.P>“ on page 6-13
- Decisions > „Decisions <DECISION>“ on page 6-16



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1661	CMM	
CONMODE	Mode	
a157	Control mode...	

Dialog

Which parameter group should be changed ?

* YES	NO	PROBE P	ROTARY P
-------	----	---------	----------

\*

MACHIN:P	DECISION		TERMIN
----------	----------	--	--------

BACK			
------	--	--	--

		SERVICE	INFO
--	--	---------	------



### Softkeys

**ROTARY P**

This key is disabled.

**SERVICE**

Only service technicians should make changes in this dialog page. For this reason, it is protected by a password.

### Probing parameters <PROBE P>

#### Application

The probing parameters for CNC measuring runs can be set with this function.

Dialog

Control mode: Prb parameters ers

	Act. val	Minimum	Maximum	Standard	Unit
<input type="checkbox"/> D Search dist before nom pt.	4.0000	1.0000	50.0000	1.0000	mm or inch
Search dist after nom pt.	30.0000	1.0000	50.0000	0.0000	mm or inch
Norm vec dist__ (space pt)	5.0000	0.0000	1000.00	0.0000	mm or inch
Workpiece dist__ (space pt)		0.0000	1000.00	0.0000	mm or inch
Clearance plane_ (space pt)		0.0000	1000.00	0.0000	mm or inch
Distance of IPOS before prob.	0.0000	0.0000	1000.00	0.0000	mm or inch
Distance of IPOS after prob.	0.0000	0.0000	1000.00	0.0000	mm or inch

* YES		PERF MOD		*			TERMIN
UMESS	PRE MENU						INFO

#### Display

The following is shown on the screen for each parameter:

- current setting,
- permissible minimum and maximum values,
- the generally recommended (default) setting and the
- unit of measurement

### Softkeys

**\* YES**

Accepts the value offered in the selected box; the cursor jumps to the next line.

**PERF MOD**

Used to accept all of the default values listed in the Perf. mod column as the current values (except for lines concerning the space point measurement) and return to the previous dialog window. All changes will be accepted as soon as they have been confirmed with **<TERMIN>**.

**TERMIN**

Used to quit current dialog window, accept changes and return to previous dialog window. Changes are accepted as soon as they are confirmed by pressing **<TERMIN>**.

**UMESS**

Used to quit the dialog window without changing data and return to the main menu.

**PRE MENU**

Used to return to previous dialog window without accepting the changes.

### Data boxes

Inputs are possible only in the "**Act. val**" column.

**Search dist before nom pt.**

Distance traveled before a programmed probing with switchover to probing speed. For rough-tolerance workpieces (with uncertain W-pos. calibration), higher values should be entered here to prevent probings at Vmax (rapid traverse).

However, please note that higher default probing values result in longer measuring times.

**Search dist after nom pt.**

Maximum travel path at probing speed in the probing direction if a probing has not found at its programmed coordinates.

**Norm vec dist\_\_  
(space pt)\_,  
Workpiece dist\_\_  
(space pt),  
Clearance plane\_\_  
(space pt)\_**

A current value may be assigned to only one of these three data boxes at a time:

Length and direction of backaway or retract path after completing a space point (3D) measurement.

**Distance of IPOS before prob.,  
Distance of IPOS after prob.**

Simplified learn (part) programming on CMMs equipped with a trigger probe head:

With values > 0, the probe automatically travels to intermediate positions before/after each probing in the CNC mode.

## Machine parameters <MACHIN.P>

### Application

The machine parameters for CNC controlled runs can be preselected with this function.

Dialog

Control mode: Machin param.

	Act. val	Minimum	Maximum	Perf.mod	Unit
<input type="checkbox"/> D Norm triangle radius__	1.0000	0.5000	20.0000	1.0000	mm (inch)
Norm triangle start angle__	0.0000	0.0000	359.000	0.0000	deg
Standstill window__	0.0400	0.0020	0.1000	0.1000	mm (inch)
Measuring force__	0.2000	0.0050	1.6000	0.2000	N
Probing speed__ !	100.000	10.0000	150.000	100.000	%
Max. speed__ !	100.000	1.0000	100.000	100.000	%
Max. acceleration__ !	100.000	1.0000	100.000	100.000	%

! Before making changes in these fields, read the operating instructions  
! or revision information. The measuring accuracy may be affected !

\* YES

PERF MOD

\*

TERMIN

UMESS

PRE MENU

INFO

### Display

The following is displayed for each parameter:

- current setting,
- permissible minimum and maximum values,
- the generally recommended (default) setting and
- the unit of measurement.

### Softkeys

**\* YES**

Accepts the value offered in the selected box; the cursor jumps to the next line.

**PERF MOD**

Used to accept all of the default values listed in the Perf. mod column as the current values (except for lines concerning the space point measurement) and return to the previous dialog window. All changes will be accepted as soon as they have been confirmed with <TERMIN>

**TERMIN**

Used to quit current dialog window, accept changes and return to previous dialog window. Changes are accepted as soon as they are confirmed by pressing <TERMIN>

**UMESS**

Used to quit the dialog window without changing data and return to the main menu

**PRE MENU**

Used to return to previous dialog window without accepting the changes.

**Norm triangle radius**  
**Norm triangle start angle**

### Data boxes

Inputs possible only in the "**Act. val**" column.

Concerns space point measurement:

Definition of the three auxiliary points at 120° intervals from the space point coordinates and of the start angle with iterative determination of the normal.

### Standstill window

The control checks the standstill during probings and fine positioning travels. The accuracy of the standstill/position check can be set with the standstill window: If the standstill window is decreased, both the accuracy and the measuring time will increase. Depending on the measuring run involved, a coarse setting will result in a shorter measuring time. At the same time, this will result in nonrepeatable measured results due to workpiece form errors.

### Measuring force

Contact probing (with probes) results in deformations (bending, flattening) which influence the effective probe tip (sphere) diameter.

Since these deformations are dependent on the measuring force, the measuring force selected for calibration must also be used for the measuring run.

The measuring force is continuously adjustable between a minimum and a maximum value. Measurements are normally performed with a measuring force of **0.2 N**. If greater deformations of the probe shaft or workpiece may be expected (e.g. in thin-walled plastic parts), a measuring force of 0.1 N should be selected.

During "self-centering" probings, a higher measuring force may be advisable in the MAN mode to achieve better centering.

Other measuring forces can also be programmed for special applications (unstable or elastic parts, plastic parts)



**Important!**

When scanning with a measuring force of 0.1 N at a high travel speed, the probe may lift off of the workpiece, thus leading to falsified measurements. For this reason, you should always select a slow travel speed when scanning with a low measuring force.

**Probing speed**

The probing speed depends on the machine type. Only a percentage value can be entered.

In the following cases the probing speed can be set to a value other than the default setting:

Probe radius	<0.7 mm	<1.4 mm	≥1.4 mm
Probing speed	≈ 25 %	≈ 50 %	Default

With the measuring probe system, the probing speed should be reduced for probing angles of approx. 30° to 50°.

Concerns travels in the CNC mode; application example:

Predeflection of the measuring probe head at maximum speed (collision protection) causes a path deviation. This could be a hindrance, e.g. when entering narrow, slanting bores. To remedy this, reduce the probing speed until the predeflection is switched off and the probe head travels exactly along its programmed path.

**Max. speed,  
Max. acceleration**



**Important!**

Changing the values for the probing speed, the max. speed and the maximum acceleration could impair the accuracy of the CMM. For this reason, values are expressed in terms of % in UMESS. For ACE (off-line parts programming) permissible fixed values must be entered for v-max und a-max.

## Decisions <DECISION>

### Application

The control parameters listed below are of interest only in special cases.

Dialog			
Control mode: Decisions			
<input checked="" type="checkbox"/> Y	Travel to IPOS without deactivating clamping ? _____ (Caution: Collision poss.)	Yes/No <input type="checkbox"/>	Standard <input type="checkbox"/>
	No. of coordinates for calculation of mean value _____	<input type="text" value="1"/>	<input type="text" value="1"/>
	Zero point travel coordinates _____	X <input type="text" value="30.0000"/>	Y <input type="text" value="-30.0000"/> Z <input type="text" value="-30.0000"/>
	Type of probe head _____	<input type="text" value="2"/>	
	1=Measuring 2=Trigger 3=RDS, HAI or PH10 22=Janus probe head (2 x trigger)		
<input type="text" value="* YES"/>	<input type="text" value="NO"/>	<input type="text" value="PERF MOD"/>	<input type="text" value="TERMIN"/>
<input type="text" value="UMESS"/>	<input type="text" value="PRE MENU"/>		<input type="text" value="INFO"/>

### Softkeys

See ► „Machine parameters <MACHIN.P>“ on page 6-13

### Data Boxes

#### Travel to IPOS without deactivating clamping?

Caution: This option may be used only by experienced operators in exceptional cases! Suppression of the clamping function deactivates the collision protection.



#### Danger!

Risk of crushing and/or damage to the probe head!

#### No. of coordinates for calculation of mean value

Vibrations affecting the machine resolution can never be suppressed completely. For particularly high accuracy demands, these vibrations can be compensated via a mean value compensation. The number of values required for the mean value calculation must be entered in this data box.

**NOTE**

The mean value calculation increases the measuring time.

**Zero point travel  
coordinates**



Following a zero point travel, a probe head position which deviates from the usual values (X=+30 mm, Y=-30 mm, Z= -30 mm) can be entered here (in machine coordinates).

**Type of probe head**

The type of probe head used must be entered by the code number.

## Setting the operating mode for the measuring probe head <DI 1502>

Operating mode	Single points	Scanning
clamped <DI 1502> = OFF	e.g. for probings on small surface segments and self-centering probings	e.g. for keeping to the scanning path exactly on curved 3D surfaces and self-centering scanning.
unclamped <DI 1502> = ON	High accuracy for probings in any direction	Maximum accuracy at high speeds.



**NOTE**

No warning will be displayed if the bending data has not been determined.



### Dialog

Vectorial probing not activated. Activate?

YES

Vectorial probing activated.

Vectorial probing is activated. Activate?

NO

Vectorial probing deactivated.

#### NOTE

After defining the operating mode, the probes can be calibrated using a suitable method:

Probe head operating mode	Probe calibration method
clamped <DI 1502> = OFF	Manual: <DI 6502> Semi-automatic: <DI 6501>
unclamped <DI 1502> = ON	Semi-automatic: <DI 15228>

#### NOTE

When measuring with small probe tip (sphere) diameters, adjust the probing behavior with <DI 1574>.



When scanning according to (KUM) nominal data, you can optimize the probing (insertion) depth and the maximum acceleration with <DI 1533>.

The probe calibration and the measuring run must always be performed in the same operating mode setting. The op. mode setting is stored in the probe data (► „Output of probe data <DI 1624>“ on page 8-6).

## Adapting the probing behavior <DI 1574>

### Application

When using probes with a probe tip radius < 1 mm, you must adapt the probing behavior of the measuring probe head to the rigidity of the probe. The radii of the probe tip and the probe shaft are mutually allocated by the program.



### NOTE

When calibrating a probe, you must always use the same probing behavior values as will be used when measuring with the same probe later on.

If high scanning speeds are required, it is advisable to correct the probe bend with <DI 1184/1186> instead of calibrating with <DI 15228>.

# Influence, correction and monitoring of temperature changes

## Influence

### Temperature influences

The reference temperature for measurement is defined as 20°C (see the relevant CMM operating instructions). I.e. a correct result can be obtained only if both the workpiece *and* the glass scales (material measure) have a temperature of 20°C.

If the temperature of the material measure exceeds the reference temperature, the material measure is too long. ⇒ Any measurements made by the machine will therefore be too short. If the temperature of the test piece exceeds the reference temperature, the test piece is too long.

The result will be output as if the measurement had taken place at 20°C only if the material measure and the test piece have the same expansion coefficient and the same temperature.

### NOTE

The following principles should be observed to keep measuring errors caused by temperature to a minimum:

### Constant temperature

Maintain temperature conditions during measurements.

If the ambient temperature changes, the workpiece will adapt more quickly than the machine. To keep this measuring uncertainty to a minimum, temperature changes should not exceed 1K/h.

### Intervals for redefining the coordinate system

For workpieces with long measuring times: Redefine the workpiece coordinate system (zero points) at regular intervals. The correct interval depends on the temperature deviations in the measuring room and the accuracy required.

### Rotary table axis

When using a rotary table over an extended period of time, the axis of the rotary table must be recalibrated at regular intervals.

### Environmental influences

Avoid temperature variations between different locations on the CMM (caused by drafts or irradiated heat), as this would alter its geometry (perpendicularity).

### Probes

If an inadmissible probe temperature change occurs during probe calibration, the probe must be recalibrated (calculation of the permissible temperature range ➤ „General procedure“ on page 7-5).

## Application examples

A temperature correction should be performed if

- the ambient temperature deviates from 20°C (reference temperature) when measuring (cf. also machine operating instructions)
- and/or the temperatures of the test piece and the material measure (CMM) differ.

The following functions are provided for this purpose:

- Manual input of temperature values and the workpiece expansion coefficient for calculation of the correction factor.
- Automatic detection of scale and workpiece temperatures via appropriate sensors.

## Temperature compensation via input <DI 6511>


### Correction factor

The correction factor is calculated from

- the expansion coefficient of the workpiece
- the temperature of the workpiece and
- the temperature of the measuring machine / scales.

### Application

These values can be entered directly in a dialog window after calling <DI 6511>.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
6511 or 15211	CMM	
TEMCOM	Temperature comp.	
a623	Temperature compens...	

Data for temperature compensation				Meas. value	
<input type="checkbox"/> D	Workpiece expansion coefficient	<input type="text" value="23.00"/>	ppm		
	Temperature of workpiece	<input type="text" value="20.00"/>	Deg C	<input type="checkbox"/>	*
	X scale temperature	<input type="text" value="20.00"/>	Deg C	<input type="checkbox"/>	*
	Y scale temperature	<input type="text" value="20.00"/>	Deg C	<input type="checkbox"/>	*
	Z scale temperature	<input type="text" value="20.00"/>	Deg C	<input type="checkbox"/>	*

<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text" value="TKOM OFF"/>	*	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text" value="TERMIN"/>
<input type="text" value="BACK"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>		<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text" value="INFO"/>

### Softkey



Resets changes made in the dialog window; the default settings appear (expansion coefficient = 0, temperatures = 20 deg C) and the dialog box automatically closes.

### Data boxes

#### Workpiece expansion coefficient

Enter the expansion coefficient of the workpiece to be measured. The value stored last will be offered for input. The expansion coefficients of the different materials can be taken from appropriate references. (ppm means  $10^{-6}/K$ ).

#### Workpiece temperature

If no temperature sensor is connected, enter the temperature of the workpiece to be measured. The value stored last will be offered.

#### Temperature of X/Y/Z scales

If no temperature sensors are connected, the temperature of the individual scales must be entered manually. These temperature readings can be taken at locations with thermoconducting contact to the scales. If no temperature sensors are installed, manual input is not possible.

#### Meas. value

These boxes show whether the corresponding temperature sensors are ready for measurement. If a temperature sensor can be used for measurement, the corresponding box will be marked with an asterisk.


## Temperature monitoring <DI 6513>

**NOTE**

This function requires special temperature sensors and adaptation of the software!

**Application**

Individual temperature limit values can be defined for the sensors available. You can also specify when the temperature measurement should take place and whether a warning message should be printed in the record (log) or the program should be interrupted if a limit is exceeded.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
6513	CMM	
Temperature comp.		
Define limit temperature...		

Dialog

Temperature monitoring (Values in deg. C)

	Limits for	Record	Cancel		
			min	max	relative
<input checked="" type="checkbox"/>	Workpiece	* <input type="text" value="18.0"/> <input type="text" value="23.0"/> <input type="text"/>	* <input type="text" value="16.0"/> <input type="text" value="25.0"/> <input type="text"/>		
	Probe	* <input type="text" value="19.0"/> <input type="text" value="23.0"/> <input type="text"/>	* <input type="text" value="17.0"/> <input type="text" value="25.0"/> <input type="text"/>		

check with

Record head  Probe change  Cycle time  min

Measures if the sensor is faulty

Message in the meas. record  or manual temperature input

* YES	NO			*	READ LTF	STR LTF		TERMIN
BACK						TOT CNC		INFO

**SoftkeyS**

**STR LTF**

Saves the data currently entered in the dialog window to the long-term file.

**READ LTF**

Reads in temperature limits and measures from the long-term file and displays them in the corresponding boxes of the dialog window.

**TERMIN**

Used to accept the data currently entered in the dialog window and close the dialog window. Only data which was previously changed will be saved as control data in the PROG mode.

**TOT CNC**

This softkey is active only in the PROG mode. If you press it, all of the data displayed in the dialog window will be saved as control data.

### **Data boxes**

#### **Limits for Record/Cancel**

Here you have the option of choosing whether a warning note should be printed in the record or the measuring run should be canceled if the temperature limits defined below are exceeded.

The nominal temperature of the ambient air sensor is based on the temperature at which the probe was calibrated. The nominal temperature of the workpiece sensor is referenced to the value of the last temperature compensation.

#### **min / max**

Data boxes for the lower and upper temperature limits in degrees Celsius (with one decimal place)

#### **relative**

As an alternative to absolute temperature limits, a permissible fluctuation, i.e. a deviation from the nominal temperature, can be specified.

#### **check with Record head**

There are several ways to define when the temperature will be measured. If you confirm the first box with **<YES>**, a check will be made to ensure that the current temperatures lie within the permissible range when the record header is called.

#### **Probe change**

Automatic check of current temperatures with every probe change.

#### **Cycle time**

The periodic temperature check function is not available for FC program runs. If necessary, a temperature check can be performed manually whenever required by entering **<DI 6514>**.

#### **Measures if the sensor is faulty Message in the meas. record**

If a fault is determined by a temperature sensor during a program run, an error message will be output to the measurement record.


#### **or manual temperature input**

This function cannot be activated for FC program runs.

### Temperature check with <DI 6514>

#### Application

With this direct input, a temperature check can be made by the user at any time. The ambient air temperature is measured and compared with the entries in the dialog window of <DI 6513>. If the temperature reading lies within the permissible limits, the measuring program will continue uninterrupted. Otherwise - depending on the inputs made in the dialog window - a warning message will be output to the record or the program run will be interrupted.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
6514	CMM	
	Temperature comp.	
	Check for limit tempo	




## Temperature record with <DI 6515>

### Application

With this direct input, the data of the last temperature measurement can be listed. The temperatures measured at the two measuring points are specified in the table:

**Workpiece 22.5** means that the sensor is attached to the workpiece.  
**Air 23.0** indicates a temperature sensor which can be positioned as required.



Record										
=====										
MEASURING RECORD      ZEISS    UMESS										
WORKPIECE NAME					MANUAL MEASUREMENT					
=====										
DRAWING NUMBER	ORDER NUMBER	SUPPLIER/CUSTOMER	OPERATION							
638596-4589-54	1457-5834-5648	Zeiss	0100							
OPERATOR	DATE	PART NUMBER								
Mueller	11/30/98	45								
=====										
ADR	REC	TASK	IDF	SY	ACTUAL	NOMINAL	U.TOL	L.TOL	DEV	EXC
=====										
Temperature of the defined sensors										
DATE:	11/30/98	Time:	2:58							
sensor - number										
Component	I	1	2	3	4					
-----										
Workpiece	I	22.5	22.6							
Air	I	23.0								

## Position of probe rack


### Restriction

**Only for measuring machines with a probe changer.**

A probe rack is required to store all of the probe configurations automatically removed by a probe changer during a CNC measuring run.


### Position

The layout drawing below shows possible locations for a probe rack on the CMM.



### Coding

A coding pin on the probe holder opening engages in a recess of the probe adapter plate to ensure that the adapter plate is always deposited in the correct probe holder.



### Prerequisites

The computer must know the exact position of each individual holder to automatically deposit and pick up probes. The following functions are available to make these positions known to the computer:

- Magazine mode ➤ „Magazine mode <DI 1556>“ on page 6-29

- Magazine definition ► „Defining the probe holder positions <DI 1557>“ on page 6-32

### Magazine mode <DI 1556>


**Options**


This function offers the following options:


- Determine length of probe to define position of holder.
- List stored rack positions
- Code for type of storage (e.g. FC)

**Application**

The positions of the probe rack locations are stored in the machine coordinates. For this reason, the exact length of the probe to be used for position determination (calibration) must be known.



DI	Pull-Down-Menu	Pictogram
1556	Probe	
LISTSTR	change	
a188	Magazine mode...	



Dialog

Probe change mode

D Calibration probe values: X  Y  Z

\*

### Calibration probe values

<DI 1556> displays the current valid length of the probe in the **Calibration probe values** data box. This value can be changed in two ways, i.e.:

- By overwriting the default value and confirming with <Enter> or
- By redefining the probe length with the <TAWETAST> softkey.

### NOTE

When using the new (black plastic) rack, you must correct the calibration probe values:

$X = 64.0000$ ,  $Y = 0.0000$ ,  $Z = \text{increase value displayed by } 10 \text{ mm.}$

### Determining the length of the probe for defining the probe holder <TAWETAST>

#### Prerequisites

- The probe must be screwed in vertically downwards in the mounting plate.
- The diameter of the probe tip (sphere) equals 8 mm for the measuring probe head.
- Any probe tip diameter is permissible for the trigger probe head.

#### Procedure


When you press the <TAWETAST> softkey, the following dialog will appear:

- **Length determination for probe change calibration probe**
- **Probe surface with probe sphere with normal in shaft dir. (meas. ph 8mm)**

Probe a flat surface parallel to the XY plane in -Z (e.g. upper surface of probe rack) with the probe tip.

- **Probe the same surface with the edge of the plate in the shaft direction**

Probe the same surface with the bottom of the mounting plate:



#### Calculated value

The probe length is calculated as the difference between the Z values of the probings and stored on the hard disk.

### Fixed assignment of configurations to rack locations <ORG MAG>

#### Application

If the assignment is activated, just enter the configuration number to change probes. The configuration always must be deposited in and removed from the probe rack by the probe head. This status is set in the control data by entering a 1 in the first line for the probe changer in column SC2.

This default setting can not be changed for the FC.

#### Special case

If you have more configurations than rack holders during a CNC run, the fixed assignment of configurations to probe rack locations must be canceled.

Dialog									
<input type="checkbox"/>	Configuration/probe rack management active!								
Cancel fixed assignment between configuration and probe rack?									
YES	NO			*					
BACK									




#### Important

If the assignment is deactivated, an operator error may under certain circumstances cause a collision when changing probes.

**Listing the storage positions <LST STOR> <DI 1558>**

**Application**

When you press the <LST STOR> softkey, the positions of all saved probe holders will be printed out and displayed on screen.



Record										
=====										
MEASURING RECORD ZEISS UMESS										
WORKPIECE NAME					MANUAL MEASUREMENT					
=====										
DRAWING NUMBER	ORDER NUMBER	SUPPLIER/CUSTOMER	OPERATION							
638596-4589-54	1457-5834-5648	Zeiss	0100							
OPERATOR	DATE	PART NUMBER								
Mueller	11/30/98	45								
=====										
ADR	REC	TASK	IDF	SY	ACTUAL	NOMINAL	U.TOL	L.TOL	DEV	EXC
=====										
Mag. pos.	Config.	Coordinates					Approach dir			
A	1	114.6420	-83.4141	-387.4454	+Y					
B	2	286.8847	-83.3695	-387.3998	+Y					
C	3	459.3701	-83.3393	-387.4693	+Y					
D	4	631.2547	-83.2940	-387.4777	+Y					
E	-	803.5263	-83.2894	-387.4586	+Y					
Current config. 2 is in magazine B										

Position in machine coordinates (with active column coupling in coupled system)

**Defining the probe holder positions <DI 1557>**


**Application**

After setting up new probe racks or modifying existing ones, the following data must be input to the computer via <DI 1557>:

- Positions of probe holders
- Codes of probe holders
- Approach direction for entering probe rack (holder)


**Prerequisites** The length of the probe used must be defined before calling the function.

**Differences** The procedure and dialog differ for the measuring and the trigger probe head, however, the function call is the same.




### Trigger probe head

**Definition** The holder center point (i.e. the point where the perpendicular or normal and the upper surface of the probe holder intersect) must be determined and saved.



### Procedure

- **<DI 1608>**  
Set initial status,
- **<DI 1619>**  
Zeroize (reset) probe data,
- **<CIRCLE>**  
Measure location opening as circle,
- **<SURFACE>**  
Measure upper surface of holder,
- **<DI 1285>**  
Calculate perpendicular from circle center point to surface,
- **<DI 1218>**  
Intersection point of perpendicular and surface; yields holder point,
- **<DI 1557>**  
Store position, enter code letter and approach direction.



**NOTE**

Entering **<DI 1557>** save the last result in the measurement record to the hard disk as the position of the probe holder. Therefore, please make sure that the point of intersection between the perpendicular and the surface is entered as the last address in the record before calling **<DI 1557>**.

**Data boxes**

Enter a letter code for the probe holder and the approach direction and confirm your input with **<Enter>**.

**Documentation**

The position stored can be checked by calling **<DI 1556> <LST STOR>**.

**Measuring probe head**

**Prerequisite**

Probe tip diameter 8mm; length of probe must be defined.



## Procedure

The position is defined or calibrated by self-centering probing of the tapered bore in the probe holder. After **<DI 1557>** is entered the following dialog appears:

- **Probe store determination for measuring probe head**
- **Position the probe above the cone bore of the store to be determined**

Position the probe about 3 mm above the tapered bore of the probe rack cover. Then start a self-centering probing of the tapered bore by pressing **<TERMIN>**. The result is stored on the hard drive as the position of the probe holder.

Dialog												
Define magazine location												
C	Magazine ID char.	=	A									
	Travel dir. into magazine	=	+Y									
<input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/>				*	<input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <b>TERMIN</b>							
<input type="text"/> <b>BACK</b> <input type="text"/> <input type="text"/> <input type="text"/>								<input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <b>INFO</b>				



## Data boxes

Enter the code for the probe holder and the approach direction for entering the probe rack and confirm with **<Enter>**.

## System information <DI 1617>

**Application**

The current system configuration is displayed on the screen after this function is called.





## Initializing the machine <DI 1590>

### Application

In certain cases (e.g. after a collision) the measuring run can not be continued.

Instead of terminating and rebooting the measuring software, you can also initialize the control and thus set it to a defined status.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1590	CMM	
CMM INIT	Mode	
	Initialize	

### NOTE

If <DI 1590> does not prove successful, press <Break> or quit UMESS.

Save previous results with <DI 1670> after logging in again!



# Chapter

## Probe calibration

---

### **This chapter contains:**

General information. . . . .	7-2
Preparing for probe calibration. . . . .	7-10
Semiautomatic probe calibration . . . . .	7-17
Manual probe calibration <DI 6502> . . . . .	7-29
CNC probe calibration . . . . .	7-31
Calibrating disk and cylinder probes. . . . .	7-32
Recalibration with reference standards. . . . .	7-33
Probe bend compensation . . . . .	7-34
Checking the calibration at regular intervals <DI 1559> . . . . .	7-49

## General information


### Reason for calibration

In most cases, a workpiece must be probed from several sides. To do this, you need several probes arranged displaced in relation to one another.

These probes must be "defined" or, to put it more aptly, calibrated before you can start measuring with them. This is done by probing a reference sphere.

The computer then determines the arrangement and radius of the probe tips (spheres) and takes these factors into account during all subsequent measurements.

### Example



### Method of calculation

A surface is probed at point P with probe  $T_1$  and then with probe  $T_2$ . Based on the probe calibration, the computer knows the distance between the two sphere center points  $\Delta X$  as well as radii  $r_1$  and  $r_2$ . It therefore takes these values into account and calculates the same value for  $x_p$  both times.

### Terms


### Calibration standard

A calibration standard is required for probe calibration.

This is a high-precision sphere which is fastened to a stand so that it can be probed from all sides. Its exact diameter is known to, i.e. stored in, the computer.

The calibration standard is permanently assigned to your CMM ex works.

If the calibration standard is moved or a reference point travel is performed, its position must be redefined (recalibrated) via a reference measurement.



### Reference measurement

Measure the calibration sphere with a calibrated probe. A reference measurement must be performed whenever you want to:

- give the same reference to several different configurations or
- recalibrate one or more probes

and the computer does not know the exact position of the calibration standard (e.g. because you have redefined (recalibrated) the machine zero point).

A reference measurement does not always have to be executed with the reference probe. Any calibrated probe can be used.

However, we recommend recalibrating the calibration standard with the master probe prior to every calibration procedure.

### Master probe

During a measurement, all of the probes in a configuration must have a common reference. The computer must know how far away each probe tip or sphere is from a defined point. This defined point is the center point of the tip or sphere of the reference probe.


For probe calibration on CMMs without CAA, the first probe is usually designated as the reference probe. For machines with CAA, the master probe is automatically the reference probe as well. The reference probe is used only for the display with the configuration list. All coordinates are referenced to it; however, it has no significance for the measurement.

### Combination

The data from a maximum of five probes with the same reference form a combination.

### Configuration

A maximum of five combinations with the same reference can be combined to form a configuration.



### Recalibration

Recalibration is required in two cases, i.e.:

- if you want to add more probes to a configuration which has already been calibrated or
- if you want to replace a damaged probe and recalibrate it.

### Reference measurement

With a reference measurement, you determine the exact position of the calibration standard. This is always necessary after moving the calibration standard or performing a reference point travel.

### Master probe

The master probe is marked with a red dot. Like the calibration standard, it is a component of your coordinate measuring machine. Its exact dimensions are known to the computer. Always use the master probe only for reference measurements!



## Types of probe calibration

### Options

There are three types of probe calibration:

#### Manual

(all points are probed manually).

- Can be used for all probes
- Possible inaccuracy due to incorrect probings
- Time-consuming

#### Semiautomatic

(The first point for each probe is probed manually. The remaining probings are determined by the computer).

- High accuracy due to exact probings
- Time-saving compared to manual calibration
- Can not be used for all probes

#### CNC-mode

(Manual and semiautomatic calibration can also be integrated in a CNC run).

- Time-saving if the same probe is calibrated frequently.

### Application

You can always perform manual probing. It is, however, advisable to use semiautomatic calibration whenever possible and calibrate only difficult probes manually.

If a given probe must be calibrated fairly often, e.g. due to large temperature fluctuations, you can program the entire calibration procedure in a CNC run.

## General procedure

### Probe

Preparing the probes

- Select the probes, taking the geometry of the workpiece and the measuring range of the CMM into account.
- Screw all probe styli into their sockets securely.
- Wait for all probes to adapt to room temperature.

### CMM

Preparing the CMM

Balance the weight of the probe head (measuring probe head) or set its prestress (trigger probe head), see machine operating instructions; the measuring probe head with microprocessor control is balanced automatically.

- Select the measuring force (measuring probe head only). See information on setting the measuring force (in the CMM operating instructions)

### Calibration standard

Preparing the calibration standard

- Clean the calibration standard and check for damage.
- Screw centerable calibration standard into any table grid bore.

### Reference measurement

Calibrate the position of the calibration sphere with the master probe.

### Calibration

Calibrating

- Semiautomatic, manual or in a CNC run (► „*Semiautomatic probe calibration*“ on page 7-17, ► „*Manual probe calibration <DI 6502>*“ on page 7-29, ► „*Learn programming*“ on page 16-1)

### Check

Checking the results

- Check whether the magnitude of the deviation between the reference and the master probe is realistic.
- Check the accuracy.

## Accuracy of probe calibration


### Bending

For maximum measuring accuracy, always calibrate the probes very carefully.

The effective diameter of the probe tip (sphere) is less than its actual diameter (unless it has been calibrated with **<DI 15228>**).

This is due to the fact that the shaft bends in response to a lateral probing (especially if you use long, thin styli).

This bending is best compensated by probing close to the equator of the sphere. The easiest way to do this is by performing semiautomatic probe calibration (➤ „*Semiautomatic probe calibration*“ on page 7-17).



### Check

Always check the results of a probe calibration:

- Is the standard deviation "S" (dispersion) low enough?
- Is the effective diameter of the probe ball output less than the nominal diameter (this does not apply to calibration with <DI 15228>)?

If these two conditions have not been met, check the prerequisites and repeat the calibration procedure.

### Accuracy

If you want to improve the accuracy:

- Recalibrate using standards for measurements in specific axes or planes (➤ „*Recalibration with reference standards*“ on page 7-33).

## Permissible temperature range

### Influence of temperature

When calibrating a probe combination, you must determine the 3D distances of all probe styli from the reference probe in addition to the radii of the probe balls.

These distances vary with changes in temperature. The data of a probe combination thus applies only to a limited temperature range. If the temperature of the probes changes to a point where it lies outside of this range, the probes must be recalibrated.

The size of the permissible temperature range ( $T_{zul}$ ) depends on

- the maximum permissible deviation of the probe data ( $A_T$ ),
- the length of the probes (styli) ( $l$ ) and
- the material the probes are made of (expansion coefficient  $\alpha$ ).


**Formula**

The size of the temperature range is calculated based on the formula

$$T_{zul} = A_T / (l \cdot \alpha).$$

**Example**

A probe combination consisting of 2 probes. Material: Steel. Calibration temperature: 21 °C. The maximum permissible deviation of the probe data has thus been defined as 2.5 μm.



**Calculation**

Permissible temperature change  $T_{perm}$ , i.e. the temperature change at which the 2.5μm error allowed is not exceeded in any direction, is determined.

**Probe 1, Z direction:**

$$T_{perm} = A_T / (l \cdot \alpha) = 2.5 \mu\text{m} / (0.05 \text{ m} \cdot 11.5 \mu\text{m/m}\cdot\text{K}) = 4.4 \text{ K}$$

**Probe 2, X direction:**

$$T_{perm} = A_T / (l \cdot \alpha) = 2.5 \mu\text{m} / (0.1 \text{ m} \cdot 11.5 \mu\text{m/m}\cdot\text{K}) = 2.2 \text{ K}$$

The smaller value specifies the limit. Here it is the expansion in X.

The permissible temperature range thus equals 21 °C ± 2.2 K - temperatures between 18.8 °C and 23.2 °C are permissible.

(Note: The center point coordinates of the reference probe always equal zero in the probe data display. The change in the length of the reference probe affects the Z coordinate of probe 2 in our example.

**Documentation**

It will save you a lot of work if you enter important data in a probe book, e.g.:

- The identification (designation) of the probe configuration
- The identification (designation) of the corresponding CNC calibration program
- The date of the last calibration
- The temperature during the last calibration
- The permissible temperature change

Both the reference measurement of the calibration sphere (reference sphere) and the result of the calibration process are printed out in the measurement record.

**Standard values**

For simple cases, you can use the standard permissible temperature change values listed in the following table:

Permissible deviation of probe date in $\mu\text{m}$	Permissible change in temperature compared with the temperature during calibration in $^{\circ}\text{K}$			
	Steel probe ( $\alpha = 11.5 \mu\text{m/mK}$ )		Aluminum probe ( $\alpha = 23 \mu\text{m/mK}$ )	
	100 mm	200 mm	100 mm	200 mm
1.0	0.9	0.4	0.4	0.2
1.5	1.3	0.6	0.7	0.3
2.0	1.7	0.9	0.9	0.4
2.5	2.2	1.1	1.1	0.6
3.5	3.0	1.5	1.5	0.8
5.0	4.4	2.2	2.2	1.1
12.0	10.4	5.2	5.2	2.6


## Preparing for probe calibration

### Application

If you are performing probe calibration for the first time, you will have to make a few basic inputs after starting the measuring software.

You will also have to establish a calculated reference between the probe used and the machine zero point.

### Defining the calibration mode <DI 6507>



DI	Pull-Down-Menu	Pictogram
6507	Probe Mode for defining...	

Dialog

Mode for probe calibration

I Number of probings (manual)

Calibration sphere: No.  Radius

Position preset of calibration sphere

Position preset  No =  X=  Y=  Z=   
 Direction normal x=  y=  z=

or measurement  \* No =

Input of normal shaft direction (pointing away from the normal center)  
 as Direction normal  x =  y=  z=   
 or sphere coord. ref. +Z  \* W1 (X) =  W2 (Z) =

Correct radius with temperature of the workpiece sensor  \*

* YES	NO				*	CATALOG	TERMIN
BACK							INFO

### NOTE

The line **Direction normal ...** and the lines **Input of normal shaft direction ...** are displayed in the dialog window only if your CMM is equipped with a measuring probe head.

**CATALOG**

**Softkey**

The Catalog dialog window appears for input of:

- The number and radius of the calibration spheres if the cursor is located in the box behind **Calibration sphere: No.**
- The number and coordinations of the positions if the cursor is located in the box after **Position present No.=.**

**Data boxes**

**Number of probings (manual)**

This inquiry is activated only during manual calibration. Enter the minimum number of points you want to probe when calibrating (at least 5). You can probe up to 100 points.

**Calibration sphere: No. Radius**

Specify the serial number of your calibration sphere. The corresponding radius is displayed.

**NOTE**

If the message **Incorrect order code number** appears, press **<CATALOG>**, enter the correct data and save it with **<ENTER>**.

**Position preset No.= X = Y = Z =**

If you enter **<YES>** here, you can specify the different positions of the calibration sphere stored under the numbers **1** to **10**. All you have to do is enter the corresponding number.

The current reference probe is saved. Overview with **<CATALOG>**.

**Direction normal**, display only, only with a measuring probe head.

**or measurement**

If you enter **<YES>** here, you can locate the position of the calibration sphere and store it under numbers 1 to 10 with **<TERMIN>**.

***For measuring machines with CAA, you must measure with the master probe.***

The master probe automatically becomes the reference probe (as indicated by configuration=0 and probe number=0 ➤ „Specifying the reference probe <DI 6506>“ on page 7-15)

**NOTE**

Ideally the location of the calibration sphere should be redefined each time!

An existing position should be selected only if it can be guaranteed that the calibration sphere has not been moved and the ambient influences (e.g. temperature) have not changed since it was defined.

**Correct radius with temperature of the workpiece sensor**

Select **<YES>** to correct the radius of the calibration sphere. This is recommended for UPMC CMMs. The measuring SW automatically switches to the expansion coefficient stored for ceramics = 0.0000055 x1/K um.

**Preset of standard shaft direction (pointing away from the normal center)**

**Application**

**Standard case**

as **Direction normal X = Y = Z =**  
 or **sphere coord. ref. +Z A1(X)= A2(Z)=**


These lines will be displayed only if a measuring probe head is used.

In order to calibrate probes located opposite each other without reclamping during tensor calibration and simultaneously ensure that no collision with the neck of the calibration standard occurs, an appropriate probing point must be omitted. To determine which point can be omitted, you must specify the current orientation of the neck of the calibration sphere.

You can specify the orientation of the neck either as a direction normal or as a sphere coordinate.

Normally the sphere coordinates are determined by angles **A1** and **A2**.

Definition of A1 and A2



**Angle A2 (Z)**

If the calibration sphere is fastened in the plane of the machine table, angle A2(Z) always equals 135 degrees.


**Softkey**

Used to quit the dialog function.





If the **measurement function** was selected, the following dialog window will be displayed.



**Selection**

You now have the option of changing probes or manually probing the master sphere ... (exact description of softkeys ▶ „Manual probe calibration <DI 6502>“ on page 7-29).



However, it is advisable to define the position of the master sphere automatically:

**Semiautomatic probe calibration**


**Probe in direction of shaft (note probe number)**

After you have probed the highest point (pole) manually, a subprogram will determine the dimensions and perform the remaining proings.

**Output**

The result is output in the record as a sphere measurement with an address


In this way, the diameter or the standard deviation can be accessed e.g. via an **IF inquiry**.



The result is output as the result of a sphere calculation. The diameter depends on the diameter of the probe ball. If the probe ball has not yet been calibrated, the sum of the diameter of the calibration sphere and the probe diameter will be output.

## Specifying the reference probe <DI 6506>

Only the probe data representation after calibration is referenced to the center point of the reference probe ball. Mathematically speaking, the data is referenced to the master probe.



Dialog

Define reference probe

Current reference probe  Configuration  Probe number

or reference probe will be the next calibrated probe

or reference measurement with calibrated probe

or reference measurement with master probe

### Data boxes

#### Current reference probe

Display of the current reference probe. Configuration=0 and probe number=0 identify the master probe as the reference probe. Acknowledge with <YES> or continue with <NO>.

#### reference probe will be the next calibrated probe

The probe measured next becomes the reference probe. No additional measurement is required.

### reference measurement with calibrated probe

The reference is restored by an additional measurement with a calibrated probe.

### reference measurement with master probe

The reference is restored by an additional measurement with the master probe

#### NOTE

The default setting should be **reference measurement with master probe**.

# Semiautomatic probe calibration

## Overview

### Probe calibration programs

Depending on the probe system and operating mode involved, various programs must be started for semiautomatic probe calibration.

Before calling any calibration technique for a measuring probe head, always check to make sure that the operating mode has been properly set with **<DI 1502>**:

Type of probe head	Operating mode	<DI 1502>	Semiautomatic probe calibration
Measuring probe head	<b>Vectorial probing</b> In this operating mode the probe head can move freely in all axes. This is required for unclamped measurement and scanning.	<b>ON</b>	<b>&lt;DI 15228&gt;</b>
	<b>Probe in axis direction</b> In this operating mode the probe head can move only in one axis.	<b>OFF</b>	<b>&lt;DI 6501&gt;</b>
Trigger probe head	Only one operating mode is possible.	not applic.	<b>&lt;DI 6501&gt;</b>


## Semiautomatic probe calibration with <DI 6501>


### Definition


This method of probe calibration is intended for trigger and measuring probe heads in the **Probing in axis direction** operating mode.

### Prerequisite

For the measuring probe head, the **Vectorial probing** operating mode must first be switched **OFF** with **<DI 1502>**.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
6501	Probe calibrate clamped semi automatically...	



**Softkey**



If the probe has already probed in the correct position, you can accept the value as a probing.

**Procedure**

Probe the highest point in the shaft direction (pole) of the calibration sphere one time.

A subprogram then determines (calculates) the dimensions, automatically probes twice on the pole and four times on the equator and evaluates these probings. (► „Inclined probes during semiautomatic probe calibration“ on page 7-27)

**Record**

The result of the calibration is documented accordingly in the measurement record.

Record					
Result of the measurement of position 1 of the sphere standard					
1	SPHERE				
	X	447.5953			
	Y	-421.8092			
	Z	-402.6472			
	D	29.9927			
6P	S/MIN/MAX	.0002	(3)	-.0001	(6) .0001
Result of reference probe determination					
2	SPHERE				
	X	0.0000			
	Y	0.0000			
	Z	0.0000			
	D	29.9926			
6P	S/MIN/MAX	.0001	(3)	-.0001	(4) .0001
Result of calibration of probe 1					
3	KUGEL				
	X	0.0001			
	Y	0.0001			
	Z	0.0004			
	D	7.9943			
6P	S/MIN/MAX	.0001	(3)	-.0001	(6) .0001

## Semiautomatic probe calibration with <DI 15228> (tensor calibration)

**Definition**

This is the standard probe calibration method for all measuring machines equipped with a measuring probe head and high-speed scanning.

**Prerequisites**

The **Vectorial probing** operating mode must be switched **ON** with <DI 1502>.

The probe being calibrated must be able to probe the hemisphere of the calibration sphere without causing a collision. The neck of the calibration standard is automatically omitted for tensor calibration.

(> „Defining the calibration mode <DI 6507>“ on page 7-10 <DI 6507>).

### Probe bend


Various measuring force settings are used during probe calibration. In addition to the usual probe data, the parameters for correcting the probe bend are also determined. These values are taken into account during the following measurements:

- Probing single points with an unclamped probe head and
- Scanning inner and outer features (bores and shafts) in all measuring planes and in space. The accuracy of the bend correction depends on the scanning speed and the curvature radius.



**Diagram**

The following overview gives you a rough idea of the scanning speed which can be reached if the specified probing uncertainty of the UMC CARAT, i.e.  $V_2 = 1.2 \mu\text{m}$  and  $U_3 = 1.8 + L/450$ , is maintained. Measurement was performed with hard metal probes assembled from probe kit components without extensions. Evaluation was made with a 2.5 filter in compliance with ISO/TC 57.



Dialog

Probe and bend tensor determination

Probe:

I    Number   

          New calibration        Or recalibration   

          Radius of shaft   

Calibration standard

          Number        Radius   

\* YES

NO


\*

DECPTMOD

TERMIN

BACK

INFO



<b>DI</b>	<b>Pull-Down-Menu</b>	<b>Pictogram</b>
15228	Probe	
	calibrate unclamped	
	semi-automatic...	

**Data boxes**

**Probe: Number**

Enter number of probe

**New calibration  
Or recalibration**

New calibration is the default setting. For procedure ▶ „Tensor calibration: Full calibration or recalibration“ on page 7-25

**Radius of shaft**

The default input is the probe radius. This information is required for the program-controlled distribution of the probing points.

If a deviating value is entered, the calibration sphere will be probed below or above the equator during semiautomatic calibration. This is advisable if probing under a similar angle will be required during the actual measurements later on.

You can enter a larger shaft radius if e.g. other probes are in the way. For example: If probe 1 is very long and probe 2 is short, a larger shaft radius must be entered to prevent collisions. The calibration procedure then takes place above the equator.

$\frac{\text{Shaft radius}}{\text{Probe radius}}$	Angle =	Calibration area
about the same (deviation < 0.15 mm)	90° (equator)	up to the equator
Shaft radius smaller than probe radius	$90^\circ + \cos \frac{\text{Radius of calibr. standard} + \text{probe radius}}{\text{Radius of calibr. standard} + \text{shaft radius}}$ max. 95°	to below the equator
Shaft radius larger than probe radius	$90^\circ - \cos \frac{\text{Radius of calibr. standard} + \text{shaft radius}}{\text{Radius of calibr. standard} + \text{probe radius}}$	above the equator


*Special case:*

max. 73° (above the equator)

above the equator

To prevent collisions with small probes (D < 0.6 mm), enter 0.3mm or less for shaft radius and probe radius.

Use a calibration standard with a sphere diameter = 15 mm!



**Calibration standard Number Radius**

The number offered can be accepted. If the number is changed, the matching radius will automatically be accepted if it is entered in the corresponding list.

**Procedure**

**TERMIN**

Exit the completed dialog page with <TERMIN>.

**Probe and bend tensor determination  
Probe sphere in shaft direction**

Probe the calibration sphere once at the highest point in the direction of the shaft. A subprogram calculates the dimensions and automatically probes thirty times within the hemisphere. The probings are then evaluated.

(> „Inclined probes during semiautomatic probe calibration“ on page 7-27)

**NOTE**

In the list of probe data (> „Output of probe data <DI 1624>“ on page 8-6) the calibration data is marked by a "+" in the last position. The actual diameter of the probe ball is calculated by compensating the measuring force and the probe bend. The results of calibrations with <DI 15228> and with <DI 6501> are therefore not comparable.

**NOTE**

If the operating mode changes (clamped or unclamped), it is advisable to additionally perform a probe calibration with <DI 6501> using a different probe combination.

If probes with disk-shaped (instead of spherical) tips are to be used for fast scanning: First calibrate the disk probe with <DI 6501> in the "Probing in axis direction" operating mode. Then record the probe bend in the "Vectorial probing" mode via <DI 1184>.


**Record**

The result of the calibration will be documented in the measurement record.

This makes it possible to access the diameter or standard deviation or dispersion with an **IF inquiry**. For example:

Record					
Result of the measurement of position 1 of the sphere standard					
1	SPHERE				
	X	447.5953			
	Y	-421.8092			
	Z	-402.6472			
	D	29.9927			
6P	S/MIN/MAX	.0002	(3)	-.0001	(6) .0001
Result of reference probe determination					
2	SPHERE				
	X	0.0000			
	Y	0.0000			
	Z	0.0000			
	D	29.9926			
6P	S/MIN/MAX	.0001	(3)	-.0001	(4) .0001
Result of calibration of probe 1					
3	SPHERE				
	X	0.0006			
	Y	0.0004			
	Z	0.0047			
	D	8.0011			
30P	S/MIN/MAX	.0002	(21)	-.0002	(10) .0005

## Tensor calibration: Full calibration or recalibration

<b>Application</b>	<p>A probe can be:</p> <ul style="list-style-type: none"><li>– completely calibrated, i.e. the geometry (X, Y, Z and radius) and the bend data (bend tensor) are defined or</li><li>– recalibrated, i.e. only the geometry is redefined and the previous bend data is retained.</li></ul>
<b>Full calibration</b>	Full calibration is performed as usual. The calibration result is displayed and saved as the sphere result.
<b>Recalibration</b>	<p>The prerequisite for recalibration is the availability of bend data from a previous full measurement.</p> <p><b>Only 6 points</b> are probed for a recalibration.</p>
<b>Limit values</b>	<p>The calibration data gained during the recalibration is compared with the data from the full calibration. <b>Limit values</b> are used for the comparison. If the new calibration data lies above the limit.</p>
	<p>The limit values for recalibration are entered in a dialog window which can be opened by pressing the <b>&lt;DECPTMOD&gt;</b> key in the tensor calibration dialog window.</p>

### Limit values for recalibration

The limit values entered are saved to a file and read-in again each time the software is restarted. They are used to monitor recalibration in order to prevent recalibration with the wrong bend parameters.

Dialog

Limit values for valid probe recalibration

Max. probe length difference  $d_l = f_1 + (L/f_2) + L * t$  (L = probe length [mm/inch])

D	Constant factor (f1)	<input style="width: 80%;" type="text" value="0.3000"/>	* 0.001 [mm/inch]
	Length dependent factor (f2) (L/	<input style="width: 80%;" type="text" value="1000.0000"/>	* 0.001
	Temperature dependent factor (t) L*	<input style="width: 80%;" type="text" value="0.115000"/>	* 0.001

Maximum radius difference	<input style="width: 80%;" type="text" value="0.1000"/>	* 0.001 [mm/inch]
Maximum dispersion	<input style="width: 80%;" type="text" value="0.1000"/>	* 0.001 [mm/inch]

	*	TERMIN
BACK	PRE MENU	INFO

$$d_l = f_1 + (L / f_2) + L * t \quad (L = \text{probe length referenced to the master probe})$$

**Probe length difference**

<b>Constant factor (f1)</b>	Dependent on the constant term from U3 of the CMM.
<b>Length-dependent factor (f2)</b>	Dependent on the length-dependent term from U3 of the CMM.
<b>Temperature-dependent factor (t)</b>	Dependent on the maximum temperature variance and the probe material.

**Maximum difference in radius**

Dependent on the rigidity of the probe. Only a constant factor is provided for the radius.

**Maximum dispersion**

Dependent on the machine accuracy and quality of the probe. An absolute check is made of the dispersion of the recalibration.

When selecting the limit values, note that the bend data have a considerable influence on the radius of the probe ball and the dispersion, but only a minimum influence on the probe geometry. For this reason, the limit values should be selected so that they are as small as possible for the radius and dispersion but larger for the geometry. The limit values for the geometry have the purpose of preventing the bend data for probes being used with any geometry other than the one for full calibration. It should here be noted the the deviation of the probe geometry in X, Y and Z depends on the basic accuracy of the machine and expansion changes due to temperature fluctuations. The accuracy of the machine is dependent on a constant and a length-dependent factor. For this reason, both a **constant (f1)** and a **length-dependent (f2)** limit value as well as a **length-dependent factor (t)** for the temperature are provided for recalibration.

**Inclined probes during semiautomatic probe calibration**

**Application**

If inclined probes are used, another dialog window will open following probing in the shaft direction. The normal direction and projected angles calculated during the position calibration are offered for acceptance. This data may also be connected if necessary.

# Probe calibration

Calibration is performed after closing the dialog window with **<TERMIN>**.


Dialog									
Shaft direction of probe									
Normal	<input type="checkbox"/>	Nx	<input type="text" value="-0.4922"/>	Ny	<input type="text" value="-0.0001"/>	Nz	<input type="text" value="0.8705"/>		
or									
<input checked="" type="checkbox"/> Y	proj. angle	<input checked="" type="checkbox"/> *	Axis	<input checked="" type="checkbox"/> Z	<input type="text" value="W1 (X/Z)"/> -29.482865	<input type="text" value="W2 (Y/Z)"/> -0.006903			
* YES			NO		*		TERMIN		
BACK			PRE MENU				INFO		



## Manual probe calibration <DI 6502>

### Application

If semiautomatic probe calibration can not be used (e.g. due to very short or special probes), the probe must be calibrated manually.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
6502	Probe calibrate clamped manually...	

Dialog									
Manual probe calibration			Probing point			1			
<input type="checkbox"/>	Direct input		<input type="text"/>						
SEL COMB	REMOVE	INSERT	PROB CHAN	*	CONF LIS		AUTO CAL	TERMIN	
BACK	PT CORR							INFO	

### Procedure

Probe the points manually. You must probe at least as many points as you defined in the calibration mode (► „Defining the calibration mode <DI 6507>“ on page 7-10).

### Softkeys

**SEL COMB**

changes the combination/configuration (► „Changing the combination <DI 1601>“ on page 8-11)

**REMOVE**

is used to remove the probe manually (► „Removing probes manually <DI 1554>“ on page 8-12)

<b>INSERT</b>	is used to insert the probe manually (▶ „Removing probes manually <DI 1554>“ on page 8-12)
<b>PRB CHAN</b>	starts automatic probe change (▶ „Inserting probes manually <DI 1555>“ on page 8-15)
<b>CONF LIS</b>	outputs data from the current configuration.
<b>AUTO CAL</b>	starts semiautomatic probe calibration (▶ „Semiautomatic probe calibration“ on page 7-17)
<b>PT CORR</b>	is used to delete incorrectly probed points. Each time you press this key, you delete one more point in reverse order to the order of probing.
<b>TERMIN</b>	terminates the current function. The computer then evaluates the probed points and calculates the probe data.

## CNC probe calibration

### Frequent calibration

If you have to calibrate probes frequently, it makes sense to create a CNC program for this job (► „*Learn programming*“ on page 16-1). Either manual and semiautomatic probe calibration is suitable for this purpose.


## Calibrating disk and cylinder probes

### Application

When calibrating disk and cylinder probes, i.e. probes with disk-shaped and cylindrical tips, you must follow a different procedure than for probes with spherical tips.


#### Disk probe

- Only manual probe calibration can be used.
- Probe 6 to 8 times near the equator.
- Travel at least once in the direction of the shaft.



#### Cylinder probe

- Only manual probe calibration can be used.
- Probe the calibration sphere four times on its equator.
- Travel in the direction of the shaft.
- Probe the calibration stand another 4 times on its equator.



### NOTE

With this probing strategy the center coordinates of the cylinder probe are defined correctly, however, its radius is incorrect. For this reason, cylinder probes must be recalibrated on gage blocks (► „Recalibration with reference standards“ on page 7-33).

## Recalibration with reference standards

### Application

An incorrect radius is calculated for cylinder probes with the normal calibration process (► „Calibrating disk and cylinder probes“ on page 7-32). For this reason, these probes must be recalibrated with reference standards (gage block, ring gage, etc.).

Recalibration also increases the calibration accuracy for measurements performed with sphere-tip probes in specific axes or planes.

### Basic procedure

- Calibrate probe(s) and save data.
- Measure a suitable reference standard in such a way that the conditions which you expect to occur during the high-precision work-piece measurement (probing direction, plane, diameter, etc.) are simulated as closely as possible.
- Correct the probe tip radius based on the difference between the actual and nominal dimension of the standard and save the corrected radius with **<DI 6510>** (► „Modifying probe data <DI 1627>“ on page 8-7).

### Example

Calibration of a cylinder probe using a gage block.

- Calibrate the probe.
- Align the gage block (**<RO SPACE>**, **<RO PLANE>**, **<ZERO POINT>**)
- Measure length of gage block.
- Calculate difference between nominal and actual dimension.
- Divide the value by 2. The result is the correction value.
- Subtract the correction value from or add it to the probe radius. The result is the correct probe radius.
- Enter and save the correct probe radius with **<DI 6510>**.

# Probe bend compensation

## General information


**Application**

When using a measuring probe head, measuring errors may result from static and/or dynamic bend. In either case, the bend parameters can be determined and taken into account during measurement:

Operation	Operating mode of measuring probe head	
	Probe head unclamped <DI 1502> = ON	Probe head clamped <DI 1502> = OFF
	Default measuring mode for CMMs with a measuring probe head. Compliance with probing uncertainty $v_2$ can be guaranteed if probe calibration is performed via <DI 15228>.	Used only in special cases: Probing of small, inclined surface elements, self-centering probing. Compliance with probing uncertainty $v_2$ can <b>not</b> be guaranteed in this mode even if the probe bend is corrected.
Static bend	Bend correction is taken into account if calibration is performed with <DI 15228>.	The bend must be determined via <DI 6520>.
Dynamic bend	Bend correction is taken into account when calibrating with <DI 15228>. See illustration ► „Semiautomatic probe calibration with <DI 15228> (tensor calibration)“ on page 7-19 If maximum accuracy and scanning speed are required, an additional bend correction must be performed with <DI 1184>. After calibrating disk probes, compensate the probe bend with <DI 1186>.	Bend must be determined with <DI 6520>.


**Static bend**

Probe bend M caused by measuring force during point probeings.



**Dynamic bend**

Probe bend M and R resulting from measuring force and friction during scanning.



**NOTE**

It is advisable to determine the bend parameters with **<DI 6520>** when operating the probe head in the clamped mode (see above) and:

- The surface normal is slanted in relation to the probing direction at the probing point.
- Only one section of a geometric element can be measured.
- A high measuring force ( $\geq 0,4N$ ) must be used.

- The bend of the probe is greater than 1mm/0.1N.
- When calibrating angle probes, high dispersions occur despite a low measuring force and a rigid probe design.
- The dynamic bend caused by friction between the probe and the test piece during scanning is not negligible.
- The uncertainty should be minimal for every measurement.

### Basic procedure

- Calibrate probes
- Determine the bend parameters <DI 6520>
- Take the bend into account during measurement <DI 1186>

## Determining bend parameters for the "clamped" probe head mode <DI 6520>

### Procedure

#### Measuring force

Preselect the measuring force

Set the measuring force with which the measurement should be performed.

#### Calibration

Calibrate the probes

- Calibrate the probes manually or automatically.

#### Alignment

Determine the position of the ring gage or plug gage.

- Only for determining the dynamic bend parameters (scanning parameters). Depending on the measuring job involved, use a ring gage or plug gage with roughly the same diameter as the feature to be measured.

Alignment procedure:

Ring gage:     - Measure plane surface with <SURFACE>  
                  - <RO SPACE>

Plug gage:     - Measure surface with <CYLINDER>.  
                  - <RO SPACE>


#### Bend parameters

Determine bend parameters.

#### Function call

Following the function call, you will first return to the main menu. From there you can continue on to other submenus.





<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
6520	Probe	
PRB BEND	calibrate clamped	
a101	Bend menu...	

Dialog

Main menu: probe deflection

Y Please select function

		STATDEL	DYNDEL	*	STATDEF	DYNDEF		TERMIN
BACK					STATLIS	DYNLIS		INFO

Determining the static bend parameters  
<STATDEF>

**Explanation**

**Probe**

<b>Number</b>	Enter probe number (1-5).
<b>Sphere or disk</b>	Specify shape of probe tip by entering <YES>/<NO>.
<b>Shaft radius</b>	Enter the shaft radius. An angular range for determining static bend parameters is determined by the program here.

**Calibration standard Number, Radius**

The number offered can be accepted. If the number is changed, the relevant radius will automatically be transferred from the catalog.

**Procedure**

After closing the dialog window, probe the calibration standard in the direction of the shaft as soon as you are prompted to do so on the screen.

**Documentation**

When you have completed the calibration procedure, the probe data and bend parameters will be printed out in the record:

Record									
Configuration = 147									
Co no	Coordinates			Radius	Force	Temp.	Date	Dev	SD
2 1	-.0002	-.0002	-.0052	3.9847	.20	.0	2. 3.1998	.0006	*-
Bending parameter: accuracy display									
Probe no. 1									
Parameter calibration (static):									
Prbdir	No.pts	Dispersion		MIN	Pt.	MAX	Pt.	Plnnom.	Pt.
-X	12	0.00458	0.00121	(5 )	0.00595	(12 )	0.00055	(2 )	
+X	12	0.00378	0.00085	(5 )	0.00509	(1 )	0.00037	(11 )	
-Y	12	0.00417	0.00054	(5 )	0.00584	(12 )	0.00024	(11 )	
+Y	12	0.00336	0.00078	(5 )	0.00483	(12 )	0.00027	(2 )	
-Z	21	0.00284	0.00012	(6 )	0.00540	(21 )	0.00083	(19 )	

The bend parameters is marked in the **SD** column:

**\* = yes**

**- = no**

**S = static bend parameter**

**D = dynamic bend parameter**

If the bend parameters already exist for the probe concerned, the following message will appear in the above case:

**Static bending parameter for probe No. 21 already exists.**

( 2 = combination, 1 = probe number)

**Determining the dynamic bend parameters <DYNDEF>**

**Explanation**

**Probe: Number**

Input of the probe number (1 - 5).

**Ring/plug gage: Diameter**

Input of the diameter to be scanned immediately afterwards.

**Scanning: Inside meas. or Outside meas.**

Select the type of measurement required with <YES> / <NO>.

**Following dialog**

(For more information: ➤ „Details on the scanning mode“ on page 19-15 - Scanning run.)



After you close the dialog window for the bend parameters, the program switches over to the dialog window for the scanning run.

Dialog									
Scanning in workpiece coordinates									
<input type="checkbox"/>	Please probe start point or select function								<input type="checkbox"/>
PROBE		STEP	POSITION	*	DIALOG	ORDER			
BACK	PRE MENU								

# Probe calibration

**Scanning in  
workpiece  
coordinates  
Please probe start  
point or select  
function**

You will be prompted to probe the start and end point or to select a function.

Dialog

Scanning run parameters

Step width :  Plane:  Inter height:  Run:

			STEP WID	*	PLANE	SECT HEI	TRAV DIR	TERMIN
BACK	PRE MEN							INFO

The measurement starts after transferring or changing the run parameters with **<TERMIN>**.

**Documentation**

If the bend parameters are defined, they will be output to the record:

Record									
Configuration = 147									
Co Nr	Coordinates			Radius	Force	Temp.	Date	Dev SD	
2 1	-.0002	-.0002	-.0052	3.9847	.20	.0	2. 3.1998	.0006	**
Bending parameter: accuracy display									
Probe no. 1									
Parameter calibration (dynamic):									
Prbdir	No.pts	Dispersion	MIN	Pt.	MAX	Pt.	Plnom.	Pt.	
-X	51	0.00187	0.00049	(27 )	0.00433	(51 )	0.00061	(48 )	
-Y	50	0.00174	0.00035	(25 )	0.00393	(50 )	0.00072	(4 )	
+X	49	0.00196	0.00047	(23 )	0.00500	(49 )	0.00044	(28 )	
+Y	50	0.00167	0.00020	(24 )	0.00407	(50 )	0.00076	(31 )	

The bend parameter is marked in the **SD** column:

**\* = yes**

**- = no**

**S = static bend parameters**

**D = dynamic bend parameters**

If the bend parameters already exist for the probe, the following message will appear in the above case:

**Dynamic bending parameter for probe No. 21 already exists!**

( 2 = combination, 1 = probe number)

## Output and deletion of bend parameters

Output of bend parameters <STATLIS>, <DYNLIS>

Dialog

List static bend parameters

I Probe: from  to  Combination  Configuration

\* YES NO \* TERMIN

BACK INFO

### NOTE

Limit values for probes: 1 - 5

Limit values for combinations 1 - 9

Limit values for configurations 1 - 9999

If no bend parameters are stored, the following message will be displayed:

**No static/dynamic bend parameters for probe 1 exist !**



Deleting bend parameters <STATDEL>, <DYNDEL>

Dialog

Delete static bending parameter

I Probe: from 1 to 1 Combination 1 Configuration 5

\* YES NO \* TERMIN

BACK INFO


**NOTE**

- Limit values for probes: 1 - 5
- Limit values for combinations 1 - 9
- Limit values for configurations 1 - 9999

## Determining bend parameters for unclamped scanning <DI 1184>

### Application

This bend correction is required for high-accuracy measurement of circles at maximum scanning speed or if disk probes are to be used for unclamped scanning.



Dialog

Bend parameter for unclamped scanning: Dynamic determination

Ring/plug gage:

D Diameter

Important: workpiece system must be referenced to ring gage/plug gage!

* YES	NO			*				TERMIN
BACK								INFO

**Procedure**

Operation	<DI>	Explanation
Calibrate the probe ball. or calibrate the disk.	<15228>  <6502>	
Clamp the plug gage (ring gage) on the CMM and determine/align the work-piece coordinates		The diameter of the gage should correspond to the object to be measured later and the clamping location should correspond to the measurement location to be used later.
Determine the bend parameters for the unclamped probe head.	<1184>	
Call the circle element and scan the ring gage.	<1104>	The speed and step size should be selected the same way as for the workpiece later on.

The diameter measured is used as a basis for calculating the bend parameters.

**Measuring with compensation of the probe bend <DI 1186>**

**Application**

<DI 1186> can be used only for the measuring probe head. The probe bend can be compensated for the following geometric elements:


**SURFACE, CIRCLE, SPHERE, CYLINDER, CONE, TORUS, 3D CIRCLE, 3D POINT, NET POINT.**

For the **POINT** program, the probe bend is compensated without calling <DI 1186> (correction in direction of workpiece coordinate system).

When used in the unclamped operating mode, compensation is especially advantageous for very fast scanning of circles. A special calibration on a gage with <DI 1184> is required for this purpose.

**NOTE**

<DI 1186> must be called again for each new measured element (part feature).



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1186	Probe	
PBC	calibrate unclamped	
	Include HSS bend	

The following message is displayed in the list and message window:

**Probe bend correction with the next geometric element**

**NOTE**

If <DI 1186> is used, geometric elements may be probed only with one probe. The scanning speed must correspond to the speed used during calibration to achieve optimum accuracy.

**Comparison of methods**

Calibration with <DI 15228>	Calibration with <DI 1184>, Measurement with <DI 1186>
<ul style="list-style-type: none"> <li>- Correction performed automatically without an additional program call.</li> <li>- Can be used universally for                             <ul style="list-style-type: none"> <li>- all measuring planes</li> <li>- inner and outer diameters</li> <li>- regardless of the diameter of the object being measured</li> <li>- at low and average scanning speeds                                      (► „Semiautomatic probe calibration with &lt;DI 15228&gt; (tensor calibration)“ on page 7-19)</li> </ul> </li> </ul>	<p>Correction performed only after calling &lt;DI 1186&gt;.</p> <p>For high scanning speeds if the calibration was performed under the same conditions as the subsequent measurement (same speed, position in measuring volume, measuring plane, inner/outer diameter):</p>

## Checking the calibration at regular intervals <DI 1559>

**Application** <DI 1559> is used to enter and activate or deactivate a calibration interval. The user can enter a time period after which a message will automatically appear prompting recalibration.

Check calibration interval?

Calibration interval (hours)

**Function** This message is displayed each time the configuration concerned is changed.

It has no influence on the program run, i.e. it serves only to inform the user.

Warning

Please recalibrate, probe configuration 47 has the defined permissible age exceeded by 10 hours.

The above message disappears when the configuration in question has been recalibrated.



# Chapter 8

## Administration of probe data/probe change

---


### **This chapter contains:**

Terms . . . . .	8-2
General . . . . .	8-4
Output of probe data <DI 1624> . . . . .	8-6
Modifying probe data <DI 1627> . . . . .	8-7
Deleting and resetting probe data . . . . .	8-9
Changing the combination <DI 1601> . . . . .	8-11
Changing probes . . . . .	8-12

## Terms

### Probe

Individual probe styli can be combined *mechanically* to form any type of *probe* or *probe cluster* required. Restrictions apply only regarding the weight of the probe (especially for the RST).



### Organization


The probe data is stored in UMESS according to a defined scheme:

- A maximum of five probes are combined to form a **combination**
- A maximum of five combinations form a **configuration**
- A maximum of 9999 configurations can be stored (only configuration 1 exists for machines without a probe changer)

The terms **combination** and **configuration** therefore always refer to the probe data.



The term **probe or probe cluster** refers to the mechanical arrangement of the probes in the probe head or in the probe changer rack.



## General

### Without probe changer

In measuring machines not equipped with a probe changer, the probes or probe clusters (mechanical) and the configuration (data) automatically correspond to one another.

### With probe changer

However, there are several different methods for storing the probe cluster data in measuring machines with a probe changer:

- The probe cluster data is stored as a single combination. The configuration comprises several probe clusters.
- The probe cluster data forms a configuration.
- The probe cluster data is stored under different configurations.

### Select probe

Before the probing can actually take place, the computer first must know which probe is required.

This is done as follows:

### Select configuration



▶ „Automatic probe change <DI 1553>“  
on page 8-17 (automatic probe change)

or




▶ „Removing probes manually <DI 1554>“  
on page 8-12 (manual probe change)

### Select combination



▶ „Changing the combination <DI 1601>“  
on page 8-11

### Select probe




Selector switch on  
control panel


**Administration**

The following functions are available for administering the probe data:


**Modify combination**



**Delete combination**




**List configuration**



# Output of probe data <DI 1624>

**Application** This function outputs the data of all calibrated probe styli in the complete current probe configuration to the record.



**Output** The following data is output:

- Combination number
- Probe number
- Center coordinates
- probe ball radii
- Measuring force used for calibration (not yet activated)
- Temperature of glass scale during calibration (not yet activated)
- Date of last calibration or manual input
- Standard deviation of calibration result
- Flag (static/dynamic) for the calibration method:  
Tensor calibration is indicated by a "+" in the 3rd position (- -+)

**Example of a configuration list**


Co	no	Coordinates			Radius	Force	Temp.	Date	Dev	SD
Configuration = 1										
1	1	0.0000	0.0000	0.0000	2.5080	0.0	20.0	16.7.1987	.0001	--+
1	2	0.8697	37.7008	36.4041	2.5097	0.0	20.0	16.7.1987	.0005	--+
1	3	37.6524	-.8423	40.1763	2.5097	0.0	20.0	16.7.1987	.0009	---
1	4	-1.0258	-37.7045	36.2374	2.5095	0.0	20.0	16.7.1987	.0004	---
1	5	-37.7127	1.0045	40.4668	2.5095	0.0	20.0	16.7.1987	.0007	---
2	1	0.0000	0.0000	0.0000	4.0045	0.0	20.0	16.7.1987	.0002	---

## Modifying probe data <DI 1627>

### Application

In special cases, manual input or correction of the probe data may be necessary.

The data of the current combination can be modified with <DI 1627>.



DI	Pull-Down-Menu	Pictogram
1627	Probe	
PRBCORR	Data	
a32	modify...	

Dialog

Change Probe field

I Modify:      Combination       Configuration

Probe 1:	X	<input type="text" value="0.00000"/>	Y	<input type="text" value="0.00000"/>	Z	<input type="text" value="0.00000"/>	R	<input type="text" value="0.49810"/>
Probe 2:	X	<input type="text" value="-10.7030"/>	Y	<input type="text" value="-57.04120"/>	Z	<input type="text" value="-29.73500"/>	R	<input type="text" value="1.50010"/>
Probe 3:	X	<input type="text" value="-69.87460"/>	Y	<input type="text" value="1.57690"/>	Z	<input type="text" value="-29.92640"/>	R	<input type="text" value="0.50120"/>
Probe 4:	X	<input type="text" value="0.00000"/>	Y	<input type="text" value="0.00000"/>	Z	<input type="text" value="0.00000"/>	R	<input type="text" value="10000000.00"/>
Probe 5:	X	<input type="text" value="70.29690"/>	Y	<input type="text" value="-1.57400"/>	Z	<input type="text" value="-29.73850"/>	R	<input type="text" value="0.49940"/>

Store:      under combination     

<input type="button" value="YES"/>	<input type="button" value="NO"/>	<input type="button" value="TERMIN"/>
<input type="button" value="BACK"/>	<input type="button" value="INFO"/>	

### Application example

Correction of Z and R for a cylinder probe after calibrating it with the calibration standard (➤ „Recalibration with reference standards“ on page 7-33).

### Changes

The activated data box is highlighted.

Only the number of the configuration is displayed.

The center coordinates and radii of the probe balls in the current combination are offered for modification.

Probes which have not been calibrated can be recognized by the radius displayed, i.e. 10000000.00

Modified data can be stored under another combination.

## Deleting and resetting probe data


### Application

If a probe which has already been calibrated is recalibrated, the existing data will be overwritten; the data does *not* have to be deleted beforehand.

### Resetting probe data (to zero) <DI 6505>

### Application

After starting this function, you can reset probes 1 to 5 of any combination and/or configuration to zero.



Dialog


Zeroize probe data

I Probe : from  to  Combination  Configuration

* YES	NO			*				TERMIN
BACK								INFO

### Deleting probe data <DI 6504>



Dialog

Delete probe data

Configuration

Complete configuration

or Probe: from  to  Combination

**Application** For CNC calibration if:



- A combination is to be recalibrated.
- Several combinations or configurations are to be recalibrated during a CNC run.
- Individual probes have been unscrewed and removed from a configuration.
- The configuration is no longer required



## Changing the combination <DI 1601>

**Application**

The combination can be changed with <DI 1601>.



**NOTE**

- The configuration number can also be entered when changing probes (► „Changing probes“ on page 8-12).
- Only configuration no. 1 exists for machines without a probe changer.
- The old configuration and combination will be reactivated following the next UMESS start.

# Changing probes

**NOTE** Only for measuring machines with a probe changer!

**Application** Assembled probe clusters can be exchanged without recalibration on coordinate measuring machines with a probe changer.

**Options** Probes can be changed in two ways, i.e.:


- manually (▶ „Removing probes manually <DI 1554>“ on page 8-12) or
- automatically (▶ „Inserting probes manually <DI 1555>“ on page 8-15)


Automatic change requires a probe changer rack.

With a double trigger probe head the upper probe can be changed only manually.

## Removing probes manually <DI 1554>

**Application** You can call this function to enable manual removal of the configuration inserted in the probe head.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1554	Probe	
RELPRB	change	
a179	remove...	

## Dialog for the measuring probe head

Dialog

Release configuration

I Config. will be dropped in 0 seconds

BACK \* \* \* \* \* TERMIN

INFO

### Application

The attracting force of the locking solenoid is deactivated ... seconds after **<TERMIN>** is selected. The probe can now be removed by pulling it downward gently.




### Important!

The probe may fall out of the mount under the force of its own weight at the end of the waiting period (... seconds)!

You therefore must either make sure that the probe is located above a rack storage position or remove it by hand.

### Dialog for the trigger probe head




**NOTE**

- This function can not be integrated in a learn (i.e. part) program.
- A probe changer mount should always be inserted in the probe head to protect against dirt.
- With a trigger probe head, the holding force of the locking solenoid is deactivated only after the probe head contact is actuated.
- If the dialog displayed does not match the probe head type, please check the probe head type setting with **<DI 1661> <DECISION>**.
- When using a double trigger probe head (probe head type 22) in **<DI 1661> <DECISION>**, the dialog will always ask whether the "top probe" is meant.

## Inserting probes manually <DI 1555>

### Application

This function can be used to insert a new probe (cluster) in the probe head. The corresponding configuration can be read-in simultaneously.



Dialog

Pick up probe configuration

Probe configuration number

\*      TERMIN

BACK      INFO

### Explanation of Dialog

#### Probe configuration number

Here you must enter the number under which the calibration data of the probe being inserted is stored or should be stored on the hard drive. A maximum of 9999 configurations are possible.

#### Stored data

The data which has already been stored under this configuration number is read in to the computer; no renewed calibration is therefore required.

#### Data storage

During the following calibration procedure, the data measured is stored on the hard disk under this configuration number.

**NOTE**

To avoid confusion, all probes should be marked with the configuration number (e.g. with adhesive labels).

**Features of the ST3 probe head with ATAC**

**Special balancing**

With the ST3 probe head, you can adapt the balancing of the probe configuration inserted.


Depending on the type of probe configuration inserted (standard, soft or dynamic sensitivity), you can select a parameter record which contains the data for special balancing.

**Customized settings**

If you have a special probe configuration, the name of the corresponding parameter record will be displayed. The matching parameter record is supplied along with every special probe configuration.

**Dialog window**

The option of selecting a parameter record will be offered in the dialog window only if you have installed an ST3 probe head.



If you have several different special probe configurations, you can select the corresponding parameter records in succession. The name of the current parameter record will be displayed.

### Conventions for the filenames of ST3 parameter records

#### Customized settings

– **ST3SSTANDARD-B**

Filename of a file with ST3 parameters for standard probe configurations

– **ST3-LENKGEH1-B**

Filename of a file with ST3 parameters for special probe configurations

The filename of all ST3 parameter records starts with "ST3".

The fourth position in the filename specifies the type of ST3 parameter record.,

"S" Parameter record for standard probe configurations (standard, soft or dynamic).

"-" Parameter record for special probe configurations.

In the filename of the parameter record for special probe configurations, the following max. 8 positions up to the next "\_" (here e.g.: **LENKGEH1**) are displayed as the name in the dialog window.

#### Directory

The files of the ST3 parameter records are stored in the directory **/home/zeiss/UC**.

### Automatic probe change <DI 1553>

#### Application

<DI 1553> initiates automatic storage of the inserted probe configuration in and removal of a selected configuration from the probe changer rack.

#### Prerequisite

The probe socket position is defined (calibrated) (► „Defining the probe holder positions <DI 1557>“ on page 6-32).

#### Assignment

If you fetch a configuration from or deposit it in a socket, the program will assign the socket and the configuration to one another.

This assignment is retained until you define a new assignment or store the configuration manually.


#### Intermediate positions

You can enter intermediate positions to move around obstacles on the way from one probe socket to another.

# Administration of probe data/probe change

**Procedure**

If you want to store a configuration, the control must know the socket position. If you have already stored or fetched the configuration, a corresponding assignment has already been stored.



Dialog

Automatic probe change: Target configuration input

I configuration number =

Magazine ID char. =

I-POS input

* YES	NO		
-------	----	--	--

\*

STORE		REPEAT	TERMIN
-------	--	--------	--------

BACK		
------	--	--

		INFO
--	--	------

**Data boxes**

**configuration number**

The number of the configuration inserted in the probe head before probe change must be entered for orientation purposes. (If no configuration is inserted in the probe head, the box remains empty. If the number of the configuration inserted in the probe head is unknown, you will be prompted to enter it again manually).

Enter the number of the configuration which must be inserted in the probe head following probe change.

- The data previously stored under this configuration number is read into the computer. No required calibration is required following probe change.



- If probe calibration is subsequently performed, the data thus determined is stored on the hard drive under this configuration number.

**Magazin ID char.**

If a socket configuration assignment already exists and does not have to be changed, no entry is required. However, if no assignment has been made yet or the assignment must be changed, you can specify the letter corresponding to the socket where the required configuration is located.

**I-POS input**

<YES>

Dialog window for additional intermediate positions is called (see following pages).

**Labeling**

To avoid confusion, all probe clusters used should be marked (e.g. with adhesive labels).


**Softkeys**



If you enter the configuration number and press <REPEAT>, the socket assigned to the configuration number will be displayed and vice versa if the box to be filled in is blank. In this way, you can easily check the socket-configuration assignment.



If no configuration-socket assignment exists, e.g. because the probe was inserted manually, the following dialog window will appear and prompt you to enter the target storage location.



**configuration =>  
magazine**

### Data boxes

Enter the call letter of the socket in which the configuration is to be stored. If you then acknowledge with **<TERMIN>**, the **Automatic probe change** dialog described above will be displayed.

### Examples of error messages

#### Example 1

Configuration 1 was stored manually in socket C. This means that the program has not yet fetched it from or deposited it in a socket (and therefore no assignment exists).

**Case 1:** No storage socket has been specified.

- Error message: **This configuration has not been assigned to a socket.**
- Remedy: Enter **C** in the **Magazine ID char.** box.

**Case 2:** Socket C has been entered in the **Magazine ID char.** box. However, this call letter has already been allocated to configuration 6.

- Error message: **Conf. 6 is entered in socket C, please confirm new allocation.**
- Remedy: Press **<TERMIN>** again. Configuration 1 is entered for socket C. Configuration 6 is no longer allocated to a socket.

#### Example 2

Configuration 1 has been stored in another socket by hand (e.g. old socket = F, new socket = A). It is therefore still assigned to socket F.

**Case 1:** An input is made specifying only the configuration.

- Error: If another configuration is deposited in socket F, the program will then fetch this configuration as configuration 1 along with the corresponding probe data.
- Remedy: If the configuration has been moved, the new storage socket also must be specified!

**Case 2:** Socket A is specified, but no configuration was previously stored there.

- Error message: **Conf. 1 is entered in socket F, please confirm new allocation.**
- Remedy: Press **<TERMIN>** again. Configuration 1 is entered for socket A and deleted from socket F.

**Case 3:** Socket A is specified. Configuration 6 was formerly stored in socket A.

- Error message: **Conf. 1 is entered in socket F, socket A has conf. 6.**
- Remedy: Press **<TERMIN>** again. Configuration 1 is entered for socket A and deleted from socket F. Conf. 6 is no longer allocated to a socket.

### Input of intermediate positions

Automatic probe change is a closed function. For this reason, you can not program intermediate positions with I-POS (> „Intermediate position <I-Pos> in the W-position system“ on page 16-31) if the machine travels from one socket to another. If you nevertheless must by-pass obstacles, you can define intermediate positions relative to the sockets.

**Function call**

If you enter <YES> for

**I-POS input** in the **Automatic probe change** window,

the following dialog window will be displayed.

Dialog									
I-positions for automatic probe change									
Ref. magazine <input type="text" value="A"/>									
Distances before storing the previous configuration									
D	1. Pos beside	<input type="text" value="0"/>	bef	<input type="text" value="20"/>	above	<input type="text" value="15"/>			
distances after storing previous configuration									
	1. Pos beside	<input type="text" value="50"/>	bef	<input type="text" value="40"/>	above	<input type="text" value="30"/>			
	2. Pos beside	<input type="text"/>	bef	<input type="text"/>	above	<input type="text"/>			
	3. Pos beside	<input type="text"/>	bef	<input type="text"/>	above	<input type="text"/>			
	4. Pos beside	<input type="text"/>	bef	<input type="text"/>	above	<input type="text"/>			
	5. Pos beside	<input type="text"/>	bef	<input type="text"/>	above	<input type="text"/>			
	6. Pos beside	<input type="text"/>	bef	<input type="text"/>	above	<input type="text"/>			
Ref. magazine <input type="text" value="B"/>									
Distances before installing the current configuration									
	1. Pos beside	<input type="text" value="0"/>	bef	<input type="text" value="10"/>	above	<input type="text" value="15"/>			
Distances before installing the current configuration									
	1. Pos beside	<input type="text" value="10"/>	bef	<input type="text" value="20"/>	above	<input type="text" value="30"/>			
<input type="text"/>				*	<input type="text"/>			REPEAT	TERMIN
<input type="text" value="BACK"/>				<input type="text"/>			<input type="text" value="INFO"/>		

### Data boxes

**Ref. magazine**


The first reference socket is the one in which you stored the configuration currently inserted in the probe head.

The second reference socket is the one from which the new configuration will be fetched.

**Distances before storing the previous configuration, distances after storing previous configuration**

The distances between the first and/or last intermediate position refer to the interval before storing or after picking up the configuration, and can be supplemented by intermediate positions outside of the automatic probe changer rack. You can not enter a distance beside the socket for the first intermediate position.

If you want to enter one or more intermediate positions after storing the probe, an intermediate position will also be requested prior to probe pick-up. If you enter no intermediate position after probe storage, you will not be able to enter an intermediate position prior to pick-up either.



--> Generated bypass route if the approach-in directions vary and no additional positions have been entered (more than two intermediate positions in the corresponding page).

—> Direct travel path (can be optimized) if the intermediate positions are taken from the **IPOS** dialog window.

The current position referenced to the sockets concerned is displayed.

The distances **bef.** and **above** socket A are in the first intermediate position. The distance **beside** socket A is in the second intermediate position.

The distances **bef.** and **above** socket B are in the last intermediate position. The distance **beside** socket B is in the next to last intermediate position.

The probes stored and picked up during a CNC run must be identical to the corresponding probes in the learn (part) program. To prevent complications, the first probe change should always be programmed with **POSITION NEXT TO = 0**.

### Control data

The control data for a probe change comprises at least 4 lines:

- Line 1: Information specifying probe to be picked up.
- Line 2: Intermediate position before storage position (corresponding to input for **DISTANCE. . .BEF. . ./HEIGHT. . .ABOVE. . .**).
- Line 3: Same as line 2, only for intermediate position after storage position.
- Line 4: Generation of a combination change (temporarily still required).

Values  $\neq 0$  entered in the **IPOS** page produce additional control data lines between lines 2 and 3. These additional lines can be modified with the control data editor to optimize the travel path.

The following is possible:

- At least 1, max. 6 lines (additional lines can be created e.g. by copying) for position(s) referenced to the socket after the probe is stored and
- Max. 1 line for the position referenced to the pick-up position before probe pick-up. If 1 or more lines have been entered with the positions referenced to the storage position after probe storage, this line must be programmed. The user is automatically prompted to enter this line.

Be careful when correcting the control data:

If you use more than two position lines, there must be a total of at least four. The next to last line refers to the position referenced to the pick-up position before probe pick-up.

Format of position information:

- 1st word Position next to socket;
- 2nd word Position in front of socket;
- 3rd Wort Position above socket.



#### Important::

The empty probe head has no collision protection!  
Extreme care should be taken when modifying the control data in order to prevent damage to the machine resulting from a collision.



# Chapter 9

## Mathematical alignment

---

### **This chapter contains:**

Coordinate systems . . . . .	9-2
Aligning the workpiece parallel to the machine coordinates. . . . .	9-3
Parallel displacement of the workpiece coordinate system . . . . .	9-15
Rotating the workpiece coordinate system . . . . .	9-23
Forming a workpiece coordinate system from a control coordinate system <DI 1713> . . . . .	9-31
Renaming the workpiece axes . . . . .	9-33
Recall of an element or a coordinate system <DI 1301> . . . . .	9-37

## Coordinate systems

A general distinction is made between the following types of coordinate system:

### The machine coordinate system


- comprises the coordinates  $X_G, Y_G, Z_G$ ,
- is embodied by the mechanical construction of the measuring machine,
- can not be changed.

### The workpiece coordinate system

- comprises the coordinates  $X_W, Y_W, Z_W$ ,
- is used to form the measured value,
- can be rotated and moved according to the drawing requirement.

### The control coordinate system

- comprises coordinates  $X_S, Y_S, Z_S$ ,
- is used as a reference for travel and probing movements during an automatic measuring run,
- is formed from any workpiece coordinate system by calling **<W-POS>**.






# Aligning the workpiece parallel to the machine coordinates

## Application

The workpiece to be measured can be clamped on the table of the measuring machine in an inclined or rotated position. The position of the workpiece in reference to the machine axes must therefore be defined before beginning a measurement. The workpiece is mathematically tilted and rotated until specific geometric elements are positioned parallel to the machine axes.

Recommended procedure for mathematical alignment of a workpiece:




### Remarks

- Despite the subsequent mathematical alignment, you must mechanically align the workpiece as precisely as possible when clamping it in order to prevent "shaft probings".
- No TILTING of the workpiece coordinate system is required when measuring flat workpieces clamped parallel to the machine table.
- No ROTATION of the workpiece is required for parts which have a rotationally symmetric shape and are measured only in the direction of the rotational axis.

### Transformation space <DI 1706>


### Main direction


Defines the "main direction" (as per DIN 32 880). The last element in the measuring record is mathematically tilted so that it lies parallel to a machine axis. This machine axis thus becomes the space axis.



## Prerequisite






- The last element in the measurement record is spatially (three dimensionally) defined or
- The computer can form a spatially defined element from the last two elements in the measurement record (examples on next page).



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1706 TRSPACE	Coord Space axis define	

Examples

The following table shows elements suitable for the application of <RO SPACE>:


Example	Step sequence	Aligned
<p>SURFACE</p> 	<p>&lt;SURFACE&gt; &lt;RO SPACE&gt;</p>	<p>Surface normal</p>
<p>CYLINDER / CONE</p> 	<p>&lt;CYLINDER&gt; (&lt;CONE&gt;) &lt;RO SPACE&gt;</p>	<p>Cylinder/cone axis</p>
<p>LINE (e.g. calculated via multiple ellipses)</p> 	<p>&lt;RECALL&gt; (&lt;LINE&gt;) &lt;RO SPACE&gt;</p>	<p>Line</p>
<p>ELLIPSE / ELLIPSE (measured in one cylinder/cone)</p> 	<p>&lt;ELLIPSE&gt; &lt;ELLIPSE&gt; &lt;RO SPACE&gt;</p>	<p>Connecting line between ellipse center points (cylinder/cone axis)</p>
<p>SPHERE / SPHERE</p> 	<p>&lt;SPHERE&gt; &lt;SPHERE&gt; &lt;RO SPACE&gt;</p>	<p>Connecting line between sphere center points</p>

### Transformation plane <DI 1702>

**Secondary direction**


Defines the "secondary direction" (as per DIN 32 880).


The last element in the measurement record is rotated mathematically about the space axis so that it lies parallel to a machine axis.



**Prerequisite**





- The last element in the measuring record contains a 3D or 2D defined axis or
- the computer can form a 3D or 2D defined axis from the last two elements in the measuring record. This axis must not lie parallel to the space axis!



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1702 TRPLANE	Coord Plane transf. Rotate plane	

Examples

The following table shows examples of combined geometric elements for which the <RO PLANE> function can be applied. This application is also possible for elements specified with <RO SPACE>.


Example:	Step seq.:	Aligned:
<p>POINT / POINT</p> 	<p>&lt;POINT&gt; &lt;POINT&gt; &lt;RO PLANE&gt;</p>	<p>Connecting line between points</p>
<p>CIRCLE / CIRCLE</p> 	<p>&lt;CIRCLE&gt; &lt;CIRCLE&gt; &lt;RO PLANE&gt;</p>	<p>Connecting line between circle center points</p>
<p>SYMMETRY POINT/ SYMMETRY POINT</p> 	<p>&lt;SYM.POINT&gt; &lt;SYM.POINT&gt; &lt;RO PLANE&gt;</p>	<p>Connecting line between symmetry points</p>
<p>CIRCLE / POINT</p> 	<p>&lt;CIRCLE&gt; &lt;POINT&gt; &lt;RO PLANE&gt;</p>	<p>Connecting line betw. circle center point and point (see remark below)</p>

Remarks


If the line to be aligned is determined by combining a POINT probing with any geometric element (see example 4), please note the following:

## Aligning the workpiece parallel to the machine coordinates

The radius correction for POINT probings takes place in the direction of the coordinate system currently valid, and not in the actual contact point. The entire alignment procedure should be repeated several times (iterative alignment) to ensure that the radius correction and the contact point coincide.



If the workpiece coordinate system is not tilted with **<RO SPACE>**, the following dialog window will automatically be displayed:





The axis about which the coordinate system will be rotated is specified by pressing this softkey.

## Transformation with selectable coordinate axis

### Application

If you want to take over the orientation of a workpiece from a drawing as the coordinate system, this can be done with the following functions:

### 3D transformation with selectable coordinate axis





### Example

For example, you can assign a calculated connecting line or the axis of a geometric element as the workpiece axis.



2D transformation with selectable coordinate axis




You can also select an axis for 2D transformation in one of four other ways. For more details: [► „Renaming the workpiece axes“ on page 9-33](#)

These functions also include **<DI 1711>** "Rename workpiece axis" ([► „Renaming the workpiece axes“ on page 9-33](#)).

# Mathematical alignment

## Entering a nominal vector

You can enter a nominal vector for alignment functions <DI 1734> and <DI 1735>.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1739		

Dialog									
Help transformation function for DI 1734 and DI 1735 with nominal vectors Alignment of actual vectors acc. to nominal vectors									
<input type="checkbox"/> Y	Alignment on				<input type="checkbox"/> *				
YES	NO			*				TERMIN	
BACK								INFO	

## DMIS postprocessor

These nominal vectors are preset e.g. by the DMIS postprocessor.

**DI <1740> Alignment according to nominals**

- Enter the address/names of the elements to be aligned.
- The actual values are preassigned and can not be changed.
- Enter the nominal values.
- Click on **Fix to nominal value**.  
The actual values will then be rotated and shifted until they agree with the nominal values.

X, Y, Z must be selected for one address. These values are used for the zero point.

X, Y or Y, Z or Z,X must be selected for **Rotate Space** for one address.

X or Y, Y or Z, or Z or X must be selected for **Rotate Plane** for one address.

Address/name		Actuals	Nominals	Fix to nominal value
50	X	-31.500000		<input type="checkbox"/>
	Y	17.500000		<input type="checkbox"/>
	Z	-4.500000		<input type="checkbox"/>
59	X	-44.772082		<input type="checkbox"/>
	Y	0.000000		<input type="checkbox"/>
	Z	0.000000		<input type="checkbox"/>
58	X	-3.000000		<input type="checkbox"/>
	Y	0.000000		<input type="checkbox"/>
	Z	0.000000		<input type="checkbox"/>
	X			<input type="checkbox"/>
	Y			<input type="checkbox"/>
	Z			<input type="checkbox"/>
	X			<input type="checkbox"/>
	Y			<input type="checkbox"/>
	Z			<input type="checkbox"/>
	X			<input type="checkbox"/>
	Y			<input type="checkbox"/>
	Z			<input type="checkbox"/>

**Printout in measuring record**

62	3D FIT	X	-1.5000
		Y	10.0000
		Z	-6.0000
	SPACE	W	2.5100
	PLANE	W	9.9423 ABOUT SPACE AXIS Z

# Parallel displacement of the workpiece coordinate system

## Organization


The following functions are important for parallel displacement of the workpiece coordinate system:

- Zeroing an element (<**ZERO POINT**> ▶ „Zeroing an element <DI 1701>“ on page 9-15)
- Zeroing a coordinate (<**DAW 1731, 1732, 1733**> ▶ „Zeroing a coordinate <DI 1731, 1732, 1733>“ on page 9-17)
- Displacement of the zero point by a defined value (<**DISPLACE**> ▶ „Displacing the zero point by a defined value <DI 1723>“ on page 9-18)
- Displacement of the zero point into a theoretical reference plane (<**BASIC DISPLACEMENT**> ▶ „Displacing the zero point into a theoretical reference plane <DI 1722>“ on page 9-19)

## Zeroing an element <DI 1701>

## Application

The <**ZERO POINT**> function enables the origin of the workpiece coordinate system to be placed in a defined geometric element.



## Reference

After the function call, the coordinates of the last element in the measurement record are set to zero.


## Example

The last element in the measurement record is a circle.

- <**ZERO POINT**>
- The center point coordinates of the circle are set to zero.
- The 3rd coordinate remains unchanged.

Function call

The **<ZERO POINT>** function in connection with **<RO SPACE>** and **<RO PLANE>** can be integrated in the following procedure without renewed probing:




### Zeroing a coordinate <DI 1731, 1732, 1733>


**Application**

These functions make it possible to reset one coordinate of the last element in the measurement protocol to zero.


**To zero (reset) the X axis:**



**To zero (reset) the Y axis:**




**To zero (reset) the Z axis:**




## Displacing the zero point by a defined value <DI 1723>

### Application

The <DISPLACE> function enables you to place the origin of the workpiece coordinate system in all three coordinate axes to a position which can not be probed. First, however, a reference to a geometric element of the workpiece which can be probed must be established via the <ZERO POINT> function.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1723 DISPLACE	Coord Zero point displace...	

Dialog

Zero point displacement

D X =  mm Y =  mm Z =  mm

\*      
 CANCEL

### Procedure


Enter or accept displacement values. Then press <Enter> to continue on to the next box or, following the last box, execute zero-point displacement.




## Displacing the zero point into a theoretical reference plane <DI 1722>

### Application

This function enables the origin of the workpiece coordinate system to be placed in a theoretical reference plane.




<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1722	Coord	
BASISDIS	Zero point	
a119	Basic displacement...	



# Mathematical alignment


**Procedure** Define the coordinates by pressing the softkey.



**Procedure** Enter the basic dimension and conclude with **<Enter>**.

Example

Dovetail



<p>- Probe SURFACE 1</p> <p>- Probe SURFACE 2 (note correction order of surfaces to maintain required symmetry surface)</p> <p>- &lt;SYMMETRY&gt;</p> <p>- &lt;INTERS&gt; (Intersection line SURFACE/SYMMETRY SURFACE)*</p> <p>- &lt;RO SPACE&gt;</p> <p>- &lt;ZERO POINT&gt;</p> <p>→ &lt;RECALL&gt; (of the sym. surface into the new coord. sys.)</p> <p>- &lt;RO PLANE&gt;</p> <p>→ &lt;RECALL&gt; (of SURFACE 2 into new coordinate system for negative displacement <b>The +/- sign of the surface angle determines the direction of the displacement!</b> *)</p> <p>- Function call: basic displ.</p> <p>If positive displ is required:</p> <p>→ &lt;RECALL&gt; (of SURFACE 1)</p> <p>- Function call: Basic (base) displ. *Note: A negative displacement makes sense in the example shown here.</p>	<table border="0"> <tr> <td>1</td> <td>SURFACEZ</td> <td></td> <td>-156.8550</td> </tr> <tr> <td></td> <td>X/Z</td> <td>A1</td> <td>44.9816</td> </tr> <tr> <td></td> <td>Y/Z</td> <td>A2</td> <td>0.2677</td> </tr> <tr> <td></td> <td>4P S/MIN/MAX</td> <td></td> <td>0.0011 (3)-0. ...</td> </tr> <tr> <td>2</td> <td>SURFACE</td> <td>Z</td> <td>-1947.8424</td> </tr> <tr> <td></td> <td>X/Z</td> <td>A1</td> <td>-44.9813</td> </tr> <tr> <td></td> <td>Y/Z</td> <td>A2</td> <td>-0.4278</td> </tr> <tr> <td></td> <td>4P S/MIN/MAX</td> <td></td> <td>0.0004 (2)-0. ...</td> </tr> <tr> <td>3</td> <td>SYM-F</td> <td>X</td> <td>896.0717</td> </tr> <tr> <td></td> <td>Y/X</td> <td>A1</td> <td>0.3480</td> </tr> <tr> <td></td> <td>Z/X</td> <td>A2</td> <td>0.0001</td> </tr> <tr> <td>4</td> <td>S-G FF</td> <td>Z</td> <td>-1052.3535</td> </tr> <tr> <td></td> <td>X</td> <td></td> <td>896.0734</td> </tr> <tr> <td></td> <td>Z/Y</td> <td>A1</td> <td>0.0800</td> </tr> <tr> <td></td> <td>X/Y</td> <td>A2</td> <td>-0.3480</td> </tr> <tr> <td>5</td> <td>ROTATE SPACE</td> <td>W</td> <td>0.3571</td> </tr> <tr> <td>6</td> <td>ZERO PT</td> <td>Z</td> <td>-1052.3524</td> </tr> <tr> <td></td> <td>X</td> <td></td> <td>896.0480</td> </tr> <tr> <td>7</td> <td>3! SURFACE</td> <td>X</td> <td>0.0000</td> </tr> <tr> <td></td> <td>Y/X</td> <td>A1</td> <td>-0.0000</td> </tr> <tr> <td></td> <td>Z/X</td> <td>A2</td> <td>-0.0004</td> </tr> <tr> <td>8</td> <td>ROTATE PLANE</td> <td colspan="2">A-0.0004ABOUT SPACE AXIS</td> </tr> <tr> <td>9</td> <td>2! SURFACE</td> <td>Z</td> <td>0.0000</td> </tr> <tr> <td></td> <td>X/Z</td> <td>A1</td> <td>-44.9820</td> </tr> <tr> <td></td> <td>Y/Z</td> <td>A2</td> <td>0.0000</td> </tr> <tr> <td>10</td> <td>DISPLACE</td> <td>X</td> <td>0.0000</td> </tr> <tr> <td></td> <td>Y</td> <td></td> <td>0.0000</td> </tr> <tr> <td></td> <td>Z</td> <td></td> <td>-24.9843</td> </tr> <tr> <td>11</td> <td colspan="3">8* COORD.SYSTEM AS FOR ADR.8</td> </tr> <tr> <td>12</td> <td>1! SURFACE</td> <td>Z</td> <td>0.0000</td> </tr> <tr> <td></td> <td>X/Z</td> <td>A1</td> <td>44.9820</td> </tr> <tr> <td></td> <td>Y/Z</td> <td>A2</td> <td>-0.0000</td> </tr> <tr> <td>13</td> <td>DISPLACE</td> <td>X</td> <td>0.0000</td> </tr> <tr> <td></td> <td>Y</td> <td></td> <td>0.0000</td> </tr> <tr> <td></td> <td>Z</td> <td></td> <td>24.9843</td> </tr> </table>	1	SURFACEZ		-156.8550		X/Z	A1	44.9816		Y/Z	A2	0.2677		4P S/MIN/MAX		0.0011 (3)-0. ...	2	SURFACE	Z	-1947.8424		X/Z	A1	-44.9813		Y/Z	A2	-0.4278		4P S/MIN/MAX		0.0004 (2)-0. ...	3	SYM-F	X	896.0717		Y/X	A1	0.3480		Z/X	A2	0.0001	4	S-G FF	Z	-1052.3535		X		896.0734		Z/Y	A1	0.0800		X/Y	A2	-0.3480	5	ROTATE SPACE	W	0.3571	6	ZERO PT	Z	-1052.3524		X		896.0480	7	3! SURFACE	X	0.0000		Y/X	A1	-0.0000		Z/X	A2	-0.0004	8	ROTATE PLANE	A-0.0004ABOUT SPACE AXIS		9	2! SURFACE	Z	0.0000		X/Z	A1	-44.9820		Y/Z	A2	0.0000	10	DISPLACE	X	0.0000		Y		0.0000		Z		-24.9843	11	8* COORD.SYSTEM AS FOR ADR.8			12	1! SURFACE	Z	0.0000		X/Z	A1	44.9820		Y/Z	A2	-0.0000	13	DISPLACE	X	0.0000		Y		0.0000		Z		24.9843
1	SURFACEZ		-156.8550																																																																																																																																										
	X/Z	A1	44.9816																																																																																																																																										
	Y/Z	A2	0.2677																																																																																																																																										
	4P S/MIN/MAX		0.0011 (3)-0. ...																																																																																																																																										
2	SURFACE	Z	-1947.8424																																																																																																																																										
	X/Z	A1	-44.9813																																																																																																																																										
	Y/Z	A2	-0.4278																																																																																																																																										
	4P S/MIN/MAX		0.0004 (2)-0. ...																																																																																																																																										
3	SYM-F	X	896.0717																																																																																																																																										
	Y/X	A1	0.3480																																																																																																																																										
	Z/X	A2	0.0001																																																																																																																																										
4	S-G FF	Z	-1052.3535																																																																																																																																										
	X		896.0734																																																																																																																																										
	Z/Y	A1	0.0800																																																																																																																																										
	X/Y	A2	-0.3480																																																																																																																																										
5	ROTATE SPACE	W	0.3571																																																																																																																																										
6	ZERO PT	Z	-1052.3524																																																																																																																																										
	X		896.0480																																																																																																																																										
7	3! SURFACE	X	0.0000																																																																																																																																										
	Y/X	A1	-0.0000																																																																																																																																										
	Z/X	A2	-0.0004																																																																																																																																										
8	ROTATE PLANE	A-0.0004ABOUT SPACE AXIS																																																																																																																																											
9	2! SURFACE	Z	0.0000																																																																																																																																										
	X/Z	A1	-44.9820																																																																																																																																										
	Y/Z	A2	0.0000																																																																																																																																										
10	DISPLACE	X	0.0000																																																																																																																																										
	Y		0.0000																																																																																																																																										
	Z		-24.9843																																																																																																																																										
11	8* COORD.SYSTEM AS FOR ADR.8																																																																																																																																												
12	1! SURFACE	Z	0.0000																																																																																																																																										
	X/Z	A1	44.9820																																																																																																																																										
	Y/Z	A2	-0.0000																																																																																																																																										
13	DISPLACE	X	0.0000																																																																																																																																										
	Y		0.0000																																																																																																																																										
	Z		24.9843																																																																																																																																										

# Rotating the workpiece coordinate system



## Selecting the space axis <DI 1707>

**Application**

With <DI 1707> it is possible to declare any axis of the workpiece coordinate system as the space axis.

**Application possibility**

Rotation of the workpiece coordinate system about an axis which is not the space axis.



DI	Pull-Down-Menu	Pictogram
1707	Coord	
AXISCHA	Space axis	
a79	change...	

**Procedure**

Select the required space axis with the softkey. The new space axis will then be output in the measurement record.


## Rotation about the zero point and one element <DI 1703>


**Application**

The workpiece coordinate system is rotated about the zero point so that a coordinate axis runs through the last element in the measurement record.

**Application e.g. with**


- rotationally symmetrical parts (see example below)
- iterative alignment (▶ „Transformation plane <DI 1702>“ on page 9-7 example 4)



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1703	Coord	
TR0+1	Plane transf.	
a23	Zero point & 1 Element	

**Example**

A notched plate must be realigned so that the width of each of its notches can be measured.




**Procedure**

- Place origin of coordinate system (<ZERO POINT>) in the center bore
- Probe first notch (<POINT> ,<POINT>, <SYMMETRY>)
- Call up <TR0+1>
- Measure notch width
- Probe second notch
- Call up <TR0+1>.

## Rerotating by an angle <DI 1709>

### Application

This function enables the workpiece coordinate system to be rotated by a defined angle about about the space axis.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1709	Coord	
TRANGLE	Plane transf.	
a213	Rerotate...	

Dialog

Rerotate about angle

Result name

Rotate about space axis x  ; or y  or z  \*

Angle

\* YES
  NO

### Data boxes

#### Result name

Accept or overwrite the default value.

#### Rotate about space axis

Specify the machine axis about which the coordinate system is to be rotated if <RO SPACE> has not been executed. If the space axis is defined, the boxes are inaccessible.

#### Angle


If you view the plane of the rerotation angle from the positive direction of the 3rd axis, the following applies:

Rotation counterclockwise (mathematically positive direction of rotation) ⇒ positive sign

Enter the rerotation angle with the correct sign and conclude with **<Enter>**.

### Example

A workpiece is to be aligned according to 2 fitting bores, however is dimensioned to them by the angle  $\Phi$ . The workpiece coordinate system therefore must be rotated by the angle  $\Phi$  following alignment.



### Procedure


- **<CIRCLE>** (measure bore I)
- **<CIRCLE>** (measure bore II)
- **<RO PLANE>** (alignment parallel to the fitting bores)
- **<ZERO POINT>** (in bore II)
- **<DI 1709>** (enter machine axis about which rotation is to be performed and enter rerotation angle  $\Phi$ )



## Defining the mode for the WP reference axis <DI 1719>

### Application

The reference axis of the workpiece coordinate system is usually changed if the angle of rotation reaches  $\pm 45^\circ$ . This function can be used to suppress changing of the reference axis.



Dialog

Define mode for WP reference axis

Rotate the ref. axis for workpiece system with DI 1709 ?

Info:  
Behavior during a plane rotation acc. to previous DI 1709 :

The workpiece coordinate system can be rotated a max. 45 degrees.

NO : Reference for the 45 degrees is the device system axis.  
The rotation carried out with DI 1709 will be overwritten.

YES : Reference for the 45 degrees is the angle from DI 1709.

\* YES

NO

\*

TERMIN

BACK

Rotate the ref. axis for workpiece system with DI 1709 ?

### Data box


- <YES>  
Always whenever the workpiece coordinate system is rotated with <DI 1709> and fine alignment <DI 1702, 1703, 1705> is also required. The axes are not changed if the 45° limit is exceeded.
- <NO>  
Normal setting when starting UMESS and after calling <DI 1608, 1610, 1707, 1706, 1711>.

### NOTE

If <DI 1709> is called repeatedly, the sum of all rerotation angles is the reference for the 45° limit.

### Example

The workpiece coordinate system must be rotated about the zero point and one element repeatedly.




### Rotating to distance <DI 1705>


**Application**

This function enables the workpiece coordinate system to be rotated so that a coordinate of a measured element assumes a specified value.

**Prerequisite**

The element required must be the last address in the record.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1705	Coord	
TRDIS	Plane transf.	
a65	Distance...	

Dialog


Transformation in plane

D COORDINATE X

YES	NO			*				
CANCEL								

**Softkeys**




Use <YES> / <NO> to select the coordinate which should be set to a defined size. When the required coordinate is displayed, enter the nominal value and acknowledge with <Enter>.

## Example

### Initial status:

The center point of bore II in X has a distance of 50 mm from the zero point of the workpiece coordinate system (in bore I).




Rotate coordinate system

<TRDIS>

### Aim:

The workpiece coordinate system is aligned so that the distance between the two bores equals 40 mm in X (nominal).



## Procedure

- Place the origin of the coordinate system (<ZERO POINT>) in bore I.
- Measure or recall bore II.
- Then rotate to distance with <TRDIS> (nom. value in X = 40).


## NOTE


- Rotation is always performed about the space axis. The space axis can be changed if necessary with <DI 1707> (► „Selecting the space axis <DI 1707>“ on page 9-23).
- A nominal value can be entered only for one coordinate direction.
- The nominal value must be smaller than the polar distance of the element concerned from the zero point.
- the coordinate system is rotated in the direction in which the smaller angle of rotation is required.

## Forming a workpiece coordinate system from a control coordinate system <DI 1713>

### Application

With this function the workpiece coordinate system is equated with the control coordinate system activated last. An initial (under certain circumstances approximate) workpiece coordinate system can thus be activated after entering <DI 1608> or <RECORD>.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1713 WLWPC	Coord Preparation WPS = WPOS	

### NOTE

- Then the coordinate system called should be optimized by an exact mathematical alignment.
- Calling <DI 1608> or <RECORD> deletes all stored zero points and angles, and therefore the workpiece coordinate system. The machine coordinates remain valid until they are redetermined.

**Overview**

The following table shows the effect individual operations have on different coordinate systems when performed in the sequence shown:

OPERATION	STORED COORDINATE SYSTEMS		
	ON DATA CARRIER CONTROL COORD.	IN THE COMPUTER WORKP.COORD. CTRL COORD.	
1 AFTER SWITCH- ON	<b>OLD SYSTEM</b>	○	○
2 <DI 1608> <RECORD>	<b>OLD SYSTEM</b>	○	○
3 DETERMINATION OF WORKPIECE COORDINATES	<b>OLD SYSTEM</b>	●	○
4 <W-POS> (MANUAL)	●	← ● →	●
5 <RECORD> (<DI 1608>)	●	○	●
6 <DI 1713>	●	●	← ●

○ = MACHINE COORDINATES

● = WORKPIECE COORDINATES

## Renaming the workpiece axes

### Free axis selection <DI 1711>

#### Application


With <AXISSEL> you can change the identifications of the workpiece axes.

This DI is suitable for use in cases where:

- The identification (designation) of the axes in the measurement record must be adapted to the identification in the drawing.
- A workpiece is aligned differently on the CMM. The existing control data can be further used. The probe numbers must, however, be corrected in the control data (<CNCCORR>) or renamed accordingly during probe calibration.


#### Procedure

- Set initial status <DI 1608>
- Enter required axis assignment <DI 1711>
- Calibrate required probes <DI 1602>
- Call record header if necessary <DI 1610>
- MEASURE
- If the identification of the axes should be canceled <DI 1711>



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1711	Coord	
AXISSEL	Preparation	
a143	Free axis selection...	

# Mathematical alignment



**Procedure**

Enter the number of the axis identification required and confirm with **<Enter>**.



**Overview**

Z↑	1		2		3		4	
	5		6		7		8	
Z↓	9		10		11		12	
	13		14		15		16	
Y↑	17		18		19		20	
	21		22		23		24	
Y↓	17		18		19		20	
	21		22		23		24	
X↑	17		18		19		20	
	21		22		23		24	
X↓	17		18		19		20	
	21		22		23		24	

**Explanation**



System 1 corresponds to the original identification of the machine axes. Each of the above diagrams shows the positive semiaxis of the coordinate system.

### Relative axis selection <DI 1720>

**Application**

With this function, the designations of the workpiece axes can be changed. The change refers to the coordinate system currently valid (which is always the initial system with <DI 1711>).

This function is mainly required for the DMIS postprocessor. It can, however, also be called up in the manual or CNC measurement mode.



**Procedure**


The code numbers of the required axis designations must be selected from the table for <DI 1711>.

## Recall of an element or a coordinate system <DI 1301>

### Application

During a measurement, any number of workpiece coordinate systems can be defined for a workpiece.

With <RECALL> it is possible to reactivate a previously defined coordinate system. The *last* address with which the required coordinate system was defined must be recalled (e.g. <ZERO POINT>, <DIS-PLACE>).



Dialog									
Recall of one result									
Result name									
<input type="checkbox"/>	C	Recall of address/name :	<input type="text" value="12"/>						
				*					
								TERMIN	
BACK							INFO		

## Example

Record				
1	SURFACE	Z	-413.752	
	X/Z	A1	0.051	
	Y/Z	A2	-0.058	
2	ROTATE SPACE	A	0.0773	
3	ZERO PT	Z	-413.751	
4	SURFACE	Y	-603.517	
	Z/Y	A1	0.029	
	X/Y	A2	-1.052	
5	ROTATE PLANE	A	-1.0521	ABOUT SPACE AXIS Z
6	ZERO PT	Y	-603.416	
7	POINT	X	262.438	
8	ZERO PT	X	262.438	
	.			
	.			
	.			
67	8*COORD. SYSTEM AS FOR ADR. 8			

### NOTE

You can convert a result with an address = n only into a coordinate system with an address < n.

With iterative alignment (car body metrology), you therefore must generate a coordinate system (e.g. displacement XYZ=0) at the start of a loop.

# Chapter

# 10

## Measuring

---

### **This chapter contains:**

Procedure .....	10-2
Probings .....	10-3
Creating/evaluating point collection files .....	10-21
Recalling results .....	10-29
Travel commands .....	10-34
Additional information .....	10-45
Interpretation of the measurement results .....	10-53

## Procedure

### Procedure

To measure geometric elements, proceed as follows:

#### Call measurement program

The measurement program call tells the computer which geometric elements should be calculated from the probings which follow. A program call is not always necessary for POINT measurements (▶ „General“ on page 11-2).

#### Probe an element

Note the number and position of the probing points when probing (▶ „Geometric elements“ on page 11-1).

#### Terminate the measurement program

By pressing the **<TERMIN>** key, you tell the computer that no further probings will follow.

The program then checks whether the geometric element has the required minimum number of points. The best fit geometric element is calculated for the points probed and the result printed.

If it is not possible to calculate the element called from the existing probings, this will be acknowledged by the output **NO RESULT** (▶ „No result“ function“ on page 10-55).

### Point file

With **<DI 1100>** measured points can initially be saved to a point collection file and evaluated later (▶ „Creating/evaluating point collection files“ on page 10-21)

The individual probing points remain stored and can be used for further calculations.

# Probing


## Probing strategies

### Best fit


The computer always calculates the best fit ideal geometric element from the probing points.

**The following principles should be noted when probing:**

**Perform as many probing as possible:**




**Large distance between probing points:**




Large distance between intersection planes:

<CYLINDER> SMALL  
DIST: BETW: MEAS: PLANES



LARGE TILT OF AXIS


<CYLINDER> LARGE  
DIST: BETW: MEAS: PLANES



SMALL TILT OF AXIS

**NOTE**

- The program automatically checks whether the required minimum number of probings (► „Geometric elements“ on page 11-1) has been performed.
- If the element called can not be calculated from the probings available, this will be indicated in the measurement record by the comment **NO RESULT**.
- A geometric element is initially calculated through the probe ball centers. Then a correction is performed by an amount equal to the radius of the probe selected last.




A probe change within an N POINT PROGRAM is therefore permissible only if the radii of the probes used are within the required measuring uncertainty!



## Probing possibilities

### Function call

If a geometric element (<CIRCLE>,<SURFACE>, etc.) is called, the following dialog window will be displayed:



### Probing

The measuring points for the geometric element selected can be probed manually or determined via a softkey function.


### Element name

The performance mode name offered in the **Element name** data box can not be changed. (Observe rules in ► „Allocating names“ on page 5-9).

### Softkeys



Combined measurement and evaluation functions.



Calls the macros defined previously.



Calls a macro for off-line programming in ACE.

<b>Scanning mode</b>	Defines the scanning mode (▶ „Preparations“ on page 19-3).
<b>Scanning run</b>	Starts a scanning run (▶ „Details on the scanning mode“ on page 19-15).
<b>Laser measurement</b>	Starts a laser measurement.
<b>Recalls</b>	Calculates the geometric element by recalling multiple addresses (▶ „Recall of several elements“ on page 10-32).
<b>File evaluation</b>	Calculates the geometric element by evaluating a point collection file (▶ „Creating/evaluating point collection files“ on page 10-21).
<b>REP EVAL</b>	The probing points of the previous geometric element are reevaluated.
<b>CMM...</b>	Combined CMM control functions.
<b>Step</b>	Initiates travel to the probing point or intermediate position with the <b>&lt;STEP&gt;</b> function (▶ „Travel from the current position in fixed steps <DI 1515>“ on page 10-41).
<b>Position</b>	Initiates travel to the probing point or intermediate position with the <b>&lt;POSITION&gt;</b> function (▶ „Positioning to workpiece coordinates <DI 1511>“ on page 10-37).
<b>RT-Step</b>	Function calls for RT table control (▶ „Rotary table operation“ on page 15-1).
<b>RT-Position</b>	
<b>RT-Pitch</b>	
<b>DSE Step</b>	Travel commands for the articulating probe holder.
<b>DSE Position</b>	
<b>VAST</b>	Branches to the dialog window for VAST functions.
<b>Nominal</b>	Terminates element with transfer to nominal input.
<b>I-Pos/Prb</b>	With a measuring probe head, points can be accepted with the probe in contact by pressing this softkey.

**Theor.element**

Branches to the dialog window for entering a theoretical element.  
(► „Theoretical elements“ on page 11-61)

**Termin**

Informs the computer that all of the points required have been defined. The element is then calculated and output to the record.

**Correction**

Used to delete the last probing point.


**Cancel**

Used to quit the dialog window without calculating the element.

## Switching on the intermediate result display <DI 1188>

### Application

When probing a geometric element, you can also have the intermediate positions displayed. These results are displayed in the Elements window as soon as the minimum number of probings for the element concerned has been reached.



Dialog

NPKTE: Mode input

Y Print of intermediate data on monitor \*

Auto\_Termin  \* Auto\_Nominal   
 or fixed point number mode

Element	Warning limit	Auto_Termin limit	or	Number of pt
Line	1.00	1000.00		2
Surface	1.00	1000.00		3
Circle	1.00	1000.00		3
Sphere	1.00	1000.00		4
Cylinder	1.00	1000.00		5
Cone	1.00	1000.00		6
Ellipse	1.00	1000.00		5
Torus	1.00	1000.00		7

\* YES NO   \*     TERMIN

PRE MENU     INFO


### Data boxes

Print of intermediate data on monitor

Enter <YES> and terminate with <TERMIN>.

**Additional display**

If you now call and probe a geometric element, you will see an extended dialog window when the minimum number of probings has been reached.



**Data boxes**

**Element name**

A default name is offered here. If the name allocation is activated, you can overwrite this name.

**Display boxes**

**X, Y, Z**

Display of coordinates.

**D (D1, D2)**

Diameter of a rotationally symmetrical element, supplementary diameter.

**A1, A2**

Projected angles (position of element relative to axes).

**AC**

Generating angle of cone.

<b>Distance point - element</b>	Distance between the last point and the element. This includes a warning limit if an unfavorable probing is performed and the Auto_Termin function with which a new element is automatically started (► „Simplified termination of probings, Warning limit input < DI 1188>“ on page 10-10).
<b>Standard deviation s</b>	Statistical deviation of individual points from the best fit measured element.
<b>MIN point no. MAX point no.</b>	Minimum/maximum deviation of individual points from the best fit element.
<b>Range MAX - MIN</b>	Range of measured points (Range).

### Simplified termination of probings, Warning limit input < DI 1188>

<b>Application</b>	Normally you terminate the probing of an element with <b>&lt;TERMIN&gt;</b> as soon as you have probed a sufficient number of points. You can terminate the probing of a geometric element more simply with the functions <ul style="list-style-type: none"> <li>– Nominal input</li> <li>– Auto Termin</li> </ul>
--------------------	--

#### Nominal input

<b>Procedure</b>	If you probe a geometric element and press <b>&lt;NOMINAL&gt;</b> , the probing will be concluded and the element will be calculated. The dialog window for the nominal input appears (► „Nominal input <DI 1459> (old 1452)“ on page 14-8). The boxes required for the nominal-actual (variance) comparison are already marked and preassigned with the rounded off measurement results. You can change these values or accept them. Then conclude the input with <b>&lt;TERMIN&gt;</b> .
------------------	--

<b>Prog mode</b>	In the programming mode, the nominal is written to the reserved control data line (► „Computer controlled manually measured sections <DI 1077>“ on page 16-25).
------------------	---


#### Auto Termin


You can also terminate an element automatically with **Auto Termin**.

#### You have two options:

- Enter cancel limit
- Enter number of points

Set both values with <DI 1188>.



DI	Pull-Down-Menu	Pictogram
1188	Record	
INTRES	Mode	
	Intermediate results...	

Dialog

NPKTE: Mode input

Y Print of intermediate data on monitor  \*

Auto\_Termin  \* Auto\_Nominal

or fixed point number mode

Element	Warning limit	Auto_Termin limit or	Number of pt
Line	1.00	1000.00	2
Surface	1.00	1000.00	3
Circle	1.00	1000.00	3
Sphere	1.00	1000.00	4
Cylinder	1.00	1000.00	5
Sphere	1.00	1000.00	6
Ellipse	1.00	1000.00	5
Torus	1.00	1000.00	7

\* YES NO   \*    TERMIN

PRE MENU    INFO

### Data boxes

#### Auto\_Termin

If you enter <YES>, the Auto Termin limit displayed in the table will take effect for the matching element. You can determine and enter a suitable value. If the last probing point deviates more from the element previously calculated, Auto\_Termin will become effective. The element will then be terminated and calculated without the last probing point. Then the following message will be displayed:

**NOTE**

**Auto\_Termin limit has been exceeded.**

The last point then becomes the first point of a new element of the same kind.

**Restrictions:** The function is effective only in the manual mode, with single points (without scanning) and without name allocation.

**or fixed point number mode**

If you confirm here with **<YES>**, the number of points displayed in the table will become effective for the corresponding element. You can determine and enter a suitable value.

**Auto\_Nominal**

If you enter **<YES>**, a **RES NOMINAL** control data line will be inserted in front of each geometric element during learn (parts) programming. This does not apply if a nominal was entered beforehand.

**Warning limit**

If the point-element distance (i.e. the distance between the last point probed and the element displayed as an intermediate result) exceeds the value entered in the table as the warning limit, a signal will sound. The following error message will then also be displayed:

**NOTE**

**Warning limit has been exceeded.**


You can then delete this value with **<Correction>** or accept it for the measurement.




## Probing correction <DI 1187>

### Application

Used to correct the coordinate values of probing points. If you call <DI 1187> and enter correction values, the coordinates of a subsequently probed point will be corrected by the value entered.



DI	Pull-Down-Menu	Pictogram
1187	Elements	
CORRPRB	Data acquisition	
a21	Probing correction...	

Dialog

Probe correction

D	Correction in x direction	0.000
	Correction in y direction	0.000
	Correction in z direction	0.000

* YES	NO		*		TERMIN
BACK					INFO

### Procedure

Enter the required value and close the dialog window with <TERMIN>. The point element window is then displayed and you can perform a probing.

The correction values are displayed on the screen.

### NOTE


The probing correction affects only the next point probed. Recalled points or other geometric elements are not corrected.

### Application examples

#### Example 1

Output of a point located  $\delta$  mm above the contact point:


Call <DI 1187>, enter correction value ( $-\delta$ ) and then probe.



**Example 2**

Output of point P' when probing a surface rotated by angle  $\alpha$ :


Call <DI 1187>, enter correction value ( $\Delta$ ) and probe.



**Example 3**

Output of contact point P' when probing a surface rotated by angle  $\phi$ :


Call <DI 1187>, enter correction value ( $-\Delta$ ) and probe.



**Example 4**

Output of contact point P, when probing with <FIXED PLANE>:

Call <DI 1187>, enter correction values  $\Delta X$  and  $\Delta Y$ , then probe.



## Correction of probing errors

### Application

There are three ways to correct probing errors in UMESS:

- **Deleting individual measuring points**

As long as an N point program or the function "**Collect points in file**" is active, individual measuring points or function calls can be deleted with the **<Correction>** key. Pressing the **<Correction>** key deletes the last probing point or the last function call (**<RECALL>**, **<FILEVAL>** etc.) within an N point program. By pressing the key repeatedly, you can move back to the N point program call step by step.

Example:

```
CIRCLE PRB POINT 1 → CIRCLE PRB POINT 2 →
CIRCLE PRB POINT 3 → <CORR> →
CIRCLE PRB POINT 2 → <CORR> →
CIRCLE PRB POINT 1
```

- **Deleting the N point program completely**

As long as an N point program or the "Collect points in file" function is active, all measured points and the program call can be deleted with **<Cancel>**.

The N point program must be recalled for a new measurement.

- **Overwriting a geometric element**


An N point program which has already been terminated can be overwritten by a repeat measurement

To do this, you first must reset the address counter with **<DI 1690>** (**>** „Setting the address counter to a random address **<DI 1690>**“ on page 6-8). The address with the incorrect measurement will then be overwritten by the new measurement.

## Self-centering probing (for the measuring probe head only)


### Application

The probe head is normally unclamped only in the probing direction. This means that the probe head can move only in the direction in which the joystick is deflected.





### Clamping release

For self-centering probing in tapered bores, tooth spaces or V slots, the clamping of one or both of the other axes must be released.




**Procedure**

Now set the **force direction** and **clamping** (see the relevant control console operating instructions).



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1502 VECFORCE	CMM Mode vectorial measuring force...	



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1551 PRBMOD	CMM Mode Probe head...	

**Set the operating mode, measuring forces and clamping on the control panel!**

Accept settings with **<TERMIN>**.

**NOTE**

The force direction selected must always coincide with the probing direction.  
Don't forget to switch back to the **vectorial** operating mode after finishing the self-centering probing. This can be done with **<DI 1502>**.


## Changing the allocation of joystick deflection to travel movements <DI 1509>

### Application

After calling <DI 1509>, you can (re)define the allocation between deflection of the joysticks and the travel direction of the probe head. This is useful e.g. if you want to locate the control panel to one side of the machine instead of at the front so that you can better observe travel movements.

### Prerequisite

This function can be executed only with a 16-bit control.



Dialog

Joystick assignment to CMM axes

Joystick	+X	+Y	+Z	+R
<input type="checkbox"/> C moves CMM in	+X	+Y	+Z	+R

		*	BAS FCT	REPEAT		TERMIN
BACK	PRE MENU					

### Data boxes

Define the required allocation. If you enter a space (blank), the corresponding axis will be deactivated.

**BAS FCT**

Restores the default initial status.


## Travel in the workpiece or control coordinate system <DI 1506>

### Application

With <DI 1506> you can assign the travel movement of the probe head to different coordinate systems.

### Prerequisite

This function can only be executed with a 16-bit control.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1506 JSTANG	CMM Mode Travel WP/control syst. ...	

### Joystick travel system



### Softkeys

Control in machine coordinate system

Control in control coordinate system (W-Pos)

Control in workpiece coordinate system


See DSE / LX operating instructions

## Displaying workpiece coordinates <DI 1507> <DI 15250>

### Application

It is often useful to know the current position of the probe when it is traveling along the workpiece. The center point coordinates of the selected probe are therefore displayed in the workpiece coordinate system.

### Display of workpiece coordinates on the control panel



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1507	Service General Coordinate display CP	

### Probe change

If you change probes on the control panel, the display will show this immediately.




### Disadvantage

No other function can be called as long as the coordinate display is active on the control panel.



Other functions will be accepted only after you actuate the **<CANCEL>** key.

### Displaying workpiece coordinates on the monitor



### Window size

Unfortunately, the size of the display can not be changed.

### Advantage

All other functions can be called even while the display is active.

### Changing probes

If you change probes on the control panel, the display will be updated only after a probing has taken place!

### Closing the window

If you call **<DI 15250>** again, the display closes.




# Creating/evaluating point collection files

## Collecting points in a file <DI 1100>

### Application

<DI 1100> stores points for calculation of a geometric element in a file. The geometric element for which these points are collected is irrelevant. It is thus possible to collect points for different elements using various measuring modes (manual probing, scanning etc.) and evaluate them later on with the <File evaluation> function (▶ „File evaluation“ on page 10-22).



DI	Pull-Down-Menu	Pictogram
1100	Elements	
FILE	Data acquisition	
	Collect points in file. ...	

### Procedure

The points can now be acquired by manual probing or one of the softkey functions (▶ „Probing possibilities“ on page 10-5).




Branches to the dialog window for VAST functions.



First you must select either the **VAST Circle** function or the **VAST surface** function for probing point acquisition (▶ „Geometric elements“ on page 11-1).





**Filename**

The default name offered in the Filename box can be changed.

The prefix "**PKT**" and the suffix "**\_U**" are added to the filename so that it has a total of 14 characters, after which the filename is stored in the **/home/zeiss/UG** directory on the hard disk.

**File evaluation**

**Application**

You can use this function to calculate geometric elements from measured points which have been stored in a point collection file.

**Procedure**

- Call a geometric element (e.g. **<CIRCLE>**, **<SURFACE>** etc.   
     > „Geometric elements“ on page 11-1)
- Press the **<Measure/Eval>** **<File evaluation>** softkeys.

Dialog																			
Recall of points for geometry element calculation																			
		Filename				From point no.				To point no.				Step width					
C		CONEFILE				1				1				1					
						1				1				1					
						1				1				1					
						1				1				1					
						1				1				1					
						1				1				1					
												* COORD				TERMIN			
BACK																INFO			

**Explanation**

Points from up to 5 different collection files can be used to calculate the geometric element (enter filenames).

### Selection by coordinates

Depending on the geometric element involved, you can select points either by their numbers or by their coordinates. You can change dialog windows by pressing the <COORD> or <PT NO.> softkey.

Dialog

Recall of points for geometry element calculation

	Filename	From X	To X	From Y	To Y	From Z	To Z
C	CONE FILE	-25.054	-23.675	-17.656	6.272	-100000.00	100000.000

BACK			

\*

PT NO.			TERMIN
			INFO

**Application tip**

If more than 5 point files must be used to form an element, proceed as follows:

<DI 1100>

Call **Collect points in file** and combine 5 of the point files to form a new file.

**Call element**

Perform file evaluation in the element concerned.

**Example**

Points from different point collection files must be evaluated to calculate (reconstruct) a cone. Points 1, 3, 5 and 7 and 15 to 28 from the **CONE\_FILE** as well as points 1 to 320 from the **SCANNING** file are required for this purpose.

Dialog

Recall of points for geometry element calculation

	Filename	From point no.	To point no.	Step width
<input type="checkbox"/> C	CONE FILE	1	7	2
	CONE FILE	15	28	1
	SCANNING10	1	320	1
		1	1	1
		1	1	1

--	--	--	--

\*

COORD			TERMIN
-------	--	--	--------

BACK			
------	--	--	--

			INFO
--	--	--	------

Press <TERMIN> to close the dialog window. The element is calculated and output to the record.



**NOTE**

Recalled points and probed points must not be mixed.

## Data transfer in VDA format <DI 1166>

### Application

Individually probed or scanned points (in probe center coordinates) can be converted to VDA format and then transferred to other systems.



#### DI

1166

#### Pull-Down-Menu

ElementS

Data acquisition

Points to VDA...

#### Pictogram

### Procedure

- After calling <DI 1100>, collect the points in a file (stored internally in machine coordinates). The filename must be specified after terminating with <TERMIN>.
- Call <DI 1166> and specify the name of the point collection file created with <DI 1100>.  
The data is converted to VDA format and the current workpiece coordinate system.

#### NOTE

The point collection files are stored in the **/home/zeiss/UI** directory of the hard disk (**VDA<Filename>\_\_B**).

## Finding kink points <DI 1189>

**Application**


Scanned contours may be made up of lines and/or arcs of circles. Prior to further processing with N-Point programs, point sets of this type must be divided into segments. Separation into segments always takes place at points where the program detects a distinct change in direction: e.g. line/arc of circle or arc of circle/arc of circle transitions.

**Prerequisite**

The points must be probed in a continuous sequence.

**Procedure**

- Save points to a collection file <DI 1100>.
- Probe contour in the scanning mode.
- Call <DI 1189> before each N-point program.
- Call N-point program. Access points from collection file by calling <File evaluation>, select segment.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1189	Eval Additions Kink recognition...	

Dialog

Kink determination with next geometry element

<input type="checkbox"/> I	No. of points per segment	<input style="width: 50px;" type="text" value="5"/>
	Form tolerance per segment	<input style="width: 100px;" type="text" value="0.30000"/>

* YES	NO	*	TERMIN
BACK			INFO

**Data boxes**

**Number of points per segment**

This input determines the minimum number of points per segment. Kinks with fewer points are ignored.

**Form tolerance per segment**

Kinks which lie within the specified form tolerance are ignored. A kink will be registered only if the form tolerance specifying the minimum number of points per segment is exceeded.

**Procedure**

The point set of the preselected file is searched through using the kink determination parameter. The segments found are then offered for selection. Use **<YES>/<NO>** to select one or more segments. Then start the calculation of the N-point element with **<TERMIN>**.

Dialog				
Segment selection				
		Segment no.	from point	to point
<input type="checkbox"/>	<input checked="" type="checkbox"/>	1	1	29
<input type="checkbox"/>	<input type="checkbox"/>	2	30	33
<input type="checkbox"/>	<input type="checkbox"/>	3	34	48
<input type="checkbox"/>	<input type="checkbox"/>	4	49	52
<input type="checkbox"/>	<input type="checkbox"/>	5	53	56
<input type="checkbox"/>	<input type="checkbox"/>	6	57	78
<input type="checkbox"/>	<input type="checkbox"/>	7	79	139

* YES	NO			*					TERMIN
BACK									INFO

**NOTE**

This function can find max. 7 segments.




# Recalling results

## Recall of an address <DI 1301>

### Application

Certain functions in UMESS always refer to the last element in the measurement record. With the <RECALL> function you can reprint any previously determined result and thus place it in the last position of the measurement record.



Dialog

Recall of one result

Result name

Recall of address/name :

			* <input style="width: 80px;" type="text" value="TERMIN"/>
BACK			INFO

### Data boxes

#### Result name

Enter the name you want to assign to the recalled element here (follow rules [▶ „Allocating names“ on page 5-9](#)).

#### Recall of address/name:

Specify the element you want to recall here.

Your options include:

– **Absolute recall**

Enter the name or address under which the element you wish to recall has been saved in the measurement record.

– **Relative recall**

Calculate the difference between the address printed last and the address of the required element, add 1, and enter this sum with a "-" sign. In this way, you can recall an element regardless of the current count on the address counter. A relative recall makes sense, e.g. when repeating program steps in loops, since an absolute recall would always access the same geometric element in such cases.

**Comparison of absolute and relative recalls:**

ADR address counter, absolute recall	Relative recall
20	-4
21	-3
22	-2
23	-1

A box labeled "Last ADR in the record" points to the value 21 in the first column.

**NOTE**

If several different functions are to be used for a single result, the result must be recalled before every function.

**Additional inquiry**

If the workpiece coordinate system has been changed between the definition and recall of an element, the following inquiry will be displayed:

**Current coordinate system?**


**YES**

The data of the element recalled is converted to the currently valid workpiece coordinate system.

**NO**

The data is retained in the original coordinate system.

The type of transformation selected is indicated in the measurement record:



## Recall of several elements

**Application**

In the **Recall of several elements** dialog window individual results previously printed in the measurement record can be linked to construct a new element.

**Function call**

The dialog window is called by actuating the <Recalls> softkey within an element. Aufgerufen wird die Eingabemaske über den Softkey <Rueckrufe> innerhalb eines Elementes.

**Data boxes**

**from address/name**

Enter name or address of first element of area to be recalled.

**to address/name**

Enter name or address of last element of area to be recalled.

**Step width**


Distance between required elements within an area.

**NOTE**

- Elements can be recalled from a maximum of eight areas.
- The use of relative addresses is possible (▶ „Recall of an address <DI 1301>“ on page 10-29).

**Example**

Calculation of a new circle from 7 previously measured circles. The individual elements required are stored under the addresses 7, 8, 9, 14, 16, 18 and 20.



**Procedure**

- Call **<CIRCLE>** function.
- Press the **<Measure/Eval>** **<Recalls>** softkeys.
- Enter elements required:

	From address/name	to address/name	Step width
c	7 14	9 20	1 2

- Close dialog window with **<TERMIN>**.


## Travel commands

### Application

The current probe can be brought to an exactly defined target position using the travel commands. The target position can either be entered directly in workpiece coordinates or via travel paths.


### Input in workpiece coordinates

To be used with: **<POSITION>**, **<POS.RES>**, **<POS NORM>** (► „Positioning to workpiece coordinates <DI 1511>“ on page 10-37 to ► „Positioning to a normal vector <DI 1514>“ on page 10-40)



### Input as travel path

To be used with: **<STEP>**, **<REF PT.>** (► „Travel from the current position in fixed steps <DI 1515>“ on page 10-41, ► „Travel from a probing position in fixed steps <DI 1516>“ on page 10-43).





### Application

With every travel command it is possible to probe a point with a search run. Before the machine reaches the target position, it is switched to probing speed. The machine then travels at this speed until a probing occurs. Probing search paths can be defined before and after the nominal position with the probing parameters (► „Probing parameters <PROBE P>“ on page 6-11).

## Search run

The search run is always performed in the direction traveled by the machine to reach the target position (exception: positioning to normal vector  $\triangleright$  „Positioning to a normal vector <DI 1514>“ on page 10-40).



- P<sub>0</sub>: Initial position
- P<sub>1</sub>: Position before nominal probing point. From here the machine switches to probing speed.
- P<sub>2</sub>: Target position (nominal probing position)
- P<sub>3</sub>: Position after nom. probing point. The error message: **No probing found** is displayed here.
- V<sub>1</sub>: Probe search path before nom. position
- V<sub>2</sub>: Probe search path after nom. position

V<sub>1</sub> and V<sub>2</sub> can be set with <DI 1661>, <PROBE P> ( $\triangleright$  „Probing parameters <PROBE P>“ on page 6-11).

## Prog mode

In learn (part) programming, the travel path required to reach the target position and the following search run are stored in the control data as a single travel command.





## Positioning to workpiece coordinates <DI 1511>

The target position must be entered in workpiece coordinates.

### Application possibilities

- Fine positioning in the workpiece coordinate system for CNC programs
- Probing defined points on surfaces
- Positioning the probe in narrow bores
- Checking the current workpiece coordinate system.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1511 POSITION	CMM Travel commands Position...	

Dialog

Position in cartesian coordinates

with probing  \*  
 or coarse position  or precision position  or safety position

Coordinates:    X     Y     Z

YES	NO	CYL COOR	SPH-COOR	*				TERMIN
BACK	PRE MENU							

**Data boxes**

with probing

- <YES>  
Probing with search run,
- <NO>  
Intermediate position

or coarse position  
or precision position  
or safety position

These boxes are currently treated as precision positions.

Coordinates:  
X ..... Y ..... Z .....

Input of the target position in the workpiece coordinate system. The position is traveled to with <TERMIN>.



With these softkeys you can change between:

- cartesian coordinates,
- cylinder coordinates and
- sphere coordinates.


**Positioning to a result <DI 1513>**

Application

This function is called to position the current probe to the coordinates of the last result in the measurement record.

Application possibilities

- Fine positioning in the workpiece coordinate system in CNC programs
- Positioning the probe to the center of a bore
- Travel to a symmetry point
- Probing of defined points



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1513	CMM	
POS-RES	Travel commands	
a97	Pos. to result...	

Dialog																															
<p>Position on result</p> <p> <input type="checkbox"/> Y with probing <input type="checkbox"/> *              or coarse position <input type="checkbox"/> or precision position <input type="checkbox"/> * or safety position <input type="checkbox"/> </p> <p>Coordinates :    X <input style="width: 80px;" type="text" value="-15.6789"/>    Y <input style="width: 80px;" type="text" value="68.9015"/>    Z <input style="width: 80px;" type="text" value="-47.8901"/></p>   <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="border: 1px solid black; padding: 2px;">* YES</td> <td style="border: 1px solid black; padding: 2px;">NO</td> <td style="border: 1px solid black; width: 40px;"></td> <td style="border: 1px solid black; width: 40px;"></td> <td style="padding: 0 10px;">*</td> <td style="border: 1px solid black; width: 40px;"></td> <td style="border: 1px solid black; width: 40px;"></td> <td style="border: 1px solid black; width: 40px;"></td> <td style="border: 1px solid black; width: 40px;"></td> <td style="border: 1px solid black; padding: 2px;">TERMIN</td> </tr> <tr> <td style="border: 1px solid black; padding: 2px;">BACK</td> <td style="border: 1px solid black; padding: 2px;">PRE MENU</td> <td style="border: 1px solid black; width: 40px;"></td> <td style="border: 1px solid black; width: 40px;"></td> <td></td> <td style="border: 1px solid black; width: 40px;"></td> <td style="border: 1px solid black; width: 40px;"></td> <td style="border: 1px solid black; width: 40px;"></td> <td style="border: 1px solid black; width: 40px;"></td> <td style="border: 1px solid black; width: 40px;"></td> </tr> </table>												* YES	NO			*					TERMIN	BACK	PRE MENU								
* YES	NO			*					TERMIN																						
BACK	PRE MENU																														

**Data boxes**

**with probing**

- <YES>  
Probing with search run,
- <NO>  
Intermediate position

**or coarse position  
or precision position  
or safety position**

These boxes are currently treated as precision positions.

**Coordinates:**  
X ..... Y ..... Z .....

Input of target position in the workpiece coordinate position. Travel to target position is started with <TERMIN>.

**NOTE**


- The element concerned must be located under the last address in the measurement record when the function is called.
- By including the <FORMULA> program (► „Determining the minimum and maximum of measurement results <DI 1341> <DI 1343>“ on page 12-40), it is possible to probe defined points based on the results of measurements.


## Positioning to a normal vector <DI 1514>

### Application

With this function a space point, i.e. a point on any curved surface, can be probed in the normal direction.

The direction of the normal also must be entered. The specified target point is automatically probed during the search run.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1514	CMM	
POSNORM	Travel commands	
	Pos. in vector direction...	

Dialog									
Position on normal									
<input type="checkbox"/> D	Coordinates:	X	<input type="text" value="561.4160"/>	Y	<input type="text" value="-670.2360"/>	Z	<input type="text" value="-274.9771"/>		
	Normal:	Nx	<input type="text" value="0.0000"/>	Ny	<input type="text" value="0.0000"/>	Nz	<input type="text" value="0.0000"/>		
* YES			NO			* REPEAT			TERMIN
BACK			PRE MENU						INFO

### Data boxes

#### Coordinates:

X ..... Y ..... Z .....

Enter the nominal position of the contact point in the direction of the normal in cartesian coordinates.

#### Normal:


Nx..... Ny..... Nz.....


Enter the direction of the normal. Travel to the position is initiated with <TERMIN>.

## Travel from the current position in fixed steps <DI 1515>

### Application

By calling the <STEP> function, the probe can be moved out of the current position in one or more axes. In this way a uniform matrix of probings can easily be realized. With the measuring probe head, probe travel while in contact can also be performed via the <STEP> function.



DI	Pull-Down-Menu	Pictogram
1515	CMM	
STEP	Travel commands	
	Step...	

Dialog

Step in cartesian coordinates

with probing  \*  
 or coarse step  or precision position  or safety position

Coordinates: X  Y  Z

YES	NO	CYL COOR	SPH-COOR	*	<input type="text"/>	<input type="text"/>	<input type="text"/>	TERMIN
BACK	PRE MENU	<input type="text"/>	<input type="text"/>		<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>

### Data boxes

- with probing
- <YES>  
Probing with search run,
- <NO>  
Intermediate position

or coarse position  
or precision position  
or safety position

Coordinates:

X ..... Y ..... Z .....

CYL COOR

SPH-COOR

These boxes are currently treated as precision positions.

Input of target position in the workpiece coordinate system. Travel to the position is started with **<TERMIN>**.

With these softkeys you can change between:

- cartesian coordinates,
- cylinder coordinates or
- sphere coordinates.


### NOTE


- The positioning errors accumulate following repeated program calls in the manual mode.
- In the CNC and PROG modes, a step away from a probing is always referenced to the center point of the probe ball in the probing position, even during automatic backaway (trigger probe head). The backaway or retract distance has no influence on the step matrix.

## Travel from a probing position in fixed steps <DI 1516>

**Application**

By calling the <REF STEP> function, probe travel can be performed by a defined distance. The travel path entered is here referenced to the coordinates of the last probing point. This makes it possible to program CNC travel paths which are referenced to an individual probing point for every workpiece.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1516	CMM	
REF STEP	Travel commands	
	Reference point/step...	

Dialog

Step in cartesian coordinates

Y with probing  \*  
 or coarse step     or precision position     or safety position   

Coordinates:    X     Y     Z

YES	NO	CYL COOR	SPH-COOR
-----	----	----------	----------

\*

			TERMIN
--	--	--	--------

BACK	PRE MENU		
------	----------	--	--

--	--	--	--

**Data boxes**


Operation as with <DI 1515>

### NOTE

- The function must be called with the probe in contact.
- The reference point defines a temporary control coordinate system. I.e. all subsequent travel commands executed with the **<STEP>** function refer to the reference point. The reference to the W-POS system is reestablished by setting an intermediate position.

### Example

Measurement of the diameter of a conical bore at a defined distance (H) from the base of the bore.



### Procedure

- Probe base of bore
- Call **<REF STEP>** with the probe in contact. Enter distance H.
- Call **<CIRCLE>** and probe the required points with the **<STEP>** function.
- After completing the circle measurement, reestablish a reference to the W-POS system by setting an intermediate position.




## Additional information


### Extreme values <DI 1460>

#### Application

If the minimum point number is exceeded, an N POINT ELEMENT will be mathematically fitted to the point set so that the sum of the errors squared is reduced to a minimum (Gauss method of least square errors).



Immediately after calculating a geometric element, the positions of the extreme values can be output with <EXTREME> if the minimum number of probing points has been exceeded. The positions of the MIN and MAX values are output in workpiece coordinates.




<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1460	Eval	
EXTREME	Additions	
a59	Extreme values...	

#### NOTE

The extreme values (L-EXTREME and U-EXTREME) are output in two consecutive record addresses. The specified nominals apply for both extreme values. If individual nominals are to be assigned to each extreme value, this can be done by recalling every address: Specify nominals with <DI 1459>. Then recall an extreme value (output as POINT).



The actual probing points of the extreme values are output.



The coordinates of the probe ball center point at the extreme probing points are output.


### Form error <DI 1449>

**Application**


This function calculates the form error of geometric elements.

**Prerequisites**

- The minimum number of probings was exceeded while measuring the element.
- The element in question must be the last one in the record (measured or via <RECALL>).



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1449	Eval	
FORM	Form	
a93	Form dev. ...	



### Explanation of dialog

#### Tolerance zone cylinder?

This inquiry appears only if the last element in the record is a **LINE**. If **<YES>** is selected, the calculation will be based on a cylindrical tolerance zone; if **<NO>** is selected, a cube shaped tolerance zone will be used.


#### NOTE

If a **NOM-ACT COMPARISON** is to be performed for the form deviation, the permissible form deviation must be entered in line D. In this case, a zero must be entered for both the upper and the lower tolerance.

### Supplementary coordinates <DI 1262>

#### Application

For point probing, only the coordinate in the probing direction is output. The remaining coordinates can also be output by calling **<XYZ>**.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1262	Eval	
XYZ	Additions	
	XYZ supplement	

### NOTE


- The result is not assigned a separate address or name.
- The function must be called immediately after the element concerned (not after <RECALL>).

### Mating size (sigma factor) <DI 1681>

#### Application

If the minimum number of points is exceeded during an N point program, the best fit geometric element will be calculated (according to the Gauss method for standard elements).

The actual contact points deviate from the calculated ones depending on the nature of the surface probed.






#### Mating size

The calculated geometry is mathematically displaced to obtain the mating size (actual contact points). The direction of displacement is always away from the material.

The displacement value is calculated from point spread  $S$  and a factor  $0 \leq \dots \leq 3$ . This factor must be empirically defined for each workpiece (the macrostructure of the workpiece surface and the diameter of the probe ball may influence the required displacement factor).

If the point spread has a normal distribution, the actual contact points and the calculated geometry will coincide provided that the displacement factor reaches a value of 3.

<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1681	Elements	
SIGMA	Data acquisition	
	Sigma displacement...	

Dialog

Sigma displacement

Mating size (SIGMA) (0 <= SIGMA <= 3) 0.0000

\*   
 CANCEL

**Procedure**

Enter the required sigma displacement factor. Values of 0 to 3 can be selected.

Each change of the sigma factor is documented

**0 ⇒ outp. of normal, SIGMA = 0,**

**0 < sigma factor ≤ 3 ⇒ Output mating size, calculation with ....SIGMA**


All subsequent calculations of geometric elements are corrected with the selected factor if the minimum number of probeings is exceeded.

Normal output is selected by entering SIGMA factor = 0.

### Selecting the reference plane <DI 1680>


**Application**

In a spatial coordinate system, a distinction can be made between three measuring planes, which are here designed as follows:



**Reference plane**

One of these planes is always the reference plane for spatially defined elements. Normally the computer determines the reference plane from the position of the respective geometric element (plane = 0). In special cases, however, another reference plane may be required. In these cases the required reference plane can be selected by entering <FIXED PLANE>.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1680	Elements	
FIXPLA	Data acquisition	
	Fixed plane...	

**Procedure**

The current reference plane is displayed. Enter the required reference plane and confirm with **<Enter>**.

Fixed plane

I PLANE = 0 (AUT=0, YZ=1, XZ=2, XY=3, XYZ=10)

\*

CANCEL

**Meaning of codes**

- 0** The computer defines the reference plane for every geometric element (default setting).
- 1, 2, 3** The corresponding plane is the reference plane for all following measurements.
- 10, 11** The points probed are output in three coordinates and are *not* corrected by the amount of the probe ball radius.
- 12, 13** The reference plane is defined by the 2nd number (see above). E.g.: An input of "10" means that the computer defines the reference plane (see "0") and 3 coordinates are output for the probing points.

**NOTE**

The setting selected here applies until the next time it is changed with **<FIXED PLANE>**.

The following table gives an overview of the application possibilities:

PROGRAM	FIXED PLANE 0	FIXED PLANE		
		1	2	3
<b>POINT</b>	OUTPUT OF PROBING COORDINATE WITH CORRECTION OF $R_k$ IN THE DIRECTION OF THE COORDINATE SYSTEM	OUTPUT OF COORDINATE PAIRS REGARDLESS OF PROBING DIRECTION WITHOUT CORRECTION OF $R_k$		
		Y Z	Z X	X Y
<b>LINE</b> <b>CYLINDER</b> <b>CONE</b>	REFERENCE AXIS SELECTED SO THAT PROJECTED ANGLES ARE $<45^\circ$ (REGARDLESS OF PROBING DIRECTION)  THE RESULTS OF A PREVIOUSLY SELECTED F-PLANE CAN BE OUTPUT AS SHOWN ON THE RIGHT BY PRESSING <RECALL>	COORDINATES OF PENETRATION POINT		
		Y Z	Z X	X Y
		3RD COORDINATE BECOMES REFERENCE FOR A1/A2		
		A1 Y/X A2 Z/X	Z/Y X/Y	X/Z Y/Z
<b>SURFACE</b>		X A1 Y/X A2 Z/X	Y Z/Y X/Y	Z X/Z Y/Z
<b>CIRCLE</b> <b>ELLIPSE</b>	ONLY THE PLANE CODE NO. OF THE MEASURING PLANE MAY BE SELECTED FOR THESE MEASURING PROGRAMS			
<b>POLAR</b>	POLAR ASSUMES ACCESS TO 1 COORDINATE PAIR.. IF 3 COORDINATE VALUES ARE GIVEN (SPHERE; SURFACE-AXIS PENETRATION POINT); THE COORDINATE PAIR MUST FIRST BE SELECTED BY FIXED PLANE.			




# Interpretation of the measurement results

## Projected angles

**Definition**

The direction of an axis in a spatial coordinate system is defined by two projected angles. A projected angle is the angle which results in a workpiece plane when viewed from the 3 axis.

**Example**



**Reference axis**


The reference axis is the coordinate axis which is common to both projection planes (the Z axis in this example).

**Representation in UMESS**

If a measuring result obtained in UMESS contains a line, an axis or a normal, two projected angles will always be output. The projection planes (and therefore the reference axis) are

- determined by the computer (<FIXED PLANE> = 0)
- or defined by calling <FIXED PLANE> (> „Selecting the reference plane <DI 1680>“ on page 10-50).

**Output example**




**Angles A1 and A2**

A1 and A2 refer to different projection planes depending on the reference axis. Definition of A1 and A2:

Reference axis	Angle	Projection plane
X	A1 A2	Y / X Z / X
Y	A1 A2	Z / Y X / Y
Z	A1 A2	X / Z Y / Z

Move the zero point of the projection plane to the axis. Then define the +/- signs according to the following diagram:



## Dispersion (standard deviation)

### Best fit

If the minimum number of points is exceeded, the N POINT ELEMENT is mathematically fitted in the point set so that the sum of the errors squared is kept to a minimum (Gauss method of least square errors).

In this case the following is output in the measurement record:

- Standard deviation S of the probing points
- The probing points with the greatest distance from the calculated element (vertical distance) including the number of the probing.

	<b>SURFACE</b>	<b>Z</b>	<b>132.102</b>				
	<b>X / Z</b>	<b>A1</b>	<b>25.302</b>				
	<b>Y / Z</b>	<b>A2</b>	<b>-10.286</b>				
	<b>7P S/MIN/MAX</b>		<b>0.596</b>	<b>(4)</b>	<b>-0.545</b>	<b>(1)</b>	<b>0.411</b>
(1)							
			(2)	(3)	(4)	(5)	(6)

- (1) Number of probing points
- (2) Standard deviation (S)
- (3) Number of the probing with the greatest distance from the calculated element in the negative direction.
- (4) Greatest deviation in the negative direction (minimum value).
- (5) Number of probing with the greatest distance from the calculated element in the positive direction.
- (6) Greatest deviation in the positive direction (maximum value).

## "No result" function

### Definition

In the safety mode ( $\triangleright$  „Continuation after a missing bore <DI 1080>“ on page 16-32) a CNC program must be able to continue running even if a bore which should be probed is missing. Also, not every error should result in cancellation of the CNC run. And that is the reason for the **No result** function.

This result occurs if an element can not be calculated, resp. if **No result** is recalled or the element is) linked with other results.

### Special case

The CNC run will be canceled and an error message will be output if no result is obtained for the following functions:

- Zero point <DI 1701>
- Rotate plane <DI 1702>

- Rotate plane + 1 element <DI 1703>
- Rerotate to distance <DI 1705>
- Rotate space <DI 1706>

# Chapter

# 11

## Geometric elements

---

### This chapter contains:

General .....	11-2
POINT <DI 1101>.....	11-6
CIRCLE <DI 1104>.....	11-9
ELLIPSE <DI 1108>.....	11-19
LINE <DI 1102>.....	11-22
SURFACE <DI 1103>.....	11-27
CYLINDER <DI 1106>.....	11-36
CONE <DI 1107>.....	11-41
TORUS <DI 1109>.....	11-46
SPHERE <DI 1105>.....	11-49
Circle segment <DI 1114>.....	11-53
3D circle <DI 1154>.....	11-58
Theoretical elements .....	11-61
Flatness macro <DI 1169>.....	11-63

## General

### Definition

In UMESS measurement results are output in the form of defined geometric elements. With the exception of the **POINT** element, all other required geometric elements must be called before probing. The element must subsequently be defined by probing. Certain rules apply to the different elements which are explained in the following text.

### NOTE


When calculating an N point element, up to a maximum of 32,766 points can be edited.

### Procedure

- Call the N-point program.
- Select the probe number.
- Obtain measuring points via single probings, scanning, or existing data.
- Terminate evaluation with **<TERMIN>**.

## Input and dialog window for N point programs

A dialog window is displayed when the N point program is called (as explained based on the circle program in the following example). This window enables convenient measurement and evaluation:



Description

See [„Probing possibilities“ on page 10-5](#)

### Macro selection


Box description

The macro which has just be selected is displayed in the **Macro selection** box.

It is also used as an data box for branching to the macro input.

If an existing macro is to be selected:

By clicking in the **Macro selection** display box, you can branch to the window for macro selection. There you can click on the required macro and close the window with **<Termin>**.



If a new macro is to be created



By clicking in the **Macro selection** display box, you can branch to the window for macro selection. Then you can branch to the macro input window by clicking on the **<Input>** softkey. (Description of the dialog window for each individual element)


Then transfer the new macro by clicking the **<Store>** box, exit the window by clicking the **<Previous>** box.



If a defined macro is no longer needed, it can be removed by actuating the **<Delete>** softkey.

## NOTE

Define a **clearance height** above the workpiece surface which can be traversed by the probe without a collision via an intermediate position.





Then the location of the element to be measured is determined by auxiliary probings.

The macro programs described below require only a minimum number of auxiliary probings to promote operating convenience. The prerequisite for a reliable program run is therefore that the axes of the elements to be measured are tilted only slightly in reference to the machine coordinates. This applies in particular to the circle, cylinder and cone macro programs.


**NOTE**

The travel paths are based on the the W-pos coordinate system!

**Entering the inner/outer code <DI 1179>**

**Application**

You can coercively specify whether a subsequent geometric element (e.g. circle, ellipse, cone or cylinder) will be displayed as an outer element or an inner element.




Dialog									
Specify internal-external code of next geometry element									
<input type="checkbox"/> Y	inner	<input type="checkbox"/> *							
	outer	<input type="checkbox"/>							
* YES NO				*				TERMIN	
BACK								INFO	

# POINT <DI 1101>

## UMESS offers two ways to probe single points

- **Without a previous program call**  
 If a probing is performed without a previous program call, a **POINT** will be output as a result in the measurement record. The result is not assigned a result name.
- **Call of <DI 1101>**  
 You can edit the default name for the following point probing by calling the function <DI 1101>. If several points are probed while this function is activated, only the last point will be accepted.



Point

Macro selection

Probe no.  ▲  
▼

Element name

Points measured: 0

Measure/Eval.

VAST

CMM...

Nominal


I-Pos/Prb

Theor.element


Termin
Correction
Cancel
Help

**Probing correction**


The calculated probe ball center point is corrected by the amount of the radius of the probe ball so that the actual contact point is output as the coordinate value:

**NOTE**

- The correction of the probing point occurs in the probing direction parallel to the workpiece coordinate system. The contact point and printed coordinate thus agree only if the probed surface runs parallel to the workpiece coordinate system.
- The angle of an inclined surface can be calculated if the surface is probed at two points with the probe moving in the same direction (► **„Calculation of the rotation and tilt angle <DI 1204>“ on page 13-2**). The two points which are output do not coincide with the contact points in this case; however, the connecting line which passes through both points runs parallel to the geometric element..
- With the measuring probe system, more points can be acquired by probing with the probe in contact (with the workpiece). This can be done by simply pressing the "fire button" on the control panel.



### Measurement record printout




## CIRCLE <DI 1104>


### Measuring a circle manually


#### Application

This program enables the measurement of bores and shafts with a negligible deviation in parallelism from the workpiece coordinates. The program automatically differentiates between inner and outer diameters. You can perform a measurement with different probes as long as they all have roughly the same radius. The probes used must all be assigned to the same probe combination.



Minimum number of  
probings: 3





<b>DI</b>	<b>Pull-Down-Menu</b>	<b>Pictogram</b>
1104	Elements	
CIRC	Geometric elements	
	Circle...	

Circle
□
□

Macro selection  
8-Point-Bore

Probe no.

Element name

Points measured:  
4

Measure/Eval.

VAST

CMM...

Nominal

I-Pos/Prb

Theor.element

Termin
Correction
Cancel
Help

X	-0.0514	Distance point - element	-0.1000
Y	0.0996	Standard deviation s	0.0707
Z	0.1574	MIN point no.4	-0.0500
D	19.9010	MAX point no. 3	0.0500
		Range MAX - MIN	0.1000

**Measurement record printout**

```

CIRCLE_1
  11    CIRCLE I    X    13.1547
                          Y    14.9982
                          D    12.0036
          4P S/MIN/MAX    0.0006 (4) -0.0003 (2) .0003
    
```

## Measuring a circle semiautomatically

<b>Application</b>	The following macro enables you to measure a circle semiautomatically via individual probings.
<b>Function call</b>	<CIRCLE> <Macro selection> <Input>

Macro input Circle

**Name of macro:**

8 point bore

**No. of points**

**Start angle**

**Angle range**

**Slot width**

**Distance IP/PRB**

Store

Previous

Help

### Data boxes

<b>Name of macro</b>	Enter any name.
<b>No. of points</b>	The number of points entered here will be distributed evenly over the selected angle range.
<b>Start angle</b>	The reference angle is the abscissa. This angle (which must be positive) applies when viewing the measuring plane from the positive direction of the third axis.
<b>Angle range</b>	Positive angle= counterclockwise travel, negative angle = clockwise travel.

**Slot width** Width of the clearance zone which can be traversed by the probe without causing a collision. The slot width can be set to zero when measuring bores.

**Distance IP/PRB** Distance between the intermediate position and the probing point. This value must be considerably less than the slot width.

### Procedure

**Start macro** The macro must be started before each measurement.


**Intermediate position** A **clearance height** which can be traversed by the probe without causing a collision must be defined above the workpiece surface by setting an intermediate position.

**Probe two points** The measured element (part feature) must initially be obtained via **two manual auxiliary probings**. These two auxiliary points must lie in the same probing axis and be a certain distance apart.

**Third auxiliary point** The control then performs another probing at the symmetry point of the two manual probings.

The geometry of the circle is calculated (i.e. reconstructed) from these three points and the macro is executed.

The control information is calculated from the data of the macro input and the three probings:



### Scanning a circle with VAST

#### Application

In contrast to the conventional probing of individual points, VAST technology offers you fast multipoint measurement in a single scanning procedure.

You can optimize the measuring accuracy or speed of a measurement to meet the required measurement strategy.




**Function call**

If the <VAST> function box is clicked on when you select the geometric element **CIRCLE**, the following window will be displayed to define the rest of the measuring run.

**The remaining procedure is divided into three stages:**


- Defining the VAST mode by clicking on one of the eight pictograms
- Input of the values for nominal geometry and form tolerance
- Optional: Change of the specified setting values.
- Start VAST measurement by clicking on the <Termin> function box

### Description of the VAST icons




#### VAST level 1: Dimension, form and position, exact

VAST scanning with maximum accuracy for measuring form, dimension and position. The preset machine parameters are optimized for maximum accuracy.




#### VAST level 2: Dimension, form and position, fast

VAST scanning with high dynamics for measuring form, dimension and position. The preset machine parameters are optimized for short measuring times with the accuracy defined for VAST level 2.




**VAST level 3: Dimension and position, exact**

VAST scanning with maximum accuracy for measuring dimension and position. The preset machine parameters are optimized for maximum measuring accuracy.



**VAST level 4: Position, fast**

VAST scanning with maximum dynamics for position measurement. The preset machine parameters are optimized to achieve short measuring times with the accuracy defined for VAST level 4.



**VAST user mode 1 . . . 4**

VAST scanning with preselectable, user-specific machine parameters. The required parameters can be entered individually in a window after clicking on the corresponding function box [setting values] and saved under a freely selectable number.

**Function and data boxes**

**Cent. point X and Y**

Data boxes for the center point coordinates of the circle to be measured.

**Note:** Axes other than **X** and **Y** may also be specified here. The respective input is adapted according to the current intersection plane, which results depending on the probe (start probe) selected.

**Intersection height Z**

Data box for the height position of the circle to be measured.

**Diameter**

Data box for the nominal diameter (in mm) of the circle to be measured

**Form tolerance**

Data box for the form tolerance (in mm) of the circle to be measured

**Nominal value**

This function box is changed by clicking on **<YES>** or **<NO>**. If confirmed with **<YES>**, the nominal window is automatically activated following the measurement.

**Softkeys**



The VAST measurement run is started with this function box.



The plane in which scanning is to be performed can be changed here.



Function box for cancelling the VAST measurement routine and return to the previous window of the **"Circle"** geometric element.



After this function box is selected, the parameters for an individual measurement run can be defined and stored (see below).

Position, fast	
Speed	<input type="text" value="5.0"/>
Step width	<input type="text" value="0.050"/>
Number of points	<input type="text" value="0"/>
Filter W/R	<input type="text" value="0"/>
Form evaluation	<input type="text" value="No"/>
Dimension definition	<input type="text" value="No"/>
Position definition	<input type="text" value="No"/>
GDT plot	<input type="text" value="No"/>
<input type="button" value="Termin"/> <input type="button" value="Store"/>	

**Preassignment**

The upper three data BOXes contain optimum default values which are dependent on the diameters of the circles and probe balls and can be modified if required or for special applications.

**Note**

If this optimized default values are altered by the user, the accuracy specified by the manufacturer can not be guaranteed for the following measurements.

**Description of the input and function boxes****Speed**

Input and display box for the scanning speed (in mm/s).

**Step width**

Input and display box for the step width between points measured in the scanning mode (in mm).

**Number of pointsicon**

Input and display box for the number of points measured during the scanning run. This value results from the diameter and step width inputs.

**Filter W/R**

The measuring data is filtered according to the value preset here to separate the waviness profile from the surface roughness.

**Form evaluation**

In addition to a calculation of the mean diameter (according to Gauss), a form evaluation according to Chebyshev (minimum circle) can also be performed (see UMESS Option 3).

- **<NO>**  
Normal Gauss calculation
- **<YES>**  
Additional evaluation or circle calculation according to Chebyshev.

### Dimension definition

Possibility for additional calculation of the tangential surface (selection criteria for controlling the nominal-actual comparison, see UMESS Option 3).

- **<NO>**  
Normal dimension calculation according to Gauss
- **<JA>**  
Additional calculation of the tangential element

### Position definition

Possibility for additional calculation of the tangential surface (selection criteria for controlling the nominal-actual comparison, see UMESS Option 3).

- **<NO>**  
Normal dimension calculation according to Gauss
- **<YES>**  
Additional calculation of the tangential element

### GDT plot

Possibility of displaying a fast plot on the monitor. With the exception of the magnification (see UMESS Option 3) all of the parameters required are preset.

### Softkeys

**Termin**

Function box for concluding this input routine and return to the VAST window. The parameters entered beforehand can then be used for the current measurement but are not stored.


**Store**

If this function box is clicked on, the parameters defined beforehand can be stored as an application-specific routine under a VAST user pictogram(no.1 to no 4).


### 4-point circle <DI 1174>

**Application** A full circle (bore) can easily be measured semiautomatically by probing 4 points.

**Other names** The 4-point circle is also commonly called a "lazy man's circle".



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1174	Elements	
	Macros	
	4Pt circle	



**Procedure** Position the probe roughly in the center of the bore.

**NOTE** Make sure that the correct probe has been selected on the control panel.

**TERMIN**

After you press the <TERMIN> key, the probe initially executes a search run until it finds a probing. Then it moves back to the center of the bore at high speed and executes another search run to locate the next probing.

### **Inclined bores**


The 4-point circle function can also be used for inclined bores if the coordinate system has been correspondingly aligned and saved as a control coordinate system.

## ELLIPSE <DI 1108>

### Application


This program is used to probe geometric elements whose axes do not run parallel to the workpiece coordinate system. It is mainly suitable for determining the direction of geometric elements.

**Minimum number of  
probings: 5**



### Application example

After measuring two ellipses, the coordinate system can be tilted parallel to the line connecting the centers of the ellipses by calling <RO SPACE>.



DI	Pull-Down-Menu	Pictogram
1108	Elements	
ELLIP	Geometric elements	
	Ellipse...	

□ □
- Ellipse

Macro selection

Measure/Eval.

VAST

CMM...

Nominal

I-Pos/Prb

Theor.element

Probe no.

Element name

Points measured:

7

Termin

Correction

Cancel

Help

X	0.0381		
Y	-0.3062	Standard deviation s	0.4971
Z	0.1574	MIN point no.	6 -0.5049
D1	20.3041	MAX point no.	4 0.3873
D2	21.0014	Range MAX - MIN	0.8922
A1	169.7383		

**Output in measured record**

```

ELLIPSE_1
  11  ELLIP I      X      0.0381
                        Y      -0.3062
                        D1     20.3041
                        Y/X    A1 169.7383
                        D2     21.0014
6P S/MIN/MAX      .4971 (6) -.5049 (4) .3873
    
```



**NOTE**


- All points must be probed in a single plane section. Therefore make sure that the probe does not travel in the 3rd coordinate.
- The ellipse is very sensitive regarding the position of the probing points if they are probed within a small sector (results are widely dispersed).
- **D1** is the small ellipse diameter, **D2** the large.
- **A1** is the angle between the reference axis and the small ellipse axis:  
Reference axis of XY plane = X axis  
Reference axis of YZ plane = Y axis  
Reference axis of ZX plane = Z axis
- A differentiation is automatically made between inner and outer ellipses.


## LINE <DI 1102>


**Application**

This measuring program places a compensating line through the points probed.


**Minimum number of  
probings: 2**





DI	Pull-Down-Menu	Pictogram
1102	Elements	
LINE	Geometric elements	
	Line...	

Line



Macro selection  
Line-1

Probe no.

Element name

Points measured:  
3

Measure/Eval.

VAST

CMM...

Nominal

I-Pos/Prb

Theor.element

Termin

Correction

Cancel

Help

X	0.0000	Distance point - element		0.9047
Y	0.0403	Standard deviation s		0.3647
Z	0.3496	MIN point no.	3	0.1470
A1	0.0567	MAX point no.	2	0.2978
A2	-0.2252	Range MAX - MIN		0.1508

### Measurement record printout

```


LINE_1
  11  LINE      Y      0.0403
           Z      0.3496
           Y/X    A1    0.0567
           Z/X    A2    0.0567
           3P S/MIN/MAX .3647 (3) .1470 (2) .2978
    
```

### Application possibilities

- Defining the workpiece coordinate system (<RO PLANE>).
- Determining the direction of a V groove by self-centering probing (measuring probe system ➤ „Correction of probing errors“ on page 10-15).
- Calculating the angle of rotation if the form deviation of the surface to be probed is too large. In this case, with a high number of points, a mean line is calculated which compensates for a possible angle error resulting from unfavorably placed probing points.
- Calculating an axis from circle centers located one behind the other.

### NOTE

The **MIN** and **MAX** values from the line calculation are arranged radially to the best fit geometric element. For this reason, it is not possible to determine the straightness deviation by adding  $|\text{MIN}| + |\text{MAX}|$ . However the straightness deviation can be viewed in the individual planes instead.



### Semiautomatic measurement


You can measure a line semiautomatically using the macro function.

Function call

<LINE>

<Macro selection>

<Input>

Macro input line	
Name of macro:	<input type="text" value="Line-1"/>
No. of points	<input type="text" value="4"/>
Distance IP/PRB	<input type="text" value="5.00"/>
	
<input type="button" value="Store"/> <input type="button" value="Previous"/> <input type="button" value="Help"/>	

### Data boxes

- No. of points** The number of points entered is distributed uniformly between the two auxiliary probings.
- Distance IP/PRB** The distance between the intermediate position and the probing point must be such that the intermediate position lies well below the clearance plane.

### Procedure

- Start macro** The macro must be started by entering its name before each measurement.
- Intermediate position** A clearance height which can be traversed without collision must be defined above the workpiece surface by an intermediate position.
- Probe two points** The element (part feature) must then be defined by two manual auxiliary probings. They should designate the start and end point of the line to be probed. The control then executes the remaining probings based on the parameters thus specified.

### NOTE

For measuring machines with a trigger probe head, a collision may be reported following the first probing during the macro run. In this case, check to make sure that the probing parameters of <DI 1661> allow sufficient clearance between the preceding interme-

date position and the probing point (► „*Probing parameters*  
<*PROBE P*>“ on page 6-11).


## SURFACE <DI 1103>

### Measuring a surface manually

#### Application


After this function call, a surface is calculated from the following points.


Minimum number of  
probing: 3




#### Explanations

- The output angles are referenced to the surface normal, which is a line located perpendicular to the surface.
- The reference axis for the projected angles is the coordinate axis which forms the smallest angle with the surface normal. Any coordinate axis can be specified as the reference axis with **<FIXED PLANE>** (**>** „*Selecting the reference plane <DI 1680>*” **on page 10-50**).
- The coordinate value is output as the penetration point (in the example Z) where the reference axis penetrates the surface.



<b>DI</b>	<b>Pull-Down-Menu</b>	<b>Pictogram</b>
1103	Elements	
SURF	Geometrical elements	
	Surface...	

Line



Macro selection  
Surf-1

Probe no.

Element name

Points measured:  
4

Measure/Eval.

VAST

CMM...

Nominal

I-Pos/Prb

Theor.element

Termin

Correction

Cancel

Help

X	0.0000	Distance point - element		-0.0985
Y	0.0000	Standard deviation s		0.0660
Z	5.1423	MIN point no.	4	-0.0442
A1	0.0019	MAX point no.	3	0.0475
A2	-0.0128	Range MAX - MIN		0.0917

**Measurement record printout**

```

SURF_1
  11  SURFACE      Z      5.1423
        X/Z      A1     0.0019
        Y/Z      A2    -0.0128
        4P S/MIN/MAX  .0660 (4) .0442 (3) .0475
    
```



## Measuring a surface semiautomatically


<b>Application</b>	You can measure a surface semiautomatically using the macro function.
<b>Function call</b>	<SURFACE> <Macro selection> <Input>

=
Macro input surface
□ □

**Name of macro:**

Surface-5

Distance IP/PRB	5.00
Distance btw. lines	10.00
Dist. btw. points on the line	7.00



Store

Back

Help

### Data boxes

<b>Distance IP/PRB</b>	The distance between the intermediate position and the probing point must be such that the intermediate position lies well below the clearance plane.
<b>Distance btw. lines</b>	Input of a dimension for the distance between grid lines located within the surface boundary.
<b>Distance btw. points on the line</b>	Input of the distance between points on a grid line. In connection with the point distance, the grid lines form the grid of the points measured within the surface boundary.

**Procedure**

**Start macro**

The macro must be started by entering its name before each measurement.

**Intermediate position**

A clearance height which can be traversed by the probe without a collision must be defined by setting an intermediate position above the workpiece surface.

**Probe four points**


The measured element (part feature) must then be defined by four manual auxiliary probings. (See next page for probing strategy).

**NOTE**



When the macro is executed, a collision may be reported after the first probing in measuring machines equipped with a trigger probe head.

In this case, check whether the probing parameters of **<DI 1661>** allow sufficient clearance between the preceding intermediate position and the probing point (► „Probing parameters <PROBE P>“ on page 6-11).

The four auxiliary probings limit the area of the surface which is to be determined by the control.



Other possibilities



The maining probings will be executed by the control based on the parameters entered.


## Scanning a surface with VAST

### Application

Surfaces which are considerably segmented or broken can be scanned quite easily with VAST:


By probing individual geometric elements, you define the position and sequence of points, circles and lines. Together these elements result in the scanning path of the probe.

Alternatively, you can also specify the scanning path via the work-piece coordinates of the individual successive geometric elements. In this case, the probing direction is derived from the preselected probe. The number assignment of the probe specified here must correspond to the one indicated on the control panel.



**Function call**

If the <VAST> function box is clicked on when the geometric element **SURFACE** is entered, the following window for defining the remainder of the measuring run will open.



**The following steps are required:**

- Define the VAST mode by clicking on one of the eight pictograms (icons) (see CIRCLE).
- Enter the individual probing points and/or geometric elements for scanning.
- Enter the parameters for the nominal geometry and form tolerance.
- Optional: Change the default settings if necessary.
- Start the VAST measurement by clicking on the <Termin> function box.

## Function and data boxes

When you click on a line, circle or point, the corresponding input field will be made available.

Once a geometric element has been selected, it remains active until it is deselected.

When the first geometric element (line or circle) has been entered, its target point automatically becomes the start point of the following geometric element.

Line

### Start point X,Y,Z Target point X,Y,Z

The target point is transferred automatically as start point for a subsequent geometric element. If there are several lines which follow in succession: After the first line, only the target point has to be probed or entered.

Circle

### Start point X,Y,Z Target point X,Y,Z Help point X,Y,Z

For a circle segment, the start and target point and subsequently a help point are probed or entered.

With a complete circle, the start and target point are identical. In addition, two help points must be probed or entered.

The target point becomes the start point of the following geometric element.

Point

### Point X,Y,Z

The probe moves to the clearance height after each probing.

### Nominal value

This function box is changed by clicking on either <Yes> or <No>. If you click on <Yes> the Nominal window will automatically be activated following the measurement.

### Safety height

Distance of probe from probing point following the probing.

### Form tolerance

Data box for form tolerance of surface to be measured (in mm).

### Contour element 1: Probe or enter start point!

Display of current number of element, user prompt.

transfer

When entering data manually, you must transfer each individual travel path segment by pressing this function box. If you define the travel path by probing, this is done when accepting the target position.

New start point

If you have already defined a travel path element: The target point is offered automatically as the start point of a new element. If you do not want this, you can define a new start point using this function box.

**Correction**

By pressing this function box you retrieve the individual elements one after the other. The coordinates displayed can be corrected. If you want to mask out or delete a single element, then you have to set its coordinates to zero.

**Termin**

You start the VAST measuring run with this function box.

**Cancel**

Function box for canceling the VAST measurement routine and return to the previous dialog window of the **"SURFACE"** geometric element.

**Parameters**


After selecting this function box you can define and store the parameters for an individual measuring run (see circle with VAST scanning).

Direction and position, fast	
Corner deviation	<input type="text" value="0.5"/>
V max in CNC	<input type="text" value="20.0"/>
Step width	<input type="text" value="0.200"/>
Number of points	<input type="text" value="0"/>
Filter Lambda c	<input type="text" value="0"/> <input type="checkbox"/>
Form evaluation	<input type="text" value="No"/> <input type="checkbox"/>
Direction determin.	<input type="text" value="No"/> <input type="checkbox"/>
Position definition	<input type="text" value="No"/> <input type="checkbox"/>
GDT plot	<input type="text" value="No"/> <input type="checkbox"/>
<input type="button" value="Termin"/> <input type="button" value="Store"/>	

## Description of the input and function boxes

### Corner deviation

During scanning runs, it is advantageous to change the scanning direction without bringing the measuring machine to a "standstill" stop. When the scanning direction is changed, a small path deviation results. The permissible value of this deviation is referred to as the "corner deviation". If in individual cases there is a risk of collision or the measuring surface can be missed, you can adapt the corner deviation to match the existing requirements.




## CYLINDER <DI 1106>

### Application

This program calculates the diameter and position of bores or shafts.

### Minimum number of probings: 5




### Probing strategy


The first three probing contacts must be made in a single section which is roughly perpendicular to the axis. Based on this information, the program then determines the approximate direction of the cylinder axis for further calculation.

These probes must all be probed with the same probe. Other points may be probed with different probes if they all have approximately the same radius. The probes must all be assigned to the same combination.


During learn (i.e. part) programming these values are stored as control data for the subsequent accelerated evaluation.





<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1106 CYLIN	Elements Geometric elements Cylinder...	

Cylinder



Macro selection  
Cyl 20 points

Probe no.

Element name

Points measured:  
8

Measure/Eval.

VAST

CMM...

Nominal

I-Pos/Prb

Theor.element

Termin

Correction

Cancel

Help

X	0.0127	Distance point - element	-0.2571
Y	0.1655	Standard deviation s	0.0930
Z	0.0000	MIN point no.	7 -0.0957
D	20.2239	MAX point no.	2 0.0574
A1	-0.0283	Range MAX - MIN	0.1531
A2	-0.5154		

### Measurement record printout


```

CYL_1
  11  CYL  I      X    0.0127
                        Y    0.1655
                        D   20.2239
                        X/Z  A1  -0.0283
                        Y/Z  A2  -0.5154
                        8P S/MIN/MAX      .0930 (7) -.0957 (2) .0574
    
```

### Explanation of result output

- The angles output are referenced to the cylinder axis.
- The reference axis for the projected angles is the coordinate axis with which the cylinder axis forms the smallest angle.  
Any reference axis can be selected with **<FIXED PLANE>** (► *„Selecting the reference plane <DI 1680>“ on page 10-50*).
- The of the point are output as a penetration point where the cylinder axis penetrates the workpiece coordinate system.

***The position of the penetration point is therefore dependent on the position of the workpiece coordinate system:***



- A This Y value results if the coordinate system is at Y'
- B This Y value results if the coordinate system is at Y.
- C This Y value results if the bore is measured as a circle or ellipse (independent of the position of the Y axis)

### Semiautomatic measurement

#### Application


You can measure a cylinder semiautomatically using the macro function.

#### Function call

**<CYLINDER>**

**<Macro selection>**

**<Input>**


Macro input Cylinder	
Name of macro:	<input type="text" value="CYL-2"/>
No. of points per section	<input type="text" value="8"/>
Start angle	<input type="text" value="0.00"/>
Angle range	<input type="text" value="360.00"/>
Slot width	<input type="text" value="5.00"/>
distance IP/PRB	<input type="text" value="2.00"/>
Distance btw. circle sections	<input type="text" value="10.00"/>
No. of circle sections	<input type="text" value="4"/>
	
<input type="button" value="Store"/> <input type="button" value="Previous"/> <input type="button" value="Help"/>	

### Data boxes

<b>No. of points per section</b>	The number of points entered is distributed evenly over the selected angle range.
<b>Start angle</b>	The angle (positive only) applies when viewing the measuring plane from the positive direction of the third axis.
<b>Angle range</b>	Positive angle = travel counterclockwise, negative angle = travel clockwise.
<b>Slot width</b>	Width of the clearance zone which can be traversed by the probe without causing a collision. The slot width can be set to zero when measuring bores.
<b>Distance IP/PRB</b>	Distance between the intermediate position and the probing point. This dimension must be considerably smaller than the slot width.
<b>Distance btw./No. of circle sections</b>	The reference for these inputs is the position of the auxiliary (help) points.

## Procedure

- Start the macro** The macro function must be started by entering its name before each measurement.
- Intermediate position** A **clearance height** which can be traversed by the probe without a collision must be defined by setting an intermediate position above the workpiece surface.
- Probe two points** The measured element (part feature) must then be determined by **two manual auxiliary probings**. These auxiliary points must lie in the same probing direction and should be a certain distance apart.
- Two further auxiliary points** The control then executes another two probings at the symmetry points of both manual probings. The second auxiliary point is located on the next section plane. The geometry of the cylinder is calculated from these four points and the macro is executed.




The positions of the following sections depend on the +/- sign for **Distance btw. circle sections**

## CONE <DI 1107>

### Application


The program calculates the position and form of inner or outer cones.


Minimum number of  
probing: 6




### Recommended probing strategy

- The first three probings must lie in one section approximately perpendicular to the axis. The 4th point must be located in another section (based on this data, the program then calculates the approximate cone data for the subsequent operation. These points must all be probed with the same probe. Additional points can be probed with different probes if they have approx. the same radius. The probes must all be assigned to the same combination.
- Probe at least three sections with 4 points each.
- If the conditions are not favorable (e.g. cone sections), additional surface lines should be probed symmetrically.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1107 CYLIN	Elements Geometric elements Cone...	

Cone



Macro selection

Measure/Eval.


VAST

CMM...

Nominal

I-Pos/PRB

Theor.element



Probe no.

Element name

Points measured:  
8

Termin
Correction
Cancel
Help

X	-0.0818	Distance point - element	-0.3095
Y	-0.0319	Standard deviation s	0.1591
Z	0.0000	MIN point no.	3 -0.1173
D	60.4166	MAX point no.	4 0.1182
A1	-0.0509	Range MAX - MIN	0.2355
A2	0.0040		
AC	22.5032		


**Measurement record printout**

```

CONE_1
  11  CONE I      X   -0.0818
                        Y   -0.0319
                        D   60.4166
                        X/Z  A1  -0.0509
                        Y/Z  A2   0.0040
                        AC   22.5032
                        8P S/MIN/MAX      .1591 (3) -.1173 (4) .1182
    
```

### Explanation of the result output

- Angles **A1** and **A2** refer to the cone axis.
- The reference axis for the projected angles is the coordinate axis with which the cone axis forms the smallest angle.  
Any reference axis can be selected with **<FIXED PLANE>**.
- The coordinates of the point where the cone axis penetrates the workpiece coordinate system are output as the penetration point.
- The (theoretical) cone diameter in the penetration point is output as the diameter.
- The position and direction of the cone should be interpreted based on the result as follows:



- Additional cone data can be calculated with **<DI 1243>** (**>** „*Additional cone program <DI 1243>*“ on page 13-13).

### Semiautomatic measurement

#### Application

#### Function call


You can measure a cone semiautomatically using the macro function.

**<CONE>**

**<Macro selection>**

**<Input>**

Macro input Cone	
Name of macro:	<input type="text" value="Cone macro"/>
no. of points per section	<input type="text" value="8"/>
Start angle	<input type="text" value="0.00"/>
Angle range	<input type="text" value="360.00"/>
Slot width	<input type="text" value="5.00"/>
Distance IP/PBR	<input type="text" value="2.00"/>
Distance btw. circle sections	<input type="text" value="10.00"/>
No. of circle sections	<input type="text" value="4"/>



**Data boxes**

**No. of points per section**

The number of points entered is distributed evenly over the selected angle range.

**Start angle**

The reference axis is the abscissa. The angle (positive only) applies when viewing the measuring plane from the positive direction of the third axis.

**Angle range**

Positive angle = counterclockwise travel, negative angle = clockwise travel.

**Slot width**

Width of the clearance zone which can be traversed by the probe without causing a collision. The slot width can be set to zero when measuring bores.

**Distance IP/PRB**

Distance between intermediate position and probing point. This dimension must be considerably smaller than the slot width.

**Distance btw./No. of circle sections**

The reference for these inputs is the position of the auxiliary points.

**Procedure**

**Start macro**

The macro function must be started by entering its name prior to each measurement.



**Intermediate position**


A **clearance height** above the workpiece surface which can be traversed by the probe without causing a collision must be defined by setting an intermediate position.

**Probe two points**

The measured element (or part feature) must then be determined by **two manual auxiliary probings**. These two auxiliary points must both lie in the same probing direction and should be a certain distance apart.

**Two further auxiliary points**

The control then performs another two probings at the symmetry point of the two manual probings. The second auxiliary point is located on the next section plane. The second auxiliary point is located on the next section plane. The geometry of the cone is calculated from these four points and the macro is executed.




The position of the sections following depend on the +/- sign for **Distance btw. circle sections**

## TORUS <DI 1109>

### Application



This program calculates the form and position of tori.

### Minimum number of probings: 7



### Probing strategy

- Minimum number of probings required: 7; at least 10 probings are recommended to compensate deviations.
- The first three probings must be located equally far away from the torus center point on one normal section (intersection plane perpendicular to the normal, e.g. points 1,2,3 or 1', 2', 3')
- Probings 4 and 5 must lie in a radial intersection plane with diameter  $D_2$  (see sketch).
- The remaining probings should be distributed over as large an area of the torus as possible.



<b>DI</b>	<b>Pull-Down-Menu</b>	<b>Pictogram</b>
1109	Elements	
TORUS	Geometric elements	
	Torus...	

**Torus**

Macro selection

Probe no.  ▲ ▼

Element name

Points measured:  
10

X	-3.5372	Distance point - element		-0.0000
Y	8.3701	Standard deviation s		0.0006
Z	0.1023	MIN point no.	4	-0.0003
D1	12.1021	MAX point no.	2	0.0003
D2	3.9837	Range MAX - MIN		0.0006
A1	0.0153			
A2	-0.0636			

## Measurement record printout

```

TORUS_1
  11      TORUS      X   -3.5372
                        Y    8.3701
                        Z    0.1023
                        D1  12.1021
                        X/Z   A1   0.0153
                        Y/Z   A2  -0.0636
                        D2   3.9837
10P S/MIN/MAX      .0006 (4) - .0003 (2) .0003

```

## Further notes on application


- Nominal input:
  - Enter large diameter **D1** under **D**
  - Enter small diameter **D2** under **AC**.
- Scanning: After the start the program will prompt you to perform the first 3 probings as described above.
- Recalls, combinations and coordinate transformations are possible.
- For maximum precision:
  - Distribute the probings over as large an area of the torus as possible.
  - Place the first three probings exactly in one plane intersecting the normal.
- The penetration point of the torus axis can be determined with **<DI 1217>** (► „Penetration point <DI 1217>“ on page 13-11).


## SPHERE <DI 1105>


### Application

This program calculates the diameter and the center point of a sphere, spherical segment or spherical zone.


Minimum number of  
probings: 4





<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1105 SPHERE	Elements Geometric elements Sphere...	

Sphere



Macro selection

Probe no.  ▲  
▼

Element name

Points measured:

Measure/Eval.

VAST

CMM...

Nominal

I-Pos/Prb

Theor.element

Termin    Correction    Cancel    Help

X	-0.1348	Distance point - element	0.5886
Y	-0.1740	Standard deviation s	0.3354
Z	0.4159	MIN point no.	5 -0.2912
D	20.4092	MAX point no.	6 0.3035
		Range MAX - MIN	0.5947

**Measurement record printout**

```

SPHERE_1
  12  SPHERE I   X   -0.1348
                               Y   -0.1740
                               Z    0.4159
                               D   20.4092
        6P S/MIN/MAX      .3354 (5) -.2912 (6) .3035
    
```

### Semiautomatic measurement

**Application** You can measure the sphere semiautomatically using the macro function.


**Function call** <SPHERE>  
 <Macro selection>  
 <Input>

Macro input Sphere	
Name of macro:	<input type="text" value="Half sphere"/>
No. of points per section	<input type="text" value="8"/>
Start angle	<input type="text" value="0.00"/>
Angle range	<input type="text" value="360.00"/>
Distance IP/PRB	<input type="text" value="2.00"/>
Distance btw. intersections	<input type="text" value="3"/>
Height of sphere cap	<input type="text" value="1.00"/>

Store

Previous

Help



### Data boxes

- No. of points per section** The number of points entered is distributed evenly over the selected angle range.
- Start angle** The reference axis is the abscissa. The angle (positive only) applies when viewing the measuring plane from the positive direction of the third axis.
- Angle range** Positive angle = counterclockwise travel, negative angle = clockwise travel.
- Distance IP/PRB** Distance between intermediate position and probing point.
- Distance btw. intersections** These intersection planes are automatically specified near the sphere cap.

**Height of sphere cap** Area of the sphere which must be assigned with intersection planes. The height must be determined linearly by values between 0 (pole) and 1 (equator).

### **Procedure**

**Start macro** Prior to each measurement, the macro function must be started by entering the name of the macro.

**Intermediate position** A **clearance height** above the workpiece surface which can be traversed by the probe without causing a collision must be defined by setting an intermediate position

**Probe one point** At the start, the measured element (part feature) must be defined by performing a manual auxiliary probing near the pole.

**Three auxiliary points** Another three probings are performed automatically to calculate the control information. The geometry of the sphere is then calculated from these four points and the macro is executed.





# Circle segment <DI 1114>

## Application

The form and position deviation of circles for which only segments can be probed can best be evaluated with <DI 1114>.

Theoretical nominal values can be entered which are considered to be fixed values for the measured segment by the computer.



DI	Pull-Down-Menu	Pictogram
1114	Elements	
CIRSEG	Special elements	
a83	Circle segment...	

Dialog

Circle segment

Element name

J Output circle  \*

Output deviation table  \*

Meas plane xy  \* or yz  or zx

Fixed value selection by  
Input or Recall ADR/name


X	*	<input style="width: 95%; border: 1px solid black;" type="text" value="10.0000"/>	<input style="width: 95%; border: 1px solid black;" type="text"/>
Y	*	<input style="width: 95%; border: 1px solid black;" type="text" value="20.0000"/>	<input style="width: 95%; border: 1px solid black;" type="text"/>
Z	<input type="checkbox"/>	<input style="width: 95%; border: 1px solid black;" type="text"/>	<input style="width: 95%; border: 1px solid black;" type="text"/>
D	*	<input style="width: 95%; border: 1px solid black;" type="text" value="30.0000"/>	<input style="width: 95%; border: 1px solid black;" type="text"/>

<input type="checkbox"/> * YES	<input type="checkbox"/> NO	<input style="width: 95%; border: 1px solid black;" type="text"/>	<input type="checkbox"/> * <input style="width: 95%; border: 1px solid black;" type="text" value="SEGMENTS"/>	<input style="width: 95%; border: 1px solid black;" type="text" value="TERMIN"/>
<input style="width: 95%; border: 1px solid black;" type="text" value="BACK"/>	<input style="width: 95%; border: 1px solid black;" type="text"/>	<input style="width: 95%; border: 1px solid black;" type="text"/>	<input style="width: 95%; border: 1px solid black;" type="text"/>	<input style="width: 95%; border: 1px solid black;" type="text" value="INFO"/>

**Example**

The center of a bore is to be the center of the radius  $r$  at the same time.




**Procedure**


- Call <DI 1114> (circle segment).
- The center point of the bore is preset as the fixed value for the radius center point.
- The program calculates only the diameter of the circle segment from the subsequent probings on the radius.
- The specified fixed value as the center point, the calculated diameter and the standard deviation are all output in the result.

**Fixed values**

Entered numerical values or measurement results or result names can be specified as fixed values.



Measurement result as fixed value



Input numerical value as fixed value

**Data boxes****Element name**

The default name offered can be changed.

**Output circle or deviation table**

If the radii are to be used again, the inquiry **Output deviation table** must be answered with <YES>. Addresses will then be assigned to the **RADMES** radii.

<b>Output circle</b>	<b>Output Deviation table</b>	<b>Output in the record</b>
yes	yes	Result circle segment + probings
yes	no	Only result circle segment
no	yes	Only probings
no	no	Only result circle segment

**Meas. plane**

Plane in which the circle segment lies.

**Fixed value selection by Input or Recall ADR/name**

- Select the icon for which a fixed value is to be preset with <YES> / <NO>.
- If a numerical value is to be given as a fixed value for the icon, it must be entered in the **Input** column and confirmed with <Enter>.
- If a measuring result is to be preset as a fixed value, the address or name of the required result must be entered in the **Recall ADR/name** column.
- The dialog window is terminated with <TERMIN>. Then probing of the circle segment is requested.

**SEGMENTS**

This softkey is used for branching to the dialog window to enter circle segments.



**Measurement record printout**

Fix value input: XY


CIRSEG\_1


2	KR-SE I	X	0.0000				
		Y	0.0000				
		D	39.8803				
	2P S/MIN/MAX		.0705	(2)	-.0499	(1)	.0499
3	RADMES	R	19.9999				
	Y/X	A1	0.1574				
4	RADMES	R	19.8903				
	Y/X	A1	5.3295				

## 3D circle <DI 1154>

### Application

With this program, circles and radii which lie inclined in space can be measured.





Dialog			
Space circle			
Element name	<input type="text" value="RKREIS 3"/>		
<input checked="" type="checkbox"/> Output circle	<input type="checkbox"/>		
Output deviation table	<input type="checkbox"/>		
Ref. plane	xy <input type="checkbox"/>	or yz <input type="checkbox"/>	or zx <input type="checkbox"/>
Fixed value selection by input or by		Recall ADR/name	
X	<input type="checkbox"/>	<input type="text" value="0.0000"/>	<input type="text"/>
Y	<input type="checkbox"/>	<input type="text" value="0.0000"/>	<input type="text"/>
Z	<input type="checkbox"/>	<input type="text" value="0.0000"/>	<input type="text"/>
D	<input type="checkbox"/>	<input type="text" value="0.0000"/>	<input type="text"/>
A1 X/Z	<input type="checkbox"/>	<input type="text" value="0.0000"/>	<input type="text"/>
A2 Y/Z	<input type="checkbox"/>	<input type="text" value="0.0000"/>	<input type="text"/>
* YES		NO	<input type="text"/>
* <input type="text"/>		<input type="text"/>	TERMIN
BACK		<input type="text"/>	INFO

### Data boxes

#### Element name

The default name offered can be changed.

#### Output circle, Output deviation table

Not yet active.

#### Ref. plane

The plane in which the projection of the 3D circle lies.

#### Fixed value selection

- Select the icon for which a fixed value is to be specified with **<YES>** / **<NO>**.
- Either numerical values in the **Input** column or measurement results via address or result name in the **Recall ADR/name** column can be specified as fixed values.
- The dialog window is concluded with **<TERMIN>**. The circle is then requested for probing.

**NOTE**

**Possible fixed value combinations**

- If all fixed values are preset, no probings are necessary. The preset values will be output as an ideal space circle.
- If all fixed values except **D** are preset, at least 1 point must be probed. The diameter will be calculated and all other values remain as preset.
- At least three probings are necessary if fixed values are entered for **A1** and **A2**.

**Measurement record printout**

```

RCIRCLE_1
  11      R-KR I      X    13.1547
                        Y    14.9982
                        Z     0.0001
                        D    12.0036
                        X/Z   A1   10.0000
                        Y/Z   A2    5.0000
  6P S/MIN/MAX      0.0006 (4) -0.0003 (2) .0003
    
```



# Theoretical elements

## Application

Sections or other constructions with theoretical planes or circles are occasionally required in technical drawings.

## Theor.element

The respective theoretical element can be selected within a geometric element

## Example

for the dialog window with the theoretical element cone

Dialog

Cone segment

Element name

Output Cone

Output deviation table

Ref. plane xy  or yz  or zx

Fixed value selection by input or by recalling ADR/name

X	<input type="checkbox"/>	0.0000	<input type="text"/>
Y	<input type="checkbox"/>	0.0000	<input type="text"/>
Z	<input type="checkbox"/>	0.0000	<input type="text"/>
D	<input type="checkbox"/>	0.0000	<input type="text"/>
A1 X/Z	<input type="checkbox"/>	0.0000	<input type="text"/>
A2 Y/Z	<input type="checkbox"/>	0.0000	<input type="text"/>
AC	<input type="checkbox"/>	0.0000	<input type="text"/>

\* YES NO   \*     TERMIN

BACK       INFO

The data boxes in the dialog window may vary according to the element called.

## Data boxes

### Element name

The default name offered can be changed.

### Output Cone, Output deviation table

Data boxes with no function.

### Ref. plane

Enter plane in which cone segment lies.

### Fixed value selection by input or by recalling ADR/name

- Select the icon for which a fixed value is to be input with <YES> / <NO>.

- If a numerical value is to be entered as the fixed value for the icon, it must be entered in **Input** column and confirmed with **<Enter>**.
- If a measuring result is to be preset as a fixed value, the address or name of the desired result must be entered in the **Recall ADR/name** column.
- The dialog window is closed with **<TERMIN>** and the theoretical element is finished.





# Chapter

# 12

## Linking results

---

### **This chapter contains:**



Intersections .....	12-2
Perpendicular calculations .....	12-15
Distance in cartesian coordinates <DI 1202> .....	12-20
Symmetry elements <DI 1206> .....	12-22
Mean value calculation <DI 1345> .....	12-25
Formula calculation <DI 1379> .....	12-27
Pitch measurements <DI 1310> .....	12-30
Determining the minimum and maximum of measurement results <DI 1341> <DI 1343> .....	12-40
Generating a plane by linking <DI 1265> .....	12-42
Generating a point by projecting from point to line <DI 1266> .....	12-45

# Intersections

## Plane intersections <DI 1218>

**Application**

Using the <INTERSEC> function, axes, circles, ellipses and surfaces can be intersected with each other.



**Procedure**

**Input address**

Enter the names or address of the elements to be intersected in the **Element 1** and **Element 2** data boxes.

**Result name**

Enter the name you want to assign to the result in the **Result** box (Follow information in [► „Allocating names“ on page 5-9](#)).

**Two intersection points**

If two intersection points may result when the two elements are intersected, both intersection points will initially be displayed in the list and message window.

**Inters. point no.: 1 X = -1.1803 Y = 14.9535**

**Inters. point no.: 2 X = 11.3661 Y = -9.7883**

**No intersection point is accepted with '0'!**

**Select intersection point**

The dialog asks which intersection point is to be accepted.

**2 Inters. point(s) - Transfer inters. point no.:**


**End function**

Enter the corresponding number and close the dialog window with **<TERMIN>**.

**NOTE**

- Differentiation between **Element 1** and **Element 2** is required only with the **AXIS/AXIS** combination to calculate the intersection angle.
- The first dialog window will not appear if the name allocation function is switched off (► „Allocating names“ on page 5-9) In this case, the last element in the record is **Element 1** and the next to last element is **Element 2**.

**This function can be applied to the following element combinations:**

**AXIS/AXIS**

- The lines can lie in any workpiece plane.
- The intersection point output and the intersection angle are projected into the plane which is common to both lines.


**AXIS/CIRCLE (ELLIPSE)**

**Prerequisite**


The penetration point of the axis output and the circle center point must not lie in the same measuring plane. The intersection point is projected into the plane which is common to both elements.

There are two possibilities:

- If **2 intersection points** exist, both of them will be displayed on the screen. The intersection point to be output in the measurement record must be defined in the dialog. The shortest distance (D) between the circle and the axis is also output.



- If **no intersection** point exists, the coordinates of the foot of the perpendicular and the shortest distance (D) between the circle and the axis are output.






**CIRCLE/CIRCLE (ELLIPSE)****Prerequisite**

Both circles must lie in the same measuring plane.


Two cases must be differentiated:

- If **two** intersection points exist, both will be displayed on the screen.

The intersection point to be output in the measurement record must be defined in the dialog. The shortest distance ( $D$ ) between the circle center points is also output.




- If **no intersection point** exists, the distance between the circle center points and the center point of the connecting line will be output.




**AXIS/SURFACE**

The penetration point of the line through the surface is output in 3 coordinates (spatially defined point)



**SURFACE/SURFACE**



Result: spatially defined intersection line





## Intersection point of axes in space <DI 1215>

### Application

This function calculates the intersection point between two axes in space. If the axes do not intersect, the point closest to both axes (center point of the perpendicular) will be output.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1215 SECT3D	Eval Inters. 2 Axis 3D	



**Procedure**

**Enter address**

Enter the names or address of the axes to be intersected in the **Element 1** and **Element 2** data boxes.

**Result name**

Enter the name you want to assign to the result in the **Result** box (see information in ► *„Allocating names“ on page 5-9*).

**End function**

Close the dialog window with <TERMIN>.

**NOTE**


- No differentiation between **Element 1** and **Element 2** is required.
- If the name allocation is not activated (► *„Allocating names“ on page 5-9*) the dialog window will not appear. The last two elements in the measurement record are then intersected.


## Surface sections <DI 1219>

### Application

With this function, the spatial elements **SPHERE** and **CYLINDER** can be intersected by an axis or a surface. A **TORUS** can be intersected with an axis. The following elements are permissible as an axis:

- Line
- Cylinder, cone or torus axis
- Calculated intersection lines



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1219 SECTMAN	Eval Inters.	
a611	Convex surface intersections	

Dialog

Convex surface intersections

C	Element1	SPHERE 1	Element2	LINE 1	Result	ENTER 1
---	----------	----------	----------	--------	--------	---------

*	TERMIN
BACK	INFO

### Procedure

#### Enter address

Enter the names or addresses of the elements which are to be intersected in the **Element 1** and **Element 2** data boxes.

#### Result name


Enter the name you want to assign to the result in the **Result** box (see information in [▶ „Allocating names“ on page 5-9](#)).

**End function** Close the dialog window with **<TERMIN>**.

**NOTE**


No differentiation between **Element 1** and **Element 2** is required. If the name allocation is not activated, the dialog window will not appear. The last two elements in the measurement record are intersected.

**SPHERE/SURFACE**



- Depending on the position of the sphere and the surface, the coordinates of the intersection circle center point, the contact point or the foot of the perpendicular will be output.
- The diameter of the intersection circle is output under D. If these two elements do not intersect, then  $D = 0$ .

**SPHERE/AXIS**



- The shortest distance between the sphere center point and the axis (perpendicular) will be output under D in the measurement record.

- If 2 intersecting points exist, both of them will be displayed in the list and message window on the screen.

**Inters. pt no.: 1 X = -1.1803**

**Y = 14.9535**

**Inters. pt no.: 2 X = 11.3661**

**Y = -9.7883**


The intersection point which is to be output in the measurement record must be determined in the dialog.

**Transfer from inters. point no: 1**

Select the required intersection point with **<YES>** / **<NO>**.

- If no intersection point exists, the coordinates of the foot of the perpendicular will be output.

### CYLINDER/AXIS



**Axis is Address: ..**  
**Surface is Address: ..**


The inquiry appears only if a cylinder or torus axis has been chosen as the intersection axis. The element to be used as the axis and the element to be used as the surface must be entered here. Select **<YES>** to accept the default addresses or **<NO>** to replace them.

**Transfer from inters.**  
**point no.: 1**

If the axis intersects the cylinder, both intersection points will be displayed on the screen in the list and message window. The intersection point to be accepted for the measurement record is selected with **<YES>** / **<NO>**.

If no intersection point is present, the coordinates of the foot of the perpendicular and the shortest distance between the axis and the cylinder axis are output.

CYLINDER/SURFACE



**Case 1** If the surface does not lie parallel to the cylinder axis, the center point and small diameter of the intersection ellipse will be output.

**Special case:** If the difference between the small and large ellipse diameter is smaller than the machine resolution, the result will be output as an intersection circle.

**Case 2** If the surface does not intersect the cylinder, the coordinates of the foot of the perpendicular and the distance between the cylinder axis and the surface will be output.

**Case 3** If the surface runs parallel to the cylinder and intersects it, the intersection lines will be calculated as the result.

Intersection lines in the mathematical sense result only if the cylinder axis and the surface normal are exactly perpendicular to each other. This is generally not the case in metrology. The following dialog will appear if the parallelism deviation between the surface and the cylinder is less than **three degrees**:


**max. parallelism dev.  
(perm. range 0 - 3 Deg)**

Here you must enter the maximum parallelism deviation between the surface and the cylinder for which lines should be calculated as the result. If the actual deviation exceeds the value entered here, an intersection ellipse will be output as the result.



**Ref. length 1**  
**Ref. length 2**


To minimize errors when calculating lines, a reference range must be specified to the computer. This reference range is limited by reference lengths 1 and 2. The reference lengths refer to the point where the cylinder axis penetrates the workpiece coordinate system.



**Line no.: 1 - accept?**

Both intersection lines are displayed on the screen. Line no. 1 is accepted with **<YES>** and line no. 2 with **<NO>**.

**TORUS/AXIS**



**Case 1**

If the axis intersects the torus, all intersection points will be displayed on the screen. The intersection point to be output in the measurement record must be defined in the dialog.

**4 inters. points (s) - accept inters. point no.:**

Enter the number of the intersection point to be output in the measurement record. If "0" is entered the coordinates of the foot of the perpendicular will be output.

### Case 2


If no intersection point exists, the coordinates of the foot of the perpendicular and the shortest distance between the axis and the torus center point will be output.


# Perpendicular calculations

## Perpendicular cylinder <DI 1285>

**Application**

Using the <PERPEN> program, you can measure the shortest distance between two geometric elements in space.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1285	Eval	
SECTMAN	Distance	
a85	Convex surface intersections	

Dialog

Perpendicular cylinder

C	Element1	SURFACE 1	Element2	POINT 1	Result	PER 1
---	----------	-----------	----------	---------	--------	-------

		*	TERMIN
BACK			INFO

**NOTE**

If the name allocation function is not activated (► „Allocating names“ on page 5-9), the dialog window will not appear. The perpendicular is formed between the last two elements in the record. One of them must be spatially defined.

## Procedure

- Enter address** Enter the names or addresses of the elements between which the perpendicular is to be calculated in the **Element 1** and **Element 2** data boxes.
- Result name** Enter the name you want to assign to the result in the **Result** box (Follow instructions in [▶ „Allocating names“ on page 5-9](#)).
- End function** Close the dialog window with **<TERMIN>**.
- Result output** The **<PERPEN>** program supplies the same data as a cylinder measurement. The result is therefore output as **PERPCY**.

**X, Y, Z:** Coordinates of the perpendicular penetration point through the reference plane.

**A1, A2:** Projected angles of the perpendicular ([▶ „Projected angles“ on page 10-53](#))

**D:** Shortest distance between reference and measured elements.




- Element 1** is the next to last element in the measurement record. It defines the **location** and **length** of the perpendicular. Any geometric element is permitted since only the coordinates of the element are used for the perpendicular calculation.

Element 1	Coordinates used
POINT probing	Coordinates of the probing point with probe radius correction in the direction of the surface normal
CIRCLE	Center point coordinates and average probing depth
AXIS	Coordinates of penetration point

An exception from the above is two intersecting axes (see example).

- Element 2** is the last element in the measurement record. It defines the direction of the perpendicular (the perpendicular is at a right angle to element 2). A 3D definition is always required for this purpose (line, surface, cylinder, cone or torus axis).


**Application examples**


Measurement task	Element 1 / Element 2
 <p>Vertical distance bore / inclined surface</p>	Surface / Circle
 <p>Vertical distance parallel surfacel</p>	Surface / Point
 <p>Vertical distance intersecting axes (intersecting angle &gt; 0,1°)</p>	Axis / Axis

**Perpendicular distance <DI 1286>**

**Application**

If only the shortest distance in space, but not the direction and penetration point of the perpendicular, is required for two geometric elements, this can also be determined with <DI 1286>.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1286 PERPDIS	Eval Distance Perpendicular	

**Output**

The length of the perpendicular, i.e. the shortest distance between the two elements, is output as the result under **D**.

**Preassignment**

The last two elements in the measuring record are always offered as the preassignments for Elements 1 and 2 with **<DI 1285>** i.e. each time **<DI 1285>** is called the preassignment changes for element 1.

If you call **<DI 1286>**, the same element will be offered as element 1 as was offered as element 2 (the last element in the record) the last time the function was called.

In this way, the values offered can simply be accepted with **<TERMIN>** if the perpendicular of the same spatially defined element is measured repeatedly.

**Example**

**<SURFACE>**

Probing point  
**<DI 1286>**  
Probing point  
**<DI 1286>**  
Probing point  
**<DI 1286>**




Each time **<DI 1286>** is called the surface is offered as a Element 1 and the previous probing point as Element 2

## Perpendicular / Perpendicular distance <DI 1272>

### Application

This function can be used if the perpendicular from a point to the perpendicular distance between two other points is required.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1272		

Dialog


3 point macrol (linking of three results for perp. dist./perp. cylinder)

<input type="checkbox"/>	Result	PERDI 2	
	Element1	8	(Address for location of perpendicular)
	Element2	6	(Address 1 for direct. of perpendicular)
	Element3	7	(Address 2 for direct. of perpendicular)

* YES	NO			*			REPEAT	TERMIN
BACK	PRE MENU						CALCUL	INFO


### Beispiel



## Distance in cartesian coordinates <DI 1202>

### Application

The <**DISTANCE**> function calculates the distance between two elements in cartesian coordinates. The coordinates of the first element are subtracted from those of the second and the result is always output as positive.



Dialog

Cartesian distance

C	Element 1	SPHERE 1	Element 2	CIRCLE 1	Result	
		DIST_1				

			TERMIN
BACK			INFO

### Procedure

#### Enter address

Enter the names or addresses of the elements between which the distance is to be calculated in the **Element 1** and **Element 2** data boxes.

#### Result name

Enter the name you want to assign to the result in the **Result** box (Follow instructions in [▶ „Allocating names“ on page 5-9](#)).

#### End function

Close dialog window with <**TERMIN**>.



**NOTE**


- The differentiation between element 1 and element 2 influences the angle output if the distance is subsequently converted to polar coordinates (<DI 1203> ► „Polar distance in one plane <DI 1203>“ on page 13-7).
- If the name allocation is not activated (► „Allocating names“ on page 5-9) the dialog window will not appear. In this case element 1 is the last element in the record and element 2 the next to last.
- Only one point from each element is used for the distance calculation. These points are:

Element	Point used
Circle, ellipse, sphere, torus	Center point
Cylinder, cone	Penetration point of the axis through the reference plane
Surface	Penetration point of the reference axis through the surface

This means that for the <DISTANCE> between a surface and a cylinder the distance between the penetration points is determined.

**Example**

<DISTANCE> between two circles:




## Symmetry elements <DI 1206>

### Application

The program forms a symmetry element from two elements which have already been measured.

The calculation is performed for those coordinates which are common to both elements.

The symmetry element calculated can be used without restriction for further "linkings" or combinations.



Dialog

Symmetry

C	Element1	CIRCLE 1	Element2	CIRCLE 2	Result	SYMM 1
---	----------	----------	----------	----------	--------	--------

	*	TERMIN
BACK		INFO

**Procedure**


<b>Enter address</b>	Enter the names or addresses of the elements from which a symmetry element is to be calculated in the <b>Element 1</b> and <b>Element 2</b> data boxes.
<b>Result name</b>	Enter the name you want to assign to the result in the <b>Result</b> box (follow instructions in <a href="#">▶ „Allocating names“ on page 5-9</a> ).
<b>End function</b>	Close the dialog window with <TERMIN>.

**NOTE**

- A differentiation between element 1 and element 2 is required only when calculating a symmetry surface from two intersecting surfaces.
- If the name allocation is not activated ([▶ „Allocating names“ on page 5-9](#)) the dialog window will not appear. In this case the last element in the record is element 1 and the next to last element 2.


### Application examples

#### Symmetry point




#### Symmetry surfaces


Surface 1 and 2 are approximately parallel ( $\pm 0.5^\circ$ )



Surface 1 and 2 intersect



#### Symmetry axis




## Mean value calculation <DI 1345>

**Application**

This program calculates the mean values of individual symbols from several record addresses.

**Application example**

For elements whose results are widely dispersed due to form error, you can perform repeat measurements and then calculate their mean value.



Dialog
□
□

Y      Form mean value from x      (CANCEL = TERMIN)

YES	NO		
-----	----	--	--

\*

--	--	--	--

CANCEL		
--------	--	--

--	--	--

### Explanation of dialog

**Result name**

An inquiry will appear only if the name allocation is activated. Enter the name you want to assign to the result (observe rules in [▶ „Allocating names“ on page 5-9](#)).

**Form mean value from X?  
(CANCEL = TERMIN)**

All symbols are offered in succession. Use <YES>/<NO> to select or reject each individual symbol for calculation of the mean value.

If you press **<CANCEL>** the symbols which have not yet been inquired on will be skipped and the dialog will be continued.

**X Y D . . . o.k.?**

Verification inquiry.

**Enter addresses**

Enter the addresses you want to link to one another for the mean value calculation in the **"Mean value"** dialog window.

Close the dialog window with **<TERMIN>**. The mean values of the selected symbols are output under a new address.

Mean value

	from address/name	to address/name	Step width
<input type="checkbox"/> C	1	4	1
			1
			1
			1
			1
			1
			1
			1
			1

\*  **TERMIN**

**BACK**  **INFO**

## Data boxes

**from address/name**

Enter the name or address of the first element of an area to be recalled.

**to address/name**

Enter the name or address of the last element of an area to be recalled.

**Step width**

Distance between the elements required within an area.


### NOTE

- Elements can be recalled from a maximum of eight areas.
- Relative addresses can also be used (► „*Recall of an address <DI 1301>*“ on page 10-29).

## Formula calculation <DI 1379>

With this function:

- function values can be calculated from measuring results (sine, root etc.)
- measuring results can be linked or combined with constants by operators
- multiple measuring results can be interlinked by operators.



Dialog

Formula

Result name

Formula

\* YES
NO
< - >
< + >

\*




TERMIN

BACK

INFO

### Explanation

**Result name**

An inquiry will appear only if the name allocation is activated. Enter the name you want to assign to the result of the calculation (Observe the rules in [▶ „Allocating names“ on page 5-9](#)).

**Formula**

Enter formula and confirm with **<Enter>**.

## Rules

- You can access measured values by entering the required symbol (X, Y, Z,...) with the address in brackets.

**Example:** The X-axis measured value from record address 18 is required. Input: **X(18)**

Relative addresses can also be used (▶ „*Recall of an address <DI 1301>*“ on page 10-29).

- Permissible **operators:**

<b>+</b>	(addition)	<b>-</b>	(subtraction)
<b>*</b>	(multiplication)	<b>/</b>	(division)

- Permissible **functions:**

<b>SIN</b>	sine	<b>COS</b>	cosine
<b>TAN</b>	tangent	<b>SQR</b>	root
<b>ASN</b>	arc sine	<b>ACS</b>	arc cosine
<b>ATN</b>	arc tangent	<b>ABS</b>	amount
<b>SGN</b>	+/- sign		

- Each formula must contain **at least one measured value.**
- Each formula may contain **a maximum of three operators.**

### NOTE


When linking (combining) different symbols, the result is output with the symbol of the first measurement.



**Application examples**


Difference of angle **A1** from address 10 and address 14:

**FORMULA = A1(10) – A1(14)**



Vertical length along a slot:


- 10 CIRCLE**
- 11 CIRCLE**
- 12 DISTANCE**
- 13 POLAR**
- 14 FORMULA <DI 1379>**  
 $D(10) / 2 + D(11) / 2$
- 15 FORMULA <DI 1379>**  
 $D(14) + R(13)$




## Pitch measurements <DI 1310>

### Application


This program can be used to check circular pitch (e.g. of hole circles, gears) and linear pitch (e.g. of rows of holes, toothed racks). The position of the individual elements, individual and cumulative pitch error, pitch spread and radial deviation (with circular pitch) are calculated.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1310 PITCH		



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1311 CIRCPIT	Eval Additions Circular pitch...	



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1312 LINPIT	Eval Additions Linear pitch...	

### Differences between various direct inputs

- <DI 1310> does not enter a preassignment in the dialog window.
- <DI 1311> enters the preassignment **Circular pitch = \***.
- <DI 1312> enters the preassignment **Linear pitch = \***.

The preassignments can be changed in the dialog window.

Dialog			
Pitch			
<input type="checkbox"/> C	Result name	<input type="text" value="PITCH 1"/>	
<input type="checkbox"/>	Circular pitch	<input type="checkbox"/>	
	Plane	xy <input type="checkbox"/>	or yz <input type="checkbox"/>
		or zx <input type="checkbox"/>	<input type="checkbox"/>
	Ref. center is	<input type="checkbox"/>	
	zero point	* <input type="text"/>	
	or address/name	<input type="text"/>	
	Nominal pitch no.	<input type="text" value="1"/>	
<input type="checkbox"/>	or linear pitch	<input type="checkbox"/>	
	in direction	x <input type="checkbox"/>	or y <input type="checkbox"/>
		or z <input type="checkbox"/>	<input type="checkbox"/>
	Pitch step	<input type="text" value="1.0000"/>	
<input type="button" value="YES"/>		<input type="button" value="NO"/>	
<input type="button" value="BACK"/>		<input type="button" value="INFO"/>	

### Softkeys

Used to accept/reject the <YES>/<NO> box currently highlighted.

Closes the dialog window and opens the "Recall of several elements" window to select the elements for the pitch measurement

Cancel the pitch measurement and returns the program to the main menu.

### Data boxes

#### Result name

This box is activated only if the name allocation is on ([▶ „Allocating names“ on page 5-9](#)).

#### Circular pitch

Enter <YES> here to check the circular pitch.

#### Plane

Select the measuring plane in which the circular pitch is to be checked with <YES>/<NO>.

- Reference center is** Defines the reference center for the pitch measurement.
- Options:
- zero point = \*** The zero point of the workpiece coordinate system is the reference center for the pitch measurement.
  - address/name** Enter the address or name which is to be the reference center for the pitch measurement.
- Nominal pitch no.** Enter the theoretical number of elements which make up the pitch circle (see example).
- linear pitch** Enter **<YES>** here to check the linear pitches.
- in direction** Select the coordinate direction in which the pitch should be checked with **<YES>/<NO>**.
- Pitch step** Enter the nominal pitch step in mm. Make sure that the +/- sign is correct. (see example).
- Procedure** Fill in the data boxes for the circular or linear pitch and close the dialog window with **<TERMIN>**. The following dialog window will then appear. The elements for pitch measurement must be defined in this window.

Dialog
□
□

Pitch

	from address/name	to address/name	Step width
<input type="checkbox"/> C	<input style="width: 100%;" type="text" value="1"/>	<input style="width: 100%;" type="text" value="4"/>	<input style="width: 100%;" type="text" value="1"/>
	<input style="width: 100%;" type="text"/>	<input style="width: 100%;" type="text"/>	<input style="width: 100%;" type="text" value="1"/>
	<input style="width: 100%;" type="text"/>	<input style="width: 100%;" type="text"/>	<input style="width: 100%;" type="text" value="1"/>
	<input style="width: 100%;" type="text"/>	<input style="width: 100%;" type="text"/>	<input style="width: 100%;" type="text" value="1"/>
	<input style="width: 100%;" type="text"/>	<input style="width: 100%;" type="text"/>	<input style="width: 100%;" type="text" value="1"/>
	<input style="width: 100%;" type="text"/>	<input style="width: 100%;" type="text"/>	<input style="width: 100%;" type="text" value="1"/>
	<input style="width: 100%;" type="text"/>	<input style="width: 100%;" type="text"/>	<input style="width: 100%;" type="text" value="1"/>
	<input style="width: 100%;" type="text"/>	<input style="width: 100%;" type="text"/>	<input style="width: 100%;" type="text" value="1"/>
	<input style="width: 100%;" type="text"/>	<input style="width: 100%;" type="text"/>	<input style="width: 100%;" type="text" value="1"/>
	<input style="width: 100%;" type="text"/>	<input style="width: 100%;" type="text"/>	<input style="width: 100%;" type="text" value="1"/>

\*

TERMIN

BACK


INFO

**Data boxes**

<b>from address/name</b>	Enter the name or address of the first element of an area to be recalled.
<b>to address/name</b>	Enter the name or address of the last element of an area to be recalled.
<b>Step width</b>	Distance between required elements within an area.

**NOTE**

- Elements can be recalled from a maximum of eight areas.
- Relative addresses can be used (**>** „*Recall of an address <DI 1301>*“ on page 10-29).
- **Circular pitch:** The elements must be recalled with a mathematically positive direction of rotation (see example). The direction of rotation applies when looking at the measuring plane from the positive counting direction of the third axis.
- **Linear pitch:** The sequence of recalled elements must agree with the +/- signs for **Pitch step** (see example).

**Example for input of row of holes (linear pitch)****Eingabe**

- **Linear pitch in direction X ? = \***
  - **Pitch step = 10**
  - **From address 23 to address 19 step 1**
- or
- **Linear pitch in direction X ? = \***
  - **Pitch step = -10**
  - **From address 19 to address 23 step 1**

Result output

```

                PITCH MEASUREMENT (LINEAR PITCH)
                =====
                NOMINAL PITCH =    10.0000 MM IN X - DIRECTION
                FROM    23 TO    19 STEP    1
                NO      POS      p      pk      fp      Fp      fu
    28  23/22      15.0682  10.0842  10.0842   .0842   .0842
    29  22/21      25.1342  10.0660  20.1502   .0660   .1502  -.0182
    30  21/20      35.0039   9.8697  30.0199  -.1303   .0199  -.1963
    31  20/19      44.9638   9.9599  39.9798  -.0401  -.0202   .0902

                EXTREME VALUES OF PITCH MEASUREMENT

    PITCH_1
    32      MIN      X      25.1342
                        Y      13.5023
                        Z      3.8612

    PITCH_2
    33      MAX      X      35.0039
                        Y      13.4865
                        Z      7.2385
    MIN PITCH STEP      9.8697

    PITCH_3
    34      MIN      X      4.9840
                        Y      13.5166
                        Z      7.6598

    PITCH_4
    35      MAX      X      15.0682
                        Y      13.5068
                        Z      9.0125
    MAX PITCH STEP      10.0842
    
```

Explanation

- An address is assigned to each pitch step (in examples 28 to 31).
- The **NO** column specifies the addresses of the elements to which the respective pitch step refers.
- Extreme values of the pitch measurement:  
The first (**MIN**) and second (**MAX**) element of the largest and smallest pitch step are output.

- The columns **POS**, **p** and **pk** contain the position of the individual elements:


**POS:** Position of the 2nd element of a pitch step in the workpiece coordinate system.

**p:** Distance between the two elements of a pitch step

**pk:** Distance between the first element of the pitch measurement (in the example address 23) and the second element of the pitch step.

### Example

Pitch step NO 21/20



- The columns **fp**, **Fp** and **fu** contain the pitch errors:

- Adjacent pitch error

$$\mathbf{fp} = \mathbf{p} - \mathbf{PITCH\ STEP}$$

(Difference between specified pitch step and actual distance between the two elements).

- Cumulative pitch error

$$\mathbf{Fp} = \mathbf{Sfp} = \mathbf{pk} - \mathbf{n} * \mathbf{PITCH\ STEP}$$


(Sum of adjacent pitch errors, difference between nominal and actual distance of an element from the first element of the pitch measurement).

- Pitch spread (difference between adjacent pitches)

$$\mathbf{fu} = \mathbf{fpi} - \mathbf{fpi-1}$$

(difference between the preceding and the current adjacent pitch error).

### Example for input of circular pitch



#### Explanation

- An address is assigned to each pitch step (in examples 28 to 32).
- The **NO** column indicates the addresses of the elements to which the respective pitch step refers.
- The **POS**, **p** and **pk** columns contain the angular positions of the individual elements:

**POS:** Angle between the reference axis and the second element of the respective pitch step.

**p:** Angle between the two elements of a pitch step.

**pk:** Angle between the first element of the pitch measurement (in the example address 24) and the second element of the respective pitch step.




## Circular pitch

PITCH MEASUREMENT (CIRCULAR PITCH)								
=====								
REFERENCE: ZERO POINT								
NOMINAL PITCH = 8.0000								
FROM 24 TO 20 STEP 2								
FROM 4 TO 3 STEP 1								
FROM 18 TO 18 STEP 1								
	NO	POS	p	pk	fp	Fp	fu	Fr
28	24/22	135.0271	45.0271	45.0271	.0028	.0028		-.0204
29	22/20	180.0354	45.0083	90.0354	.0013	.0041	-.0015	.0035
30	20/4	225.0134	44.9780	135.0134	-.0023	.0018	-.0036	.0142
31	4/3	269.9812	44.9678	179.9812	-.0034	-.0016	-.0011	.0216
32	3/18	315.0065	45.0253	225.0065	.0011	-.0005	.0045	-.0143
EXTREME VALUES OF PITCH MEASUREMENT								
PITCH_1								
33	MIN	X	-8.0146					
		Y	.0121					
		Z	25.3681					
PITCH_2								
34	MAX	X	-5.5746					
		Y	-5.6024					
		Z	27.3846					
	MIN PITCH STEP		44.9678					
PITCH_3								
35	MIN	X	.0627					
		Y	8.0021					
		Z	19.2684					
PITCH_4								
36	MAX	X	-5.7562					
		Y	5.6624					
		Z	23.7516					
	MAX PITCH STEP		45.0271					

**Example**

Pitch step NO 22/20



**Reference axis**

The reference axis is always an axis of the workpiece coordinate system or an axis parallel to it. It is dependent on the measuring plane selected:


Measuring plane	Reference axis
ZY plane (1)	Y axis (or one parallel)
XZ plane (2)	Z axis (or one parallel)
YX plane(3)	X axis (or one parallel)

The **fp**, **Fp** and **fu** columns contain the pitch errors (in mm):


- fp:** Adjacent pitch error (difference between the nominal and actual arc length of an individual pitch step).
- Fp:** Cumulative pitch error (difference between the nominal and actual arc length between the first element of the pitch measurement and the second element of the respective pitch step). Sum of the adjacent pitch errors.
- fu:** Difference between adjacent pitches (Difference between the arc length of the previous and the current pitch step)  

$$\mathbf{fu = fpi - fpi-1}$$

## Example



- The **Fr** column contains the radial runout of the second element of the respective pitch step. The radial runout is the radial deviation of the element from the nominal pitch circle. The nominal pitch circle is defined by the reference center and the first element of the pitch measurement.




- Extreme values of the pitch measurement:  
The first (**MIN**) and second (**MAX**) element of the largest and smallest pitch step are output.


## Determining the minimum and maximum of measurement results <DI 1341> <DI 1343>

**Application** Using these functions you can determine the minimum or maximum for 1 symbol from the preselected measurement results.

**NOMINAL/ACTUAL** Enter the nominal value for the designed symbol immediately before calling <DI 1341/1343>.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1341	Elements Special elements Min calculation...	



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1343	Elements Special elements Max calculation...	

Dialog

Calculate minimum

C Result name

Minimum of X -Values  \*

or Y -Values

or Z -Values

or D -Values

or D2-Values

or A1-Values

or A2-Values

or AC-Values

\* YES NO   \*     TERMIN

BACK         INFO

**Procedure**

Accept/reject the highlighted <YES>/<NO> BOX. Close the dialog window with <TERMIN>. The following dialog window then appears.

Calculate minimum

	from address/name	to address/name	Step width
<input type="checkbox"/> C	1	4	1
			1
			1
			1
			1
			1
			1
			1
			1
			1

\*  **TERMIN**

**BACK**  **INFO**


**Data boxes**

- from address/name** Enter the name or address of the first element of an area to be recalled.
- to address/name** Enter the name or address of the last element of an area to be recalled.
- Step width** Distance of the elements required within an area.

## Generating a plane by linking <DI 1265>

**Application**

There are three ways of generating a plane by linking. However, you can choose only one of them at a time.



Dialog

Generate plane by linking

? Select linking type with YES/NO keys

\* Plane through point vertical to line

Plane through point and line

Plane vertical to two lines

Addr/Name of point/line element


Addr/Name of line element

Result name


\* YES NO   \*    TERMIN

PRE MENU     INFO


Plane through point  
vertical to line



Plane through point  
and line



### Plane vertical to two lines



### Explanation

The normal vector of the plane is vertical to the two directions of the elements selected, whereby the selection of **Addr/Name of point/line element** specifies the position of the plane.


For deviations, the position of the plane can then be moved parallel to the first task **Plane through point vertical to line**.



## Generating a point by projecting from point to line <DI 1266>

### Application

You can choose one of three options, depending on the features the **Point** result should have.



Dialog

Generate point by projecting from point to line

? Select linking type with YES/NO keys

\* Generate point result

Generate 3D point result

Generate edge point result

Addr/Name of point element

Addr/Name of line element

Result name

\* YES


NO

\*

TERMIN

PRE MENU

INFO



### Generate point result

Only the XYZ coordinates are stored for the **Point** result. The distance of the point from the line is given with the point as **D** (diameter).

### Generate 3D point result

For the **3D point**, the direction of the perpendicular is provided to the 3D point as the normal vector. The distance of the point from the line is given with the 3D point as **D** (diameter).

### Generate edge point result

For the **Edge point** result, the direction of the line (axis) is included as the direction. The distance between the point and the line is given with the edge point as **D** (diameter).

# Chapter

# 13

## Conversion of results

---

### **This chapter contains:**


Conversion of results . . . . .	13-2
Calculation of polar distances . . . . .	13-7
Penetration point <DI 1217> . . . . .	13-11
Additional cone program <DI 1243> . . . . .	13-13
Cone angle correction <DI 1144> . . . . .	13-15

# Conversion of results

## Angle output in degrees, minutes and seconds <DI 1682>

**Application**

This function converts the decimal angle of the last record address into degrees/minutes/seconds.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1682	Eval	
ANGDMS	Angle	
a53	Output Deg/Min/Sec	

The result is output under the same record address.

Record						
LINE_1						
31	LINE	Y	36.4214			
		Z	55.9114			
	X/Z	A1	1.5793			
	Y/Z	A2	-39.8900			
		A1	1 DEG	34 MIN	45.30 SEC	
		A2	-39 DEG	-53 MIN	-24.10 SEC	

Angle deviations can be output only in decimal degrees.

**NOTE**


For the nominal input, nominals and tolerances for angles can also be entered in deg/min/sec. The numerical values must be separated by a slash. It is not necessary to call <DI 1682>.

## Calculation of the rotation and tilt angle <DI 1204>

**Application**

The <ANGLE> function converts the project angles of the last record address into rotational and tilting angles.

If the last record address contains no projected angles, the angle formed by the last two elements in the record and a reference axis will be calculated. In addition, the polar distance between the two elements will be output.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1204	Eval	
ANG	Angle	
	Angle	


**Reference axis**

The reference axis is dependent on the measuring plane:


Measuring plane	Reference axis
YZ plane (1)	Y axis (or one parallel)
ZX plane (2)	Z axis (or one parallel)
XY plane (3)	X axis (or one parallel)

**Result output**

- The last record address contains an axis or a normal:




- If the last address contains no axis or normal:
  - The last two addresses each contain a point probing (**D** = Projected polar distance of both points):



POINT	Y	4.5132
POINT	Y	17.7539
ANG	D	9.7667
	Y/X	A1 40.5548

↑  
Reference axis


- The last two addresses contain two centers in one plane (**D** = Projected polar distance between the centers):



CIRCLEI	X	55.5132
	Y	53.6750
	D	12.0265
CIRCLEI	X	12.5132
	Y	20.6750
	D	12.0120
ANG	D	73.9765
	Y/X	A1 40.5810

↑  
Reference axis

- The last two addresses contain two centers along one axis (**D** = Spatial polar distance between the centers, **A1**, **A2** = Projected angle of connecting line, **„Projected angles“ on page 10-53**):




CIRCLEI	X	15.1021
	Z	20.0210
	D	10.0160
CIRCLEI	X	15.5132
	Z	20.1750
	D	10.0120
ANG	D	24.9765
	Z/Y	A1 0.1462
	X/Y	A2 0.2810


- The last two addresses contain two spatially defined points (sphere, penetration point, space point): The spatial polar distance (**D**) and a projected angle of the connecting line are output.

## Changing the reference axis and direction of rotation <DI 1251>

### Application

You can use this program to change the direction of rotation and the reference axis in results previously measured or calculated. In this way you can e.g. adapt measured angles to drawing data.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1251 CONVANG a51	Eval Angle Conversion...	

### Explanation

Element ANGLE\_1  
Result ANGCONV\_2

This inquiry will not appear if the name allocation is switched off (>„Allocating names“ on page 5-9).

Conversion of A1?  
Conversion of A2?

This inquiry will appear only if the reference element contains two projected angles. Select between A1 and A2 with <YES> / <NO>.

(+Z -Z +X -X) Ref. axis =

Enter the required angle reference angle and confirm with <Enter>.

The reference axis can be changed only within a measuring plane. The axes offered in brackets are allowed.

Clockwise rotation?


The direction of rotation applies when viewing the measuring plane from the positive counting direction of the 3rd axis.

- <YES>

Mathematically negative direction of rotation (-)

- <NO>

Mathematically positive direction of rotation (+)



**Possibilities for representing an angle in the Y/X measuring plane**

REFERENCE AXIS	ROTATION	RESULT
+ X	CLOCKWISE (NEGATIVE)	30°
- Y		300°
- X		210°
+ Y		120°
+ X	COUNTERCLOCKWISE (POSITIVE)	330°
- Y		60°
- X		150°
+ Y		240°




## Calculation of polar distances


### Polar distance in one plane <DI 1203>

#### Application

The <POLAR> function enables

- conversion of the cartesian coordinates of a geometric element to polar coordinates (polar distance from zero point)
- determination of the polar distance from the <DISTANCE> between two elements in a measuring plane.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1203 DISPOL2D	Eval Distance polar 2D	


#### Name allocation

If the name allocation is activated (> „*Setting the operating mode for the measuring probe head <DI 1502>*“ on page 6-18) a result name inquiry will appear.


<DI 1203> will be used for the last element in the record.

#### NOTE


- The element entered must always contain a pair of coordinates.
- If a geometric element is preset, its polar distance from the zero point of the workpiece coordinate system will be calculated.




The reference axis of the angle output is dependent on the measuring plane:



If the element entered is the **<DISTANCE>** between two geometric elements, the polar distance of both elements is calculated.



The angle output is dependent on which element was element 1 with the calculation of **<DISTANCE>** :





## Space diagonal <DI 1261>

### Application

The <R POLAR> function enables

- conversion of the cartesian coordinates of a geometric element to polar coordinates (polar distance from zero point)
- determination of the polar distance from the <DISTANCE> between two elements in the 3D coordinate system.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1261 DISPOL3D a61	Eval Distance polar 3D	

### Result name


If the name allocation is activated (> „*Setting the operating mode for the measuring probe head <DI 1502>*“ on page 6-18) an additional result name inquiry will appear.

### NOTE


<DI 1261> is applied to the last element in the record.

- Interpretation of results:  
**RD**: Length of space diagonals **WX**, **WY**, **WZ**: Angle between space diagonal and coordinate axis.
- With a nom-act comparison, the nominal value for the space diagonal must be entered in the **R** input line.
- The element entered must be defined by three coordinates (X, Y and Z).
- If the specified element is a point defined by 3 coordinates (e.g. space point, sphere center, intersection point), its polar distance

will be calculated from the zero point of the workpiece coordinate system.




- If the element entered is the **<DISTANCE>** between two spatially defined elements, the polar distance between the two elements will be calculated.



## Penetration point <DI 1217>

**Application** This function calculates the penetration point of an axis or normal through the reference plane.




**Result name** If the name allocation is activated (> „*Setting the operating mode for the measuring probe head <DI 1502>*“ on page 6-18), a result name inquiry will appear.

<DI 1217> is applied to the last element in the record.

**Result** The result is output as an intersection point:

Record				
DUSPKT_1 (LINE_5)				
14	CRNR-PT	X	13.7654	
		Y	10.6544	

Examples



**NOTE**


For a surface, the normal is placed at the point where the reference axis penetrates the surface. The point where the normal penetrates the reference surface is output.

## Additional cone program <DI 1243>

### Application

The following data can be determined with <DI 1243>:

- The cone diameter at a defined point
- The center coordinates with a given cone diameter.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1243 ADDCONE	Eval Additions	
a43	Additional cone...	

### Result name

If the name allocation is activated (>„*Setting the operating mode for the measuring probe head <DI 1502>*“ on page 6-18) an additional result name inquiry will appear.

<DI 1243> is applied to the last element in the record, which must be a cone.


### Explanation

#### Calculate diameter?

- <YES>  
The diameter of the cone is defined for a specified height.
- <NO>  
The coordinates of a specified diameter are defined.

#### Diameter calcul/height =

Enter height **H** where the diameter is to be defined (enter the correct +/- sign!).



Output:


```
ADDCONE_1(CONE_1)
  INTERS. HEIGHT  100.000
34 CON DIA      D  53.136
```

If a negative cone diameter is output, the diameter is on the other side of the cone tip

# Conversion of results

**Coord. determ./  
diameter =**

Enter diameter **D** for which the center point coordinates are to be calculated.



Output:

```
ADDCONE_2(CONE_1)
DIAMETER D 50.000
35 CON.CO  X 53.136
           Y 15.243
           Z  5.542
```

**Height = 200.000 ok?  
Diameter = 60.000 ok?**


Verification inquiry depending on preceding input.



## Cone angle correction <DI 1144>

### Application

3D circle sections can not be measured by a CMM without deviations. These deviations (in the axis of the measured element) lead to considerable falsification of the measuring result for cones. The probings can be corrected via their distance from the calculated intersection plane of the circle and the cone angle.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1144	Elements Data acquisition Cone correction...	

### Procedure

- Measure cone.
- Call <DI 1144>;  
the element window for CIRCLE then opens.
- Scan cone segment as circle.

### NOTE

The program takes the cone angle of the cone evaluated last. The result of the cone measurement must be available as the last address (if necessary via recall).

<DI 1144> must be called individually for each section.



# Chapter

# 14

## **Dimensional, form and position tolerances**

---

### **This chapter contains:**

Dimensional tolerances .....	14-2
Form tolerances .....	14-18
Position tolerances .....	14-30
Superposition of form and position deviations .....	14-60
Deleting outliers <DI 1181> .....	14-66
Filtering points <DI 1185> .....	14-69

## Dimensional tolerances

### Nominal-actual comparison

Measurements are subjected to a nominal-actual (variance) comparison by specifying nominal sizes. The degree of tolerance utilization or extent to which tolerances are exceeded is then output in the measurement record (printout).

### Procedure

- Select the nominal-actual mode (▶ *„Nominal-actual mode <DI 1454>“* on page 14-2) <DI 1454>
- Specify the nominals and permissible tolerances (▶ *„Nominal input <DI 1459> (old 1452)“* on page 14-8) <DI 1452>
- Enter program for acquiring / converting the toleranced geometric element, e.g. <CIRCLE>
- A result which was previously printed out can be checked for its dimensional accuracy by calling <NOM-ACT> and then <RECALL>.
- If required, record output can be limited to results with nominals or where the tolerance has been exceeded. (▶ *„Defining the scope of the record <DI 1665>“* on page 5-14).
- Further application: The nominal-actual function can also be used **without** checking the nominals for the purpose of displaying the measuring results more clearly in the record (z ▶ *„Nominal input <DI 1459> (old 1452)“* on page 14-8; ▶ *„Input of identifications“* on page 5-9).

### Nominal-actual mode <DI 1454>


### Application

Four methods are available for calculating deviations for a nominal-actual (variance) comparison):

- Standard
- Number scale
- Car body
- Actual value - nominal value

**NOTE**

- The **STANDARD** nominal-actual mode is activated when the software is delivered. Another mode can be set with **<DI 1454>**.
- This mode setting remains the same until it is changed with **<DI 1454>**, even if UMESS is interrupted in the meantime (long-term mode).
- For CNC measuring runs, the nominal-actual mode must be defined by a learn (part) program, since it is not contained elsewhere in the control data.



Dialog

Mode for nom-act comparison

? Select mode with YES/NO keys

\* Nom-act comp. acc. to perf. mode

Nom-act comp. acc. to number scale

Nom-act comparison for car body

Nominal-actual comparison with actual - nominal


* YES	NO					*			TERMIN
	PRE MENU								INFO

**Procedure**

Select the mode required with **<YES>/<NO>** and close the dialog window with **<TERMIN>**.

## Standard mode

In the standard mode deviations are calculated according to the following rules:



	Enter nominal <b>without</b> +/--sign	Enter nominal <b>with</b> +/--sign
Deviation calculation	$ \text{ACT}  -  \text{NOM} $	$\text{ACT} - \text{NOM}$
(1)	$(10.1) - (10.0) = +0.1$	$(+10.1) - (+10.0) = +0.1$
(2)	$(9.7) - (10.0) = -0.3$	$(+9.7) - (+10.0) = -0.3$
(3)	$(5.1) - (5.0) = +0.1$	$(-5.1) - (-5.0) = -0.1$
(4)	$(4.9) - (5.0) = -0.1$	$(-4.9) - (-5.0) = +0.1$
(5)	$(0.1) - (0.1) = \mathbf{0!!}$	$(+0.1) - (-0.1) = \mathbf{+0.2}$


### NOTE

- If the actual dimension is very close to the zero line (near the limit deviation), the +/- sign **must** be entered for the nominal size (cf. example 5).
- With negative actual dimensions, the +/- sign of the deviation depends on whether the nominal dimension was entered with or without a +/- sign (cf. examples 3 and 4).

## Number scale mode

In NC production in particular it is advantageous to take the correction data for the machine tool directly from the measurement record. This is possible in the number scale mode.

In the number scale mode, deviations between actual and nominal dimensions are calculated according to the following rules (compared with **Standard**, the deviation calculation is different when the actual values are negative):




	Enter nominal <b>without</b> +/- sign	Enter nominal <b>with</b> +/- sign
Deviation Calculation	$ACT - \text{sgn}ACT \times NOM$	$ACT - NOM$
(1)	$(+ 0.1) - (+) (10.0) = +0.1$	$(+10.1) - (+10.0) = +0.1$
(2)	$(+ 9.7) - (+) (10.0) = -0.3$	$(+ 9.7) - (+10.0) = -0.3$
(3)	$(- 5.1) - (-) ( 5.0) = -0.1$	$(- 5.1) - (- 5.0) = -0.1$
(4)	$(- 4.9) - (-) ( 5.0) = +0.1$	$(- 4.9) - (- 5.0) = +0.1$
(5)	$(+ 0.1) - (+) ( 0.1) = \mathbf{0!!}$ sgn = +/- sign	$(+ 0.1) - (- 0.1) = \mathbf{+0.2}$

**NOTE**

If the actual dimension is very close to the zero line (near the limit deviation), the +/- sign **must** be entered for the nominal dimensions (cf. example 5).

## Car body mode

The car body mode takes into account that the following applies to the +/- sign of the deviation:



	Enter nominal <b>without</b> +/- sign	Enter nominal <b>with</b> +/- sign
Deviation calculation	$ ACT  -  NOM $	$sgnNOM \times ACT -  NOM $
(1)	$0.1 - 0.2 = -0.1$	$(-) (+0.1) - 0.2 = -0.3$
(2)	$0.8 - 1.0 = -0.2$	$(-) (-0.8) - 1.0 = -0.2$
(3)	$5.2 - 5.0 = +0.2$	$(+) (+5.2) - 5.0 = +0.2$
		$sgn = +/- \text{ sign}$

### NOTE

If the actual dimensions lies very close to the zero line (near the limit deviation), the +/--sign **must** be entered for the nominal (cf. example 1).



### Nom-act comparison with actual-nominal value

If you set this mode, the calculation of the nom-act (variance) comparison will always be performed from the actual to the nominal value.

**NOTE**


- The mode setting is displayed in the measurement record as follows by calling <DI 1454>:  
**Nom-act comparison: CAR BODY MODE = 3**
- A line is created with the corresponding code by calling <DI 1454> in the **Nominal** column of the control data list.

Protokoll										
Nom-act comparison: CAR BODY MODE = 3										
=====										
CONTROL DATA LIST ZEISS UMESS										
WORKPIECE NAME: 1454										
FILE NAME: CNC _____ 30B										
CONTORL DATA LINES: 11 NOMINAL LINES: 0										
=====										
NO	X	Y	Z	Function	SC2	SC1	PCN	CCN	ADR	
	Dialog			Function	SC2	SC1	PCN	CCN	ADR	
NO	Nominal	U.Tol	L.Tol	Function	SC2	SC1	PCN	CCN	ADR	
NO	Identification			Function	SC2	SC1	PCN	CCN	ADR	
=====										
1	3	0	0	0	NOM MOD	0	1	1454	0	
2	X ABCDE	6	0	0	0	NOMINALS SN	0	2	1459	0
3	50.0000	0.5000	-0.5000		LDL NOM V SN	1	0	9919	0	
4		0	0	0	0	NOMINALS SN	0	2	1459	0
5		0.0000	0.0000		LDL NOM V SN	0	0	9919	0	

## Nominal input <DI 1459> (old 1452)

**Application**

This function opens the **Nominal input** dialog window. Nominal dimensions and tolerances can be entered for elements to be checked for dimensional accuracy.



Dialog

Nominal input

Nom-act comparison mode : PERF MOD  
Tolerance mode : ISO middle

Recall ID  Next line number   
or line number

	?	Symbol	Idf	Nominal	UTOL	LTOL	Norm
<input type="checkbox"/>	*	X	ABCDE	0.0000	0.1000	-0.1000	
<input type="checkbox"/>		Y		0.0000	0.0000	0.0000	
<input type="checkbox"/>		Z		0.0000	0.0000	0.0000	
<input type="checkbox"/>		D, D1		0.0000	0.0000	0.0000	
<input type="checkbox"/>		A1		0.0000	0.0000	0.0000	
<input type="checkbox"/>		A2		0.0000	0.0000	0.0000	
<input type="checkbox"/>		AC, D2		0.0000	0.0000	0.0000	
<input type="checkbox"/>		R		0.0000	0.0000	0.0000	

* YES	NO	OPEN UT	OPEN LT		L/S DIM	TERM LIN	TERMIN
BACK					TOL MOD		INFO

**NOTE**

- Geometric elements can be concluded with **<NOMINAL>**. The boxes required for the nominal-actual comparison are preassigned with the rounded off measuring results (► „Switching on the intermediate result display <DI 1188>“ on page 10-8).
- For other functions, **<ACT-NOM>** must always be called immediately before the call with the toleranced dimensions.

- The values of the last nominal value input are stored and offered as the default values the next time the function is called.
- The active evaluation mode from the long-term file is displayed in the header of the dialog window (in the example: **STANDARD**).

### Procedure with nominal input

<b>First box</b>	When the nominal window is called the cursor is initially positioned in the <b>?</b> column. Select the required line using the cursor keys <v> and <^> or by actuating <NO>.
<b>Select line</b>	<p>Activate required line with &lt;YES&gt;. An asterisk (*) then appears in the <b>?</b> column. This means that the nominal input line is activated and the values entered will be included in the nominal-actual (variance) comparison.</p> <p>Move inside of a box with the &lt;&gt;&gt; and &lt;&lt;&gt; cursor keys. Jump to the next box with the &lt;v&gt; and &lt;^&gt; cursor keys or &lt;Enter&gt;.</p>
<b>Identification</b>	Depending on the setting of <DI 1667> you can enter a 5-digit or max. a 10-digit identification in the <b>ldf</b> column. Confirm your input with <Enter>.
<b>Nominal</b>	<p><b>Nominal</b> column: See rules for +/- sign in <b>► „Nominal-actual mode &lt;DI 1454&gt;“ on page 14-2</b>. Conclude input with &lt;Enter&gt;.</p> <p>ISO fits (e.g. <b>25.6H7</b>) can also be entered in this column. After you confirm with &lt;Enter&gt; the tolerances will be entered automatically and the fit identification will be transferred to the <b>NORM</b> box.</p>
<b>Tolerances</b>	<b>UTOL</b> and <b>LTOL</b> columns: Enter upper and lower tolerance and confirm each time with <Enter>.
<b>Next line</b>	After confirming the <b>LTOL</b> column with <Enter>, jump to the next line and fill it in as described above or skip it.
<b>Termin input</b>	When all of the data required has been entered, close the dialog window with <TERMIN>.
<b>Inaccessible boxes</b>	The <b>Next line number</b> , <b>Recall ID</b> and <b>Line number</b> boxes were previously used to enter the nominal blocks. These boxes are now inaccessible (disabled).

## Softkeys

**\* YES**

Selects the line required for the nominal-actual comparison.

**NO**

Skips one line.

**OPEN-UT**

**Upper tolerance open:** If you press this softkey, the number 1000 will be entered in the **UTOL** column and the cursor will then jump to the **LTOL** column.

**OPEN-LT**

**Lower tolerance open:** If you press this softkey, the number -1000 will be entered in the **LTOL** column and the cursor will then jump to the next line.

**L/S DIM**

**Largest/smallest dimension:** Enter the largest permissible dimension in the **Nominal** column and the smallest permissible dimension in the **UTOL** column and confirm each input with **<ENTER>**. If the **<L/S DIM>** softkey is actuated, the nominal as well as the upper and lower tolerance will automatically be calculated and entered in the corresponding column (symmetrical tolerance range). The cursor will then jump to the next line.

**TERM LIN**

**Line end:** Pressing this softkey terminates the line and accepts the values it contains. It does not matter which column a value was entered in. The whole line will automatically be accepted.

**TERMIN**

Accepts the values entered and closes the dialog window.

**BACK**

Cancels the function and returns the program to the previous menu.

**INFO**

Initiates screen display of nominal input information. The program is returned to the dialog window with **<PRE MENU>**.

### NOTE

For angles, the nominal dimension and tolerances may also be entered in the form **degrees/minutes/seconds**. Separation must be performed with a slash (/). When you press **<Enter>**, the values entered will be converted to decimal degrees.

**TOL MOD**

Tolerance mode:

Dialog			
Tolerance mode			
Preassignment of tolerance fields with			
<input checked="" type="checkbox"/> Y	Last input value	<input type="checkbox"/>	or synthetic <input type="checkbox"/>
	or sym. tolerances	<input type="checkbox"/>	or casting <input type="checkbox"/>
	or ISO fine	<input type="checkbox"/>	<input type="checkbox"/> _____
	or ISO medium	<input checked="" type="checkbox"/> *	<input type="checkbox"/> _____
	or ISO coarse	<input type="checkbox"/>	<input type="checkbox"/> _____
	or ISO very coarse	<input type="checkbox"/>	<input type="checkbox"/> Percentile <input type="text" value="0 %"/>
<input type="checkbox"/> * YES	<input type="checkbox"/> NO	<input type="checkbox"/> *	<input type="checkbox"/> SELECT <input type="checkbox"/> CONTINUE <input type="checkbox"/> TERMIN
<input type="checkbox"/> BACK			<input type="checkbox"/> INFO

**\* YES**

Selects the type of tolerance preassigned to the tolerance boxes. The tolerance mode defined is accepted and displayed in the „Nominal input“ dialog window with <TERMIN>.

**NO**

**SELECT**

Selection of the parameters stored for synthetic and casting tolerances.

**CONTINUE**

Preselects additional parameter lines for plastic or casting tolerances.

**Data box**

Percentile

Tolerance utilization in %.

General tolerances for cast parts made of light metal alloys:

	3D diagonal range (3D)	Degree of accuracy	Mold depend.	Series of casting tolerances	Allowance	Highest nominal diameter		Lowest nominal diameter
GRAVITY DIE CAST		GTA 14/5	n. dep.	GTA 15	0 mm	over 1000 mm	up to 1250 mm	up to 18 mm
			dep.	GTA 14/5				
		GTA 15	n. dep.	GTA 15/5				
			dep.	GTA 15				
		GTA 15/5	n. dep.	GTA 16				
dep.	GTA 15/5							
PRESSURE DIE CAST	over 500 mm	GTA 14	n. dep.	GTA 14	0.2 mm	over 1000 mm	up to 1250 mm	up to 18 mm
			dep.		0 mm			
		GTA 14/5	n. dep.	GTA 14/5	0.3 mm			
			dep.		0 mm			
	over 180 to 500 mm	GTA 13/5	n. dep.	GTA 13/5	0.15 mm	over 400 mm	up to 500 mm	
			dep.		0 mm			
		GTA 14	n. dep.	GTA 14	0.2 mm			
			dep.		0 mm			
		GTA 13	n. dep.	GTA 13	0.1 mm			
			dep.		0 mm			
	over 50 to 180 mm	GTA 13/5	n. dep.	GTA 13/5	0.15 mm	over 120 mm	up to 180 mm	
			dep.		0 mm			
		GTA 12/5	n. dep.	GTA 13	0 mm			
			dep.		0 mm			
up to 50 mm	GTA 13	n. dep.	GTA 13	0.1 mm	over 30 mm	up to 50 mm		
		dep.		0 mm				
SAND MOLD		GTA 15/5	n. dep.	GTA 16	0 mm	over 1000 mm	up to 1250 mm	up to 50 mm
			dep.	GTA 15/5				
		GTA 16/5	n. dep.	GTA 17				
			dep.	GTA 16/5				



**NOTE**

The adjustable parameters are based on DIN16901 for plastics and DIN1688, Parts 1, 3 and 4 for metal castings.

## Setting a warning limit <DI 1664>

### Application

A warning limit can be set with this function. This means that: If a measured value exceeds a preset degree of tolerance utilization, a corresponding message will be output to the measurement record.



### Input values

The warning limit can be set to any value between 0 and 100%.

### Softkeys



Deactivates the warning limit check.



Terminates the dialog window, the value entered is accepted.



Terminates the dialog window without accepting the entered or modified value.

### Measurement record printout

If a measured value exceeds the warning limit, this is displayed in the measurement record by the exclamation marks in the **EXC** column.

**Example**

(The warning limit has been set to 70% here)

Record										
ADR	REC	TASK	IDF	SY	ACTUAL	NOMINAL	U.TOL	L.TOL	DEV	EXC
Warning limit set to					70.0 %					
2		CIRCLE I	Cir. 3 D		108.721	109.000	0.150	-0.150	-0.279	-0.129
3		CIRCLE I	Cir. 3 D		108.860	109.000	0.150	-0.150	-0.140	!!!!
4		CIRCLE I	Cir. 3 D		109.070	109.000	0.150	-0.150	0.070	++

### Interpretation of results

**Example**

for the record output of a geometric element with toleranced dimensions

Record										
ADR	REC	TASK	IDF	SY	ACTUAL	NOMINAL	U.TOL	L.TOL	DEV	EXC
22		CIRCLE I	Cir.3 X		-10.130	10.000	0.100	-0.100	0.130	0.030
			Cir.3 Y		20.050	20.000	0.100	-0.100	0.050	++
			12/45D		108.721	109.000	0.150	-0.150	-0.279	-0.129

**The following columns concern the nominal input:**

**IDF**

Identification assigned by the user (if entered).

**NOMINAL,  
U.TOL, L.TOL**

Values entered for nominal size, upper and lower limit deviations.

**DEV**

Difference between actual and nominal sizes, calculated according to the rules explained in [▶ „Nominal-actual mode <DI 1454>“ on page 14-2.](#)



**EXC**

The histogram printed in this column gives you a quick overview of the dimensional accuracy of the measured values checked. If the deviations lie within the prescribed tolerance, this will be indicated by a corresponding number of +/- signs:

Deviations towards the upper limit deviation are indicated by plus signs.

Deviations towards the lower limit deviation are indicated by minus signs.

**Histogram**

Each plus or minus sign corresponds to a 25 % tolerance utilization starting from the center of the tolerance range:

Nominal size outside of the tolerance zone: **34.3**<sub>-0.1</sub>  
-0.5

%	DEV	EXC
75 - 100	-0.1	++++
50 - 75	-0.15	+++
25 - 50	-0.2	++
0 - 25	-0.25	+
0	-0.3	-+
0 - 25	-0.35	-
25 - 50	-0.4	--
50 - 75	-0.45	---
75 - 100	-0.5	----

Nominal inside of the tolerance zone: **12.0** $\pm$ 0.1

%	DEV	EXC
75 - 100	0.1	++++
50 - 75	0.075	+++
25 - 50	0.05	++
0 - 25	0.025	+
0	0	-+
0 - 25	-0.025	-
25 - 50	-0.05	--
50 - 75	-0.075	---
75 - 100	-0.1	----

**NOTE**

If a result is out of tolerance, the numerical value over or under the tolerance will be output. If a specified warning limit is exceeded, (**>** „*Setting a warning limit <DI 1664>*” on page 14-13) exclamation marks will be printed out.

The record output can be limited to results with a defined tolerance utilization (► „Defining the scope of the record <DI 1665>“ on page 5-14).

### Output of deviations referenced to the tolerance center

**Description of the output mode**

For a record printout, the value in the **DEV** (deviation) column should be output referenced to the tolerance center.

In the default mode, this value is output referenced to the nominal size.

**Activating the output mode**

Your system administrator can activate this output mode for you in the file `/home/zeiss/UC/MODLZBDRU__snB` (sn corresponds to the session number) with parameter **S59:1**.

**Code for this output mode**

In the output this mode can be recognized by the vertical line | located at the **DEV** value. Depending on the output medium, there may also be 2 small vertical lines.

**Example 1**

DEV value referring to nominal

Record										
ADR	REC	TASK	IDF	SY	ACTUAL	NOMINAL	U.TOL	L.TOL	DEV	EXC
1		CIRCLE I X_1	X	X	100.8000	100.0000	1.0000	-1.0000	0.8000	++++
		Y_1	Y	Y	149.9000	150.0000	0.2000	-0.2000	-0.1000	--
		D_1	D	D	49.9000	50.0000	0.1000	-0.1000	-0.1000	----
		4P S/MIN/MAX			.0000		(3)	.0000	(1)	.0000
2		CIRCLE I X_2	X	X	100.5000	100.0000	1.0000	0.0000	0.5000	+-
		Y_2	Y	Y	149.9000	150.0000	0.0000	-0.2000	-0.1000	+-
		D_2	D	D	50.0500	50.0000	0.1000	0.0000	0.0500	+-
		4P S/MIN/MAX			.0000		(1)	.0000	(1)	.0000
3		CIRCLE I X_3	X	X	99.5000	100.0000	3.0000	-1.0000	-0.5000	---
		Y_3	Y	Y	150.0500	150.0000	0.2000	-0.1000	0.0500	+-
		D_3	D	D	50.1500	50.0000	0.3000	-0.0500	0.1500	+
		4P S/MIN/MAX			.0000		(3)	.0000	(1)	.0000

Example 2

DEV value referring to tolerance center

Record										
ADR	REC	TASK	IDF	SY	ACTUAL	NOMINAL	U.TOL	L.TOL	DEV	EXC
=====										
1		CIRCLE I	X__1	X	100.8000	100.0000	1.0000	-1.0000	0.8000	++++
			Y__1	Y	149.9000	150.0000	0.2000	-0.2000	-0.1000	--
			D__1	D	49.9000	50.0000	0.1000	-0.1000	-0.1000	----
		4P	S/MIN/MAX		.0000		(3)	.0000	(1)	.0000
2		CIRCLE I	X__2	X	100.5000	100.0000	1.0000	0.0000	0.0000	+-
			Y__2	Y	149.9000	150.0000	0.0000	-0.2000	0.0000	+-
			D__2	D	50.0500	50.0000	0.1000	0.0000	-0.0000	+-
		4P	S/MIN/MAX		.0000		(1)	.0000	(1)	.0000
3		CIRCLE I	X__3	X	99.5000	100.0000	3.0000	-1.0000	-1.5000	---
			Y__3	Y	150.0500	150.0000	0.2000	-0.1000	-0.0000	+-
			D__3	D	50.1500	50.0000	0.3000	-0.0500	0.0250	+
		4P	S/MIN/MAX		.0000		(3)	.0000	(1)	.0000


## Form tolerances

### Definition

Form tolerances limit the deviation of an individual element from its ideal geometric form.

To calculate form deviations, geometric elements must be probed with a large number of points. The actual deviation is determined from the extreme, i.e. **MIN** and **MAX** values.

### Ablauf



### Example


Record										
ADR	REC	TASK	IDF	SY	ACTUAL	NOMINAL	U.TOL	L.TOL	DEV	EXC
1		CIRCLEI	Bo-1	X	-6.0371					
				Y	-2.5704					
				D	9.0238					
4P		S/MIN/MAX			.0099 (1)	-0.0062		(3)		0.0056
2		GDT RND	Bo1tD		0.1592	0.0500				0.1092
					Actual form deviation	Permissible form deviation				Amount

The following form deviations can be checked in UMESS:

- Straightness ➤ „*Straightness <DI 1401>*“ on page 14-19
- Flatness ➤ „*Flatness <DI 1402>*, with reference length *<DI 1472>*“ on page 14-21
- Roundness ➤ „*Roundness <DI 1403>*“ on page 14-26
- Cylindricity ➤ „*Cylindricity <DI 1404>*“ on page 14-28

## Straightness <DI 1401>

### Symbol




### Application

The straightness of lines, cylinder axes and cone axes can be checked with this function.

### Prerequisite

The element to be checked is the last address in the record (measured or placed via recall).



### Data boxes

#### Result name



An inquiry appears only if the name allocation is activated (➤ **„Setting the operating mode for the measuring probe head <DI 1502>“ on page 6-18**). Enter the result name and confirm with <TERMIN> (follow rules in ➤ **„Allocating names“ on page 5-9**).

#### Tol.zone cyl.?


Define the form of the tolerance zone:

- <YES>  
Cylindrical tolerance zone
- <NO>  
Tolerance zone either cuboid or formed by two parallel planes.

With a **cylindrical** tolerance zone, the program calculates the polar distance between the calculated element and the most distant measuring point. The diameter of the actual tolerance cylinder is then obtained by doubling the polar distance.



If a **block-shaped** tolerance zone is specified, the program will calculate the vertical distance between the calculated element and the most distant measuring point.



If **two parallel planes** form the tolerance zone, the straightness deviation will be calculated in one direction only - perpendicular to the line.

**Identific. t**

An inquiry appears only if a cylindrical tolerance zone has been defined.

Enter the identification (max. 10 characters) and diameter of the tolerance zone and confirm each input with **<TERMIN>**.

**Identific. tY**  
**Identific. tZ**

An inquiry appears only if **Tol.zone cyl.? = <NO>** has been set.

Enter the identification (max. 10 characters) and the cross section of the tolerance block (tx, ty, tz) and confirm with **<TERMIN>**.

If the tolerance zone is to be formed from two parallel planes, **tx < 0** must be entered for one coordinate direction.

Output examples


Record										
ADR	REC	TASK	IDF	SY	ACTUAL	NOMINAL	U.TOL	L.TOL	DEV	EXC
16		LINE E		Z	-0.123					
				X	-14.993					
		Z/Y		W1	0.124					
		X/Y		W2	0.042					
		10P S/MIN/MAX			.056		(2)	.002	(5)	.084
Cylindrical tolerance zone:										
17		GDT STR		t	0.168	0.200				++++
Block shaped tolerance zone:										
18		GDT STR		tx	0.159	0.200				++++
				tz	0.015	0.200				+
Tolerance zone from two parallel planes:										
19		GDT STR		tx	0.159	0.200				++++

Corresponds to radius of tolerance cylinder

2 x max

**Flatness <DI 1402>, with reference length <DI 1472>**


Symbol



Application


This function calculates the form deviation of the flatness of a surface.

It determines the distance between two planes which are parallel to the best fit surface and enclose all measuring points.



**Prerequisite**

The <SURFACE> element or a result of the <MIN FLAT> or <MAX FLAT> function (➤ „*Min-max flatness* <DI 1110/1111/1140>“ on page 14-60) is the last address in the record.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1402 GDTPLA	Eval Form Flatness...	

**Data boxes**

**Result name**

An inquiry appears only if the name allocation is activated (➤ „*Setting the operating mode for the measuring probe head* <DI 1502>“ on page 6-18). Enter the result name and confirm with <TERMIN> (follow the rules in ➤ „*Allocating names*“ on page 5-9).

**Identific. t**

Enter the identification (max. 10 characters) and tolerance and confirm with <TERMIN>.




Output example

Record										
ADR	REC	TASK	IDF	SY	ACTUAL	NOMINAL	U.TOL	L.TOL	DEV	EXC
1		SURFACE	X		171.133					
		Y/X	W1		-0.128					
		Z/X	W2		0.012					
		450P S/MIN/MAX			.058	(78)	-.099	(423)	.103	
2		GDT FLT	t		0.202	0.200				0.002


Flatness with reference length

Symbol



Prerequisite

The <SURFACE> element (comprising max. 5000 points) must be the last address in the record.



<b>DI</b>	<b>Pull-Down-Menu</b>	<b>Pictogram</b>
1472	Eval	
GDTFLAPART	Form	
	Flatness/Length...	

### Data boxes

**Result name** This box will be assigned only if the name allocation is activated. Enter the result name for the first deviation. The names of all following deviations will then be incremented automatically.

Flatness with reference length

Result name

Reference length

Nominal tolerance

Output

only the maximum deviation

or all deviations out of tolerance

or all deviations

\* YES NO  \*    TERMIN

BACK     INFO

- Reference length** Edge length of the square part surface to which the flatness is referenced.
- Nominal tolerance** Preset tolerance zone.
- Output only the maximum deviation**
  - **<YES>** Only the maximum deviation of the part surface will be output.
- ... or all deviations out of tolerance**
  - **<YES>** All deviations of the part surface exceeding the nominal tolerance will be output.
- ... or all deviations**
  - **<YES>** All deviations of the part surface will be output.


Output example

Record										
ADR	REC	TASK	IDF	SY	ACTUAL	NOMINAL	U.TOL	L.TOL	DEV	EXC
=====										
1		SURFACE		X	171.133					
		Y/X		W1	-0.128					
		Z/X		W2	0.012					
		450P S/MIN/MAX			.058		(78)	-.099	(423)	.103
2		GDT FLT		t	0.202	0.200				0.002
		GDT Flatness with reference length				50.000				
		Output: Only the maximum deviation								
3		GDT FLT		t	0.198	0.200				++++
				X	172.587					
				Y	-266.142					
				Z	278.365					

A result address is assigned to each deviation output. The deviation and the lower left-hand corner point of the corresponding part surface are output.


## Roundness <DI 1403>

### Symbol




### Application

This function calculates the polar distances (radii) from the center point of the best fit circle to the nearest and furthest probing point. The difference between the two radii is the roundness deviation **t** of the circle.



### Prerequisite

The <CIRCLE> element or a result of the <MIN RUND> or <MAX RUND> function (➤ „*Min-max roundness <DI 1112/1113/1141>*“ on page 14-62) is the last address in the record.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1403 GDTROUN	Eval Form Roundness...	

### Data boxes

#### Result name

An inquiry appears only if the name allocation is activated (➤ „*Setting the operating mode for the measuring probe head <DI 1502>*“ on page 6-18). Enter the result name and confirm with <TERMIN> (follow rules in ➤ „*Allocating names*“ on page 5-9).

#### Identific. t

Enter the identification (max. 10 characters) and tolerance and confirm with <TERMIN>.


Output example

Record										
ADR	REC	TASK	IDF	SY	ACTUAL	NOMINAL	U.TOL	L.TOL	DEV	EXC
11		CIRCLE I		X	171.133					
				Y	20.121					
				D	50.546					
		150P S/MIN/MAX			.053	(72)	-.092	(124)	.104	
12		GDT RND		t	0.196	0.100				0.096

Amounts added


## Cylindricity <DI 1404>

### Symbol



### Application

The program calculates the polar distance from the best fit cylinder axis to the nearest (MIN) and the furthest probing point (MAX). The difference between the two radii is the form deviation of the cylinder.



### Prerequisite

The <CYLINDER> element must be listed under the last record address (measured or placed via recall)

DI	Pull-Down-Menu	Pictogram
1404 GDTCYL	Eval Form Cylinder form...	

## Data boxes

**Result name** An inquiry appears only if the name allocation is activated (► **„Setting the operating mode for the measuring probe head <DI 1502>“ on page 6-18**). Enter the result name and confirm with **<TERMIN>**. (follow rules in ► **„Allocating names“ on page 5-9**).

**Bezeichnung t** Enter the identification (max. 10 characters) and tolerance and confirm with **<TERMIN>**.

### Output example

Record										
ADR	REC	TASK	IDF	SY	ACTUAL	NOMINAL	U.TOL	L.TOL	DEV	EXC
11		CYL I		X	42.949					
				Z	-33.067					
				D	30.027					
		Z/Y		W1	0.008					
		X/Y		W2	-0.003					
		250P S/MIN/MAX			.027		(4)	-.018	(149)	.009
12		GDT CYL		t	0.027	0.050				+++


Amounts added

## Position tolerances

**Definition**


A form deviation is calculated by determining the 3D position of a **measured element** in relation to a **reference element**.

**Procedure**



**NOTE**


- When checking the **PERPENDICULARITY, POSITION, CONCENTRICITY** and **COAXIALITY**, the maximum material condition (**MMC**) for the measured and the reference element can be included in the evaluation.
- When checking the **PARALLELISM, PERPENDICULARITY** und **ANGULARITY** (tilt), half of the form deviation is always included. Prerequisite: the measured element is a surface.





## Parallelism <DI 1415>

### Symbol



### Application


This program is used to determine the parallelism of surfaces and axes (cylinder axis, cone axis etc.).

The following cases can appear:


Measured element	Reference element
Surface	Surface
Surface	Axis
Axis	Surface
Axis	Axis

### NOTE

- The measured element must be the last address in the record.
- The reference element is always the one which is spatially aligned, i.e. is always the element for which <RO SPACE> was last applied.
- If the measured element is a surface, half the form deviation is included in the calculation of the parallelism.



DI	Pull-Down-Menu	Pictogram
1415 GDTPAR	Eval Position Parallelism...	



**SUR/AX**

The combination of measured element and reference element must be specified by softkey (**SUR** = surface, **AX** = axis)

**AX/SUR**

The measured element is before the slash. The spatially aligned reference element is after the slash.

### Case 1: Surface/surface parallelism

**Data boxes**

**Result name**

An inquiry appears only if the name allocation is activated (➤ „**Setting the operating mode for the measuring probe head <DI 1502>**“ on page 6-18). Enter the result name and confirm with <TERMIN>. (Follow rules in ➤ „**Allocating names**“ on page 5-9).

**Identification t**

Possibility of entering an identification with a maximum of 10 characters and specifying the permissible parallelism deviation (distance between two parallel planes).

**REF LENGTH L = mm**

The reference length is the length of the measured element to which permissible parallelism deviation **t** refers. If the measured element is a surface, the reference length is regarded as the length and width of this surface. The program thus calculates with a square surface having the lateral length L.

### Calculation principle

$t_x = \text{reference length} \times \tan A1$  Only the input of a test length is possible!  
 $t_y = \text{reference length} \times \tan A2$

$$\Rightarrow t = (t_x^2 + t_y^2)^{1/2} + 1/2 * \text{Form deviation of the measured element}$$

where t = distance between two parallel planes, parallel to the reference surface which includes the measured element.

### Output example

Record							
1	SURFACE	Z	-443.1780				
	X/Z	A1	0.0639				Reference element
	Y/Z	A2	-0.0442				
	4P S/MIN/MAX		.0051	(1)	-.0029	(2)	.0029
2	ROTATE SPACE	A	0.0777	ABOUT SPACE AXIS Z			
3	SURFACE	Z	-10.0325				
	X/Z	A1	0.0140				Measured element
	Y/Z	A2	-0.0081				
	4P S/MIN/MAX		.0011	(1)	-.0006	(2)	.0006
4	GDT PAR	t	0.0147	0.0500	Test length 50		++
		L	50.0000				
$t_x = 50 \times \tan 0.0140 = 0.0122$ $t_y = 50 \times \tan 0.0081 = 0.0071$ $\Rightarrow t = (0.0122^2 + 0.0071^2)^{1/2} + 1/2 * 0.0012 = 0.0147$							

### Test length

The test length corresponds to the diameter of the measured surface under consideration (a circular surface or the diagonal of a square inscribed in a circle).

If the surface concerned is rectangular, an evaluation can also be performed with GDT rectangularity.

### Case 2: Surface/axis parallelism

#### Data boxes

#### Result name

An inquiry appears only if the name allocation is activated (**> „Setting the operating mode for the measuring probe head <DI 1502>“ on page 6-18**). Enter the result name and confirm with **<TERMIN>**. (Follow rules in **> „Allocating names“ on page 5-9**).

- Meas plane X/Y?** A check for parallelism between axes and surfaces is limited to one plane. The correct measuring plane must be selected with **<YES>/<NO>**.
- Identific. tZ** Possibility of entering an identification with a maximum of 10 characters and specifying the permissible parallelism deviation (distance between two parallel planes).
- REF LENGTH L = mm** The reference length is the length of the measured element to which permissible parallelism deviation **t** refers.

If the measured element is a surface, the reference length will be regarded as the length and width of the surface. The program therefore calculates with a square surface having sides of length L.

### Calculation principle

**tz = ref. length x tan A1 + 1/2 \* Form deviation of the measured element**

**tx = ref. length x tan A2 + 1/2 \* Form deviation of the measured element**

### Output example

Record									
1	CYL I	X	443.9220						
		Y	-565.2997						
		D	30.0802						
		X/Z	A1	-0.0971					Reference element
		Y/Z	A2	-0.0371					
	8P S/MIN/MAX			.0247	(7)	-.00196	(2)	.0210	
2	ROTATE SPACE	A	0.1039						UM RAUM-ACHSE Z
3	SURFACE	Y	-32.0625						
		Z/Y	A1	0.0233					Measured element
		X/Y	A2	-5.3523					
	4P S/MIN/MAX			.0006	(4)	-.0003	(3)	.0003	
4	GDT PAR	tz	0.0207	0.0500				Test length 50	++
		L	50.0000						
5	GDT PAR	tx	4.6847	0.0500				Test length 50	4.6347
		L	50.0000						
<p>tz = 50 * tan 0.0233 + 1/2 * 0.006 = 0.0207</p> <p>tx = 50 * tan 5.3523 + 1/2 * 0.006 = 4.6847</p>									

**Measuring plane** The surface/axis parallelism can be checked in two measuring planes. Input of one test length per measuring plane is possible. However, it only makes sense to consider the parallelism in the Z/Y coordinate plane.

If **<RO PLANE>** is performed with the measured element before **GDT PAR**  $\Rightarrow$  **tx = 1/2** form deviation.

### Case 3: Axis-surface parallelism

**Data boxes**

**Result name** An inquiry appears only if the name allocation is activated (**>„Setting the operating mode for the measuring probe head <DI 1502>“ on page 6-18**). Enter the result name and confirm with **<TERMIN>** (follow rules in **>„Allocating names“ on page 5-9**).

**X/Y measuring plane?** The check for parallelism between axes and surfaces is limited to one plane. Select the correct plane with **<YES>/<NO>**.

**Identific. tZ** Possibility for entering an identification with a maximum of 10 characters and specifying the permissible parallelism deviation.

**REF. LENGTH L = mm** The reference length is the length of the measured element to which the permissible parallelism deviation **t** refers.

### Calculation principle

$$tz = \text{reference length} \times \tan A1$$

$$tx = \text{reference length} \times \tan A2$$

### Output example

Record									
1	SURFACE	X	-443.1583						
	X/Z	W1	0.0630					Reference element	
	Y/Z	W2	-0.0468						
	8P S/MIN/MAX		.0039	(7)	- .0023	(2)	.0023		
2	ROTATE SPACE	W	0.0785	ABOUT SPACE AXIS Z					
3	CYL I	Z	-32.0625						
		X	65.2997						
		D	30.0802						
	Z/Y	W1	0.0037					Measured element	
	X/Y	W2	-5.3843						
	10P S/MIN/MAX		.0012	(5)	- .0011	(7)	.0020		
4	GDT PAR	tz	0.0032	0.0500	Test length 50			+	
		L	50.0000						
5	GDT PAR	tx	4.7125	0.0500	Test length 50				4.6625
		L	50.0000						
			tz = 50 * tan 0.0037 = 0.0032						
			tx = 50 * tan 5.3843 = 4.7125						

### Measuring plane

The axis-surface parallelism can be checked in two measuring planes. Input of one test length per measuring plane is possible. However, only measurement of the parallelism in the Z/Y coordinate plane makes sense.

If <RO PLANE> is performed with the measured element before **GDT PAR** ⇒ **tx = 0**.

### Case 4: Axis-axis parallelism

#### Data boxes

#### Result name

An inquiry appears only if the name allocation is activated (► „**Setting the operating mode for the measuring probe head <DI 1502>**“ on page 6-18). Enter the result name and confirm with <TERMIN> (follow rules in ► „**Allocating names**“ on page 5-9).

#### Tol.zone cyl.?

The form of the tolerance zone can be specified with the axis-axis combination:

- **<YES>**  
Cylindrical tolerance zone
- **<NO>**  
Block-shaped tolerance zone

**Identific. td**  
**Identific. tZ**  
**Identific. tX**

Possibility for entering an identification with a maximum of 10 characters and specifying the permissible parallelism deviation. With a block-shaped tolerance zone, the tolerance is specified in the direction of two coordinate axes. An identification can be entered for each direction.

**REF LENGTH L = mm**

The reference length is the length of the measured element to which the permissible parallelism deviation refers.

**tx = test length x tan W1**    The axis-axis parallelism is checked in  
**ty = test length x tan W2**    two measuring planes or a cylindrical  
**td = (tX<sup>2</sup>+tY<sup>2</sup>)<sup>1/2</sup>**        tolerance zone!

**Output example**

Record									
1	CYL I	X	-443.1583						
		Y	65.2997						
		D	30.0802						
	X/Z	A1	0.0437						Reference element
	Y/Z	A2	-0.0021						
	8P S/MIN/MAX		.0039	(7)	- .0023	(2)	.0023		
2	ROTATE SPACE	A	0.0438						ABOUT SPACE AXIS Z
3	CYL I	Z	-32.0625						
		X	65.3587						
		D	30.0842						
	X/Z	A1	0.0325						Measured element
	Y/Z	A2	-0.0251						
	10P S/MIN/MAX		.0025	(3)	- .0029	(4)	.0029		
4	GDT PAR	tx	0.0283	0.0500				Test length 50	+++
		ty	0.0219	0.0500					++
		L	50.0000						
5	GDT PAR	td	0.0358	0.0500				Test length 50	+++
		L	50.0000						
$tx = 50 * \tan 0.0325 = 0.0283$ $ty = 50 * \tan 0.0251 = 0.0219$ $td = (0.0283^2 + 0.0219^2)^{1/2} = 0.0358$									


## Measuring plane

Input of one test length per measuring plane is possible. One test length is required for the cylindrical tolerance zone.

<RO PLANE> must be executed together with another element to clearly define **tx** or **ty**.

## Angularity (slope) <DI 1435>

### Symbol




### Application

The program checks the slope of axes and surfaces in relation to one another.


### NOTE

- The measured element must be the last address in the record (measured or placed via <RECALL>).
- The reference element is the spatially aligned element (to which <RO SPACE> was last applied).
- The tolerance zone is formed by 2 parallel planes which are located at distance **t** apart and inclined towards the reference element by the nominal angle.
- If the measured element is a surface, half the form deviation will be taken into consideration.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1435 GDTANG	Eval Position Angularity...	





**SUR/AX**

The combination of measured element and reference element must be specified by the softkey. (**SUR** = surface, **AX** = axis)

**AX/SUR**

The measured element is before the slash, the spatially aligned reference element after the slash.

### Data boxes

#### Result name

An inquiry appears only if the name allocation is activated (➤ „**Setting the operating mode for the measuring probe head <DI 1502>**“ on page 6-18). Enter the result name and confirm with <TERMIN> (follow rules in ➤ „**Allocating names**“ on page 5-9).

#### NOM ANGLE = Deg

Enter nominal inclination angle. Confirm with <Enter>.

#### Meas plane X/Y?


The inclination check is limited to one plane. The plane offered is accepted with <YES>, the alternative plane is selected with <NO>.

#### Identific. tX

Possibility for entering an identification of max. 10 characters length and specifying the tolerance (distance between two parallel planes). Confirm all inputs with <Enter>.

REF LENGTH L = mm

Enter length of measured element to which tolerance refers.



If you press **<Enter>** the input will be terminated and the result will be output.

**Calculation principle**

$$tx = \text{reference length} \times \tan (A1_{\text{act}} - A_{\text{nom}}) + 1/2 \times \text{form deviation}$$


**Output example**

Record										
ADR	REC	TASK	IDF	SY	ACTUAL	NOMINAL	U.TOL	L.TOL	DEV	EXC
3		SUEFACE		Z	-28.3805					
		X/Z		W1	-40.0781					
		Y/Z		W2	-0.0948					
		4P S/MIN/MAX			.0014		(4)	-.0008	(3)	.0008
4		GDT ANG		tx	0.0689		0.0500			0.0189
				L	50.0000					
				W	20.0000					

$tx = 50 * \tan (40.0781-40) + 1/2 * 0.0016 = 0.0689$

## Perpendicularity with MMC <DI 1425>

### Symbol




### Application


This program makes it possible to check the perpendicularity of axes and surfaces in any combination.

### NOTE

- The measured element must be the last address on the record.
- The reference element must be spatially aligned (<RO SPACE>).
- If the toleranced element (together with the reference element) is not approximately parallel to a plane of the workpiece coordinate system, the measured element must be aligned mathematically. The following sequence results:
  - Determine measured element
  - <RO PLANE>
  - <RECALL> measured element
  - <GDT PER>
- If the measured element is a surface, half the form deviation is included in the calculation of the perpendicularity.
- If necessary, the maximum material condition (MMC) for the measured and reference element can be included in the program (this does **not** apply to surfaces!).



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1425 GDTPERP	Eval Position Perpendicularity...	



**SUR/AX**

The combination of measured element and reference element must be specified by softkey (**SUR** = surface, **AX** = axis)

**AX/SUR**

The measured element is before the slash, the spatially aligned reference element after the slash.

**Data boxes**

**Result name**

An inquiry appears only if the name allocation is activated (► „*Setting the operating mode for the measuring probe head <DI 1502>*“ on page 6-18). Enter the result name and confirm with <TERMIN> (Follow the rules in ► „*Allocating names*“ on page 5-9).

**GDT REC: d (M)? A (M)**

The question mark shows which question is currently activated. The following must be entered:

**(M)? A (M)**

– <YES>

The maximum material condition is applied to the measured element (offered only if the measured element is an axis).

**(M) A? (M)** Offered only if the reference element is an axis.

- **<YES>**

The address of the reference element must be entered in the dialog.

- **<NO>**

The reference element is the zero point of the workpiece coordinate system.

**d (M) A (M)?**

- **<YES>**

The maximum material condition is applied to the reference element. (Permitted only if the reference element is an axis and not the zero point).

**GDT REC:**

**d (M) A (M) o.k.?**

The inputs are displayed once again for verification.

**Identific. tY**

Enter identification (max. 10 characters) and tolerance in succession and confirm each time with **<Enter>**. Only one inquiry appears for the cylindrical tolerance zone (diameter of tolerance cylinder **td**), and two inquiries for the block-shaped tolerance zone (cross section of tolerance cylinder **tx**, **ty** or **tz**).

**REF ADDRESS =**

An inquiry appears only if the zero point was not selected as the reference. Enter address of reference element and confirm with **<Enter>**. It is **not** permissible to enter relative addresses.

**NOTE**


The reference element must be in the current coordinate system!

**Idf Nominal  
UTOL LTOL**

Inquiry appears only if the maximum material condition was specified for the reference element. Enter identification, nominal diameter, upper and lower tolerance of element in succession and confirm with **<Enter>**.

**REF LENGTH L = mm**

Enter length of measured element to which specified tolerance refers.



If the measured element is a surface, the reference length must be specified in two coordinate directions (**Lx**, **Ly** or **Lz**).

**Calculation principle for surface/surface**

$tx = \text{ref. length1} \times \tan A1 + 1/2 \times \text{form deviation of the measured element}$

$ty = \text{ref. length2} \times \tan A2 + 1/2 \times \text{form deviation of the measured element}$


$t = \text{ref1. length} \times \tan A1 + \text{ref. length2} \times \tan A2 + 1/2 \text{ form.}$

Output example for surface/surface

		Record					
1	SURFACE	Z	-443.1780				
		X/Z	W1	-0.0021			
		Y/Z	W2	-0.0199			
	4P S/MIN/MAX		.0055	(1)	-.0032	(2)	.0031
2	GDT PER	t	0.0050	0.0500			+
		L	50.0000				
$tx = 50 * \tan 0.0021 + 1/2 * 0.0064 = 0.0050$							
3	GDT PER	t	0.0205	0.0500			++
		L	50.0000				
$ty = 50 * \tan 0.0199 + 1/2 * 0.0064 = 0.0205$							
4	GDT PER	t	0.0223	0.0500			++
		L1	50.0000				
		L2	50.0000				
$t = 50 * \tan 0.0021 + 50 * \tan 0.0199 + 1/2 * 0.0064 = 0.0223$							

## Position with MMC <DI 1407>

### Symbols



### Application

This program can be used to check the position of geometric elements.


### NOTE

- The reference element is either the zero point of the workpiece coordinate system or a previously measured element.
- The maximum material condition for the measured and reference element can be included in the evaluation if required.
- The measured element must be the last element in the measurement record.
- If MMC is to be applied to the reference element, the reference element must have a diameter.

Exception:


If **GDT POS** with **MMC** is called following a record printout containing no diameter in its result, the last result printed will be used. This result must contain the **DISTANCE** from two probed points (if the **DISTANCE** is formed from "linkings" or combinations, no inside/outside identification results and the maximum material value can not be calculated).

Example



Sequence for example shown:

**POINT, POINT, DISTANCE, SYMMETRY, GDTPOS with MMC.**



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1407 GDTPOS	Eval Position Position...	

**Data boxes**

**Result name**

An inquiry appears only if the name allocation is activated (➤ **„Setting the operating mode for the measuring probe head <DI 1502>“ on page 6-18**). Enter the result name and confirm with **<TERMIN>** (follow rules in ➤ **„Allocating names“ on page 5-9**).

**GDT POS: d? (M) A (M)**

The question mark shows which question is currently activated. The following must be entered:

**d? (M) A (M)** Form (shape) of tolerance zone

- **<YES>**  
Cylindrical
- **<NO>**  
Cuboid

**d (M)? A (M)**

- **<YES>**  
The maximum material condition is applied to the **measured element**.

**d (M) A? (M)**

- **<YES>**  
Address of reference element must be entered in dialog.



– **<NO>**

The reference element is the zero point of the workpiece coordinate system.

**d (M) A (M)?**– **<YES>**

The maximum material condition is applied to the reference element. (allowed only if the reference element is **not** the zero point).

**GDT POS: d (M) A (M)**  
o.k.?

The inputs are displayed again for verification.

**IDF.= / X =**

Enter identifications for nominal values and for tolerance.

**IDF.= / tD =**

**Identification**

Maximum of 10 characters (printed out in measurement record).

**IDF.= / Y =**

**Nominal position**

Depending on how the measured element is output in the record, the nominal position must be specified in cartesian (X, Y or Z) or in polar coordinates (A, R). If the tolerance zone is cylindrical, changeover is possible using the **<POLAR>** / **<CARTES>** softkeys if **d ?** has been answered with **<YES>**.

**Tolerance**

With a circular or cylindrical tolerance zone, the diameter of the tolerance zone must be specified (one input). With a cuboid tolerance zone, the length of the sides must be specified (two inputs). If a negative value is entered for the tolerance zone, the corresponding coordinate will be omitted in the record.

**REF ADDRESS =**

An inquiry appears only if the zero point is not defined as a reference. Enter address of reference element and confirm with **<Enter>**.

The input of relative addresses is **not** allowed.

**NOTE**

The reference element must be in the current coordinate system!

**Idf Nominal**  
**UTOL LTOL**

An inquiry appears only if the maximum material condition was specified for the measured element. Enter the identification, nominal diameter, upper and lower tolerance of the element in succession and confirm with **<Enter>**.


REF LENGTH

L1 = mm

REF LENGTH

L2 = mm

An inquiry appears only if the measured element is a cylinder or a cone. In this case, the tolerance zone must be defined spatially. The area within which compliance with tolerance is checked must be defined by entering **L1** and **L2**.



## Calculation principle for POSITION with maximum material condition

(See output example for numerical value)

$$tD_{\text{Nom(MMC)}} = tD_{\text{Nom}} + \left| \text{Maximum-Materialcon}_{\text{Meas}} - \text{Actual}_{\text{Meas}} \right| + \left| \text{Maximum-Materialcon}_{\text{Ref.}} - \text{Actual}_{\text{Ref.}} \right|$$

$$tD_{\text{Nom(MMC)}} = 0.2000 + \left| 14.9000 - 14.9857 \right| + \left| 30.0000 - 30.0126 \right|$$

$$tD_{\text{Nom(MMC)}} = 0.2984$$

The largest deviation of the axis of the measured element (ADR 19) from the reference element (ADR 18) is roughly  $Y = 100$  mm. To simplify the calculation, it was performed with the reference element <RO SPACE> in this example.

$$\begin{aligned} X(Y=100) &= \text{sgn}(W2)100 * \tan W2 + X(Y=0) \\ &= +100 * \tan 0.0120 + (-24.9969) = -24.9760 \end{aligned}$$

$$\begin{aligned} Z(Y=100) &= \text{sgn}(W1)100 * \tan W1 + Z(Y=0) \\ &= +100 * \tan 0.0259 + (-13.0002) = -12.9550 \end{aligned}$$

$$\begin{aligned} \text{Difference: } \Delta X &= X_{\text{Meas}}(Y=100) - X_{\text{Ref.}}(Y=100) \\ &= -24.9760 - (-25.0000) = 0.0240 \end{aligned}$$

$$\begin{aligned} \Delta Z &= Z_{\text{Meas}}(Y=100) - Z_{\text{Ref.}}(Y=100) \\ &= -12.9550 - (-13.0000) = 0.0450 \end{aligned}$$


$$\begin{aligned} tD &= 2 * (\Delta X^2 + \Delta Z^2)^{1/2} \\ &= 2 * (0.0240^2 + 0.0450^2)^{1/2} = 0.1020 \end{aligned}$$

Output example

Record										
18	1!	CYL I	Z	0.0000						
			X	0.0000						
			D	30.0126						
		Z/Y	W1	0.0000						Reference element
		X/Y	W2	0.0000						
19		CYL I	Z	-13.0002						
			Y	-24.9969						
			D	14.9857						
		Z/Y	W1	0.0259						Measured element
		X/Y	W2	0.0120						
		10P S/MIN/MAX		.0025	(3)	-.0029	(4)	.0029		
20		GDT POS	X2	-24.9760	$t_{D_{Act}}$	25.0000	$t_{D_{Nom}}$	$t_{D_{Nom(MMC)}}$	0.0240	
			Y2	-12.9550	-13.0000				0.0450	
			tD	0.1020	0.2000	0.2984				++
	1		X/Y	W1	-59.7750	(Used only for further processing in SAM)				
			D1	14.9857	14.9000	0.1000	0.0000	0.0857	+++	
			D2	30.0126	30.0000	0.2000	0.0000	0.0126	----	
			L1	100.0000						
			L2	100.0000						

Symmetry <DI 1410>

Symbol




Application

This program checks the position of the measured element with respect to a reference center plane.

The deviation from the reference point is doubled for the calculation of the actual tolerance. This value is then compared with t-nom.

**NOTE**

- The measured element must be the last address in the record.
- The reference element is either the next to last element in the record or a coordinate plane.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1410 GDTPOS	Eval Position Position...	

**Data boxes**

**Result name**

An inquiry appears only if the name allocation is activated (➤ „*Setting the operating mode for the measuring probe head <DI 1502>*“ on page 6-18). Enter the result name and confirm with <TERMIN> (follow rules in ➤ „*Allocating names*“ on page 5-9).

**Ref. = 0?**

Answer with <YES> or <NO>.

- <YES>

The zero point of the workpiece coordinate system is the reference for the calculation.

- <NO>

The evaluation program refers to the next to last element in the record. You therefore must make sure that the reference center plane is stored under this address.

**Direction? X**

This inquiry appears only if the reference and the measured element contain several coordinates. The coordinate direction offered is accepted with <YES>, the alternative direction is selected with <NO>.

**Identific. tX**

Enter identification (max. 10 characters) and permissible deviation and confirm each time with <Enter>.

**Calculation principle**

$tx = 2 \times \text{Actual}$
-------------------------------


The deviation of the actual value (symmetry point) from the reference mean plane is calculated and doubled to obtain the actual tolerance.

## Output example

Record										
ADR	REC	TASK	IDF	SY	ACTUAL	NOMINAL	U.TOL	L.TOL	DEV	EXC
21		POINT		X	20.0805					
22		POINT		X	-20.0776					
23	21	SY-P	22	X	0.0015					
24		GDT-SYM		tx	0.0030	0.0500				+

### Runout <DI 1445>

Symbol




Application

Elements of rotationally symmetrical parts can be checked with the help of runout tolerances. Cylindrical, conical or run-out surfaces are checked for deviations which would occur in the direction of the arrow(s) if the parts in question were rotated about the reference axis.

**NOTE**

- The measured element must be the last address in the record.
- The reference element depends on the task selected.
- Form errors of the tolerated surfaces may here be included in the runout deviation without being recognized as such.
- The reference element must always be spatially aligned.
- The **CIRCLE** and **SURFACE** programs are recommended for determining normal deviations of the **RADIAL RUNOUT** and **AXIAL RUNOUT** applications. The **MIN-MAX-ROUND** and **MIN-MAX-FLAT** programs must be used for larger form errors. (▶ „*Superposition of form and position deviations*“ on page 14-60).
- The **CUMULATIVE RADIAL RUNOUT** and **CUMULATIVE AXIAL RUNOUT** routines require measurement of the entire element surface. The **MIN-MAX-ROUND** and **MIN-MAX-FLAT** programs must be used in such cases. (▶ „*Superposition of form and position deviations*“ on page 14-60).



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1445 GDTRUN	Eval Position Run...	

Dialog							
GDT RUN							
<input type="checkbox"/> Y	Softkey input						<input type="checkbox"/>
SUR/SUR				SUR/AX	AX/SUR	AX/AX	*
RAD RUN				AX.RUN	CU RA RU	CU AX RU	
CANCEL							

Softkeys for the GDT runout function

```

graph TD
    A[Softkeys for the GDT runout function] --- B[ ]
    B --- C[ ]
    B --- D[ ]
    B --- E[ ]
    C --- F[ ]
    C --- G[ ]
    D --- H[ ]
    D --- I[ ]
    E --- J[ ]
    E --- K[ ]
  
```

The required function can be selected via softkey here. The subsequent dialogs vary according to the function selected:

### Data boxes

#### Result name

An inquiry appears only if the name allocation is activated (► „**Setting the operating mode for the measuring probe head <DI 1502>**“ on page 6-18). Enter the result name and confirm with <TERMIN> (follow rules in ► „**Allocating names**“ on page 5-9).

#### Ref. = 0?

An inquiry appears only for **RADIAL RUNOUT**:

– <YES>

An axis of the workpiece coordinate system is the reference axis.

– <NO>

The evaluation program refers to the next to last element in the record. It therefore must be guaranteed that the reference axis is stored under this address.

#### RADIUS R = mm

An inquiry appears only for **RADIAL RUNOUT**:

Enter radius of plane surface and confirm with <Enter>.

#### Identific. t

Enter the identification (max. 10 characters) and tolerance and confirm with <TERMIN> .

### Calculation principle for radial runout

$$t = 2 \times (X^2 + Y^2)^{1/2}$$

Record										
ADR	REC	TASK	IDF	SY	ACTUAL	NOMINAL	U.TOL	L.TOL	DEV	EXC
50		CIRCEL I		X	-0.0021					
				Y	-0.0013					
				D	30.0336					
		8P S/MIN/MAX			.0011		(5)	-.0006	(2)	.0006
51		GDT RARU		t	0.0049	0.0500				+

### Calculation principle for axial runout


$$t = ((2 \times R \times \tan A1)^2 + (2 \times R \times \tan A2)^2)^{1/2} + 1/2 \times \text{form deviation}$$

Record										
ADR	REC	TASK	IDF	SY	ACTUAL	NOMINAL	U.TOL	L.TOL	DEV	EXC
33		SURFACE		Z	-0.0007					
		X/Z		W1	-0.0063					
		Y/Z		W2	0.0175					
		45P S/MIN/MAX			.0017		(9)	-.0056	(2)	.0046
34		GDT AXRU		t	0.0161	0.0500				++
				R	17.0000					



## Concentricity with MMC <DI 1408>

### Symbol





### Application

This program determines the displacement of a circle center point in relation to a reference point.

#### NOTE

- The measured element must be the last address in the record (measured or placed via <RECALL>).
- The reference element is either the zero point of the workpiece coordinate system or a previously measured element.
- The tolerance zone is always circular.
- If required, the maximum material condition for the measured and reference elements can be included in the calculation.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1408 GDTCON	Eval Position Concentricity...	

### Data boxes

#### Result name

An inquiry appears only if the name allocation is activated (> „**Setting the operating mode for the measuring probe head <DI 1502>**“ on page 6-18). Enter the result name and confirm with <TERMIN> (follow rules in > „**Allocating names**“ on page 5-9).

#### GDT KON: d (M)? A (M)

The question mark shows which inquiry is currently activated. The following must be entered:

**d (M)? A (M)**

- <YES>  
The maximum material condition is applied to the *measured element*.

**d (M) A? (M)**

- <YES>  
The address of the reference element must be entered in the dialog.
- <NO>  
The reference element is the zero point of the workpiece coordinate system.

**d (M) A (M)?**

- <YES>  
The maximum material condition is applied to the *reference element*. (allowed only if the reference element is *not* the zero point).

**d** No inquiry is made on the shape of the tolerance zone. a circular tolerance zone is always computed.

The inputs are displayed once again for verification.

**GDT CON:**  
**d (M) A (M) o.k.?**

**Identific. td**

Enter identification (max. 10 characters) and permissible deviation in succession and confirm each time with <Enter>.

**REFERENCE ADDRESS =**

Enter address of reference element and confirm with <Enter>.

***The reference element must always be in the current coordinate system!***

**Idf Nominal**  
**UTOL LTOL**

The inquiry appears only if the maximum material condition was specified for one of the elements. Enter identification, nominal diameter, upper and lower tolerance of element and confirm with <Enter>.

**Calculation principle for CONCENTRICITY with maximum material condition**

(See output example for numerical value)

$$tD_{Nom(MMC)} = tD_{Nom} + \left| \text{Maximum-Materialcon}_{Meas} - \text{Actual-Meas} \right| + \left| \text{Maximum-Materialcon}_{Ref} - \text{Actual}_{Ref} \right|$$

$$tD_{Nom(MMC)} = 0.0400 + \left| 14.9000 - 14.9857 \right| + \left| 30.0000 - 30.0126 \right|$$

$$tD_{Nom(MMC)} = 0.1383$$

$$\text{Difference: } \Delta X = X_{Meas} - X_{Ref} = 42.0140 - 42.0065 = 0.0075$$

$$\Delta Z = Z_{Meas} - Z_{Ref} = -32.8820 - (-32.8998) = 0.0178$$

$$tD = 2 \times (\Delta X^2 + \Delta Z^2)^{1/2}$$


$$= 2 \times (0.0075^2 + 0.0178^2)^{1/2} = 0.0386$$

Output example

Record										
ADR	REC	TASK	IDF	SY	ACTUAL	NOMINAL	U.TOL	L.TOL	DEV	EXC
=====										
18		CIRCLE I		Z	-32.8998					
				X	42.0065					Reference element
				D	30.0126					
		8P S/MIN/MAX			.0025		(3)	-.0029	(4)	.0029
19		CIRCLE I		Z	-32.8820					Measured element
				X	42.0140					
				D	14.9857					
		10P S/MIN/MAX			.0032		(5)	-.0016	(4)	.0020
20		GDT CON		X	0.0075	0.0000			0.0075	
				Z	0.0178	0.0000			0.0178	
				tD	0.0386	0.0400		0.1383		++
18		X/Y		A1	-59.4567					(Used only for processing in SAM)
				D1	14.9857	14.9000		0.1000	0.0000	0.0857
				D2	30.0126	30.0000		0.2000	0.0000	0.0126
										----

Coaxiality with MMC <DI 1409>

Symbol




Application

This program determines the displacement of an axis (e.g. cylinder or cone axis) compared with a reference axis.

**NOTE**

- The measured element must be the last address in the record (measured or placed via <RECALL>).
- The reference element is either an axis of the workpiece coordinate system or a previously determined element.
- The tolerance zone is always cylindrical.
- If required the maximum material conditions for the measured and the reference element may be included in the calculation.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1409 GDTCOA	Eval Position Coaxiality...	

**Data boxes**

**Result name**

An inquiry appears only if the name allocation is activated (▶ „**Setting the operating mode for the measuring probe head <DI 1502>**“ on page 6-18). Enter the result name and confirm with <TERMIN> (follow rules in ▶ „**Allocating names**“ on page 5-9).

**GDT KOA: d (M)? A (M)**

The question mark shows which question is currently activated. The following entries must be made:

**d (M)? A (M)**

- <YES>  
The maximum material condition is applied to the measured element.

**d (M) A? (M)**

- <YES>  
Address of reference element must be entered in dialog.
- <NO>  
Reference element is zero point of workpiece coordinate system.

**d (M) A (M)?**

- <YES>  
The maximum material condition is applied to the **reference element**. (allowed only if the reference element is **not** the zero point.

**d** No inquiry (concerning form of tolerance zone). The calculation is always performed with a cylindrical tolerance zone.

**GDT KOA: d (M) A (M)**  
o.k.?

The inputs are redisplayed for verification.

**Identific. td**

Enter identification (max. 10 characters) and permissible deviation in succession and confirm with **<Enter>**.

**REF ADDRESS =**

The inquiry appears only if the zero point was not defined as a reference. Enter the address of the reference element and confirm with **<Enter>**. The input of relative addresses is **not** allowed.

***The reference element must be in the current coordinate system!***

**Idf Nominal**  
**OTOL UTOL**


An inquiry appears only if the maximum material condition was specified. Enter the identification, nominal diameter, upper and lower tolerance of the element in succession and confirm with **<Enter>**.

**REF LENGTH**  
**L1 = mm**

**REF LENGTH**  
**L2 = mm**

Enter area to which tolerance entered refers.

- L1** Start of test area,
- L2** End of test area in reference to workpiece coordinate system.



### Calculation principle


See example for GDT-POS (► „Position with MMC <DI 1407>“ on page 14-45)

# Superposition of form and position deviations

## Min-max flatness <DI 1110/1111/1140>

### Application

These programs calculate the superposition of the form and position deviation of a surface. The distance between two planes which are parallel to the workpiece coordinate system and enclose all measuring points between them is determined.




### Difference

There are three programs which differ in result output:

- Min flatness
- Max flatness
- Min-max flatness

### Min flatness


The coordinates of the lowest probing point (referenced to a plane of the workpiece coordinate system) and the distance between the highest and lowest probing point are output.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1110 MINPLA		

**Max flatness**


The coordinates of the highest probing point (referenced to a plane of the workpiece coordinate system) and the distance between the highest and lowest probing point are output.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1111 MAXPLA		

**Min-max flatness**

The coordinates of the highest and the lowest probing point (referenced to a plane of the workpiece coordinate system) and the distance between the highest and lowest probing point are output



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1140 EXTPLA a175	Elements Special elements Min/Max Flat...	

Dialog

Min-Max-Plane

Element name

Use of the last probing points from ADR =  \*

* YES	NO			*				TERMIN
	PRE MENU							INFO

### Data boxes

**Element name**

Enter the name to be assigned to the result here (follow rules in **► „Allocating names“ on page 5-9**). Accept the name offered with **<Enter>** or type in another name and confirm it with **<Enter>**.

**Use of the latest probing points from ADR = 7**

– **<YES>**

The computer checks whether the probing points of a surface, of a line or from min-max flatness are stored under the specified address. If they are, these probing points can be used to calculate the min-max flatness.

– **<NO>**

The computer opens an element window and prompts you to probe the surface.

The last element in the measurement record is always offered as the **ADR**. It can not be changed.

**NOTE**


– The result can subsequently be used to check the **GDT PARALLELISM**, **GDT PERPENDICULARITY** or **GDT RUNOUT**.

– Nominal input (**► „Nominal input <DI 1459> (old 1452)“ on page 14-8**): Enter permissible deviation under A1 in the **NOMINAL** column, set **UTOL** and **LTOL** to zero.

### Min-max roundness <DI 1112/1113/1141>

**Application**

These programs calculate the superposition of the form and position deviation for a circle measurement. The distance between two concentric circles ( $t_{act}$ ) which enclose all probing points is determined. The center point of these circles is the reference point.





**NOTE**

Nominal input (> „Nominal input <DI 1459> (old 1452)“ on page 14-8): Enter permissible deviation under **A1** in the **NOMINAL** column; set **UTOL** and **LTOL** to zero.


**Difference**

There are three programs which differ in the result output:

- Min roundness
- Max roundness
- Min-max roundness

**Min roundness**


The coordinates of the probing point with the smallest radius and the distance between the concentric circles (t) are output.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1112 MINROUN		

**Max roundness**


The coordinates of the probing point with the largest radius and the distance between the concentric circles are output.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1113 MAXROUN		

**Min-max roundness**

The coordinates of the probing points with the smallest and the largest radius and the distance between the concentric circles are output under two addresses.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1141 EXTROUN a177	Elements Special elements Min/Max Round...	

Dialog

Min-Max round

Element name

Reference to zero point ?  Workpiece plane

Reference to address

Use of the last probing points from ADR =

\* YES NO   \*    TERMIN

PRE MENU    INFO

## Data boxes

### Element name

Here you must specify the name which is to be assigned to the result (follow rules in [▶ „Allocating names“ on page 5-9](#)). Accept the name offered with **<Enter>** or type in another name and confirm with **<Enter>**.

### Reference to zero point?

#### – <YES>

The reference point for the calculation is the zero point of the workpiece coordinate system. It therefore must be ensured that the zero point is in the center of the circle to be checked.

#### – <NO>

The reference point for the calculation is a previously determined element.

### Workpiece plane

Input to this box will be prompted only if the zero point is the reference point. The workpiece plane in which the circle to be checked is located must be entered here.

### Reference to address

Input to this box will be prompted only if you answer the question **Reference to zero point ?** with **<NO>**. The address of the element to be used as the reference element must be entered here.

### Use of the last probing points from ADR = 9

– **<YES>**

The computer checks whether the probing points of a circle or from min-max roundness are stored under the address specified. If this is the case, these probing points are used for the calculation of the min-max roundness.

– **<NO>**

The computer opens an element window and prompts you to probe a circle.

The last element in the measuring record is always offered as **ADR**. It can not be changed.

## Deleting outliers <DI 1181>


### Application

Individual measuring points of the N point elements surface, line, circle and cylinder can be deleted as outliers if their distance to the best fit element exceeds a fixed threshold value.

The threshold value is formed from:

#### Factor x standard deviation

Factor = integer from 0 - 20



Dialog

Outlier inspection

Delete outlier

Factor for outlier =  \* Standard deviation

* YES	NO			*	OPTIONS			TERMIN
BACK								INFO

### Data boxes

#### Delete outlier?

<YES>/<NO> to activate/reject function.

#### Factor for outlier = ... \* Standard deviation

Input of an integer from 0 to 20 (empirical value).

**Softkey****OPTIONS**

Branching to the 2nd dialog window

**2nd dialog window**

Dialog	
Outlier inspection	
<input type="checkbox"/> Y Delete outlier	<input type="checkbox"/> *
Factor for outlier inside Workpiece	= <input type="text" value="4"/> * Standard deviation
Factor for outlier outside workpiece	= <input type="text" value="4"/> * Standard deviation
Number of neighboring points to be deleted	<input type="text" value="0"/>
Print deleted outliers on screen?	<input type="checkbox"/>
Print deleted outliers in record?	<input type="checkbox"/>
<input type="button" value=" * YES"/> <input type="button" value=" NO"/>	<input type="button" value=" *"/> <input type="button" value=" TERMIN"/>
<input type="button" value=" BACK"/>	<input type="button" value=" INFO"/>

**Data boxes****Delete outlier?**

&lt;YES&gt; activates the function.

**Factor for outlier inside/outside workpiece = .. \* Standard deviation**Input of an integer from 0 - 20 (empirical value). You can differentiate between outliers which show a depression (**within the workpiece**) and those which show an elevation (**outside of the workpiece**).**Number of neighboring points to be deleted**

Input of the number of points (0 - 20) to be deleted before and after the outlier.

**Print deleted outliers on screen/in record?**

&lt;YES&gt; Outliers are output on the screen or printer.

### NOTE

The function is reset by calling **<DI 1608>** (initial status), by calling **<DI 1610>** (recorder header) or by restarting the measuring system.

## Filtering points <DI 1185>

### Application

The filters described below isolate the waviness profile from the influences of roughness.

The filter type must be selected depending on the type of form tester to be simulated to ensure that the results of the measurements are comparable.

Type of filter	Mode of operation for form tester	Transfer at limiting wavelength
ISO TC57	digital	50%
2RC (ISO 4291)	analog	75%

### Definition


A mean line results from the profile filtration, which takes the waviness and other profile sections of longer wavelength into account. The surface roughness is suppressed in the process. The mean line results by evaluating the profile points within the same sections (= double wavelength): A weighted assessment is made of the points lying within each section. The best fit profile thus acquired forms the basis for calculating the waviness parameters.

Profile filters are characterized by their limiting wavelength. This parameter specifies the wavelength at which the amplitude of a sinus curve still amounts to 50 or 75% after filtration.

# Dimensional, form and position tolerances

**Application**

The filters can be used for the following scanned elements: Circle, circle section(s), line, surface, cylinder, sphere.



Dialog

Point filtering mode

Y Point filtering mode activated  \*

Current filter settings : (The filter selected last is displayed here)

Filter type : Gauss-Filter

Input of threshold wavelength Lambda-C for circles

Transfer with the limit wave length = 50 %

Segments won't be linked

Modification of filter settings via softkey <MODE>

* YES	NO		MODE	*				TERMIN
BACK								INFO

**Data box**

**Point filtering mode activated**

- <YES>**  
Filter is activated.
- <NO>**  
Filter is deactivated.



**Softkey**

**MODE**

Branching to the dialog window **Select filter mode**

-	Dialog	■	■									
<p>Select filter mode (Standard)</p> <p><input checked="" type="checkbox"/> Filtering with ISO TC 57 (Gauss) <input type="checkbox"/> *</p> <p style="padding-left: 40px;">Input of waves per rotation (W/R) for circles</p> <p style="padding-left: 40px;">Input of threshold wavelength (Lambda c) for lines</p> <p style="padding-left: 40px;">Transfer with the limit wave length : 50 %</p> <p style="text-align: center;">or</p> <p><input type="checkbox"/> Filtering with 2-RC-Filter <input type="checkbox"/></p> <p style="padding-left: 40px;">Input of waves per rotation (W/R) for circles</p> <p style="padding-left: 40px;">Input of threshold wavelength (Lambda c) for lines</p> <p style="padding-left: 40px;">Transfer with the limit wave length : 75 %</p> <p style="text-align: center;">or</p> <p><input type="checkbox"/> Analysis (next page) <input type="checkbox"/></p>												
<table border="1" style="display: inline-table; border-collapse: collapse;"> <tr> <td style="padding: 2px 5px;">* YES</td> <td style="padding: 2px 5px;">NO</td> <td style="width: 20px;"></td> <td style="width: 20px;"></td> </tr> </table>		* YES	NO			*	<table border="1" style="display: inline-table; border-collapse: collapse;"> <tr> <td style="width: 20px;"></td> <td style="width: 20px;"></td> <td style="width: 20px;"></td> <td style="padding: 2px 5px;">TERMIN</td> </tr> </table>					TERMIN
* YES	NO											
			TERMIN									
<table border="1" style="display: inline-table; border-collapse: collapse;"> <tr> <td style="padding: 2px 5px;">BACK</td> <td style="width: 20px;"></td> <td style="width: 20px;"></td> <td style="width: 20px;"></td> </tr> </table>		BACK					<table border="1" style="display: inline-table; border-collapse: collapse;"> <tr> <td style="width: 20px;"></td> <td style="width: 20px;"></td> <td style="width: 20px;"></td> <td style="padding: 2px 5px;">INFO</td> </tr> </table>					INFO
BACK												
			INFO									

**Data boxes**

**Filtering with ISO TC 57 (Gauss)**  
**Filtering with 2-RC-Filter**

Selection of a filter type.

**Analysis (see next page)**      Select of filters which deviate from both standards.

Select filter mode (Analysis)

J Filtering with Gauss

or

2 RC-Filter

or

Rectangular filter (fast approximation for Gauss)  \*

Input of W/C for circles

or

Input of Lambda c for circles

Link segments

Transfer with the limit wave length:

(0 = Standard / Gauss: 50 % , 2 RC: 75 %)

\* YES NO   \*     TERMIN

BACK PRE MENU

**Data boxes**

**Rectangular filter (fast approximation for Gauss)**

Circle smoothing by forming mean value over neighboring probing points.

**Input of W/C for circles or Input of Lambda c for circles**

Selection whether old control data should be enabled for operation with the current program.

**Link segments**

To take as many points as possible into account, broken contours can be combined to form a continuous contour during filtering. a long wavelength can then be selected.

**Transfer with the limit wave length**

Any value between 0% (standard) and 99% can be selected.

**Procedure**

If a filter is activated, another dialog window for defining the filter will be displayed after you terminate an element:

Dialog

Selection of the filtering wavelength

<input type="checkbox"/> Y	Wavelength	No. of points	
	8.0000	17	<input type="checkbox"/> *
	25.0000	51	<input type="checkbox"/>
			<input type="checkbox"/>
			<input type="checkbox"/>
			<input type="checkbox"/>
			<input type="checkbox"/>
			<input type="checkbox"/>
			<input type="checkbox"/>
			<input type="checkbox"/>
			<input type="checkbox"/>


  

* YES	NO			*			TERMIN
BACK							INFO

Depending on the setting in the filter mode, input either of the **Wavelength** or of the **No. of points** will be requested.

**Special feature**

When scanning lines, the filter plane is offered for selection in an additional dialog window. One or two planes can be selected.



**NOTE**

The filter mode is deactivated by:

- -Calling <DI 1185>, <NO> again
- -Calling <DI 1608> - initial status
- -Calling <DI 1610> - record head
- -Restarting the measuring system

With  $\lambda_c$  you can choose between the values 0.8 and 2.5 as well as their decimal powers.

The smallest wavelength is selected so that values  $\geq 3$  points can be detected; the largest wavelength corresponds to  $\leq$  half of the scanned path.

A comparison of measured results requires evaluations to be performed at the same limiting wavelength.

# Chapter 15

## Rotary table operation

---

### **This chapter contains:**

Procedure for measuring with a computer controlled rotary table	15-2
Preparations. . . . .	15-3
Positioning commands. . . . .	15-4
Rotary table measurement mode . . . . .	15-11


## Procedure for measuring with a computer controlled rotary table

- Prepare rotary table > *„Preparations“ on page 15-3*
- Position rotary table > *„Positioning commands“ on page 15-4*
- Define rotary table axis > *„Defining the rotary table axis“ on page 15-12* to > *„Displaying the rotary table axis“ on page 15-16*
- Measurement:
  - Define workpiece and control coordinate system > *„Procedure“ on page 15-11*
  - If necessary, uncouple workpiece/control coordinate system from rotary table > *„Coupled rotation/uncoupling of workpiece/control coordinate system <DI 1566> (<DI 1567>)“ on page 15-19*
  - Position rotary table > *„Positioning commands“ on page 15-4*
  - Measure > *„Procedure“ on page 15-11*
- To end rotary table operation: Deactivate rotary table, initialize rotation axis > *„Procedure“ on page 15-11*

## Preparations

Prepare rotary table as per the relevant operating instructions:

- The clamping surface of the rotary table must point roughly in the direction of a machine axis.
- No mechanical alignment is required. The eccentricity error and wobble error are compensated mathematically.



Exception: E.g. clamping between centers with an alignment deviation between the rotary table and the workpiece axis of  $\leq 0.1$  mm requires mechanical prealignment, cf. relevant rotary table operating instructions.

- CNC run with rotary table: Make sure that the angular position (slope) of the workpiece is approximately the same as during learn (part) programming.
- Travel to rotary table reference point (absolute zero point) (this step is not mandatory): **▶ „Traveling to the rotary table reference point <DI 1570>“ on page 15-10**

## Positioning commands

### Positioning with the computer or joystick

#### Options

You can position (rotate) your rotary table

- with the left-hand joystick or
- via computer command.

#### Difference

During learn or part programming the control data accepts only rotary table positions which you have set via computer. Therefore in the learn program you must confirm each position which has been traveled to via joystick control via computer command **<DI 1521>**.

#### The following computer commands are available:

- Rotate to a defined angular position with display of the current position **▶ „Rotating the rotary table to an angular position <DI 1521>“ on page 15-4**
- Rotate by a defined angular step with display of the current position **▶ „Rotating the rotary table by an angular step <DI 1522>“ on page 15-7**
- Rotate by an angular pitch with display of the current position **▶ „Rotating the rotary table by a scale division <DI 1523>“ on page 15-8**
- Align to machine coordinates **▶ „Aligning the rotary table parallel to the machine coordinates <DI 1524>“ on page 15-9**
- Travel to reference point **▶ „Traveling to the rotary table reference point <DI 1570>“ on page 15-10**
- Set current position to 0° **▶ „Setting the rotary table position to zero <DI 1520>“ on page 15-10**

#### Joystick

The joystick can be protected against accidental actuation. Prerequisite: The left joystick is equipped with a pushbutton (like the one on the right joystick for programming intermediate positions).

- Press the left push button once after power-up.
- You must then press the left push button simultaneously in order to move the rotary table with the joystick.

### Rotating the rotary table to an angular position <DI 1521>


#### Application


You can use this function to read off the current position of the rotary table and/or travel to another angular position.



**Please note**

- Do not rotate the rotary table while defining the workpiece coordinate system.
- Learn programming with rotary table: You must program each position traveled to via joystick with this function.
- You can also use the function within a geometric element (cf. function call) under the following conditions:
  - The element is not used to define the workpiece coordinate system.
  - You have switched on **Rotate workpiece system too** (**>„Coupled rotation/uncoupling of workpiece/control coordinate system <DI 1566> (<DI 1567>“** on page 15-19)



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1521 RTPOS	CMM RT05 Position...	

**Procedure**

Enter the nominal position and close window with **<TERMIN>**. The new position is then logged and (during learn or part programming) written to the control data.

**Important!**

Make sure that the clamped parts can not cause a collision.

If you do not want to rotate the rotary table, exit the window with **<BACK>**.

# Rotary table operation

Dialog

W Position RT05      0.0000      act.position      0.0000  
0/0/0.0

BACK      \*      TERMIN

INFO

### Data boxes

**Position RT 05**

Enter nominal position in decimal degrees or in deg/min/sec (type with slash).


**act.position**

Display of actual position in decimal degrees and in deg/min/sec.  
No input or editing is possible.

## Rotating the rotary table by an angular step <DI 1522>

### Application

You can use this function to read off the current rotary table position and/or move the rotary table by a defined angle.



Dialog					
W	Step	RT05	0.0000	act. position	0.0000 0/0/0.0
			*		
BACK			TERMIN		
			INFO		

### Data boxes

#### Step RT 05

The value entered last is offered and can be accepted. New inputs must be decimal or in °/'/" (type in with slashes). The direction of rotation is determined by the +/- sign entered: the positive sign denotes counterclockwise rotation and the negative sign stands for clockwise rotation (this direction of rotation applies when viewing the surface of the rotary table from the front and above).

#### act.position

Display of the actual position in decimal degrees and in deg/min/sec. Input or editing is not possible.



## Data boxes

### Rotary table pitch

The "pitch" i.e. scale division last entered is offered for acceptance or overwriting. The direction of rotation is determined by the +/- sign: The positive sign denotes counterclockwise rotation and the negative sign clockwise rotation (this direction of rotation applies when viewing the surface of the rotary table from the front and above).

### act.position

Display of the actual position in decimal degrees and in deg/min/sec. Input or editing is not possible.

### Procedure

Enter the pitch or scale division and close the window with **<TERMIN>**. The new position is logged and (for learn or part programming) written to the control data.



### Important!

Make sure that the clamped parts can not cause a collision.

If the rotary table should not be rotated, quit the window with **<BACK>**.

## Aligning the rotary table parallel to the machine coordinates **<DI 1524>**


### Application


You can use this function to align an element of the part clamped to the rotary table parallel with the machine coordinate system. The rotary table will rotate by the angle specified in the last record print-out.

### NOTE

You may call this function only after the following elements: **LINE, CYLINDER, SPHERE, SURFACE, POLAR**.

If 2 projected angles are printed, rotation will be performed by the angle of the rotary table's rotational plane.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1524 RTANG	CMM RT05 Angle	


## Traveling to the rotary table reference point <DI 1570>


### Application

With the reference point (rotary table zero point) mechanically aligned to the rotary table, you can repeat CNC programmed rotary movements and positions even if the machine has been switched off in the meantime. You can thus perform exact travel to an initial or home position referenced to this point even after a power failure.

To execute a reference point travel, call <DI 1570> (► „Reference point travel <DI 1570>“ on page 6-2) or start UMESS (► „Prerequisites“ on page 2-3).

Make sure that no fixtures or workpieces can cause a collision while rotating to the reference point. The rotary table counter will be reset to 0 at the reference point.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1570 RERPT	CMM Travel commands Reference point travel...	


### Procedure


See ► „Reference point travel <DI 1570>“ on page 6-2.

## Setting the rotary table position to zero <DI 1520>

### Application

With this function you can set the current rotary table position to 0°. Application e.g. to subsequently adjust the rotary table with <RTPOS> instead of with <RT STEP>.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1520 RTZEROP	CMM RT05 set to zero	

# Rotary table measurement mode

## Procedure

### Alignment

Before you start measuring,

- define the rotary table axis (▶ *„Defining the rotary table axis“ on page 15-12*) and save with <DI 1568> (▶ *„Storing, reading in and deactivating the rotary table axis <DI 1568>“ on page 15-14*) or
- read in the rotary table axis with <DI 1568> (▶ *„Storing, reading in and deactivating the rotary table axis <DI 1568>“ on page 15-14*).

### Measurement

- Define the workpiece coordinate system and W-position.  
**Please note:** Do **not** rotate the rotary table while performing element measurements and function calls to define the zero point of the workpiece coordinate system (▶ *„Rotating the rotary table to an angular position <DI 1521>“ on page 15-4*).
- Use <DI 1566> to determine whether and how you want to connect the workpiece coordinate system and/or the W-position with the rotary table.  
The following options are available (▶ *„Coupled rotation/uncoupling of workpiece/control coordinate system <DI 1566> (<DI 1567>)“ on page 15-19*):
  - coordinate system rotates along with table, eccentricity and wobble error compensated; this condition is automatically active following each UMESS start and after <DI 1608>, <RECORD>;
  - coordinate system does not rotate with table, but the eccentricity and wobble errors are compensated;
  - coordinate system does not rotate with table and eccentricity and wobble errors are not corrected.

Application examples and information ▶ *„Coupled rotation/uncoupling of workpiece/control coordinate system <DI 1566> (<DI 1567>)“ on page 15-19*.

### Positioning the rotary table

- Computer controlled with positioning commands (▶ *„Positioning with the computer or joystick“ on page 15-4*);
- Manually via joysticks, during learn (part) programming with subsequent position acceptance via <DI 1521>. The intermediate position or probing does not store the rotary table position in the control data.

### Correcting the rotary table axis

### Deactivating the rotary table axis

Once you have defined the workpiece coordinate system, you can also rotate the rotary table within an N point element (with the joystick or <RT POS>) if you have activated **Rotate workpiece system too** (► „*Coupled rotation/uncoupling of workpiece/control coordinate system <DI 1566> (<DI 1567>)*“ on page 15-19).

You must occasionally redefine the rotary table axis or correct it via an offset measurement (► „*Defining the rotary table axis*“ on page 15-12).

If you measure parts afterwards or in-between without the rotary table: Deactivate the rotary table axis (► „*Storing, reading in and deactivating the rotary table axis <DI 1568>*“ on page 15-14). Otherwise you may inadvertently rotate (and therefore displace) your coordinate systems.



## Defining the rotary table axis

### Important!

It is generally advisable to redefine (recalibrate) the rotary table axis following each probe calibration.

The rotary table axis must be redefined and stored in the following cases:

- After assembling/moving a mobile rotary table.
- Following each UMESS start with reference point travel, i.e. if the control has been switched off in the meantime.  
Alternatively: Offset measurement (► „*Linear offset correction <DI 1572>*“ on page 6-4).
- After each reference point travel started with <DI 1570>.  
Alternatively: Offset measurement (► „*Linear offset correction <DI 1572>*“ on page 6-4).
- At intervals, if the rotary table axis can be expected to drift due to temperature influences during longer measurements.

Explanation:

The rotary table axis stored is referenced to the zero point of the machine coordinate system. Fluctuations in temperature may displace the actual rotary table axis in relation to the one stored. During longer measurements, this "drifting" will cause an eccentricity error if only the workpiece coordinate system is redefined after changing workpieces. Alternatively, you can correct this thermally induced displacement of the table axis by performing an offset measurement (► „*Linear offset correction <DI 1572>*“ on page 6-4).



- Following probe recalibration if there is no common reference probe. A common reference probe exists if the calibration standard has not been moved or recalibrated.

**NOTE**

Definition of the axis is not required in the following cases:

- After a UMESS start without a reference point travel, i.e. if the control cabinet remains on in the meantime. In this case the rotary table axis is automatically read from the hard disk.
- If an offset measurement is possible (► „*Linear offset correction <DI 1572>*“ on page 6-4). The offset correction also detects the rotary table axis.

**Procedure for defining the rotary table axis**

**Set to initial status**

**<DI 1608>**

**Set offset to zero**

If an offset correction has been activated, it must be deactivated with **<DI 1572>** (► „*Linear offset correction <DI 1572>*“ on page 6-4).

**Define the rotary table axis**

Be very careful when performing this operation. Calculation of the elements or features may be adversely affected by such factors as probe bend, form deviations and/or unfavorable position of the probing points.

**The following options are available:**

- If it is accessible, you can use the bore of the rotary table with a 180° reversal measurement for calibration:  
Measure the bore via  
**<CYLINDER>, <RT 05> <RT STEP> 180°, <CYLINDER>, <SYMMETRY>**  
or **<SURFACE>** (face), **<CIRCLE>, <DI 1285>** (perpendicular), **<RT 05> <RT STEP> 180°, <SURFACE>, <CIRCLE>, <DI 1285>, <SYMMETRY>**
- 180° reversal measurement of a cylinder with little form deviation fastened to the rotary table in a roughly upright position:  
**<CYLINDER>, <RT 05> <RT STEP> 180°, <CYLINDER>, <SYMMETRY>**
- Fasten sphere to rotary table. Measure after each **<RT STEP>**. (select **<RT STEP>** so that you can measure at least 6 spheres over as large an angular range as possible):  
**<SPHERE>, <RT 05> <RT STEP>** (e.g. 60°), **<SPHERE>, ... , <RECALL>** of the spheres to **<CIRCLE>, <RECALL>** to **<SURFACE>, <DI 1285>** (perpendicular);

- (with measuring probe head) Fasten triple ball to rotary table and perform self-centering probing of triple ball following each **<RT STEP>**:  
**<POINT>**, **<RT 05>** **<RT STEP>**, **<POINT>**, . . . , **<CIRCLE>** via **<RECALL>**, **<SURFACE>** via **<RECALL>**, **<DI 1285>** (perpendicular)
- Perform measurement on reversal on the actual workpiece.


### Store rotary table axis


Use **<DI 1568>** (► „*Storing, reading in and deactivating the rotary table axis <DI 1568>*“ on page 15-14).

## Storing, reading in and deactivating the rotary table axis <DI 1568>

This function features the following options:

- Storing of the rotary table axis defined according to ► „*Defining the rotary table axis“ on page 15-12* (last element in record).
- Read-in of the stored rotary table axis.
- Deactivation of the rotary table axis; if this is done, it doesn't matter if the rotary table is accidentally moved.
- Listing of the stored rotary table axis.
- Correction of the direction of the rotary table axis.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1568 RTCAL a75	CMM RT 05 Axis...	

Dialog

Activate RT system

RT 05  
 Y active  \*

Rotary table axis  
 read from file  \*  
 or from address   
 or initialize  address(absolute) =

Rotary table axis  
 output   
 is opposite to the positive CMM axis

* YES	NO						* TERMIN
BACK	PRE MENU						INFO

### Data boxes

**RT 05 active**

Must be accepted with <\* YES>.

**Rotary table axis:  
read from file**

Required e.g. if you have in the meantime deactivated the rotary table axis with **Rotary table axis initialize**.

**Rotary table axis:  
from address**

Used to store the rotary table axis; the element which was printed last in the record and you should have determined by the method outlined in [„Defining the rotary table axis“ on page 15-12](#) is always stored. Its address can be obtained from the **address (absolute)** display box.

If you are using a mobile rotary table and it is clamped in -X or -Y, you should simultaneously select **Rotary table axis output** to check the axis direction and correct it if necessary.

**Rotary table axis  
initialize**

Used to deactivate the stored rotary table axis. The axis is deleted in the computer, but retained on the hard disk, from where it can be read in as required. In this way you can make sure that any accidental movement and/or deadadjustment of the rotary table will have no influence on your coordinate systems, e.g. whenever you are not performing measurements on the rotary table.

**Rotary table axis output**

Used to call the **Rotary table axis** dialog window to check the axis direction (+/- sign) (► *„Displaying the rotary table axis“ on page 15-16*). This is interesting especially if you are using a mobile rotary table and it is clamped in **-X** or **-Y** of the machine coordinates.

**Rotary table is opposite to the positive CMM axis**

This box must be selected if the rotary table is installed in **-X** or **-Y**.

**Procedure**


Select the option(s) required and close the window with **<TERMIN>**.


If you select **Rotary table axis output**, the **Rotary table axis** dialog window will then be displayed ► *„Displaying the rotary table axis“ on page 15-16*.

**Displaying the rotary table axis**

**Application**

If you are using a mobile rotary table and it is pointing in the **-X** or **-Y** direction of the machine coordinates, you might be determining the direction of the rotary table axis incorrectly by using the method explained in ► *„Defining the rotary table axis“ on page 15-12*. You can list and check the current rotary table axis using the **Rotary table axis** dialog window.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1568	CMM	
RTCAL	RT 05	
a75	Axis...	


**Rotary table axis output**

Dialog									
RT axis									
Axis vector	x	<input type="text" value="0.000447214"/>	y	<input type="text" value="0.002449494"/>	z	<input type="text" value="0.999997100"/>			
Axis point	X	<input type="text" value="212.383500"/>	Y	<input type="text" value="-317.715000"/>	Z	<input type="text" value="0.0000000"/>			
<input type="checkbox"/> Y	store on file		<input type="checkbox"/> *						
<input type="button" value="YES"/>			<input type="button" value="NO"/>						
			* <input type="button" value="REPEAT"/>			<input type="button" value="TERMIN"/>			
<input type="button" value="BACK"/>			<input type="button" value="PRE MENU"/>						

### Data boxes

#### Axis vector, Axis point

The dialog window lists the inclination of the RT axis (as direction cosine of its unit vector) and its penetration point through the zero plane of the machine coordinate system:



If your rotary table axis is pointing in the **-X** or **-Y** direction, a minus sign also must be assigned to the corresponding axis vector.

### store on file

Two cases must be differentiated:

- After **Rotary table axis read from file** (▶ „*Storing, reading in and deactivating the rotary table axis <DI 1568>*“ on page 15-14)

If you check this box, the rotary table axis will be stored to the hard disk with the displayed values after you press <TERMIN>. If it is not checked, the computer will only temporarily store the values entered when you press <TERMIN>. The previous status then remains stored on the hard disk (and can be reactivated from there).

- After **Rotary table axis from address** (▶ „*Storing, reading in and deactivating the rotary table axis <DI 1568>*“ on page 15-14)

the rotary table axis will be stored in any case, i.e. either with the original or with the edited values.

### Procedure

Check the +/- sign of the **Axis vector**. Then determine whether you want to store the displayed status in the computer only temporarily or save it permanently to the hard disk. Close the window with <TERMIN>.


## Coupled rotation/uncoupling of workpiece/control coordinate system <DI 1566> (<DI 1567>)

### Application

With this function you can influence the coupling of the workpiece and control coordinate systems to the rotary table.

### Standard case

The workpiece and control coordinate systems rotate along with the rotary table. The wobble error and eccentricity error are mathematically compensated if the rotary axis was defined (calibrated) beforehand.



### This coupling is automatically produced

- after UMESS start and
- after <DI 1608> or <RECORD>.

### Therefore please note

You should always deactivate the rotary table axis whenever you are not performing measurements on the rotary table. Otherwise your coordinate systems will be rotated out of adjustment if you accidentally move the rotary table.

### Options


- Safety device on the control panel (button on left-hand joystick),
- <DI 1568>, Rotary table initialize = YES,
- <DI 1568>, RT 05 active = NO.

### Special case

Even when you are performing measurements on the rotary table, it is not always advisable to rotate the coordinate systems as well:

## Example 1

You should not rotate W-position with the rotary table if your CNC program measures elements or features which are repeated in a loop <DI 1051>:



## Prerequisite


The workpiece is arranged central to the rotary table axis. Align exactly with critical probing (otherwise there is a danger of collision or probing errors) or by turning the zero point of the control coordinate system along with the rotary table, cf. example 3.

## Example 2

The workpiece coordinate system should not be rotated along with the table if you want to measure the pitch or division of a part which is aligned to the rotary table axis. In this case you can omit the correction of the wobble and eccentricity errors; the residual alignment error will be entered in the measuring result. However, you must not adjust the rotary table during an N point program.

## Example 3

Correct only the wobble error and the eccentricity error:







### Data boxes

#### Workpiece system/ Wpos system rotate

Used to rotate the workpiece coordinate system and/or W-position along with the table, cf. explanation at the beginning of the chapter. You can also reach this status after a UMESS start and after **<DI 1608>/<RECORD>**.

#### Workpiece system/ Wpos system correct eccentricity and wobble

Used to rotate only the zero point of the workpiece and/or control coordinate system along with the rotary table and retain the coordinate directions. See the beginning of the chapter for application information and example.

This setting can be reversed (undone) by:

- calling the dialog window again and selecting **rotate**.
- or by setting the initial status **<DI 1608>**, **<RECORD>**
- or by restarting UMESS.

This setting is not eliminated by:

- initializing MASCH **<DI 1590>**,
- CNC start, CNC end.

#### Workpiece system/ Wpos system do not rotate

The workpiece and/or control coordinate system are retained and do not rotate along with the rotary table. The wobble and eccentric errors of the workpiece are not corrected. See the beginning of the chapter for application notes and example.

Reverse (undo) the setting as for **correct eccentricity and wobble**.

### NOTE

Couple only if the workpiece coordinates and the and the W-pos have been defined (calibrated). **<DI 1566>** must be recalled following each change of the coordinate system.

# Chapter 16

## Learn programming

---

### **This chapter contains:**

General .....	16-2
Procedure for learn programming .....	16-5
Control coordinate system .....	16-6
Starting learn programming <DI 1639> .....	16-13
Execution of learn programming .....	16-16
Travel paths and intermediate positions .....	16-30
Generating programs .....	16-36
Terminating learn programming <DI 1632> .....	16-85

# General


## Application

With UMESS you can create CNC programs by learn (part) programming and run them as automatic measurements.

### Learn programming:

Manual measurement of a workpiece with simultaneous storing of all codes and travel paths on the hard drive as a CNC program.


If necessary, store externally/save CNC programs to DAT or via LAN.



### CNC run:


Decodes the control data of the CNC program and converts it into travel and computer commands which exactly reproduce the learn programmed run on a workpiece of the same type.

If necessary, retrieve CNC program from DAT or via LAN to the hard drive and enter it in the workpiece catalog.



**Coordinate systems**


The travel paths of the current probe always refer to a predefined coordinate system, the control coordinate system, during learn programming and later on during the CNC measuring run. Like the identically named command you use to save a control coordinate system, the term **W-pos** is also used for control coordinate systems.

**W-position**

With the W-position you save the position of the control coordinate system and its angles relative to the machine coordinate system to the hard disk.

**Control coordinate system**

The control coordinate position (W-position) is defined relative to the workpiece. If the workpiece position changes, the W-position must be moved accordingly (e.g. CNC run at a position other than the one with learn programming).



## Procedure for learn programming

<b>Preparation</b>	Preparations for learn programming: Clamp workpiece, calibrate probes (as for manual measurement).
<b>Programming</b>	<p>Creating a new CNC program:</p> <ul style="list-style-type: none"> <li>– Define and store control coordinate system or activate stored control system: ▶ <b>„Control coordinate system“ on page 16-6.</b></li> <li>– Start learn programming: ▶ <b>„Starting learn programming &lt;DI 1639&gt;“ on page 16-13.</b></li> <li>– Execute learn programming: ▶ <b>„Execution of learn programming“ on page 16-16.</b></li> <li>– Terminate learn programming: ▶ <b>„Terminating learn programming &lt;DI 1632&gt;“ on page 16-85.</b></li> <li>– If necessary, correct CNC program (see below).</li> </ul>
<b>Correction</b>	<p>Correcting or extending a CNC program:</p> <ul style="list-style-type: none"> <li>– via learn programming: ▶ <b>„Continuing the learn programming of an existing workpiece“ on page 16-14,</b></li> <li>– via control data correction: ▶ <b>„Correcting control data &lt;DI 1642&gt;“ on page 17-31,</b></li> <li>– with CNC debugger: ▶ <b>„CNC debugger &lt;DI 1070&gt;“ on page 18-17.</b></li> </ul>

# Control coordinate system

## Defining and storing the control coordinate system

### Function calls

The following functions are used to store and activate a control coordinate system:

- **<DI 1708>** or **<WS->WPOS>** stores the current workpiece coordinate system as W-position (control coordinate system) in the computer (► *„Storing the W-position in the computer <DI 1708>“ on page 16-9*).
- **<DI 1710>** or **<WPTCAT>** stores the current workpiece coordinate system as W-position (control coordinate system) (► *„Storing the W-position/Deleting the W-position <DI 1710>“ on page 16-7*):
  - in the computer
  - and on a long-term W-position file under any name you specify.
- **<DI 1712>** or **<WPFCAT>** downloads one of the stored W-positions to the computer as the current W-position (► *„Reading in the W-position <DI 1712>“ on page 16-10*).

### Options for defining and storing a W-position

- Define workpiece coordinates fully (mathematical alignment) and then save them as a control coordinate system.
- This method is always recommended at the start of a CNC program in order to obtain an exact control coordinate system for each workpiece.
- After executing **<DI 1608>** probe one point each for **X, Y, Z** (with a prismatic workpiece) and reset to zero (**<ZERO PT>**). Then store as W-position.
- This method is recommended only in the manual mode where a roughly defined control coordinate system is sufficient, e.g. prior to learn programming or a CNC run. The exactly mathematically aligned control coordinate system must be defined in the CNC program (see previous section).
- Use the machine zero point without any manual probing: **<DI 1608>**, then store as W-position; this method is recommended during learn programming and CNC operation only if the workpiece is clamped in a fixture whose position in relation to the zero point remains constant.

### Check

When in doubt you can check the position of the control coordinate system currently stored in the computer by positioning a probe as follows:



<DI 1608>	Set initial status,
<DI 1713>	Workpiece system same as W-position system,
<DI 1511>	Position in workpiece system with <b>X=0, Y=0, Z=0</b> .

**Important:**

A risk of collision exists if the zero point is located on an edge of the workpiece. Enter a coordinate  $\neq 0$  if necessary!

**Please note**

This method does not work for a W-position stored during a CNC run with <DI 1708> (► „*Storing the W-position in the computer <DI 1708>*“ on page 16-9).


**Rotary table**


The W-position and rotary table are automatically coupled after a UMESS start and after <DI1608>/<RECORD>. If necessary, uncouple the W-pos or secure the rotary table against deadadjustment when not measuring on the rotary table (► „*Coupled rotation/uncoupling of workpiece/control coordinate system <DI 1566> (<DI 1567>)*“ on page 15-19).

## Storing the W-position/Deleting the W-position <DI 1710>

You can use this function call

- to store the current workpiece coordinate system as the control coordinate system in the computer and under a selectable W-pos number in the W-pos file.
- and/or to delete a W-pos in the catalog.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1710 WPTCAT	Coord Control system WPOS store as WP no....	

Dialog

Store W-Pos in catalog

W-Pos number  Comment

Overwrite

\* YES NO \* CATALOG TERMIN

BACK DELETE INFO

### Softkeys

**CATALOG**

lists the W-pos file (➤ *„W-position catalog“ on page 16-11*).

**DELETE**

deletes the W-position specified for **W-Pos number** without inquiry.

### Data boxes

#### W-Pos number

Enter the number under which you want to store the W-position. You can also make this entry with **<CATALOG>** (➤ *„W-position catalog“ on page 16-11*).

The W-position file can store a maximum of 32 000 W-positions.

#### Comment

Here you can enter a comment on the stored W-position comprising max. 30 characters. This comment will be displayed in the catalog (➤ *„W-position catalog“ on page 16-11*). It will not be stored in the control data.

#### Overwrite

Select this box if a W-position you want to overwrite is already stored under the specified **W-Pos number**. Otherwise the error message explained under "Procedure" will be displayed in the manual mode and during learn programming. There is no backup in the CNC run.

## Procedure

### Cursor keys

You can move between data boxes using the  $\wedge$  and  $\vee$  keys.

### Catalog

If you require information on existing W-positions (e.g. free numbers): change to the W-position file via **<CATALOG>** (► „*W-position catalog*“ on page 16-11). From there you will automatically return to your starting part.

### Storing

After entering the data in the window, close the window with **<TERMIN>**. A message confirming successful storing or deletion will then appear on the screen in the list and message window.

#### W-Pos ... stored in catalog

#### W-Pos ... deleted from catalog

If the message **W-Pos already exists** is displayed, you have specified the number of an existing W-position. In this case, specify a new number, select **Overwrite**, or delete the old W-position.

## Storing the W-position in the computer <DI 1708>


### Application


This function call stores the current workpiece coordinate system in the computer as the current control coordinate system. The W-position file previously stored is lost. The W-position file remains unchanged.

It is applied during a CNC program to define an exact control coordinate system without making use of the W-position file (► „*Defining and storing the control coordinate system*“ on page 16-6).

### Disadvantage

This W-position is not directly available to you for continuing learn programming or starting a CNC run in the middle of the program. You must either reconstruct it manually or let the CNC program run up to the program line concerned so that it can be downloaded to the computer.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1708 WS->WPOS	Coord Control system WPOS store as WP no.1...	

### Message

Successful storage is acknowledged by display of the message **W-POS** in the list and message window.



## Data boxes

### W-Pos number

Enter the number of the required W-position. If you need information on the number stored: Change to the W-position file with **<CATALOG>** (► „W-position catalog“ on page 16-11). From there you automatically return to the starting point.

Input of 0: ► „W-position displacement <DI 1769, DI 1771>“ on page 16-66

## W-position catalog

### Application

The dialog windows **Store W-Pos in catalog** and **Read W-Pos from catalog** contain the **<CATALOG>** softkey. If you press this key, the W-position file will be listed in the dialog window. This is used e.g. to access information on the number of a W-position you want to read or unassigned W-position numbers. You can also transfer a W-position directly from the file to your dialog window.

### Function call

► „Storing the W-position/Deleting the W-position <DI 1710>“ on page 16-7 or ► „Reading in the W-position <DI 1712>“ on page 16-10, then softkey **<CATALOG>** (without entering a W-pos no.).

### Screen output

Dialog					
W-pos catalog					
Name	Comment	X	Y	Z	
□	1 Part A	301.3249	117.1664	1.5001	
	2 Part B	441.4915	157.1541	122.4501	
	3	442.9637	557.4464	122.4129	
	4 COMPRESSOR WHEEL	605.0642	201.6458	85.4276	
	5	632.0613	237.4032	73.2482	
	6 CONTROL CAN	467.3692	162.9217	145.3925	
	7 HOUSING KL	34.2568	570.3541	221.3492	
	8	328.1515	120.5885	300.7500	
	9 HOUSING GR	52.1744	-58.3008	202.4777	

* YES	NO			*	SELECT L			TERMIN
BACK								INFO

**Scrolling in the W-position file**

**Procedure**

- Use the <Page Up>/<Page Down> keys to scroll up/down one page at a time.
- Use <NO> or the v cursor key to scroll down one line at a time
- Use <SELECT L>. to select a defined W-position/line.

**Selection of a W-position**

Accept the displayed W-position for entry to the calling dialog window with <\* YES> or <TERMIN>. Otherwise return to the calling window with <BACK>.

**Explanation of screen output**

**Name**


W-position number, entered with <DI 1710>.

**Comment**

Additional information on the W position, entered with <DI 1710>.

**X, Y, Z**

Distance from the origin of the control coordinate system to the machine zero point in the direction of the machine axes; this looks as follows in the XY plane:



# Starting learn programming <DI 1639>


## Learn programming a new workpiece

Preparations for learn programming

➤ „*Procedure for learn programming*“ on page 16-5

The following description applies if

- you are creating a completely new CNC program or
- you want to overwrite the control data of an existing CNC program completely.



DI	Pull-Down-Menu	Pictogram
1639 PROG	CNC PROG Start...	

Dialog
□
□

Programming of CNC runs Cat name: Standardkatalog

Start new workpiece  \*

or process existing workpiece

WP code  Workpiece name

Comment

Start line

Result address

W-Position

* YES	NO	<input type="text"/>	<input type="text"/>
BACK	<input type="text"/>	<input type="text"/>	<input type="text"/>

*	<input type="text"/>	CATALOG	<input type="text"/>	TERMIN
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	INFO

**NOTE**

At the start of learn programming, all control coordinates are referenced to the W-position currently stored in the computer (► „*Defining and storing the control coordinate system*“ on page 16-6). If you want to start your learn program later as a CNC run, you must use this W-position again.

**CATALOG**

To display the control data catalog

**TERMIN**

To end the dialog window, learn programming is started.

**Softkeys**

**Data boxes**

**Start new workpiece  
or process existing  
workpiece**

Press <YES> to start a new workpiece

**WS code**

A workpiece is selected after the workpiece code is selected with <Enter>.

**Workpiece name**

Display of selected workpiece name.

**Comment**

Comment on workpiece selected.

**Start line**

Input of CNC run start line.

**Result address**

Used to set the result address.

**W-Position**

Number of the required W-position.

**Continuing the learn programming of an existing workpiece**

**Procedure**

A finished CNC program can be overwritten section by section via learn programming or extended by adding new program steps ("patching").

The following conditions must be observed:

**Coordinate system**

– A CNC program will usually contain at least one call for defining the control coordinate system before the section to be newly programmed. You must activate this control coordinate system before continuing such a program via learn programming.

Options:

- If its position is known, determine it manually and store it.
- If the W-position is present in the W-position file: Read it with <DI 1712>.



- Otherwise start the CNC run and stop at the point where the new learn programming is to be performed.

Continue programming by pressing <PROG> each time.

#### W-Position

- The workpiece must be aligned corresponding to the W- position entered.

#### Correct line

- If you continue programming at a random point, the following control data lines will be overwritten by the new programming steps. If you want to supplement a program without losing any existing control data, you must first enter the control data lines (▶ „*Inserting additional control data lines with <INSERT>*“ on page 17-39).

Another possibility: Append new control data lines to the end of the existing program, then move the control data lines appended to the correct position with <CNC CORR> and <MOVE>

(▶ „*Moving control data lines <MOVE>*“ on page 17-42).

#### Continuing a learn program

If result addresses already exist, the address counter must be reset before the function call <DI 1690>. Otherwise the existing results will be overwritten by new ones and can no longer be recalled.

#### Inserting control lines

Adaptation with <CNC CORR> may result in a duplication of result addresses if the learn program is subsequently extended. This would cause complications in connection with recalls, formula applications or form and position tolerances.

Therefore:

- set the address counter with <DI 1690> so that all previously existing addresses are overwritten.
- Extend the learn program at the position required.
- Adapt addresses automatically by calling <CNC CORR>.

**Alternative:** Increase all existing addresses located behind the gap manually to prevent the creation of identical addresses.

# Execution of learn programming

## Procedure

### Differences

Learn or teach-in programming basically differs from manual measurement in the following points:

- During learn programming the software stores all machine and travel commands (control data) specific to the workpiece. The workpiece catalog manages the individual workpieces (CNC programs). (► **„Workpiece catalog“ on page 17-5**).
- You must define the travel paths with intermediate positions (► **„Travel paths and intermediate positions“ on page 16-30**).
- Normally you should start each CNC program as follows:
  1. Define the control parameters: <DI 1661> (not necessarily required, cf. ► **„Probing, probing parameters, machine parameters“ on page 16-20**).
  2. Set initial status: with <DI 1608> or <REC HEAD>.
  3. Align the workpiece mathematically and define the workpiece coordinate system.
  4. Define the W-position and store with <DI 1710> or <DI 1708>; do not use the number of the initial W-position with <DI 1710>, i.e. assign another number.


Then program the actual measuring run; use special generation programs if necessary (► **„Generating programs“ on page 16-36**).

- For calling measuring and evaluation programs ► **„Program calls“ on page 16-20**
- Suitable programming strategies shorten the measuring time during the CNC run (► **„Reserve address <DI 1456>“ on page 16-29**).
- Rotary table: Positions traveled to with the joystick during learn programming must be written to the control data with <DI 1521> (► **„Positioning commands“ on page 15-4**).

## Screen display during learn programming

### Display

Your fully programmed control data lines are displayed for checking in the list and message window:



### Example

The example shows the dialog window as it would appear after programming the first 7 control data lines. UMESS will then wait for programming step 8. For an explanation of the codes and abbreviations, please see [► „Interpretation of the control data“ on page 17-29](#).

The number of program lines visible depends on the size of your list and message window (increase its size if necessary).

## Correction during learn programming <DI 1032> and <DI 1694>

### Application

Incorrect program calls, incorrectly set intermediate positions and other errors can be canceled (undone) during learn programming.

### Alternative

Continue programming and quit learn program, afterwards clear errors via renewed learn programming ([► „Continuing the learn programming of an existing workpiece“ on page 16-14](#)); control data correction ([► „Correcting control data <DI 1642>“ on page 17-31](#)); delete incorrect control data lines ([► „Deleting control data lines <DELETE>“ on page 17-43](#)).


**Options**

The following options exist to perform corrections during learn programming:


**Delete a control data line**

e.g. after an incorrectly set intermediate position or an incorrect probing.

The last control data line can always be deleted with **<DI 1032>**.



You can enter the number of control data lines to be deleted with **<DI 1694>**.



Dialog									
Programming correction									
No. of complete lines		<input type="text" value="0"/>							
<input type="checkbox"/>	New programming step =		<input type="text" value="1"/>		New result counter =		<input type="text" value="1"/>		
* YES				NO		*		TERMIN	
BACK								INFO	

**Data boxes**

**No. of complete lines**

Display only for orientation

**New programming step =**

Enter the program line from which the new program is supposed to start.

Limit 1 - Total number of lines.

**New result counter =**

Correct the result counter (address counter) if necessary, e.g. if you want to repeat the learn programming of several addresses.

**NOTE**

Function call of **<DI 1032>** and **<DI 1694>** is possible only outside of an N point program.

Correction possibility within an N point program:

- **<Correction>** key
- **<Cancel>** key

These correction calls clear all previous probings and intermediate positions performed within the N point program and the program call. The programming step counter is set to the line of the original program call.

- If functions have to be deleted which change the workpiece coordinate system, first restore the preceding coordinate system before performing the correction (e.g. **<RECALL>**).
- The control data editor can be called during programming with (**<DI 1642>** or **<CNC CORR>**).
- **<DI 1641>** or **<CNC LIST>** can be used to list the current program (the program call does not generate a control data line). You therefore have the possibility of gathering information on the programming steps required and the result addresses.

### Program calls

#### Program calls

during learn programming are handled the same as in the manual mode:

- Activate point measurements via direct probing or with **<DI 1101>**.
- Call N point program as usual, conclude with **<TERMIN>** or **<NOMINAL>** (► *„Computer controlled manually measured sections <DI 1077>“ on page 16-25*).
- If you press the **<PRE MENU>** or **<BACK>** key while programming a function, the program step counter will go to the first step of the function. You can then continue the learn programming (► *„Correction during learn programming <DI 1032> and <DI 1694>“ on page 16-17*).

#### Fixed plane

If you use an incorrect fixed plane during learn programming, errors will occur in the subsequent CNC measuring run (the measuring plane of the geometric element is stored in the control data).

#### Nominal input

The options available for nominal input are explained in ► *„Computer controlled manually measured sections <DI 1077>“ on page 16-25*.

### Probing, probing parameters, machine parameters

#### Probing

The CNC program automatically accepts each probing during learn programming. The relevant control data line stores the following for each point probed:

- Center coordinates of the probe referenced to the control coordinate system at the moment it contacts the workpiece,
- Probe number,
- Probing direction.

### Probing and machine parameters (<DI 1661> or <DI 1662>)

#### There are three options

- Always program the relevant functions as well (at the start of learn programming). Please note the restrictions when learn programming <DI 1662>.
 

Advantage: This measure ensures that each measuring run is optimally tailored to the particular workpiece and measurement, even if the parameters have been changed in the meantime (e.g. by other users).

If the program occasionally has to be executed with parameters other than the ones programmed, set the required values in the manual mode. Then, when the CNC mode is started, skip the programmed parameters by entering an appropriate start line.
- If the mode seldom changes: Do not define any parameters in the CNC program, but set the parameters before the CNC start instead.
- If the parameter data should or must be changed section by section within the CNC program (e.g. to measure critical elements): incorporate the parameter changes at a suitable point in the CNC program if the corresponding function is learn programmable.

### Programmable stop <DI 1096>

#### Application

This function can be used to integrate stop functions in the measuring run during learn programming. The machine then stops at the programmed point during the CNC run. This is useful e.g. for the purpose of removing probes which would be in the way during the rest of the measuring run.

#### Function call

During the stop phase, you can call other UMESS functions, e.g. to edit probing or control parameters, modify the record output etc.

#### NOTE



You can program a user comment with <DI 1677> immediately **before** the stop command which appears on the screen in the CNC run.

#### Not allowed

The following functions are not allowed during the stop:

<DI 1610, 1612, 1613, 1629, 1632, 1633, 1634, 1635, 1636, 1639, 1640, 1641, 1642, 1644, 1649, 1676, 1677, 1678>.

Function call Possible only in **PROG**



**Data boxes**

with rapidly program call

- <YES>  
The CNC run automatically calls a specific function and/or opens its dialog window at the programmed stop. When the input has been concluded and the function has been executed, the CNC run will continue automatically, cf. comment in dialog window. You must enter the required function in the **Direct input function** box.



Generated control data line

Record									
NO	X	Y	Z	Function	SC2	SC1	PCN	CNN	ADR
Dialog									
...	0	0	1661	0 CNC STOP	0	1	9996	1996	

↑  
Function to be called

- <NO>

The CNC run stops and is resumed only after this is requested by the operator. Other functions can also be called up during the Stop phase, ► „Function call during the stop phase“ on page 18-13

Generated control data line

Record									
NO	X	Y	Z	Function	SC2	SC1	PCN	CCN	ADR
Dialog									
...	0	0	0	0 CNC STOP	0	1	9996	1996	

Direct input function

If you have selected **with rapidly program call**, enter the function to be called automatically here. If you want to call several functions in succession automatically, program <DI 1096> the number of times required in succession.

## Probe head mode <DI 1551>

### Application


If you want to change the probe head mode during a CNC run, you must program every changeover with this function. This function is superfluous for manual measurement.

### Application examples

- Changeover to the **MAN** operating mode for self-centering probing contacts in CNC and return to the **AUTO** operating mode;
- Alteration of the measuring force during the CNC measuring run.

### Please note

You must set an intermediate position with the probe in a non-contact position before executing the function call.



### Set operating mode, measuring forces and clamping at control panel

### Data box

Prompt to enter settings on the control panel (in accordance with the control panel operating instructions). Please also note that:

- You must select at least one measuring force direction (= probing direction).
- Either no clamping or one clamping is allowed; two clampings correspond to the automatic mode.
- Measuring force and clamping in der gleichen Achse sind nicht erlaubt.

**TERMIN**

Press **<TERMIN>** as soon as you have set the probe head mode. Learn programming can now continue as long as the computer does not recognize the status set as illegal or need more information on the probing direction.

### Prbg direction =

This inquiry will appear only if you have activated more than one measuring force direction. It therefore prompts the user to enter more information on the probing direction. You may specify only one axis in which the measuring force is activated as the probing direction.

Generated control data line

Record										
NO	X	Y	Z	Function	SC2	SC1	PCN	CCN	ADR	
Dialog										
98	0.00	0.00	.20	YE		Y	PRB MODE	0	0	0 1510

Axis clamped

YE = Changeover to MAN operating mode;  
NO = Changeover to AUTO operating mode;

Activated measuring forces with magnitudes and axes (sequence: X, Y, Z).

If a probing direction is requested as described above, it will not appear in this control data line. Instead it will appear in encoded form, i.e. under **SC1** for the following probing(s).

**Computer controlled manually measured sections <DI 1077>**

**Application**


Manually measured sections can be integrated into CNC programs.

**Application examples**

- Used for manual probing where roughly toleranced parts (castings) could cause collisions.
- Used to define the W-position before the first travel movement at the start of a CNC program. As a result, the workpiece can be measured in any position regardless of the stored W-position.

**Function**

<DI 1077> programs the changeover between manually measured sections and CNC measurement.



### NOTE


- Via learn programming of the manual section, a dialog results which is subsequently used to guide the operator: All probings stored in the control coordinate system will appear as a clearly interpretable user comment in the dialog window. (► „*User guidance in manual sections*“ on page 18-16).
- This user guidance concerns only the probings (in the control coordinate system). All other functions, e.g. the start and termination of N point programs, alignment commands, recalls etc. are automatically initiated by the CNC run, even in the manual section
- The coordinate measuring machine travels to intermediate positions and probings in the workpiece coordinate system, even in the manual section.

### NOTE

- The manual section ignores intermediate positions in the control coordinate section. You can therefore omit programming of the travel paths (intermediate positions) if it can be ensured that the section will always be performed manually. Normally, however, it should be possible to optionally execute the section concerned either manually or automatically. This can best be achieved by masking or demasking the control data lines relevant for changeover prior to the CNC start.
- **<DI 1096>** is ineffective in manual sections.


**Overview**

The following overview compares the individual steps performed during programming and during the CNC run:



**Function call**

possible only in **PROG**



**Data box**

**Activate operation mode 'MANCNC' ?**

- **<YES>**  
The manual mode is switched (or left) on.
- **<NO>**  
The CNC mode is switched (or left) on.



### Comment line in the control data <DI 1679>

**Application**

This function can be used to insert any text in the control data. These texts are not taken into consideration during the CNC run.

**Function call**

Possible only in **PROG**.




All of the text in the data boxes is deleted.

## Reserve address <DI 1456>

### Application

If you can not enter function calls right away during a learn program but nevertheless want the address flow to resume immediately afterward, you can reserve an address with **<DI 1456>**.



Record						
16	0	RESERVE ADR	0	1 1456	0	45

### Control data

A line is reserved in the control data.

## Strategies for time-optimized programs


### NOTE

For a time-optimized CNC program, please observe the following guidelines:

- The probe should travel around the workpiece only once and in one direction.
- Avoid probing elements repeatedly, i.e. use **<RECALL>** instead.
- Use intermediate positions sparingly (➤ „*Travel paths and intermediate positions*“ on page 16-30).
- Utilize the possibilities for time optimization by adjusting the probing and machine parameters individually (section by section) (➤ „*Probing, probing parameters, machine parameters*“ on page 16-20).
- If necessary, make sure that the program continues running following missing bores (➤ „*Continuation after a missing bore <DI 1080>*“ on page 16-32).

# Travel paths and intermediate positions

## Overview



### How this function works

In the CNC mode your measuring machine travels from one point to the next. You must specify all travel movements except for probings in the learn program by setting intermediate positions or entering travel commands. This is necessary:

- to be able to travel around the workpiece without collision by changing the direction of travel;
- to position the probe in relation to a new geometric element;
- to ensure that the probing direction is clearly recognized if and when it is changed;
- to enable collision-free travel to the next workpiece following a measuring run.

### Positions

Options for programming intermediate positions and travel movements:

- Normal intermediate position in the **W-position system** defined via the correspondingly labeled control panel key or (if installed) the push-button in the right-hand joystick or in N point programs via softkey <I-Pos/Prb> (> „**Intermediate position <I-Pos> in the W-position system**“ on page 16-31).
- Fine positioning in the **workpiece coordinate system** via the travel and positioning commands (> „**Fine positioning in the workpiece coordinate system**“ on page 16-31). The fine position can be influenced by the standstill window using <DI 1661>.




**NOTE**

- Use intermediate positions sparingly; as a rule of thumb when measuring an element: Set one intermediate position before the probing and none afterwards.
- As long as one of the axes is in a limit position, you can not program any intermediate positions.
- Before switching over to another probe: Set an intermediate position.
- To optimize travel paths: Observe **► „Comment line in the control data <DI 1679>“ on page 16-28.**

**Intermediate position <I-Pos> in the W-position system**

**Application**

If the intermediate position keys are pressed when the probe is not in contact, the coordinates of the preselected probe will be programmed as an intermediate position. The probe then travels to this position with an accuracy of several tenths of a millimeter **in the W-position system** (control coordinate system).



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1510	CNC Intermediate position	

**Probing**

If the keys are pressed with the probe in contact (with a measuring probe head) a probing will be programmed.

Follow instructions in **► „Overview“ on page 16-30.**

**Fine positioning in the workpiece coordinate system**

**With the travel functions**

- <POSITION>,
- <STEP>,
- <REF STEP>,
- <POS-RES>,
- <POSNORM>

you can program fine positions *in the workpiece coordinate system* based on the conditions defined with **<DI 1661>** (► „Travel commands“ on page 10-34).

#### Advantage

Advantage of using the workpiece coordinate system: You can thus take the specific circumstances of each workpiece measured (e.g. due to manufacturing inaccuracies) into account. This is possible even in critical situations (e.g. when positioning in narrow bores, probing defined points, traveling or probing relative to the last probing, etc.).

### Continuation after a missing bore **<DI 1080>**

#### Application

Sometimes bores may be missing or chips, burs etc. may obstruct the probe in a bore. For such cases, continuation of the CNC program can be ensured via the safety mode. This works for the following measuring programs:

- **<DI 1104>** (circle),
- **<DI 1106>** (cylinder),
- **<DI 1107>** (sphere),
- **<DI 1108>** (ellipse),
- **<DI 1112>** (min. round),
- **<DI 1113>** (max. round),
- **<DI 1114>** (circle segment).

#### Special cases

For complicated elements or part features (e.g. oblong holes) you may need other measuring programs, e.g. **<DI 1101>** (point). In such cases, it is advisable to use **<DI 1081>** as well (► „Bore element **<DI 1081>**“ on page 16-34).

#### Additional condition


The bore must not be used for alignment or for defining the workpiece coordinate system (zero point).

#### Procedure

for learn programming the safety mode:

- Activate the safety mode with **<DI 1080>** at the start of the CNC program or before reaching critical bores.
- If you are using functions other than those mentioned above, program **<DI 1081>** as well (► „Bore element **<DI 1081>**“ on page 16-34).
- Measure the bore or critical element using one of the programs specified above. When doing so, keep to the following sequence of intermediate positions and calls:
  - Set **I-POS** outside the bore,
  - Call function (e.g. **<CIRCLE>**),

- Set **I-POS** inside the bore (not too deep, otherwise collision will be too great),
- Measure the element as usual with probings and intermediate positions,
- **<TERMIN>**,
- Set the **I-POS** again outside the bore.



( ● = I-POS)

### Control data:

NO	Function	Note
	.	
m	YE MISSING BORE	Safety mode on
	.	
n-1	I POS	last I POS before element
n	CIRCLE	
n+1	I-POS	do not set too low
n+2	PROBING +Y	
n+3	PROBING -Y	
n+4	I POS	
n+5	PROBING +X	
n+6	PROBING -X	
n+7	N POINT TERM	
n+8	I-POS	I POS outside the element; here the CNC run continues if a collision occurs
	.	

- If necessary switch off **<DI 1080/1081>** again.


### Function

If a collision occurs in the CNC run between the first **I-POS** outside the bore and **N-POINT TERM**, the program will continue from the next **I-POS** after **N-POINT TERM**, cf sketch.

The screen displays the message: **Element cannot be calculated; NO RESULT** appears in the record(> „**No result** function“ on page 10-55).

### Function call

Possible only in **PROG**



**DI**

**1080**

**BOREMISS**


**Pull-Down-Menu**

**CNC**

**PROG**

**Continue with problems...**

**Pictogram**



### Data box

- **<YES>**  
Activates the safety mode.

Activate operation mode 'Missing drill hole' ?

- **<NO>**  
Deactivates the safety mode.

### Bore element <DI 1081>

**Application**

You can not measure complicated elements such as for example oblong holes, rectangular holes, grooves, joints etc. via a single measuring program call. In many cases you must first perform the required probing as points or individual elements and then calculated the dimensions required by recalling and linking or combining individual elements.

**Safety mode**

In this case you can obtain a safety mode as for circle etc. To do this, you mark the point where an oblong bore begins and ends with **<DI 1081>** In this way the program recognizes where it must continue the CNC run if the oblong bore is missing or following a collision in the oblong bore (e.g. with burs or chips).

**Procedure**

- Activate the safety mode with **<DI 1080>** if this has not already been done (► „**Continuation after a missing bore <DI 1080>**“ on page 16-32).
- As soon as you start the bore element: Mark the beginning of the bore element with **<DI 1081>**.

**Control data:**

NO	Function	Remark
	:	
m	YE MISSING BORE	Safety mode on
	:	
n-1	I POS	Last I POS outside element
n	BORE ELE ST	
n+1	I POS	Do not set too low
n+2	POINT	
n+3	PROBING -Y	
n+4	N POINT TERM	
n+5	I POS	
n+6	PROBING -X	
n+7	N POINT TERM	
n+8	BORE ELE END	I POS outside the element; here the CNC run continues if a collision occurs
n+9	I POS	
	:	

} Bracketing for bore element

- Measure the bore element, e.g. with single-point measurements.
- Once you have all probing for your bore element: Mark the end of the bore element with **<DI 1081>**.
- Set the intermediate position outside the bore element from which the CNC run should be continued if the bore element is missing.



# Generating programs

## Overview

### Application

Generating programs can reduce your programming time when measuring regularly arranged elements, processing alternative program sections, repeating program steps etc.

### The following generating programs are available

- Loops to repeat program steps. The number of repetitions is specified or dependent on conditions (▶ **„Loops <DI 1051>“ on page 16-36**).
- Branching to run alternative program steps depending on the given measuring results or branching within the program (▶ **„Conditional branchings and jumps <DI 1050>“ on page 16-44**).
- W-position displacement (▶ **„W-position displacement <DI 1769, DI 1771>“ on page 16-66**) for elements with a regular arrangement.
- **EXCALL** workpiece jump to load other CNC programs as subprograms or define a batch measurement (▶ **„EXCALL workpiece jump“ on page 16-71**).
- CNC macro for transferring previously created control data lines to a CNC program or taking them over into different CNC programs in unmodified or corrected form. (▶ **„CNC macro mode“ on page 16-77**).

## Loops <DI 1051>

### Application

Loops simplify programming if identical or similar elements are arranged in a regular pattern (e.g. hole circles, Bore patterns). Application example: ▶ **„Application example for loops and branchings“ on page 16-64**

### Scope

A loop comprises all of the control data lines necessary to reach, measure and evaluate a recurring program section. You can either predefine a fixed number of repetitions (e.g. hole circle) or make this contingent on certain conditions (e.g. repeated measurement of an element with different probing parameters if the standard deviation exceeds a specific limiting value).

### Programming loops

- Start the learn programming as usual.
- When you reach a measurement section which is to be measured by loops, open the **Loops** dialog window with **<DI 1051>**.


- Select the type of loop and mark its starting point, if necessary make other input(s): ➤ „**Control data of loops and branchings**“ **on page 16-58**
- If a coordinate system is to be formed or changed within a loop, an offset with the coordinates X, Y, Z = 0.0000 must be programmed at the start of the loop.
- Learn program the first of the recurring measurement sections including the travel path to the next measurement section. Additional (nested) loops and/or branches are allowed within a loop (**maximum nesting depth: 10 levels**).
- Open the **Loops** dialog window with <DI 1051>, mark end of loop and make any other inputs which may be necessary. Control data line(s) generated: ➤ „**Control data of loops and branchings**“ **on page 16-58**
- Continue learn programming as usual.

**A distinction is made between the following loop types:**

**1. Loop without condition**

You define the number of repetitions. The loop variable controls the repetitions in the program. Starting from an initial value, the loop variable changes by one preset step size with every run. The loop is then repeated as often as necessary until the loop variable no longer exceeds the specified final value.

Structure:




**2. Loop with condition at the end**

You specify a condition for the end of the loop, e.g. a certain measured value. The program checks whether the condition has been fulfilled after each cycle. The loop is then repeated as often as required until the specified condition has been met. Since the check is first made at the end of the loop, the CNC program must run through the complete loop at least once.

With this type of loop, the loop variable counts the number of loop cycles (cycle counter). You thus have the option of including the number of repetitions in the end condition e.g. to prevent closed loops.



Structure:




**3. Loop with condition at the start**

You specify a condition for cycling the loop, e.g. a certain measured value. The program then checks whether this condition has been fulfilled before each cycle. The loop is repeated as often as necessary until the condition has been met. Since this check takes place at its start, the loop cycle may be omitted completely.

With this type of loop, the loop variable internally counts the number of loop cycles (cycle counter). You thus have the option of including the number of repetitions in the end condition e.g. to prevent closed loops.

Struktur



Additional information

- When performing learn (part) programming, you measure each element or feature only once. The result name therefore appears in the record only once. However, during a CNC run such an element will usually be measured several times. All repeat measurements are therefore indexed to differentiate between them in the record:

Learn programming	CNC run
CIRCLE_5	CIRCLE_5 CIRCLE_5_1 CIRCLE_5_2...
LINE	LINE LINE_1 LINE_2...


It is not possible to enter indexed result names, i.e. only the recall and linking of such names are allowed.


- When calculating the nesting depth, UMESS considers loops and branches with equality of access. **The max. nesting depth is 10.**
- Each loop which has been started must also be closed (the no. of "open" calls = the number of "close" calls).

- If you want to access any addresses or results determined in loops, proceed as follows when a loop has been completed:
  - End **PROG**.
  - Start CNC mode.
  - Continue learn programming

**Function call**

Possible only in **PROG**.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1051 LOOPS	CNC PROG Loops...	

Dialog

---

Loops Nesting depth=

Y Loop start (DO LOOP) \* FRM  TO  STEP WIDTH

Loop end (END LOOP) Continuous address counter \*

---

Repeat (REPEAT)

Until (UNTIL)

Continuous address counter

---

Repeat If (DO WHILE)

Repeat End (END DO)  Continuous address counter

* YES	NO			*	CURRENT		REPEAT	TERMIN
BACK	PRE MENU							INFO

## Softkeys

**\* YES/NO**

Used to accept/reject the highlighted **<YES>/<NO>** box.

**CURRENT**

This softkey enters the current nesting depth in the dialog window. It should be used, for example, after jumping to an existing CNC program with **<PROG>** to correct or extend it via learn programming. Generally to be used if there is any doubt on the nesting depth displayed.

Alternative: Before **<PROG>**, execute a CNC run up to the line to be jumped to. In this case, the correct nesting depth will immediately appear in the dialog window and there is no need to press the softkey.

**REPEAT**

Used to cancel changes (entries reset to original status).

**TERMIN**

Used to close dialog window and program the control data lines corresponding to the entries.

## Data boxes

### Loop start (DO LOOP)

Used to start programming a loop of the type "**without condition**". All subsequent control data lines will be assigned to this loop until it is concluded with **Loop end (END LOOP)**.

### FRM

Initial value for loop variable; e.g. enter 2 if the bore pattern programmed with the loop should be measured starting with the 2nd bore.

### TO

Final value for loop variable; e.g. enter 20 if the bore pattern programmed with the loop should be measured up to bore 20.

### STEP WIDTH

Step size for the loop variable; the loop variable changes by this value with every loop cycle. For example, enter 3 if only every third bore of the bore pattern programmed with the loop is to be measured. Thus, with an initial value of 2, bores 2, 5, 8, ... .

### Loop end (END LOOP)

Used to terminate the programming of a loop of the type **without condition**. All control data lines since the last **Loop start (DO LOOP)** call are integrated in this loop.

### Continuous address counter

– **<NO>**

The same address is assigned to all elements measured within the loop. Therefore, only the values recorded last can be referenced in the CNC run (e.g. with **<RECALL>**).

– **<YES>**

Continuous addressing; the addressing of the learn program and the CNC run do not agree. If the number of elements measured is decided individually for each CNC run due to the loop condition, the addressing will also vary accordingly. In such cases you should set the address counter behind the loop to the (maximum) value expected in the CNC run if recalls, SAM applications, etc. require unambiguous address assignment.

**Repeat (REPEAT)**

Used to start programming a loop of the type **condition at end**. All subsequent control data lines belong to this loop until it is terminated with **Until (UNTIL)**.

**Until (UNTIL)**

Used to end programming of a loop of the type **condition at end**. All control data lines since the last **Repeat (REPEAT)** call belong to this loop. Then enter the end condition in the two-line data box below (► *„Formulating conditions for loops and branchings.“ on page 16-49*).

**Please note:** With this type of loop the condition may be based on results gained within the loop.

**Repeat If (DO WHILE)**

Used to start programming a loop of the type **condition at start**. All subsequent control data lines belong to this loop until it is terminated with **Repeat End (END DO)**. Then enter the end condition in the two-line data box below (► *„Formulating conditions for loops and branchings.“ on page 16-49*).

**Please note:** The commands belonging to the loop are not yet learn programmed. Therefore with this type of loop the condition can not be based on results gained within the loop.

**Exception:** Loop variable I may be included (► *„Formulating conditions for loops and branchings.“ on page 16-49*).

**Repeat End (END DO)**

Used to terminate programming of a loop of the type **condition at start**. All control data lines since the last **Repeat If (DO WHILE)** call belong to this loop.


**Procedure**

If necessary, update the nesting depth with **<CURRENT>**. Select the required loop type with **<YES>/<NO>** and mark whether you want to program at the start or end of the loop. Make any additional inputs necessary. Used to enter an end/repeat condition ► *„Formulating conditions for loops and branchings.“ on page 16-49* Individual boxes can be selecting with the **∨** and **∧** cursor keys. Close the dialog window with **<TERMIN>**. Control data line(s) generated: ► *„Control data of loops and branchings“ on page 16-58*

## Conditional branchings and jumps <DI 1050>

<b>Application</b>	<p>A branching or jump must be programmed if parts of a measuring run may only be executed under certain conditions. The CNC run will then skip certain parts of the program or branch to others.</p> <p>You formulate the conditions during learn (part) programming and assign the respective program branches to them. The CNC run checks whether the conditions apply and then continues in the assigned program branch.</p>
<b>Example for condition</b>	<p>The diameter of the circle measured last falls below a defined limiting value.</p>
<b>"Intelligent" CNC programs</b>	<p>In this way you can make CNC programs "intelligent". Depending on the prevailing conditions (e.g. measuring results), the program executes alternative program steps, changes the probing parameters, repeats measurements, searches for measuring elements, etc.</p>
<b>Another possibility</b>	<p>Measure different variations of a workpiece family with a single program which identifies the variation concerned based on a measured value or a missing measured element (part feature) and then branches to the appropriate program section(s).</p>
<b>Application example</b>	<p>➤ <b><i>„Application example for loops and branchings“ on page 16-64</i></b></p>

Structure for (three-fold) branching



### Programming branches

- Start learn (part) programming as usual.
- On reaching the point where the CNC program should branch, call the **Branching** dialog window with **<DI 1050>**.
- Start branching (mark **If (IF)**, cf. dialog window), enter condition 1 (➤ *„Formulating conditions for loops and branchings.“ on page 16-49*) and close dialog window with **<TERMIN>**.
- Program the branch to be run if condition 1 applies.
- If alternative conditions should be checked (condition 2, 3, ...):
  - call the **Branching** dialog window with **<DI 1050>**,
  - mark **Or if (ELSE IF)**, enter condition 2,3, ... (➤ *„Formulating conditions for loops and branchings.“ on page 16-49*),
  - Close dialog window with **<TERMIN>**,
  - program the branch to be run if condition 2, 3, ... is met.
- If a special branch should be run in case none of the conditions is met:
  - Call the **Branching** dialog window with **<DI 1050>**,
  - Mark **Or (ELSE)**,
  - Close the dialog window with **<TERMIN>**,
  - Program the branch which is to be run if none of the conditions are met.
- Terminate branching: Call the **Branching** dialog window with **<DI 1050>**, Mark **Branch. end (END IF)**, end dialog window with **<TERMIN>**.
- Continue learn programming as usual.

Control data lines  
generated

#### ➤ *„Control data of loops and branchings“ on page 16-58*



#### NOTE

- **<DI 1050> (If)** must appear once per branching.
- **<DI 1050> (Or if)** may appear any number of times per branching or not appear at all (depending on whether and how many alternative conditions exist).
- **<DI 1050> (Or)** may appear only once per branching or not at all. In the latter case, the CNC run is continued and no branching is executed after **<DI 1050> (Branch. end)**.
- **<DI 1050> (Branch. end)** must appear once per branching.
- New branches may be placed inside of a single branch (nesting). Loops are also permitted. The maximum nesting depth is 10 levels.



When calculating the nesting depth, UMESS considers loops and branches with equality of access.

**Function Call** Possible only in **PROG**.

	<u>DI</u> <b>1050 JUMPS</b>	<u>Pull-Down-Menu</u> <b>CNC PROG Jumps...</b>	<u>Pictogram</u> 
---	------------------------------------	---	---

Dialog

Branching Nesting depth =

**J** If (IF)  \*

X>D (2)

Or if (ELSEIF)

Continuous address counter  \*

Or (ELSE)  Continuous address counter  \*

Branch. end (ENDIF)

* YES	NO			*	CURRENT		REPEAT	TERMIN
BACK	PRE MENU							INFO

### Softkeys

**\* YES/NO**

Used to accept/decline the highlighted <YES>/<NO> box.

**CURRENT**

This softkey enters the current nesting depth in the dialog window. It should be used e.g. if an existing CNC program has been jumped to with <PROG> in order to correct or extend it with learn programming. Generally used if there is any doubt concerning the nesting depth displayed.

Alternative: Before **<PROG>**, execute a CNC run up to the line to be jumped to: in this case, the correct nesting depth is displayed immediately in the dialog window and there is no need to press the softkey.

**REPEAT**

Used to cancel changes (entries reset to original status)

**TERMIN**

Used to close dialog window and program the control data lines corresponding to the entries

### Data boxes

If (IF)

Used to start programming a branching together with the together with the corresponding program branch. Then enter the branching condition (condition 1) in the two-line data box below (➤ *„Formulating conditions for loops and branchings.“ on page 16-49*). All subsequent control data lines belong to this branching until it is closed with **Branch. end (ENDIF)**.

#### NOTE

You must select **If (IF)** once per branching.

Or if (ELSE IF)

Used to start programming an alternative condition together with the applicable program branch. Then enter the branching condition (condition 2, 3, ..) in the two-line data box below (➤ *„Formulating conditions for loops and branchings.“ on page 16-49*).

#### NOTE

You can select **Or if (ELSEIF)** as often as required per branching or not at all.

Continuous address counter

After a branching, the CNC run always continues with the address which is valid after the longest branch has been run. I.e. there may be gaps in the address count if shorter branches are run.

The following applies to learn programming:

– **<NO>**

During learn programming, the addressing is restarted for each branch. Each time this is done, the address counter is reset to the value it had after If (IF) for the first element.

– **<YES>**

Continuous addressing; the addressing of the learn program and the CNC run do not coincide, since you run through each branch during programming. Adjust the address counter if recalls, SAM applications etc. require unambiguous address assignment.

Or (ELSE)

Used to start programming a branch which should be run if none of the conditions are met. Then program the appropriate program steps.

#### NOTE

**Or (ELSE)** may be selected once per branching or not at all.

**Branch. end (ENDIF)** Used to conclude programming of a branching. All control data lines since the last **If (IF) = \*** call belong to this branching.

**NOTE**

**Branch. end (ENDIF)** must be selected once per branching.

**Procedure** If necessary, update the nesting depth with **<CURRENT>**. Select the applicable program branch or branching end with **<\* YES>/<NO>**. Make any additional inputs required. For entering conditions ▶ **„Formulating conditions for loops and branchings.“ on page 16-49**  
Individual boxes can be selected with the **v** and **^** cursor keys. Close the dialog window with **<TERMIN>**.

**Formulating conditions for loops and branchings.**

**Applications** The **Loops** dialog window expects input of the end or repeat condition for **Until (UNTIL)** und **Repeat If (DO WHILE)**. The branching condition also must be entered for **If (IF)** and Or if (**ELSEIF**) in the **Branching** dialog window.

**Structure** A loop or branching condition comprises::

- Variables: Symbol for a measured value which should be compared in the condition.
- Indices of variables: Address of the measured value to be compared.
- Constants.
- Relational operators.
- Logical operators.
- Brackets.

**Example** for a condition: **Z(-2)<-.3MM.OR.I(1)>10.**

Application example: ▶ **„Application example for loops and branchings“ on page 16-64**

**NOTE**

A basic knowledge of programming logical expressions is very useful when formulating conditions.

**Variable** The following overview shows which symbol you must use for which measurement result (e.g. **D** for the diameter of a cylinder).

<b>I</b>	Loop variable
<b>X, Y, Z</b>	Coordinates of the element or absolute distances
<b>D</b>	Diameter
<b>D1</b>	Diameter 1 with ellipse and torus

<b>NX, NY, NZ</b>	Normal standardized at space point
<b>W</b>	Angle (degrees)
<b>W1</b>	Angle 1 (projected angle, angle of rotation, polar angle)
<b>W2</b>	Angle2 (projected angle, tilt angle)
<b>WK</b>	Cone angle
<b>WX, WY, WZ</b>	Axis angle space diagonal (Distance polar 3D)
<b>RD</b>	Space diagonal; space point: deviation; ROM: space distance
<b>DX</b>	Distance in X axis (with +/- sign)
<b>DY</b>	Distance in Y axis (with +/- sign)
<b>DZ</b>	Distance in Z axis (with +/- sign)
<b>V</b>	Pipe measurement option: Rotation angle
<b>B</b>	Pipe measurement option: Bend. angle
<b>RX, RY, RZ</b>	Direction line with edge point
<b>S</b>	Standard deviation
<b>KOORD_OD_ISTW</b>	Coordinate or actual angle of pitch feature
<b>EINZ_TEILUNG</b>	Single pitch
<b>SUM_TEILUNG</b>	Total pitch
<b>EINZ_TEI_FEHL</b>	Single pitch error
<b>SUM_TEI_FEHL</b>	Total pitch error
<b>TEI_SPRUNG</b>	Difference between adjacent pitches
<b>RUNDLAUFFEHL</b>	Circular pitch: Radial runout
<b>SCHRITT</b>	Pitch step (recorded under <b>EXTREME VALUES OF PITCH MEASUREMENT</b> )

Form, position deviation with following abbreviations:			
<b>TIST</b>	<b>tREAL</b>		
<b>TDIST</b>	<b>TXIST</b>	<b>TYIST</b>	<b>TZIST</b>
<b>TDMMC</b>	<b>TXMMC</b>	<b>TYMMC</b>	<b>TZMMC</b>
not yet implemented			
<b>TWISTTRIST</b>	<b>TRIST</b>	<b>TWMMC</b>	<b>TRMMC</b>

**Index**

The address of the measured value to be compared is shown behind the variable as an index in round brackets (exception: loop variable I, see below).

The following are permitted:

- Absolute addresses; example: **X(10)** means coordinate **X** of the element with the address **10**.
- Relative addresses; example: **W1(-1)** means projected angle **1** of the next to last element.
- No address. Then the last element measured is always the one in question (equivalent to index **(0)**).

**NOTE**

Relative indexing therefore differs from indexing with recall. I.e. index **0** refers to the last element, index **-1** to the next to last element, etc.

Loop variable **I** has the nesting depth as index (i.e. must not exceed max. 10). You can also omit the index. In this case the program accepts the current nesting depth as the index. Please make sure that the nesting depth increases by 1 if you request the loop variable with an **IF**-clause within the loop. You will find an example in [▶ „Application example for loops and branchings“ on page 16-64](#), line 31 or line 42. If you omitted the index at **I**, the program would interpret **I(3)** at line 31 and **I(4)** at line 42.

**Constants**

Constant values must not exceed a maximum length of 18 digits before and 4 digits after the decimal point. Example: 34.1.

If constants are subject to mm-inch conversion, they must be labeled with **IN** or **MM** (append without a space). Examples: **1234.5678MM**; **1234IN**.

**NOTE**

The millimeter-inch conversion may require an additional control data line due to a differing number of decimal places (therefore max. 9 lines are available for the user since the 10th line is required for displacements, ► „Control data of loops and branchings“ on page 16-58).

**Relational operators**

The following operators are allowed in order to compare variables with other variables within a condition:

Meaning	Symbol	Relational operation (Example)	Rule of precedence
less than	<	<b>S&lt;0.1MM</b>	Standard deviation of the last address less than 0.1 mm
less than equal to	<=	<b>I&lt;=I(1)</b>	Current loop variable less than or equal to loop variable nesting depth 1
equal to	=	<b>I=3</b>	Current loop variable equal to 3
greater than	>	<b>W(2)&gt;45</b>	Angle of address 2 greater than 45°
greater than equal to	>=	<b>NX(-1)&gt;=0.1</b>	S point normal from next to last address greater than or equal to 0.1
not equal to	<>	<b>I(1)&lt;&gt;I(3)</b>	Loop variable nesting depth 1 not equal to loop variable nesting depth 3

The value of a relational operation can only be **TRUE** or **FALSE**.

Examples:

Result in measuring record	Relational operation (example)	Value of relational operation
S 0.034	<b>S&lt;0.1MM</b>	TRUE
2 W 44.978	<b>W(2)&gt;45</b>	FALSE
NX 20.166	<b>NX(-1)&gt;=0.1</b>	TRUE
4 X 7.986 10 X -3.226	<b>X(4)&lt;X(10)</b>	FALSE

In a relational operation there is always a relational operator between two variables or between a variable and a constant.

Arithmetic operations (+, -, ·, / etc.) must not be included in a comparison. They first must be executed under a separate address with **<DI 1379>** (formula). The condition can then refer to the result of the formula via the corresponding index.

Example for angle between two bores

		Record					
52	CIRCLE	0	0	1104	1410		
	.						
61	N POINT TERM	3	2	1191	1420	29	
62 BORE16	LDL RESNAME	0	0	9919	0		
63	CIRCLE	0	0	1104	1410		
	.						
72	N POINT TERM	3	2	1191	1420	30	
73 BORE17	LDL RESNAME	0	0	9919	0		
	.						
111	POLAR	0	3	1203	0	57	
113 BORE17	DL REFNAME	0	0	9911	0		
114 POL2D_1	LDL RESNAME	0	0	9919	0		
115	POLAR	0	3	1203	0	58	
116 BORE16	DL REFNAME	0	0	9911	0		
117 POL2D_2	LDL RESNAME	0	0	9919	0		
118 A1(58) -W1(57)	FORMULA 0	2	1379	0	59		
119 FORMULA(20)	LDL RESNAME	0	0	9919	0		
120 A1>90	IF	1	1	9951	1951		
	.						
	.						

### Logical operators

The following symbols may be used as logical operators in order to link or combine two or more relational operations or negate a comparison (logical operation):

Meaning	Symbol	Application	Rule of precedence
not (complement)	.NOT.	Negation	Highest status
and (logical product)	.AND.	Linking of relational operations	
or (logical total)	.OR.		
logically equal	.EQV.		
logically unequal	.NEQV.		

A logical operator is always placed between two relational operations and/or the minus sign is placed in front of a relational operation, cf. the following examples. If a logical operation contains more than one such operator, the specified precedence applies, cf. the information at the end of the chapter.

Since relational operations can only be **TRUE** (applicable) or **FALSE** (nonapplicable), the value of a logical operation also must be **TRUE** or **FALSE**.

The following truth tables apply.

Truth table for logical operator .NOT.:

Value of relational operation	Value of logical operation
TRUE	FALSE
FALSE	TRUE

Sample results for .NOT.X(9)>0.5:

Result in measurement record	Logical operation	Value of operation
9 X 0.034	.NOT.X(9)>0.5 FALSE	TRUE, i.e. the condition applies
9 X 1.408	.NOT.X(9)>0.5 TRUE	FALSE, i.e. the condition does not apply

Truth table for logical operator .AND.:

Value of relational operation 1	Value of relational operation 2	Value of logical operation
TRUE	TRUE	TRUE
TRUE	FALSE	FALSE
FALSE	TRUE	FALSE
FALSE	FALSE	FALSE



Sample results for  $X(9) > 0.5 .AND. Y(9) > 3.0$ :

Value in measurement record	Logical operation	Value of operation
9 X 0.034 Y 3.513	$X(9) > 0.5 .AND. Y(9) > 3.0$ FALSE TRUE	FALSE, i.e. the condition does not apply
9 X -1.408 Y -3.513	$X(9) > 0.5 .AND. Y(9) > 3.0$ FALSE FALSE	FALSE, i.e. the condition does not apply
9 X 1.408 Y 3.513	$X(9) > 0.5 .AND. Y(9) > 3.0$ TRUE TRUE	TRUE, i.e. the condition applies

Truth table for logical operator .OR.:

Value of relational operation 1	Value of relational operation 2	Value of logical operation
TRUE	TRUE	TRUE
TRUE	FALSE	TRUE
FALSE	TRUE	TRUE
FALSE	FALSE	FALSE

Sample results for  $X(9) > 0.5 .OR. Y(9) > 3.0$ :

Result in measuring record	Logical operation	Value of operation
9 X 0.034 Y 3.513	$X(9) > 0.5 .OR. Y(9) > 3.0$ FALSE TRUE	TRUE, i.e. condition applies
9 X -1.408 Y -3.513	$X(9) > 0.5 .OR. Y(9) > 3.0$ FALSE FALSE	FALSE, i.e. condition does not apply
9 X 1.408 Y 3.513	$X(9) > 0.5 .OR. Y(9) > 3.0$ TRUE TRUE	TRUE, i.e. condition applies

Truth table for logical operator .EQV.:

Value of relational operation 1	Value of relational operation 2	Value of logical operation
TRUE	TRUE	TRUE
TRUE	FALSE	FALSE
FALSE	TRUE	FALSE
FALSE	FALSE	TRUE

Example results for  $X(9) > 0.5.EQV.Y(9) > 3.0$ :

Result in measurement record	Logical operation	Value of operation
9 X 0.034 Y 3.513	$\underbrace{X(9) > 0.5}_{\text{FALSE}} .EQV. \underbrace{Y(9) > 3.0}_{\text{TRUE}}$	FALSE, i.e. condition does not apply
9 X -1.408 Y -3.513	$\underbrace{X(9) > 0.5}_{\text{FALSE}} .EQV. \underbrace{Y(9) > 3.0}_{\text{FALSE}}$	TRUE, i.e. condition applies
9 X 1.408 Y 3.513	$\underbrace{X(9) > 0.5}_{\text{TRUE}} .EQV. \underbrace{Y(9) > 3.0}_{\text{TRUE}}$	TRUE, i.e. condition applies

Truth table for logical operator .NEQV.:

Value of relational operation 1	Value of relational operation 2	Value of operation
TRUE	TRUE	FALSE
TRUE	FALSE	TRUE
FALSE	TRUE	TRUE
FALSE	FALSE	FALSE

Example results for  $X(9) > 0.5 \text{ .NEQV. } Y(9) > 3.0$ :

Result in measurement record			Logical operation	Value of operation
9	X	0.034	$X(9) > 0.5 \text{ .NEQV. } Y(9) > 3.0$ FALSE                      TRUE	TRUE, i.e. condition applies
	Y	3.513		
9	X	-1.408	$X(9) > 0.5 \text{ .NEQV. } Y(9) > 3.0$ FALSE                      FALSE	FALSE, i.e. condition does not apply
	Y	-3.513		
9	X	1.408	$X(9) > 0.5 \text{ .NEQV. } Y(9) > 3.0$ TRUE                              TRUE	FALSE, i.e. condition does not apply
	Y	3.513		

### Rule of precedence and brackets

If an operation contains more than one logical linking (combinatorial) symbol, the following precedence applies when editing:

- 1st priority:                      Relational sign (>, >=, <, <=, <>);
- 2nd priority:                      NOT-operation;
- 3rd priority:                      AND-operation;
- 4th priority:                      OR-operation;
- 5th priority:                      EQV-operation, NEQV-operation.

With several equivalent linking symbols, editing must be performed from left to right. With OR operations, checking is performed only until one of the linked relations applies.


The rule of precedence for editing can be influenced with brackets. Expressions in brackets form a unit. In addition to the generally applicable rules for using brackets, please also note the following conditions:

- A maximum of 5 bracket levels is possible.
- Index brackets do not form a bracket level.
- 20 logical operations per bracket level are possible.

Examples


I>5.AND..NOT.(X(11)<X(15).OR.S(11)<0.01)

is edited in this order:




I>5.AND..NOT.X(11)<X(15).OR.S(11)<0.01

is edited in this order:



I(2)=2.OR.I(2)=4.OR.I(2)=6.OR.I(2)=8. OR.I(2)=10.OR.I(2)=12

is edited in this order (as soon as a comparison applies, the others are not taken into account):




Control data of loops and branchings

Example 1

<DI 1051>, Loop start (DO LOOP) = \*

(open loop with a fixed number of runs):




The code numbers not explained are the function-specific codes.


**Example 2**

**<DI 1051>, Loop end (END LOOP) = \***

(Close loop with a fixed number of runs):




- The code numbers not explained are the function-specific codes.
- If the address counter is not serial (continuous) only the nesting depth will appear under SC2:



**Example 3**

**<DI 1051>, Repat (REPEAT) = \***

(Open loop with condition at end):




The code numbers not explained are the function-specific codes.


**Example 4**

**<DI 1051>, Until (UNTIL) = \***

(Close loop with condition at end):




- The code numbers not explained are the function-specific codes.
- The end condition requires 1 control data line per 24 characters. A maximum of 9 lines is possible (millimeter-inch conversion ➤ **„Formulating conditions for loops and branchings.“ on page 16-49**). **SC1** codes the line number. The **DL COND** line is omitted with a scope of only two lines and repeated correspondingly often with 4 or more lines.
- If the address counter is not serial (continuous) only the nesting depth will appear under SC2:



Example 5

<DI 1051>, Repeat If (DO WHILE) = \*

(Open loop with condition at start):




- The code numbers not explained are the function-specific codes.
- The start condition requires 1 control data line per 24 characters. A maximum of 9 lines is possible (millimeter-inch conversion ➤ „**Formulating conditions for loops and branchings.**“ on page 16-49, note on constants). **SC1** codes the line number. The **DL COND** line is omitted with a scope of only two lines and repeated correspondingly often with 4 or more lines. With a content of one line the **LDL COND** line is also omitted.

**Example 6**

<DI 1051>, Repeat end (END DO) = \*

(Close loop with condition at start):




The code numbers not explained are the function-specific codes. If the address counter is not serial (continuous) only the nesting depth will appear under **SC2**.

**Example 7**

<DI 1050>, If (IF) = \*

(Open branching, input condition 1):




- The code numbers not explained are the function-specific codes.
- The branching condition requires 1 control data line per 24 characters. A maximum of 9 lines is possible (millimeter-inch conversion **> „Formulating conditions for loops and branchings.“ on page 16-49**, note on constants). **SC1** codes the line number. The **DL COND** line is omitted with a scope of only two lines and repeated correspondingly often with 4 or more lines. With a content of one line the **LDL COND** line is also omitted.

**Example 8**

**<DI 1050>, Or if (ELSE IF) = \***

(Open branching 2, 3 ..., enter condition 2, 3, ...):



- The code numbers not explained are the function-specific codes.
- The condition requires 1 control data line per 24 characters. A maximum of 9 lines is possible (millimeter-inch conversion **> „Formulating conditions for loops and branchings.“ on page**




16-49, note on constants). **SC1** codes the line number. The **DL COND** line is omitted with a scope of only two lines and repeated correspondingly often with 4 or more lines. With a content of one line the **LDL COND** line is also omitted.

- If the address counter is not serial (continuous) only the nesting depth will appear under SC2 (cf. control data for <DI 1051>, **Until (UNTIL) = \***).

**Example 9**

<DI 1050>, **Or (Else) = \***

(Open alternative branching):




The code numbers not explained are the function-specific codes. If the address counter is not serial (continuous) only the nesting depth will appear under SC2.

**Example 10**


<DI 1050>, **Branch. end (END IF) \***

(End conditional branching):



The code numbers not explained are the function-specific codes.

## Application example for loops and branchings



1

Loop with end condition to initially identify the workpiece variant via a "sawtooth probing".

2

Branching with two subbranchings which are executed depending on the status when loop 1 is completed:

2a

If the branching condition applies, a bore measurement with definition of the W-pos takes place, followed by a jump to the end of the program.

2b

If the branching condition does not apply, the program runs through this branch. It contains:

3

Loop with fixed number of runs (20). It initially repeats a W-pos displacement. Subsequent branching(s) follow for certain values of the loop values:

4

For certain values of the loop variables, additional probings are performed which are programmed within this (single-branch) branching condition. The program should omit probings for loop variable values 4 and 8, since they are not worthwhile here:

5

Probing in +Y (omitted if the loop variable has the value 4).

6

Probing in +X (omitted if the loop variable has the value 8).


**Additional example**

► ***„Batch measurement with <DI 1644>“ on page 18-8***


## W-position displacement <DI 1769, DI 1771>

### Application

Learn programming is easier if the elements to be measured recur regularly. For this purpose, you must program a polar <DI 1769> or a cartesian <DI 1771> W-pos displacement, depending on the arrangement of the measured elements:



Measurement with cartesian W-pos displacement




Measurement with polar W-pos displacement

All you have to do then is program the first element of the group.

### Procedure

- Start learn programming as usual and define the W-position within the program.
- As soon as you reach the element group: Open the loop with <DI 1051>, **Loop start (DO LOOP) = \***. For entering data with **FROM, TO, STEP WIDTH** (examples for XZ plane):



- Call **<DI 1769>** or **<DI 1771>** (depending on the type of W-position displacement).
- Enter the data requested by the displacement program in the dialog window. Above example: **Start angle = -45, Pitch = 8, Plane = 2**, cf. explanation of dialog.
- After closing the dialog window, set an intermediate position **outside the first element** of the group.
- Learn program (teach-in) the measurement of the first element of the group, completing the run by setting an intermediate position **outside of this element**.
- Close the loop with **<DI 1051>**, **Loop end (END LOOP) = \***.
- If further programming is required after the element group, recall the original W-position.

Options:

- Read-in the original (home) W-pos with **<DI 1712>**:
- You can also enter **0** to simplify operation. The W-position from the CNC start or from the last call of **<DI 1710>**, which took place within the program is then valid. It is of course also possible to enter the W-pos number. However, in this case you should make sure that the W-position concerned is stored this number for every CNC run.
- **<RECALL>** of the corresponding coordinate system, then **<DI 1710>**.
- **<DI 1713>**.
- Option after polar displacement: Call **<DI 1769>** again, enter **0** for all values.
- Option after cartesian displacement: call **<DI 1771>** again, enter accumulated values with the opposite sign.

- Learn program (teach-in) the remaining measurements **after the element group**.
- Terminate learn programming.

Dialog


W-Pos Displac. Polar


D Pitch circle rad=  Start angle =

Pitch =  Plane (YZ = 1,ZX = 2,XY = 3) =

* YES	NO			*				TERMIN
BACK								INFO



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1769	Coord	
WPCDPOL	Control system WPOS	
a69	Displacement polar...	

**Function Call**

(for polar W-position displacement)

**Softkeys**

**\* YES**

accepts the value offered in the highlighted box.

**TERMIN**


closes the dialog window, accepts the programming of the control data lines and returns you to the calling (starting) menu.

**BACK**

returns to the menu used last without programming a control data line.


**Data boxes**

**Pitch circle rad**




**Start angle**

The start angle must be specified for the first (learn programmed) element. The positive counting direction (counterclockwise) applies when viewing the measuring plane from the positive direction of the 3rd axis:




The following illustration shows the reference axis for the start angle of the respective measuring plane.



Cf. also example under "Procedure".

**Pitch**

Number of measured elements in the entire pitch circle:




Cf. also example above under "Procedure".

**Plane**


The program always offers plane 3 as the measuring plane in which the W-pos displacement is to be performed. This default value can be accepted with **<Enter>** or overwritten and confirmed with **<Enter>**.

See also the example under "Procedure".






**Function Call** (for cartesian W-pos displacement)


<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1771 WPDCCAR	coord Control system WPOS	
a71	Displacement cartesian...	

**Data boxes** Example:



## EXCALL workpiece jump

**Application** Using the **EXCALL** function, you can jump from one CNC program to another and from the target location back to the calling program:



## Application examples

### Subprograms

You only have to program recurring elements once as a special CNC program. You can then call these subprograms from one or more main program(s). If necessary, you can make the call dependent on certain conditions or measuring results **<DI 1050>**.

### Modules

You can put together a CNC measurement from several different individual (partial) runs.

### Batch (serial) measurements

You can combine several different workpieces to form a continuous measuring run (**>** „*Batch measurement with <DI 1644>*“ on page **18-8**). This option can be used as an alternative to **<DI 1644>** offering the advantage that you can define and store any number of series with **EXCALL**.

### PCM


The application range of **EXCALL** is extended in connection with UMESS Opt.9 (PCM): Feature and element oriented measurement can be selected at the CNC start.

#### NOTE

- You can not learn program (teach-in) the workpiece jump, but only create it by correcting the control data correction. For more information, see "Procedure".
- The program called need not exist prior to the learn programming or control data correction.
- You can call additional programs (subprograms) from the program originally called if necessary. Nesting of up to 10 jumps (levels) is permissible.


**Jump**

In the CNC run, **EXCALL** jumps to the first line of the workpiece program called. At the end of this workpiece program, the CNC run continues with the next line of the calling program. For this reason you must make sure that the W-positions and workpiece coordinate systems of the linked (combined) workpieces are compatible, see also "Procedure" below:



**Address counting**

The CNC run sets the addresses which are in the control data. If you use EXCALL to call partial runs as in the example above, you will normally require continuous address counting and unambiguous address assignment (e.g. for recalls). You therefore must match the addresses of the calling program with those of the programs called (via control data correction, **> „Adjusting control data addresses <AUTO--ADR>, <MAN-ADR>“ on page 17-49**):



**How to structure addressing**

The example shows how to structure the addressing and reserve the option of subsequent program extensions by selecting suitable start counters. Of course you can also directly learn program the addressing required.

**Batch measurements**

It is not usually necessary to change the addresses for batch measurements. Each workpiece starts again with address counter 1.

**EXCALL address correction during a CNC run**

In connection with PCM options UX9 or UX10, an EXCALL address correction is possible during the CNC run. It is not necessary to adapt the addresses of the programs called via control data correction.

(**> „Terminating learn programming <DI 1632>“ on page 16-85**, see UX 9 **> „Hardware“ on page 1-5**, "Partial runs").

**Procedure**

- Learn program the main (calling) program as usual. As soon as you reach a point where a jump to another workpiece is to take place:

- If necessary, program the W-position of the workpiece to be called (<DI 1712> or W-position displacement); this step can be omitted e.g. if the workpieces linked have been programmed with the same W-position or the calling workpiece contains <DI 1712> itself.
- Generate a blank line for the **EXCALL** workpiece jump. <DI 1676> "Comments in the measurement record" is useful for this purpose (➤ „**Comments in the measurement record <DI 1676>**“ on page 5-33). This enables you to record the name of the workpiece to be called immediately.
- If the workpiece to be called changes the W-position or the workpiece coordinate system, install the old systems (e.g. <RECALL> and <DI 1708>).
- If continuous address counting is required, adjust the address counter now, see above.
- You can of course also insert these steps later on via control data correction. You must use the control data correction to enter **EXCALL** anyway, see next step.
- Terminate learn programming and edit the main program with the control data correction, ➤ „**Correcting control data <DI 1642>**“ on page 17-31: <DI 1642>.

Select the line reserved for **EXCALL** with <SELECT L> (➤ „**Selecting a control data line <SELECT L>**“ on page 17-35), use search functions if necessary (➤ „**Searching for control data lines <FUNCT ->, FUNCT <-, CHAR. ->, CHAR. <->**“ on page 17-51), and request for editing with the <MODIFY> softkey (➤ „**Modifying a control data line <MODIFY>**“ on page 17-35).

The **Function** column is now highlighted. Type in **EXCALL** and transfer with <Enter>.

Enter 1 for one line in the **SC1** column.

#### NOTE

If your **EXCALL** call (command) is more than 24 characters long, you must set the number of lines to 2 in the **SC1** column. The entries in the following line will include **LDL EXCALL** in the **Function** column and the rest of the workpiece name.

The cursor will then jump to the front data box. Enter the name of the workpiece to be called here and confirm with <Enter>.

#### NOTE

If you are working with several CNC catalogs, it is advisable to enter the catalog code in brackets along with the workpiece name. This will ensure that the subprogram concerned is found even if it is located in another catalog.

Conclude the control data line with **<EXECUTE>**; see next page for the control data line generated:

Record									
NO	X	Y	Z	Function	SC2	SC1	PCM	CCN	ADR
----- Dialog -----									
...	DOOR			EXCALL	0	1	9971	1971	
Simple call of a workpiece									
...	DOOR( )			EXCALL	0	1	9971	1971	
Call of a workpiece with catalog code									
...	Workpiece with a long na			EXCALL	0	2	9971	1971	
...	me(XY)			LFZ EXCALL	0	0	9919	0	
Call of a workpiece with a long name and catalog code									

Insert additional jump commands in the same way if required.

- If continuous address counting is required, adapt the addresses, see above.
- Conclude control data correction (▶ **„Copying control data lines from other workpieces <MIX>“ on page 17-55**).


Example for batch (serial) measurement ▶ **„Batch measurement with <DI 1644>“ on page 18-8**

## CNC macro mode

### Application

CNC macros reduce the amount of programming required for control data occurring in unchanged or modified form in one or more CNC program(s), e.g. slots. To do this, you combine recurring control data in one special CNC program, the so-called CNC macro. Then, during learn programming, you call the corresponding macro whenever you require the control data.

### Example:



You must repeatedly measure the vertical distance from bores to a surface (by perpendicular). You require different probe combinations for surfaces and bores. You then want to determine the penetration point of the perpendicular through the surface (by section).

### Control data

In the CNC macro you must define whether you want to transfer control data and, if so, whether it should be transferred in modified or in unmodified form.

- Unmodified transfer means: The control data lines concerned are copied to the CNC program by the macro as a block. Therefore: This is useful for lines which can be transferred to the CNC program on a 1-to-1 basis (e.g. function calls, change to a defined probe combination).
- Correction-programmed transfer means: The control data concerned is transferred from its function line by line, but still has to be adapted. User guidance can be created for this purpose via correction programming. In this way, the learn programmer is told what to do next, e.g. to set an intermediate position.

It thus follows that: Correction-programmed transfer is ideal for variable data, e.g. when probing bores with varying arrangements and diameters.

### Procedure

1. Create a CNC macro (► **„Creating a CNC macro“ on page 16-78**).
2. Incorporate macro during learn programming (► **„Copying a macro to a learn program <DI 1079>“ on page 16-81**).

## Creating a CNC macro

Basic principles and overview

Procedure for generating a macro

➤ „CNC macro mode“ on page 16-77

Learn program (teach-in) the recurring control data lines or copy them from an existing CNC program.

### NOTE

- Assign a logical name to the workpiece.
- Normally you can omit the alignment and W-position functions unless you want to transfer original coordinate values to your CNC program.
- Start the address counter at 1; addresses will be added to the current value after they are transferred to the CNC program.



Example

The following CNC program results for our example from **„CNC macro mode“ on page 16-77** (initially without highlighted control data lines):

NO	X	Y	Z	Function	SC2	SC1	PCN	CCN	ADR
WORKPIECE NAME: MACRO									
FILE NAME: 0038 CONTROL DATA CARRIER: UB = LUCRT( 2)									
CONT. DATA LINES: 44 NOM VAL LINES: 2									
PROGRAM PACKAGE REQUIRED: UMESS									
-----									
	Dialog								
-----									
1				DEBUG ON			0	1	9970 1970
2	PROG 5			DEBUGGER			0	1	9978 0
3	1	1	1	0 PRB-COMB CHA	0		1	9978	0
4	-45.4314	19.8866	35.1621	I POS	0	11110	0	1101	
5	STEP			DEBUGGER			0	1	9978 0
6				SURFACE	0		1103	1410	
7	PROG 15			DEBUGGER			0	1	9978 0
8	-21.5336	23.7614	7.8107	I POS	0	11110	0	1101	
9	-21.6217	23.8805	2.4950	PROBING -Z	0	11107	0	1103	
10	-39.4108	51.9681	6.4969	I POS	0	11110	0	1101	
11	-40.5145	54.6050	2.4945	PROBING -Z	0	11107	0	1103	
12	-59.1392	19.1776	6.9025	I POS	0	11110	0	1101	
13	-59.1434	19.1853	2.4931	PROBING -Z	0	11107	0	1103	
14	-59.1395	19.1786	6.0439	I POS	0	11110	0	1101	
15	CONT 17			DEBUGGER			0	1	9978 0
16				N POINT TERM	0		1	9978	0 1
17	PROG 21			DEBUGGER			0	1	9978 0
18	1	1	1	0 PRB-COMB CHA	0		1	9978	0
19	-48.2945	28.3960	6.0490	I POS	0	11110	0	1101	
20	-48.3069	30.2341	-1.8208	I POS	0	11110	0	1101	
21	STEP			DEBUGGER			0	1	9978 0
22				CIRCLE	0		1104	1410	
23	PROG 31			DEBUGGER			0	1	9978 0
24	-52.3068	30.2147	-1.8144	PROBING -X	0	11109	0	1103	
25	-27.4574	30.3538	-1.8212	PROBING +X	0	11111	0	1103	
26	-42.6768	30.2648	-1.8218	I POS	0	11110	0	1101	
27	-42.6198	19.6020	-1.8264	PROBING -Y	0	11108	0	1103	
28	-39.3580	44.3868	-1.8060	PROBING +Y	0	11112	0	1103	
29	-39.2836	31.7323	-1.8215	I POS	0	11110	0	1101	
30	-39.2803	31.7224	9.9111	I POS	0	11110	0	1101	
31	2 STEP			DEBUGGER			0	1	9978 0
32				N POINT TERM	3		0	1191 1420	2
33	Switch to current			BTEXT			0	2	1677 0
34	probe			LDL TEXT			0	0	9919 0
35	PROG			DEBUGGER			0	1	9978 0
36	1	1	1	0 PRB-COMB CHA	0		1	1601 1521	
37	2 STEP			DEBUGGER			0	1	9978 0
38				PERPENDIC	0		1	1769 1610	3
39	-3			RECALL 1 ADR			0	1	1301 0 4
40	PROG			DEBUGGER			0	1	9978 0
41	D			NOM VALUES	1		1	1452	0
	1	UMESS-NOMINAL D1 D			0.0000		0.0000	0.0000	
42	CONT			DEBUGGER			0	1	9978 0
43	0.0000	0.0000	0.0000	INTERSEC	3		1	1218	0 5
44	0.0000	0.0000	0.0000	P-END	0		0	9999	999

- Request this CNC program for control data correction with **<DI 1642>** and create the highlighted control data lines as described below.
- Insert 1 blank line at the start, request modification and enter the words **DEBUG ON** in the function column, **<Enter>**. In this way the file is marked as a CNC macro.

- Insert 1 blank line in front of the first control data lines to be transferred, request modification and enter the word **DEBUGGER** in the **Function** column, enter a 1 in the **SC1** column.
- The **Dialog** column is now highlighted. Here you must specify how you want to transfer which of the following macro lines to the CNC programs.

### 3 options

#### PROG xxx

Correction-programming of the control data from the next line to line xxx-1 on a line by line basis (lines 3 to 4 or 8 to 14 in the example given). If you do not specify a line, you can only correction-program the next function (line 36 or 41 in the example given).

Restriction: You can perform correction programming only on the following functions:

- Intermediate positions in the W-position system.
- Probing in the W-position system.
- Changing the probe combination with **<DI 1552>**.
- Nominal input **<DI 1459>**
- Relative recall of single result (**<DI 1301>**, absolute recall is illegal).

#### CONT xxx

Edit the control data from the following line to line xxx-1 and copy it (line 16 in the example). If you do not specify a line, this applies to the rest of the macro (starting with line 43 in the example).

#### xxx STEP

Edit the accept the next xxx functions (not lines!) (lines 32 to 34 or 38 to 39 in the example). If you do not specify a number, this applies only to the next function (line 21 in the example).

**Note:** Text lines are executed, but not transferred to the control data of the CNC program during learn programming (lines 33 to 34 in the example).

Conclude with **<Enter>**.

- Insert a blank line in front of the control data line xxx 1 and mark it as a debugger line: **DEBUGGER, SC1 = 1, PROG, CONT** or **STEP**.
- In this way you can use the debugger functions to determine whether each line/function should be executed and programmed (copied) or transferred via correction programming. Note that
  - the line specified must contain the next debugger function and
  - when setting the function, the next function (xxx+1) must be the debugger function.
 Please refer to the example.
- After inserting all debugger lines, conclude the control data correction as usual.

- Copy the macro to a learn program ➤ *„Copying a macro to a learn program <DI 1079>“ on page 16-81*

## **Copying a macro to a learn program <DI 1079>**


### **Basic principles and overview**

- *„CNC macro mode“ on page 16-77*
- *„Creating a CNC macro“ on page 16-78*

Procedure for copying macros to a learn program:

- Store the required macros in the workpiece catalog and note their numbers and names (unless of course this has already been done).
- Start learn programming as usual.
- As soon as you reach a section you want to copy from a macro: Call **<DI 1079>**.

Function call (for learn programming only)



Dialog																	
CNC adm.: Macro selection						Cat code: Library-English dialog											
<input type="checkbox"/>	WP code	<input type="text" value="circle"/>	Workpiece name			<input type="text" value="CIRCLE DIA.D"/>			Comment			<input type="text" value="Input CIRCLE Dialog"/>					
* YES				NO				*				CHAN CAT		CATALOG		TERMIN	
BACK														INFO			

**Data boxes**

- WP code** Workpiece code of macro.
- Workpiece name, Comment** Displayed for checking purposes.

## Procedure

Enter the macro required or select the macro concerned using the **<CATALOG>** softkey.

Close window with **<TERMIN>**. The macro will then be loaded:

- The learn program processes the control data to be copied (marked by debugger lines with **CONT** or **STEP**, ► **„Creating a CNC macro“ on page 16-78**) like a normal CNC run and writes them to the control data. See example below.

Cancellation is possible and resets the programming step to the status prior to the macro start. System changes made by the canceled macro are, however, retained (e.g. W-position).

If you inadvertently call a normal CNC program instead of a macro, this will have no effect.

- The control data provided for correction programming (marked by debugger lines with **PROG**, ► **„Creating a CNC macro“ on page 16-78**) prompt the learn programmer to:
  - make inputs (combination changes, nominal sizes, recalls); in these cases the usual dialog is displayed;
  - travel to the intermediate positions in the W-position system and confirm by pressing the key specified;
  - execute probings in the W-position system for which the probing direction and probe number can be selected.

See example below.

To cancel the correction programming: never recall all probings of an N point element by correction, i.e. always probe at least one point. Otherwise the system will get hung up.

If you probe too few points for an N point element: The calculation will be canceled and the macro will continue.

The macro from [▶ „Creating a CNC macro“ on page 16-78](#) generates the following control data lines:

```

WORKPIECE NAME:    ....
FILE NAME: 0040          CONTROL DATA CARRIER: UB = LUCRT( 2)
CONT: DATA LINES: 388  NOM VALUES:    ...
PROGRAM PACKAGE REQUIRED:  UMESS
=====
NO | X | Y | Z | Function | SC2 | SC1 | PCN | CCN | ADR
-----|-----|-----|-----|-----|-----|-----|-----|-----|-----
1 |   |   |   | Dialog   |     |     |     |     |
2 |   |   |   | RECORD HEAD | 0 | 6 | 1610 | 1650 |
3 |   |   |   | DL R HEAD | 0 | 0 | 9911 | 0 |
  |   |   |   | DL R HEAD | 0 | 0 | 9911 | 0 |
  |   |   |   | . |
  |   |   |   | . |
63 | 1 | 3 | 1 | 0 PRB-COMB CHA | 0 | 1 | 1601 | 1521 |
64 | -135.4314 | 69.8866 | 35.1621 | I POS | 0 | 11110 | 0 | 1101 |
65 |   |   |   | SURFACE | 0 | 0 | 1103 | 1410 |
66 | -117.5336 | 73.7614 | 7.8107 | I POS | 0 | 11110 | 0 | 1101 |
67 | -118.6217 | 73.8805 | 2.4950 | PROBING -Z | 0 | 11107 | 0 | 1103 |
68 | -128.4108 | 101.9681 | 6.4969 | I POS | 0 | 11110 | 0 | 1101 |
69 | -131.5145 | 104.6050 | 2.4945 | PROBING -Z | 0 | 11107 | 0 | 1103 |
70 | -148.1392 | 69.1776 | 6.9025 | I POS | 0 | 11110 | 0 | 1101 |
71 | -148.1434 | 69.1853 | 2.4931 | PROBING -Z | 0 | 11107 | 0 | 1103 |
72 | -151.1395 | 69.1786 | 6.0439 | I POS | 0 | 11110 | 0 | 1101 |
73 |   |   |   | N POINT TERM | 3 | 0 | 1191 | 1420 |
74 | 1 | 2 | 1 | 0 PRB-COMB CHA | 0 | 1 | 1601 | 1521 |
75 | -140.2945 | 78.3960 | 6.0490 | I POS | 0 | 11110 | 0 | 1101 |
76 | -140.3069 | 80.2341 | -1.8208 | I POS | 0 | 11110 | 0 | 1101 |
77 |   |   |   | CIRCLE | 0 | 0 | 1104 | 1410 |
78 | -141.3068 | 80.2147 | -1.8144 | PROBING -X | 0 | 11109 | 0 | 1103 |
79 | -118.4574 | 80.3538 | -1.8212 | PROBING +X | 0 | 11111 | 0 | 1103 |
80 | -131.6768 | 79.2648 | -1.8218 | I POS | 0 | 11110 | 0 | 1101 |
81 | -131.6198 | 68.6020 | -1.8264 | PROBING -Y | 0 | 11108 | 0 | 1103 |
82 | -128.3580 | 93.3868 | -1.8060 | PROBING +Y | 0 | 11112 | 0 | 1103 |
83 | -127.2836 | 80.7323 | -1.8215 | I POS | 0 | 11110 | 0 | 1101 |
84 | -128.2803 | 80.7224 | 9.9111 | I POS | 0 | 11110 | 0 | 1101 |
85 |   |   |   | N POINT TERM | 3 | 0 | 1191 | 1420 | 18 |
86 | 1 | 1 | 1 | 0 PRB-COMB CHA | 0 | 1 | 1601 | 1521 |
87 |   |   |   | PERPENDIC | 0 | 1 | 1769 | 1610 | 19 |
88 | -3 |   |   | RECALL 1 ADR | 0 | 1 | 1301 | 0 | 20 |
89 D |   |   |   | NOMINALS | 1 | 1 | 1452 | 0 |
  1 | UMESS-NOMINAL | D1 | D | 0.0000 | 0.0000 | 0.0000 | 0.0000 |
90 | 0.0000 | 0.0000 | 0.0000 | INTERSEC | 3 | 1 | 1218 | 0 | 21 |
  |   |   |   | . |
  |   |   |   | . |
388 | 0.0000 | 0.0000 | 0.0000 | P-END | 0 | 0 | 9999 | 999 |
=====

```

## Terminating learn programming <DI 1632>

### Application


This call terminates the learn programming function. The computer then transfers all of the remaining program data to the storage unit. An end label is set there. This ensures that additional storage space will be made available for the next CNC program.

### Please differentiate between the following cases:

- Terminating learn programming of a new workpiece: The function call sets an end label and terminates the learn programming.
- Terminating learn programming after a program correction:

If the number of the last programming step of the correction is higher than that of the last program step of the original CNC program: The function call will set the end label.

If the number of the last programming step of the correction is lower than that of the last program step of the original CNC program: A dialog window will appear inquiring whether the remaining lines of the workpiece should be overwritten or saved.



Dialog			
CNC adm.: End programming mode		Cat name: Standardkatalog	
Programming line	<input type="text" value="122"/>	Complete lines	<input type="text"/>
Correction end	<input type="text"/>	Nominal lines	<input type="text" value="0"/>
Overwrite previous WP	<input type="checkbox"/>		
or store as			
<input type="checkbox"/>	WP code	<input type="text" value="Test"/>	Workpiece name
			<input type="text"/>
		Comment	<input type="text"/>
* YES NO		*	CATALOG TERMIN
BACK		PRG CAN	INFO

### Softkeys



Programming is cancelled without the modifications being stored.

### Data boxes

**Programming line**

Display of last program line modified.

**Complete lines**

Display of total number of program lines for the workpiece.

**Nominal lines**

Display of number of nominal lines (applies only to old CNC runs with old nominal records).

**Correction end**

– **<YES>**

Modified lines are stored, lines not modified are kept.

**Overwrite previous WP**

– **<YES>**

The program will be terminated after the program line displayed.

**All following lines will be deleted!**

– **<NO>**

The previous workpiece will remain unchanged. The part of the program up to the program line displayed will be stored under another name (see below).



or store as WP code  
Workpiece name  
Comment

A new code, workpiece name or comment can be entered here if the previous dialog was answered with <NO>.



# Chapter

# 17

## **Control data modification and management**


---

### **This chapter contains:**

Workpiece catalog . . . . .	17-5
Editing control data . . . . .	17-28

**Definition**

Control data are the encoded commands of a CNC program (> „General“ on page 16-2). All CNC programs are listed in the workpiece catalog. The term **workpiece** is also used to refer to CNC programs.



**Data boxes**

- WP code** Max. 10 characters
- Workpiece name** Max. 30 characters
- Comment** Max. 30 characters

To select a workpiece, you must enter the corresponding workpiece identification or workpiece name. Your input will be checked immediately. If the workpiece identification or name entered is not listed in the current control data catalog, an error message will be displayed.

Using the **<CATALOG>** softkey, you can list the available workpieces in a dialog window and select the desired workpiece there. The workpiece identification, workpiece name and comment will be transferred to the dialog window.

Dialog			
NC adm.: Main menu		Cat name:	Standardkatalog
<input type="checkbox"/> c	WP code	<input type="text" value="502"/>	Workpiece name
			<input type="text" value="0105 502 ZSB.tank flap 1"/>
		Comment	<input type="text"/>
CNC RUN		CNC LIST	
		*	PROG
			CATALOG
			WP ADM
			CAT ADM
BACK		CNC CORR	
			INFO

### Softkeys

- CNC RUN** Start the CNC run **<DI 1640>** (▶ *„Starting a CNC run for a single workpiece <DI 1640>“ on page 18-3*).
- CNC LIST** List the control data on screen / printer **<DI 1641>** (▶ *„Adjusting control data addresses <AUTO-ADR>, <MAN-ADR>“ on page 17-49*).
- PROG** Program CNC runs **<DI 1639>** (▶ *„Starting learn programming <DI 1639>“ on page 16-13*).
- CATALOG** List the workpiece catalog on screen (▶ *„Creating a new control data catalog“ on page 17-25*).
- WP ADM** Used for workpiece administration. See next page.
- CAT ADM** Catalog administration (▶ *„Managing workpiece catalogs <DI 1630>“ on page 17-19*).

**CNC CORR**

Modify/correct control data <DI 1642> (▶ „Correcting control data <DI 1642>“ on page 17-31).

Dialog											
CNC adm.: Main menu				Cat name:		Standardkatalog					
<input type="checkbox"/> c	WP code	<input type="text" value="502"/>	Workpiece name		<input type="text" value="0105 502 ZSB.tank flap 1"/>						
			Comment		<input type="text"/>						
DEL WP				COP WP		* CHAN CAT		ENTER		PRI CAT	TERMIN
BACK				MOD WP						INFO	

**Softkeys**

- DEL WP** Delete workpiece <DI 1635> (▶ „Deleting workpieces <DI 1635>“ on page 17-12).
- COP WP** Copy workpiece <DI 1643> (▶ „Copying workpieces <DI 1643>“ on page 17-18).
- CHAN CAT** Change Catalog (▶ „Changing the control data catalog“ on page 17-23).
- ENTER** Enter workpiece in catalog <DI 1634> (▶ „Entering a workpiece in the workpiece catalog <DI 1634>“ on page 17-10).
- PRI CAT** List workpiece catalog <DI 1650> (▶ „Listing the workpiece catalog <DI 1630, 1650>“ on page 17-5).
- MOD WP** Modify workpieces <DI 1645> (▶ „Modifying workpiece attributes <DI 1645>“ on page 17-17).



### Softkeys

<b>CNC RUN</b>	Start a CNC run.
<b>CNC LIST</b>	Output the control data of a workpiece.
<b>SELECT WP</b>	Enter the workpiece required in the <b>Line select</b> box. If this softkey is pressed, the WP code, workpiece name and comment will be transferred to the data boxes.
<b>INFO WP</b>	Display information on the current workpiece.
<b>PROG</b>	Start learn programming.
<b>CATALOG</b>	Softkey without function in this dialog window.
<b>WP ADM</b>	Call workpiece administration.
<b>CAT ADM</b>	Call catalog administration.
<b>CNC CORR</b>	Edit the control data of a workpiece.
<b>MASK</b>	<p>This function activates a window for selective display of the catalog.</p> <p>In the default setting, an "*" is entered in the <b>WP code</b>, <b>Workpiece name</b> and <b>Comment</b> data boxes so that all workpieces are displayed. If you enter a character string in one of the data boxes, only workpieces corresponding to the character string entered will be displayed. A character string can be combined with an "*". The window function is activated after pressing <b>&lt;TERMIN&gt;</b> .</p> <p>Example: <b>WP code = *</b>, <b>Workpiece name = K*</b>, <b>Comment = *</b>; all workpieces starting with the letter K will be displayed.</p>



### Data boxes

<b>WP code</b>	The required workpiece can be selected with <b>&lt;Enter&gt;</b> after typing in the workpiece code.
<b>Workpiece name</b>	Display of the workpiece name selected or input of the workpiece name to be selected.
<b>Comment</b>	Display of the comment on the workpiece selected.
<b>Line select.</b>	Input of the catalog line in which the required workpiece is entered. See "Procedure" for more information.
<b>Search criteria</b>	The workpiece names of the catalog are searched through based on the character string entered here. The cursor points to the first workpiece name found. See "Procedure" for more information.
<b>Procedure</b>	<p>Up to 10 programs (catalog lines) are displayed on the screen. The following possibilities exist for scrolling or searching through larger catalogs:</p> <ul style="list-style-type: none"> <li>– Scroll up / down with <b>&lt;SHIFT&gt; &lt;↑&gt;/&lt;SHIFT&gt; &lt;↓&gt;</b></li> <li>– Page up / down with <b>&lt;Page Up&gt; / &lt;Page Down&gt;</b>.</li> <li>– Enter the line (first columns of display) in the <b>Line select.</b> data box and accept with <b>&lt;Enter&gt;</b>. The required workpiece then moves to the center of the dialog window.</li> <li>– Enter character string in <b>Search criteria</b> data box and accept with <b>&lt;Enter&gt;</b>. A typical character string would be e.g. the workpiece identification and the full or partial workpiece name.</li> </ul> <p>When you press <b>&lt;Enter&gt;</b>, the program will search starting from the current line (cursor position). If you want to browse through the entire catalog, you must initially select the 1st catalog line.</p> <p>After a successful search, the corresponding workpiece will move to the center of the dialog window.</p> <p>You can jump between <b>Line select.</b> and <b>Search criteria</b> with the <b>↑</b> and <b>↓</b> cursor keys.</p> <p>Conclude with <b>&lt;BACK&gt;</b> or <b>&lt;TERMIN&gt;</b>.</p>


### Explanation of the information listed

<b>WP code</b>	Workpiece code listed in the workpiece catalog, 10 characters in length.
<b>Workpiece name</b>	You must assign a name to the workpiece at the end of programming ( <b>▶ „Learn programming a new workpiece“ on page 16-13</b> ). This name will automatically be entered in the workpiece catalog.

# Control data modification and management

**File name** The system stores the workpiece under this name. UMESS automatically assigns this name following learn programming. In specially cases, you may also do this yourself. For more information on file names, see [▶ „Entering a workpiece in the workpiece catalog <DI 1634>“ on page 17-10](#)

**Output to the printer and/or record window**



Dialog

List workpiece information

Information

J  \* Short information  
 Detailed workpiece information

Select

\* WP code  
 Workpiece name  
 Comment  
 Creation date  
 Update  
 Operator

Search criteria

\_\_\_\_\_

\_\_\_\_\_

from \_\_\_\_\_ to \_\_\_\_\_

from \_\_\_\_\_ to \_\_\_\_\_

\_\_\_\_\_

\* YES NO \_\_\_\_\_ \* \_\_\_\_\_ CATALOG \_\_\_\_\_ TERMIN

BACK \_\_\_\_\_ \_\_\_\_\_ \_\_\_\_\_ INFO

**Output** In its structure the listed catalog (printer, record window) corresponds to the output in the dialog window, see above.



Softkey without function

## Data boxes

### Information

#### Short information

#### Detailed workpiece information

Short information: Output of the dialog window catalog display to the record window and/or to the printer.

Detailed workpiece information: Output of all catalog information to the record window and/or to the printer.

### Selection

Workpiece output can be limited based on the selection criteria: **WP code, Workpiece name, Comment, Creation data, Update (Modification data)** and **Operator**. Selection can be made based on several criteria or only one. The wildcard character is an \* (asterisk).

### Example of short information

Record				
Line	WP code	Workpiece name	File name	Comment
1	502 0105 502	ZSB.Tank 1	CNC_____23B	A LM
2	5471 0105 547	ZSB.Tank 2	CNC_____17B	A
3	1412-1/4 013G1412	REV. 1/4	CNC_____106B	VRKT. GODKENDE
4	2001 0840579.01		CNC_____42B	SUB-routine XY
5	2003 0906750.01		CNC_____46B	SUB-routine XY
6	1454 1454		CNC_____30B	
7	2002 1463199.01		CNC_____44B	SUB-routine XY
8	2000 1555671.01	(GE, XY-Tasus)	CNC_____40B	SPC-meting
9	test 1685 1685		CNC_____24B	
10	W9 23.5090.20		CNC_____118B	hydr. T312br

## Example of detailed workpiece information

Record	
WP code	: 1
Workpiece name	: ZYL UNIV.D
Comment	: Module for cyl. macro
Created	: 18. 6.1997
Operator	: IP-AT/JWa
Last modification	: 27. 7.1998
Operator	: IP-KD/Bronner
No. of control data lines	: 52
No. of nominal lines	: 0
Revision code	: 06.00.00
File name	: CNC_____23B
Status	: FREE

## Entering a workpiece in the workpiece catalog <DI 1634>

### Application

If a workpiece exists only in the memory of the computer, you must enter it in the workpiece catalog with this function. Otherwise UMESS will not be able to access the workpiece.

### Application

Copying a workpiece from an external data carrier to the system with a UNIX command.

### <DI 3500>

No entry is required if you have stored a workpiece with <DI 3500> or <DI 3460>.

### Prerequisites

Any workpiece entered must meet the following requirements ([► „Managing workpiece catalogs <DI 1630>“ on page 17-19](#)):

- Its workpiece file must be stored in the `/home/zeiss/UB` directory.
- Its complete file name must be `CNC_XXXXXXXXB`, where `XXXXXXXX` here stands for an eight-digit combination. The

length of the file name must be 14 characters where the first three characters must be **CNC** and the last one must be **B**.

UMESS automatically assigns this file name corresponding to the catalog code during learn programming.

Example: file name = **12345678**. The full name of the file is then **CNC\_12345678B**.

The workpiece catalog also lists the file names of the workpieces entered (for screen output, ► „*Listing the workpiece catalog <DI 1630, 1650>*“ on page 17-5).

When copying via a UNIX command, you must assign the file name manually.

- Rights: group **ikd1**, owner **kd1**.

Dialog

CNC adm.: Enter WP in catalog      Cat code: Standardkatalog

C File name


WP code       Workpiece name   
 Comment


* YES	NO		DIR LIST
-------	----	--	----------

*		CATALOG	EXECUTE	TERMIN
---	--	---------	---------	--------

BACK			
------	--	--	--

			INFO
--	--	--	------



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1634	CNC Workpiece administration enter...	

## Softkeys

**DIR LIST**

List all files on the directory **/home/zeiss/UB**, function not yet implemented.

**CATALOG**

List the workpiece catalog; e.g. check which workpiece number or file names are still free. Use and operation as for **<CATALOG>**,  
 ► „Listing the workpiece catalog **<DI 1630, 1650>**“ on page 17-5

**EXECUTE**

Input the file with the filename entered in the catalog.

## Data boxes

**File name**

Name under which the file to be entered is stored in the **/home/zeiss/UB** directory.

**WP code**

Code under which the workpiece is entered in the catalog.

**Workpiece name**

Enter name of workpiece, max. 30 (random) characters.

**Comment**

Enter a comment on this workpiece.

## Deleting workpieces <DI 1635>


**Application**


You can use this function to delete workpieces from the catalog and from the hard disk.



### Important!

Workpieces will be irrevocably erased if they are deleted from the catalog! They can then be recovered only by restoring a previous data backup.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1635	CNC	
DELETE	CNC Workpiece administration	
	delete...	

Dialog			
CNC Admin: Delete workpieces		Cat name: Standardkatalog	
Password	<input type="text"/>		
<input type="checkbox"/> WP code	<input type="text" value="test data"/>	Workpiece name	<input type="text" value="HOUSING"/>
		Comment	<input type="text"/>
or			
select		Search criteria	
<input type="checkbox"/> WP code		<input type="text"/>	
<input type="checkbox"/> Workpiece name		<input type="text"/>	
<input type="checkbox"/> Comment		<input type="text"/>	
<input type="checkbox"/> Creation date		from	<input type="text"/> to <input type="text"/>
<input type="checkbox"/> Update		from	<input type="text"/> to <input type="text"/>
<input type="checkbox"/> Operator		<input type="text"/>	
* YES NO <input type="text"/> INFO WP		* <input type="text"/> CATALOG EXECUTE TERMIN	
BACK <input type="text"/> <input type="text"/> <input type="text"/>		<input type="text"/> <input type="text"/> <input type="text"/> INFO	

### Softkeys

**INFO WP**

Shows additional information on the workpiece.

**CATALOG**

Used to the workpiece catalog, e.g. select workpieces. Use and operation as for <CATALOG>, > „Listing the workpiece catalog <DI 1630, 1650>“ on page 17-5. You return to this screen page from the display of the workpiece catalog.

**EXECUTE**

Deletes the file with the workpiece code entered and the corresponding workpiece name in the catalog and in the memory.

**NOTE**

A verification inquiry is made beforehand:

**Do you really want to delete workpiece xxxxxxx ?**

**TERMIN**

Used to close the dialog window.

### Data boxes

**Password**

An input is required only if a password has been entered in the catalog function.

**WP code**

Code of the workpiece in the catalog.

- Workpiece name** Name of workpiece, max. 30 (random) characters in length.
- Comment** Comment on this workpiece.
- Select/Search criteria** Workpieces are distinguished by a number of features in the catalog entry. When deleting workpieces, you can define these distinguishing features as search criteria: First select the required search criterion. Then define the character string for the search criterion. Multiple search criteria are possible.
- You can terminate the character string of a search criterion with an asterisk (\*). In this case any character string may follow. Example: "**WOR\***" as search criterion deletes **WORKPIECE A, WORKPIECE B, ...**
- Using **<EXECUTE>** you can display a list of **all workpieces marked for deletion.**

Dialog

CNC adm.: Delete workpieces      Cat name:      Standardkatalog  
 !! Delete the workpieces display with <EXECUTE> !!

I Line select.       7      Search criteria     

Line	WP code	Workpiece name	File name	Comment
1	1	0105 547 ZSB.tank flap 2	CNC_____17B	x
2	2	013G1412 REV. 1/4	CNC_____106B	x
3	3	0840579.01	CNC_____42B	x
4	4	1454	CNC_____30B	x
5	5	1685	CNC_____24B	x
6	6	Side wall, front le.	E46/4 CNC_____11B	x
7	7	Test with loop	CNC_____27B	x
8	8	Toothing1	CNC_____33B	x

* YES	NO		INFO WP	*			EXECUTE
BACK							INFO

You can display this list section by section using the **<Page Up>** / **<Page Down>** keys.

**All of the workpieces remaining in this list will be deleted when you press <EXECUTE>.**



## Workpiece information

### Application

This function displays workpiece information on the screen. You can edit the data displayed with <DI 1645> (> „*Modifying workpiece attributes <DI 1645>*“ on page 17-17).

### Function call

**INFO WP**

This function can be called from different dialog windows in the workpiece administration.

Dialog			
<input type="checkbox"/>	CNC adm.: Info on workpieces	Cat name:	Standardkatalog
WP code	test data	Workpiece name	Housing
		Comment	
Created from	OFi	on	18.03.1998
Changed from	Kwd	on	25.03.1998
Status	FREI	Revision	R 7.7.0
File name	CNC 6B		
Control data lines	115		
Nominal lines	0		
Continue after input of RETURN			
	< - >	< + >	TERMIN
BACK			INFO

### Softkeys

< - >

Move back one catalog position and display the corresponding workpiece information.

< + >

Move forward one catalog position and display the corresponding workpiece information.

### Data boxes

#### WP code

Workpiece code of selected workpiece.

#### Workpiece name

Name of selected workpiece.

#### Comment


Comment on current workpiece name.

<b>Created from/on</b>	Operator and date of creation.
<b>Changed from/on</b>	Operator and date of last change.
<b>Status</b>	Status of workpiece.
<b>Revision</b>	Software revision used.
<b>File name</b>	Name of file stored in the /home/zeiss/UB directory.
<b>Control data lines</b>	Number of control data lines.
<b>Nominal lines</b>	Number of nominal value lines (only for old control data predating revision ► <b>„Selecting a control data line &lt;SELECT L&gt;“</b> on page <b>17-35</b> ).

## Modifying workpiece attributes <DI 1645>

### Application

You can use this function to edit workpiece attributes. When it is called, a workpiece which has a **DISABLED** status due to incorrect application will automatically be set to the **FREE** status.



DI	Pull-Down-Menu	Pictogram
1645 CNCMOD	CNC Workpiece administration Modify catalog...	

Dialog			
CNC adm.: Modify WP attribute		Cat name:	Standardkatalog
<input type="checkbox"/> c	WP code	test data	Workpiece name Housing
New attribute:		Comment	
WP code	test data	Workpiece name	Housing
Created from	OFi	on	18. 3.1998
Changed from	Jwd	on	25. 3.1998
Status	FREE	Revision	R 7.7.0
File name	CNC	6B	
* YES	NO	< - >	< + >
BACK			INFO
		CATALOG	EXECUTE
			TERMIN

### Softkeys



Select the workpiece located in front of the workpiece displayed in the current catalog.



Select the workpiece located after the workpiece displayed in the current catalog.



List the workpiece catalog, to check for example which workpiece codes or file names are still free. Use and operation as for <CATALOG>, > „Listing the workpiece catalog <DI 1630, 1650>“ on page 17-5. You return to this point from the workpiece catalog.

**EXECUTE**

Store the data modified in the catalog.

**Data boxes**


**WP code,  
Workpiece name,  
Comment**

Selection of the required workpiece.

**New attribute**

Here you can edit the attributes of the selected workpiece. This new data can then be stored with the workpiece in the workpiece catalog by pressing <EXECUTE>.

**Copying workpieces <DI 1643>**



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1643 CNCLIN	CNC Workpiece administration copy...	

Dialog											
CNC adm.: Copy workpieces						Cat name:		Standardkatalog			
Source :											
Catalog code			<input type="checkbox"/>		Catalog name			Standardkatalog			
<input type="checkbox"/> WP code		test data		Workpiece name			DATACOM				
Comment											
Destin.:											
Catalog code			<input type="checkbox"/>		Catalog name			Standardkatalog			
WP code		test data		Workpiece name			DATACOM				
Comment											
* YES		NO		INFO WP		*		CATALOG		EXECUTE	
TERMIN		BACK								INFO	

### Softkeys

**INFO WP**

Information on the workpiece data in the catalog.

**CATALOG**

To list the workpiece catalog; e.e. to check which workpiece codes or file names are still free. Effect and operation as for **<CATALOG>**, **▶ „Listing the workpiece catalog <DI 1630, 1650>“ on page 17-5.** You return to this point from the workpiece catalog.

**EXECUTE**

To execute the copy command corresponding to the data entered.

### Data boxes

**Source/Destin.**

Source = entries for the original workpiece, Destination = entries for the copied workpiece.

The copied workpiece must be assigned a different **WP code** and **Workpiece name** than the original workpiece.

Reason: It must be possible to distinguish between these two features if they are located in the same catalog.

**Catalog code**

Catalog code (2 characters). Work with up to 400 catalogs is possible.

**WP code**

Code of selected workpiece.

**Workpiece name**

Name of selected workpiece.

**Comment**


Comment on current workpiece name.

## Managing workpiece catalogs <DI 1630>

**Application**

This function features the catalog functions you need to manage multiple control data catalogs.


### Catalog structure of control data management



Control data catalog management involves the following responsibilities

1. Creation of new control data catalogs
2. Changeover between control data catalogs
3. Change or deletion of a password for a control data catalog
4. Edit or delete the control data catalogs
5. Defining an output

You can call the catalog functions from the UMESS main menu:



Dialog									
CNC adm.: Main menu					Cat name: Standardkatalog				
<input type="checkbox"/> c	WP code	<input type="text" value="502"/>	Workpiece name		<input type="text" value="0105 502 ZSB.tank flap 1"/>				
			Comment		<input type="text"/>				
PASSWORD DEF OUTP				*	CHAN CAT CREA CAT MOD CAT TERMIN				
BACK					INFO				

## Softkeys

Use the **<CAT ADM>** softkey to call the main menu of the control data catalog. You can then use the softkeys in the menu to execute various control data catalog administration program functions.

**PASSWORD**

Change or delete a password, > „*Changing or deleting a password in the workpiece catalog*“ on page 17-21

**DEFER OUTP**

Define the output, > „*Defining the output columns of the catalog*“ on page 17-22

**CHAN CAT**

Change the control data catalog, > „*Changing the control data catalog*“ on page 17-23

**CREA CAT**

Create a new control data catalog, > „*Creating a new control data catalog*“ on page 17-25

**MOD CAT**

Modify or delete a control data catalog, > „*Modifying or deleting a control data catalog*“ on page 17-26

## Changing or deleting a password in the workpiece catalog

### Application

You can use the <PASSWORD> program function in the catalog administration of <DI 1630> to change or delete the password of a control data catalog. Choose a password which all users with access rights can easily remember and is easy to write.

You do not necessarily have to assign a password to every control data catalog, see **Deleting passwords**

Dialog													
Cat adm.: Password admin.				Cat name:		Standardkatalog							
<input type="checkbox"/>		Change password		Pass word		<input type="text"/>							
<input type="checkbox"/>		new password		Password verification		<input type="text"/>		<input type="text"/>					
* YES				NO				*		CHA CAT		TERMIN	
BACK												INFO	

## Data boxes

- Pass word** Enter the old password which was valid until now.
- new password** Enter the new password (max. 10 characters).
- Password verification** Enter the new password again for verification. If the two passwords are not identical, the message '**Passwords do not match. Please repeat entry**' will appear.
- If you entered the same password both times, it will become effective as soon as you close the dialog window with **<TERMIN>**.
- Deleting passwords** You do not necessarily have to assign a password to each control data catalog.
- To delete a password, just press **<Enter>** for **new password** and for **Password verification**. The password protection of the corresponding control data catalog will then be deleted as soon as you close the dialog window with **<TERMIN>**.

## Defining the output columns of the catalog

- Application** Using the **<DEF OUTP>** program function in the catalog administration of **<DI 1630>**, you can define which information will be output for individual workpieces and in which order this will be done in the control data catalog.

Dialog			
Cat adm.: Output definition		Cat name: Standardkatalog	
<input checked="" type="checkbox"/> Y	Recorder	<input type="checkbox"/> *	
	Order according to WP code or after workpiece name	<input type="checkbox"/> *	<input type="checkbox"/>
Catalog display		<input type="checkbox"/> 9	<input type="checkbox"/> 1
	1 = WP code	<input type="checkbox"/> 2	<input type="checkbox"/> 5
	2 = Workpiece name	<input type="checkbox"/> 3	<input type="checkbox"/>
	3 = Comment	<input type="checkbox"/> 4	<input type="checkbox"/>
	4 = Operator	<input type="checkbox"/> 6	<input type="checkbox"/>
	5 = File	<input type="checkbox"/> 8	<input type="checkbox"/>
	6 = Status		
	7 = Creation date		
	8 = Update		
	9 = Line counter		
<input type="checkbox"/> * YES	<input type="checkbox"/> NO	<input type="checkbox"/> *	<input type="checkbox"/> CHA CAT
<input type="checkbox"/> BACK			<input type="checkbox"/> TERMIN
			<input type="checkbox"/> INFO



**Data boxes****Reorder**

&lt;YES&gt;

Here you can select output of the control data sorted alphabetically either by workpiece code or by workpiece name.

**Catalog display**

Here you can define which information will be output and in what order. Enter the code numbers concerned in the data boxes in the required order (see dialog window for code numbers).

**Softkey**


Changes the control data catalog, ► „*Changing the control data catalog*“ on page 17-23

**Changing the control data catalog****Application**

You can change control data catalogs using the <CHAN CAT> program function in the catalog administration of <DI 1630>.

Dialog			
Cat adm.: Change catalog		Cat name	Standardkatalog
<input type="checkbox"/> C	Catalog code	<input type="checkbox"/>	Catalog name <input type="text" value="Standardkatalog"/>
	No. of entries	<input type="text" value="31"/>	
* YES		NO	
BACK			
		*	CATALOG
			TERMIN
			INFO

### Data boxes

#### Catalog code

To select a control data catalog, you must enter its identification. Your input will be checked immediately. If the identification entered does not exist in the catalog of control data catalogs, the message **Control data catalog does not exist** will be displayed.

With the **<CATALOG>** softkey, you can list the existing control data catalogs present in the catalog and select the one you require. The identification and name of the selected control data catalog and the number of entries will then be copied to the dialog window.

#### No. of entries

User information only: The number of workpieces entered in the current control data catalog is then displayed.

### Softkey



All existing control data catalogs are displayed in the catalog of control data catalogs.

Dialog			
<input type="checkbox"/>	CNC data admin. catalog		
	No Catalog description	Create	Update
<input type="checkbox"/>	Z1 Zeiss-Kat Messmodul Bibliothek	04.08.1998	04.08.1998
	ZA Library-English dialog	04.08.1998	04.08.1998
	ZD Messbibliothek Dialog Deutsch	04.08.1998	04.08.1998
	___ Standardkatalog	04.08.1998	04.08.1998
* YES NO		*	SELECT L TERMIN
BACK			INFO

### Softkeys



Select a control data catalog. The identification of the control data catalog, the name of the control data catalog and the number of entries will then be copied to the dialog window.

**NO**

Jump to the next line in the catalog of the control data catalogs.

**SELECT L**

Select a control data catalog by specifying a line in the catalog of the control data catalogs.

**Line**


In order to select a control data catalog, you must enter the appropriate identification of the control data catalog (e.g. 3) in the catalog of control data lines.

**Creating a new control data catalog**

**Application**

You can create new control data catalogs with the <CREA CAT> program function in the catalog administration of <DI 1630>.

**Alternative function call**



Dialog

Control data catalog: Create a new catalog

Catalog code       Catalog name      \_\_\_\_\_

Pass word      \_\_\_\_\_

Password verification      \_\_\_\_\_

\* YES   NO   \_\_\_\_\_      \*      \_\_\_\_\_ CATALOG      \_\_\_\_\_ TERMIN

BACK   \_\_\_\_\_      \_\_\_\_\_      \_\_\_\_\_      \_\_\_\_\_ INFO

### Data boxes

**Catalog code**

Each control data catalog has a code comprising two characters. Enter the new code. Your input will be checked immediately. If the identification of the control data catalog entered already exists in the catalog of the control data catalogs, the following message will be displayed:  
**Catalog already exists.**

**Catalog name**

You must enter a text (catalog name) comprising at least 5 characters.

**Pass word and Password verification**

You can protect your new control data catalog with a password, **► „Changing or deleting a password in the workpiece catalog“ on page 17-21.** It is not, however, necessary to assign a password. If you do not want to assign a password, leave the data boxes empty and skip them with **<Enter>**.

### Softkey



Displays the catalog of the control data catalogs, **► „Changing the control data catalog“ on page 17-23**

## Modifying or deleting a control data catalog

**Application**

With the **<MOD CAT>** function in the catalog administration of **<DI 1630>** you can change or delete the control data catalogs.

Dialog													
Cat adm.: Modify catalog						Cat name: Standardkatalog							
<input type="checkbox"/> Y	Modify catalog				<input type="checkbox"/> *	Catalog name				Standardkatalog			
	or delete catalog				<input type="checkbox"/>	Pass word							
* YES				NO				* CHA CAT				TERMIN	
BACK												INFO	

A rectangular button with a black border and a white background, containing the text "CHA CAT" in black, bold, uppercase letters.**Softkey**

Changes the control data catalog, ► *„Changing the control data catalog“ on page 17-23*

**Data boxes****Modify catalog****<YES>**

You can give the selected control data catalog another name.

**or delete catalog****<YES>**

You can delete the selected control data catalog if it is empty and you know the corresponding password.

**Pass word**


► *„Changing or deleting a password in the workpiece catalog“ on page 17-21*

## Editing control data

### Listing control data <DI 1641>

**Application**

This function can be used to print the control data of a CNC program either in full or section by section.



Dialog			
CNC adm.: List control data		Cat code:	Standardkatalog
WP code	<input type="text" value="5471"/>	Workpiece name	<input type="text" value="0105 547 ZSB.tank flap 2"/>
		Comment	<input type="text" value="Alignment"/>
<input type="checkbox"/> I	From line	<input type="text" value="1"/>	to line <input type="text" value="172"/>
Type of output			
All	<input type="checkbox"/>		
or control data	<input type="checkbox"/>		
Nominal values	<input type="checkbox"/>		
GDT	<input type="checkbox"/>		
<input type="checkbox"/> * YES	<input type="checkbox"/> NO	<input type="checkbox"/> INFO WP	* <input type="checkbox"/> CATALOG <input type="checkbox"/> TERMIN
<input type="checkbox"/> BACK			<input type="checkbox"/> INFO

**Softkeys**

**INFO WP**

Information on the workpiece data in the catalog (▶ „*Workpiece information*“ on page 17-15).

**CATALOG**

Lists the workpiece catalog; e.g. in order to check which workpiece codes or file names are unassigned. Use and operation as for <CATALOG>, (▶ „*Listing the workpiece catalog <DI 1630, 1650>*“ on page 17-5). You return to this point from the workpiece catalog.

- WP code** Code of selected workpiece.
- Workpiece name** Name of selected workpiece.
- Comment** Comment on current workpiece name.
- From line, to line** Start and end line of the control data to be output. The default values are the first line and the last line of the program.
- Type of output** Extent of the control data to be output.
- All** Output of all information contained in the control data.
- or control data Nominal values, GDT** This is an older function used only with UMESS revisions predating Rev. 7.5.4. The output selects the nominal values from the control data.
- Example** Control data list, requested with **<ALL>**:

Protokoll											
=====											
CONTROL DATA LIST ZEISS UMESS											
WORKPIECE NAME : 0105 547 ZSB.tank flap 2											
FILE NAME : CNC _____ 17B											
CONTROL DATA LINES : 172 NOMINAL LINES: 0											
=====											
NO	X	Y	Z	Function	SC2	SC1	PCN	CCN	ADR		
Dialog											
NO	NOMINAL	U.Tol	L.Tol	Function	SC2	SC1	PCN	CCN	ADR		
NO	Identification			Function	SC2	SC1	PCN	CCN	ADR		
=====											
1	1001	3	0	0.000	1.000	P_PARAM	2	7	0	1500	
2	2001	3	0	0.000	0.000	DL P_PARAM	2	0	0	1911	
3	1020	3	0	0.000	0.020	DL F_PARAM	1	0	0	1911	
4	2000	3	0	0.005	0.000	MEAS FORCE	3	0	0	1911	
5	1004	3	0	0.000	3.500	DL F_PARAM	1	0	0	1911	
6	1001	3	0	0.000	70.000	DL F_PARAM	1	0	0	1911	
7	1014	3	0	0.000	125.000	LDL F_PARAM	1	0	0	1919	
8	PRINTER ON										
9	1	3	0 0	0.000	0.000	REC DEF	0	1	1665	0	
10	2	1	1 10	0.000	0.000	REC DEF	0	1	1665	0	
11	1	3	0 0	0.000	0.000	REC DEF	0	1	MMMM	MMMM	
=====											

## Interpretation of the control data

### Key to column headings and codes used:

- NO** Consecutive number of learn program.
- X | Y | Z** Coordinates of probings or intermediate positions.
- Function** Short description of coded function.

- SC2** For **fine positioning** (e.g. step, position, scanning): Address of the valid workpiece system.
- For **N POINT TERM**: Plane code.
- For **RECALL**: Number of addresses.
- SC1** For **probing** and **intermediate position** from left to right: Column number, probe combination, probe number and probing direction.
- For **fixed plane <DI 1680>**: Plane code.
- For **data lines**: Number of continuous control data lines.
- PCN** Program code for masking, program code, program-specific select code (from left to right).
- **MMMM** denotes masked control data lines which are not taken into account in the CNC run.
  - Program codes:
    - 11 = N point programs,
    - 12 = Linking (binder) program,
    - 13 = Recall program,
    - 14 = Evaluation program,
    - 15 = Machine control program,
    - 16 = Control function,
    - 17 = Coordinate transformation.
  - Program-specific select code.
- CCN** Control code for masking, column number, select code for control modes, select code (from left to right):
- **MMMM** denotes masked control data lines which are not taken into account in the CNC run.
  - Column number: Normally 1, for multi-column machines 2, 3, 4 (depending on column number).
  - Select code for control modes:
    - 1 Positioning columns,
    - 2 Positioning the rotary table,
    - 3 Scanning,
    - 4 Geometric information,
    - 5 Technological information,
    - 6 Coordinate system information,
    - 7 Special control functions,
    - 8
    - 9 CNC program run information.



- Special select code:
  - 01 Intermediate position,
  - 03 Probing within an N-point element,
  - 10 N-point element call and workpiece position operations,
  - 11 Fine position in workpiece system without probing,
  - 13 Fine position in workpiece system with probing,
  - 20 N-point element terminated,
  - 40 Workpiece coordinate system manipulations,
  - 43 Position to normal vector,
  - 51 Step in workpiece system without probing,
  - 53 Step in workpiece system with probing.

<b>ADR</b>	Consecutive addresses of the measurement results in the record.
<b>Dialog</b>	Data entered by the operator, e.g. texts from the record header, recall addresses, coordinate system, <b>YES</b> , <b>NO</b> , scanning information, etc.
<b>Nominal</b>	Value of the nominal.
<b>U.Tol</b>	Upper tolerance referenced to the nominal size.
<b>L.Tol</b>	Lower tolerance referenced to the nominal size.
<b>Identification</b>	Identification of nominal size entered.
<b>additional explanation</b>	Where necessary, the operating instructions will provide information on deviating control data codes in the respective program description.

**NOTE**

Complex program functions call for considerable experience in order to interpret the codes correctly. Errors can often be corrected faster and more effectively by repeating the learn programming of the lines concerned.


## Correcting control data <DI 1642>

<b>Application</b>	Control data correction enables you to adapt a CNC program to changed conditions without repeating the learn programming procedure. This is useful for eliminating errors, adding new program steps, etc.
<b>Preparations</b>	<ul style="list-style-type: none"> <li>– If you have not already done so, switch to printer output with <b>&lt;DI 1614&gt;</b>; you will then receive an error record with references to lines which you should check again after the control data correction.</li> <li>– After finishing the correction, you must decide whether you want to overwrite the original status or retain it alongside the corrected version (▶ „<b>Copying control data lines from other workpieces &lt;MIX&gt;</b>“ on page 17-55). In the latter case, you should list the current workpiece catalog before performing the correction. This</li> </ul>

will make it easier for you to reach a decision on a suitable file name..

**For users of Option 9 (PCM):**

If you want to correct parameterized control data, the PCM edit mode must be activated via **<DI 1666>**.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1642 CNCCOLL	CNC Control data correct...	

Dialog							
CNC adm.: Control data corr.				Cat name: Standardkatalog			
<input type="checkbox"/> c	WP code	<input type="text" value="5471"/>	Workpiece name	<input type="text" value="0105 547 ZSB.tank flap 2"/>			
			Comment	<input type="text" value="Alignment"/>			
* YES		NO	INFO WP	*	CATALOG	TERMIN	
BACK						INFO	

## Softkeys

**INFO WP**

Information on the workpiece data in the catalog (▶ „**Workpiece information**“ on page 17-15).

**CATALOG**

Lists the workpiece catalog; e.g. in order to check which workpiece codes or file names are unassigned. Use and operation as for **<CATALOG>**, (▶ „**Listing the workpiece catalog <DI 1630, 1650>**“ on page 17-5). You return to this point from the workpiece catalog.

### Procedure

Enter workpiece code or select workpiece in question using <CATALOG> and end dialog window with <TERMIN>.

Dialog

Select control data line

                     Line                     

```

=====
L-No      X          Y          Z          Function      SC2 SC1 PCN CCN ADR
=====
1  1001  3  0      0.000  1.000 P_PARAM      2    7      0 1500
2  2001  3  0      0.000  0.000 DL P_PARAM   2    0      0 1911
3  1020  3  0      0.000  0.020 DL F_PARAM   1    0      0 1911
4  2000  3  0      0.005  0.000 MEAS FORCE   3    0      0 1911
5  1004  3  0      0.000  3.500 DL F_PARAM   1    0      0 1911
6  1001  3  0      0.000  70.000 DL F_PARAM   1    0      0 1911
=====
    
```

MODIFY	SELECT L	UNDO	DEMASK	*	INSERT	COPY	EXECUTE	TERMIN
BACK	SPEC FCT	RESTART	MASK		DELETE	MOVE	CONVERS	INFO

### Softkeys

- MODIFY**

Modifies variable data (>„*Modifying a control data line <MODIFY>*“ on page 17-35).
- SELECT L**

Jumps to any control data line of the program being processed (>„*Selecting a control data line <SELECT L>*“ on page 17-35).
- UNDO**

Reverses the last change made. The control data will then be restored to the status it had prior to the last action. This function must be performed immediately after <Execute>.
- DEMASK**

Demasks control data lines (>„*Unmasking a control data line with <DEMASK>*“ on page 17-38).
- INSERT**

Inserts masked control data lines above the current line (>„*Inserting additional control data lines with <INSERT>*“ on page 17-39).
- COPY**

Copies data lines (>„*Copying control data lines with <COPY>*“ on page 17-40).

<b>EXECUTE</b>	This softkey executes the correction just requested (e.g. insert, modify etc.). The dialog window will tell you when to press this softkey. It can be canceled immediately afterwards by pressing <b>&lt;UNDO&gt;</b> .
<b>TERMIN</b>	Terminates control data correction (▶ <b>„Copying control data lines from other workpieces &lt;MIX&gt;“</b> on page 17-55).
<b>BACK</b>	Returns you to the calling menu without implementing the modifications selected.
<b>SPEC FCT</b>	Calls other softkeys assigned with special functions (▶ <b>„Softkeys for special functions &lt;SPEC FCT&gt;“</b> on page 17-48).
<b>RESTART</b>	This softkey cancels all changes made during the current correction run. The control data list appears in its original state.
<b>MASK</b>	Masks control data lines (▶ <b>„Masking a control data line &lt;MASK&gt;“</b> on page 17-37).
<b>DELETE</b>	Deletes control data lines (▶ <b>„Deleting control data lines &lt;DELETE&gt;“</b> on page 17-43).
<b>MOVE</b>	Moves control data lines to another position in the program (▶ <b>„Moving control data lines &lt;MOVE&gt;“</b> on page 17-42).
<b>CONVERS</b>	Control data transformation (▶ <b>„Converting control data &lt;CONVERS&gt;“</b> on page 17-44).
<b>INFO</b>	More information.

### Procedure


- Options for scrolling in control data:
  - Jump to a specific control data line: Enter the line number in the **Line** data box, if necessary activate the data box with the **<SELECT L>** softkey (▶ **„Selecting a control data line <SELECT L>“** on page 17-35).
  - back 1 line (scroll down): **<Shift> + <>** (press simultaneously).
  - forward 1 line (scroll up): **<Shift> + <>** (press simultaneously).
  - back 1 page (11 lines): **<Page down>**.
  - forward 1 page (11 lines): **<Page up>**.
  - Used to search for control data lines with certain functions or character strings: ▶ **„Searching for control data lines <FUNCT ->, FUNCT <-, CHAR. ->, CHAR. <->“** on page 17-51.
- Enter the type of the modification required or conclude it by pressing a softkey.

- Used to interpret the control data ➤ „*Interpretation of the control data*“ on page 17-29.

## Selecting a control data line <SELECT L>

### Application

This function enables you to jump to any line of the control data being processed. For other ways to scroll through control data, see ➤ „*Correcting control data <DI 1642>*“ on page 17-31.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1642 CNCCORR	CNC Control data correct... <SELECT L>	

### Dialog

#### Select control data line

Line ...

### Explanation of dialog

Enter the required line number. Confirm with <Enter>.


The requested control data line will appear in the center of the displayed control data block. You can then enter another line number to jump to it in the same way, select a new change function by pressing a softkey, or terminate the control data correction mode.

## Modifying a control data line <MODIFY>

### Application

With this function you select editing of the current control data line.

Procedure for modifying (editing) a control data line (handling of lines for subsequent input of nominal size ➤ „*Computer controlled manually measured sections <DI 1077>*“ on page 16-25):



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1642 CNCCORR	CNC Control data correct... <MODIFY>	


- Jump to the control data line you want to modify (➤ „*Selecting a control data line <SELECT L>*“ on page 17-35).
- Press the <MODIFY> softkey.

- The box available for editing is then highlighted. The input (sequence of changes, protection of fixed values) is program controlled.
  - Change or accept the data displayed in the highlighted box.
  - **<Enter>** accepts the contents of the box and executes a jump to the next editable box. After going through all editable boxes, this key causes a jump to the next line.  
If you do not want to go through all boxes: Press **<EXECUTE>** to end the line modification mode and jump to the next line.
  - Control data interpretation ➤ **„Interpretation of the control data“ on page 17-29.**
- Modify the next line, select new edit function or terminate control data correction with the softkey.

## Masking a control data line <MASK>

### Application

Parts of a CNC measuring run can be (temporarily) masked by masking the corresponding control data lines and reactivated by unmasking them. (➤ „Unmasking a control data line with <DEMASK>“ on page 17-38).



Dialog

Control data block MASK

I From line  To line

---

L-No	X	Y	Z	Function	SC2	SC1	PCN	CCN	ADR
3	1020	3	0	0.000	0.020	DL F_PARAM	1	0	0 1911
4	2000	3	0	0.005	0.000	MEAS FORCE	3	0	0 1911
5	1004	3	0	0.000	3.500	DL F_PARAM	1	0	0 1911
6	1001	3	0	0.000	70.000	DL F_PARAM	1	0	0 1911
7	1014	3	0	0.000	125.000	LDL F_PARAM	1	0	0 1919
<input type="checkbox"/> 8						PRINTER ON	0	0	1614 0
9	1	3	0 0	0.000	0.000	REC DEF	0	1	1665 0
10	2	1	1 10	0.000	0.000	REC DEF	0	1	1665 0
11	1	3	0 0	0.000	0.000	REC DEF	0	1	MMMM MMMM
12	2	1	1 10	0.000	0.000	REC DEF	0	1	MMMM MMMM
13		1	1	5	0	PRB-COM-CHAN	0	1	1552 1520
14	4654	364	GDA tank flap			RECORD HEAD	0	8	1610 1650

MODIFY SELECT L UNDO DEMASK

\*

INSERT COPY EXECUTE TERMIN

BACK SPEC FCT RESTART MASK

DELETE MOVE CONVERS INFO

### Softkeys

As for ➤ „Correcting control data <DI 1642>“ on page 17-31.


**Procedure**

- Enter first (or last) line of the area to be masked behind **From line**. **<Enter>** first selects the requested line and then offers the default value to be accepted or overwritten, unless this has already been done. Jump to the end line box by pressing **<Enter>** or the v cursor key.
- Enter the last (or first) line of the area to be masked behind **To line**. **<Enter>** first selects the requested line and then offers the default value to be accepted or overwritten, unless this has already been done. If necessary, return to the **From line** data box with the ^ cursor key.
- Mask the selected area by pressing **<EXECUTE>**. The masked lines will be marked by **MMMM** in the **PCN** and **CCN** columns. The dialog window illustrated above shows the masking of lines 11 and 12 as examples.
- Mask another block of lines in the same way, select another editing function, or terminate control data correction with the softkey.

**Unmasking a control data line with <DEMASK>**

**Application**

This function is used to reenable masked control data lines. The **MMMM** characters in the **PCN** and **CCN** columns are then replaced by the original values (originally displayed prior to masking).



The execution and operation of this function are the same as for masking (➤ „Masking a control data line <MASK>“ on page 17-37).




## Inserting additional control data lines with <INSERT>


### Application

Using this function you can insert blank lines in an existing CNC program for additional programming steps.

### NOTE


- The control data lines inserted are masked. They can be overwritten via learn programming or control data correction.
- Blank lines which have not been overwritten are treated as masked lines, i.e. ignored during the CNC run.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1642 CNCCORR	CNC Control data correct... <INSERT>	

### Procedure

- Enter the line number before which the blank line(s) should be inserted in the **Before Line** box. <Enter> first selects the requested line and then offers the default value to be accepted or overwritten, unless this has already been done. Jump to the **Number lines** box by pressing <Enter> again or using the v cursor key.
- Enter the number of control data lines which must be inserted in the **Number Lines** box. If necessary, return to the **Bef Line** data box with the ^ cursor key.
- Insert by pressing the <EXECUTE> softkey. The dialog window illustrated shows an inserted control data line as an example.
- Insert additional line(s) in the same way, select another edit function, or terminate control data correction by pressing the corresponding softkey.




### Copying control data lines with <COPY>

**Application**

This function copies one or more control data line(s) to another position in the program.

It may be necessary to check the addresses afterwards (> „Adjusting control data addresses <AUTO-ADR>, <MAN-ADR>“ on page 17-49).



<u>DI</u> 1642 CNCCORR	<u>Pull-Down-Menu</u> CNC Control data correct... <COPY>	<u>Pictogram</u> 
------------------------------	--	----------------------

Dialog

Control data block COPY

From line  To line  Bef Line

---

L-No	X	Y	Z	Function	SC2	SC1	PCN	CCN	ADR	
3	1020	3	0	0.000	0.020	P_PARAM	1	0	0 1911	
4	2000	3	0	0.005	0.000	DL P_PARAM	3	0	0 1911	
5	1004	3	0	0.000	3.500	DL F_PARAM	1	0	0 1911	
6	1001	3	0	0.000	70.000	DL F_PARAM	1	0	0 1911	
7	1014	3	0	0.000	125.000	LDL F_PARAM	1	0	0 1919	
<input type="checkbox"/>	8					BLANK	0	0	1614 0	
	9					PRINTER ON	0	1	1665 0	
	10					RECORD HEAD	0	1	1665 0	
	11	1	3	0 0	0.000	0.000	DL R HEAD	0	1	MMMM MMMM
	12	2	1	1 10	0.000	0.000	DL R HEAD	0	1	MMMM MMMM
	13	1	1	5	0	PRB-COM-CHAN	0	1	1552 1520	
	14	4654	364	GDA tank flap		RECORD HEAD	0	8	1610 1650	

MODIFY	SELECT L	UNDO	DEMASK	*	INSERT	COPY	EXECUTE	TERMIN
BACK	SPEC FCT	RESTART	MASK		DELETE	MOVE	CONVERS	INFO

### Procedure

- Enter the first (or last) line of the area to be copied in the **From line** box. **<Enter>** first selects the requested line and then offers the value to be accepted or overwritten, if this has not already been done. Jump to the end line box by pressing **<Enter>** again or the v cursor key.
- Enter the last (or first) line of the area to be copied in the **To line** box. **<Enter>** first selects the requested line and then offers the value to be accepted or overwritten, if this has not already been done. Then jump to the next box by pressing **<Enter>** again or the ^ cursor key. If necessary, return to the **From line** data box with the v cursor key.
- Enter the number of the line above which the copied line(s) should be inserted in the **Bef Line** box. **<Enter>** first selects the requested line and then offers the value to be accepted or overwritten, if this has not already been done. If necessary, return to the other data boxes with the ^ cursor key.
- Copy by pressing the **<EXECUTE>** softkey. The copied lines then appear in the position required.


- Copy another block of lines in the same way, select another editing function, or terminate the control data correction function.
- Check the addresses if necessary (▶ **„Adjusting control data addresses <AUTO-ADR>, <MAN-ADR>“** on page 17-49).


### Moving control data lines <MOVE>

#### Application

This function moves one or more control data line(s) to another position in the program.

It may be necessary to check the addresses afterwards (▶ **„Adjusting control data addresses <AUTO-ADR>, <MAN-ADR>“** on page 17-49).



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1642 CNCCORR	CNC Control data correct... <MOVE>	


#### Dialog window

Structure and data as for the **Control data block COPY** dialog window (▶ **„Copying control data lines with <COPY>“** on page 17-40) except that the selected control data lines are not duplicated, but transferred instead.

## Deleting control data lines <DELETE>

### Application

Function for deleting control data lines.



<u>DI</u> 1642 CNCCORR	<u>Pull-Down-Menu</u> CNC Control data correct... <DELETE>	<u>Pictogram</u> 
------------------------------	--	----------------------

Dialog

Control data block DELETE

I From line  To line

---

Z-No	X	Y	Z	Function	SC2	SC1	PCN	CCN	ADR
1	1020	3	0	0.000	0.020	P_PARAM	1	0	0 1911
2	2000	3	0	0.005	0.000	DL P_PARAM	3	0	0 1911
3	1004	3	0	0.000	3.500	DL F_PARAM	1	0	0 1911
4	1001	3	0	0.000	70.000	MEAS FORCE	1	0	0 1911
5	1014	3	0	0.000	125.000	DL F_PARAM	1	0	0 1919
6						BLANK	0	0	MMMM MMMM
7						PRINTER ON	0	0	1614 0
8	OP-30	MES				RECORD HEAD	0	1	1665 0
9	2	1	1 10	0.000	0.000	DL R HEAD	0	1	1665 0
10	1	3	0 0	0.000	0.000	DL R HEAD	0	1	MMMM MMMM
11	2	1	1 10	0.000	0.000	DL R HEAD	0	1	MMMM MMMM
12	1	1	5	0	PRB-COM-CHAN	0	1	1552 1520	

MODIFY SELECT L UNDO DEMASK

\*

INSERT COPY EXECUTE TERMIN

BACK SPEC FCT RESTART MASK

DELETE MOVE CONVERS INFO

### Procedure

- Enter first (or last) line of the area to be deleted in the **From line** box. **<Enter>** first selects the requested line and then offers the value to be accepted or overwritten, if this has not already been done. Jump to the end line box by pressing **<Enter>** again or the v cursor key.
- Enter the last (or first) line of the area to be deleted in the **To line** box. **<Enter>** first selects the requested line and then offers the value to be accepted or overwritten, if this has not already been done. If necessary, return to the **From line** data box with the ^ cursor key.
- Delete by pressing the **<EXECUTE>** softkey.


- Delete another line block in the same way, select another edit function or terminate control data correction with the softkey.
- Check the addresses if necessary (▶ „Adjusting control data addresses <AUTO-ADR>, <MAN-ADR>“ on page 17-49).

## Converting control data <CONVERS>

### Application

This function changes the softkey assignment so that you can perform the following transformations during control data correction:

- Exchange of the X and Y coordinates,
- Exchange of the Y and Z coordinates,
- Exchange of the Z and Xcoordinates,
- Rotation of the coordinate systems: XYZ to YZX or XYZ to ZXY,
- Mirroring of the X, Y or Z coordinates.



DI	Pull-Down-Menu	Pictogram
1642 CNCCORR	CNC Contol data correct... <CONVERS>	

Dialog

L-No	X	Y	Z	Function	SC2	SC1	PCN	CCN	ADR	
1	1001	3	0	0.000	0.5000	P_PARAM	2	6	0	1500
2	2001	3	0	0.000	0.0000	DL P_PARAM	3	0	0	1911
3	1020	3	0	0.000	0.0000	DL F_PARAM	1	0	0	1911
4	2000	3	0	0.200	0.0000	MEAS FORCE	3	0	0	1911
5	1004	3	0	0.000	15.0000	DL F_PARAM	1	0	0	1911
6	1001	3	0	0.000	100.000	LDL F_PARAM	1	0	0	1919
7						BLANK	0	0	MMMM	MMMM
8						PRINTER ON	0	0	1614	0
9						RECORD HEAD	0	8	1610	1650
10	97	GH-6090-CC				DL R HEAD	0	0	9911	0
11	145	-14578				DL R HEAD	0	0	9911	0
12	xyz					DL R HEAD	0	0	9911	0


+ROTAT Z	UNDO	+ROTAT X	+ROTAT Y	*	XYZ->YZX	XYZ->ZXY	EXECUTE	TERMIN
-ROTAT Z	PRE MENU	-ROTAT X	-ROTAT Y		MIRROR X	MIRROR Y	MIRROR Z	INFO

### Softkeys

- ± ROTAT Z**
- ± ROTAT X**
- ± ROTAT Y**

These softkeys are used to exchange control data coordinates; as seen from the positive direction of the specified axis, the coordinates of the other two axes are rotated 90° in the direction of the sign (+ = CCW and - = CW).

Example for a bore with four probings in the XY plane:



**UNDO**

This softkey cancels the last change made. The status of the control data prior to the last action is thus restored. This function must be performed immediately after pressing **<EXECUTE>**.

**XYZ->YZX**

These keys rotate control data coordinate systems; the coordinate values are exchanged as labeled on the softkey.

**XYZ->ZXY**


**MIRROR X**

These softkeys mirror control data coordinates on the respective axis.

**MIRROR Y**

**MIRROR Z**

Example:



**EXECUTE**

Pressing this softkey executes the conversion just requested. The **Change of probe arrangement** dialog window may be displayed, see below under procedure. Cancellation is possible by pressing **<UNDO>** immediately afterwards.

**TERMIN**

To terminate conversion, return to the calling softkey assignment.

### Procedure

- Select the type of conversion required with the softkey. The heading changes depending on the transformation selected. The line range to be converted must also be specified by making entries in the **From line =** and **To line =** data boxes; operation as for masking **► „Masking a control data line <MASK>“ on page 17-37.**
- Perform change with the **<EXECUTE>** softkey. The program then changes to the **Change of probe arrangement** input mask.



Dialog

Change of probe arrangement

Number of probe combination:

<input style="width: 20px;" type="text" value="1"/>	Prb off	1	to probe	<input style="width: 20px;" type="text" value="1"/>
		2		<input style="width: 20px;" type="text" value="2"/>
		3		<input style="width: 20px;" type="text" value="3"/>
		4		<input style="width: 20px;" type="text" value="4"/>
		5		<input style="width: 20px;" type="text" value="5"/>


\*

TERMIN

BACK

INFO

In this window you must adapt the probes to the transformation.  
 Example for **<MIRROR X>**:



The numbers must match the proposed assignment on the control panel. Terminate with **<TERMIN>**.


The dialog window will not be displayed if the transformation does not affect the probe configuration.

- Reverse process with **<UNDO>** if necessary.
- Close dialog window with **<TERMIN>**, return to control data change, final termination there with **<TERMIN>**.

## Softkeys for special functions <SPEC FCT>

### Application

The <SPEC FCT> softkey can be used to assign auxiliary functions to the softkeys which facilitate changing the control data.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1642 CNCCORR	CNC Control data correct... <SPEC FCN>	

Dialog

L-No	X	Y	Z	Function	SC2	SC1	PCN	CCN	ADR
1	1001	3	0	0.0000 0.5000 P_PARAM	2	6	0	1500	
2	2001	3	0	0.0000 0.0000 DL P_PARAM	2	0	0	1911	
3	1020	3	0	0.0000 0.0000 DL F_PARAM	1	0	0	1911	
4	2000	3	0	0.2000 0.0000 MEAS FORCE	3	0	0	1911	
5	1004	3	0	0.0000 15.0000 DL F_PARAM	1	0	0	1911	
<input type="checkbox"/>	6	1001	3	0.0000 100.000 LDL F_PARAM	1	0	0	1919	
7				BLANK	0	0	MMMM	MMMM	
8				PRINTER ON	0	0	1614	0	
9	OP-30	MES		RECORD HEAD	0	8	1610	1650	
10	97	GH-6090-CC		DL R HEAD	0	0	9911	0	
11	145-14578			DL R HEAD	0	0	9911	0	
12	xyz			DL R HEAD	0	0	9911	0	

MODIFY UNDO FUNCT -> CHAR. ->

\*

AUTO-ADR FORMULA EXECUTE TERMIN

BACK FUNCT <- CHAR. <-

MAN-ADR NOM CONV MIX INFO

**MODIFY**

As in the calling menu, ➤ „Correcting control data <DI 1642>“ on page 17-31.

**UNDO**

As in the calling menu, ➤ „Correcting control data <DI 1642>“ on page 17-31.

**FUNCT ->**

Search for control data lines with a defined function and /or before the current line, ➤ „Searching for control data lines < FUNCT ->, FUNCT <-, CHAR. ->, CHAR. <->“ on page 17-51.

**FUNCT <-**

<b>CHAR. -&gt;</b>	Search for control data lines with a defined character or digit string and /or before the current line, <b>&gt; „Searching for control data lines &lt; FUNCT -&gt;, FUNCT &lt;-, CHAR. -&gt;, CHAR. &lt;-&gt;“ on page 17-51.</b>
<b>CHAR. &lt;-</b>	
<b>AUTO-ADR</b>	Automatic address adjustment for all control data lines, beginning with address counter 1, <b>&gt; „Adjusting control data addresses &lt;AUTO-ADR&gt;, &lt;MAN-ADR&gt;“ on page 17-49.</b>
<b>FORMULA</b>	Changes control coordinates systematically by a defined value, <b>&gt; „Systematically changing control data coordinates &lt;FORMULA&gt;“ on page 17-53.</b>
<b>EXECUTE</b>	Executes an address adjustment requested with <b>&lt;AUTO-ADR&gt;</b> or <b>&lt;MAN-ADR&gt;</b> . The prompt to activate this softkey appears in the dialog window. Reversal possible immediately afterwards with <b>&lt;UNDO&gt;</b> .
<b>MAN-ADR</b>	Address adjustment with optional start counter for a defined line range, <b>&gt; „Adjusting control data addresses &lt;AUTO-ADR&gt;, &lt;MAN-ADR&gt;“ on page 17-49.</b>
<b>NOM CONV</b>	Automatic nominal adjustment, <b>&gt; „Automatic nominal value adjustment &lt;NOM CONV&gt;“ on page 17-54.</b>
<b>MIX</b>	Copies control data lines from another CNC program to the workpiece being edited, <b>&gt; „Copying control data lines from other workpieces &lt;MIX&gt;“ on page 17-55.</b>

## Adjusting control data addresses <AUTO-ADR>, <MAN-ADR>

### Application

Correction of the control data may confuse the control data address counter. In this case, the numbering in the **ADR** column of the control data list will no longer be consecutive or reference addresses, e.g. for recalls, will be incorrect. For this reason, you should update the control data addresses by calling this function after making major changes.


### Differentiation

There are two types of address adjustment:

1. Automatic adjustment (**<AUTO-ADR>** softkey). This method continuously increments the addresses including the reference address in the entire control data file starting with address 1.
2. Manual address adjustment (**<MAN-ADR>** softkey). This method continually increments the addresses including the reference address in a selected range based on your inputs, which include selection of the start value. If available, reference addresses can also be adjusted outside of the range specified.

## NOTE

If your program contains an address change with **<DI 1690>**, this will also be taken into account.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1642 CNCCORR	CNC Control data correct... <SPEC FCT>	

## Dialog window

(illustrated for the manual address adjustment)

Dialog

Manual address adaption

From line  To line  St-adr

---

L-No	X	Y	Z	Function	SC2	SC1	PCN	CCN	ADR	
1	1001	3 0	0.0000	0.5000	P_PARAM	2	6	0	1500	
2	2001	3 0	0.0000	0.0000	DL P_PARAM	2	0	0	1911	
3	1020	3 0	0.0000	0.0000	DL F_PARAM	1	0	0	1911	
4	2000	3 0	0.2000	0.0000	MEAS FORCE	3	0	0	1911	
5	1004	3 0	0.0000	15.0000	DL F_PARAM	1	0	0	1911	
<input type="checkbox"/>	6	1001	3 0	0.0000	100.000	LDL F_PARAM	1	0	0	1919
7					BLANK	0	0	MMM	MMM	
8					PRINTER ON	0	0	1614	0	
9	OP-30	MES			RECORD HEAD	0	8	1610	1650	
10	97	GH-6090-CC			DL R HEAD	0	0	9911	0	
11	145-14578				DL R HEAD	0	0	9911	0	
12	xyz				DL R HEAD	0	0	9911	0	

MODIFY UNDO FUNCT -> CHAR. ->

\*

AUTO-ADR FORMULA EXECUTE TERMIN

BACK FUNCT <- CHAR. <-

MAN-ADR NOM CONV MIX INFO

## Procedure


- Automatic adjustment:  
No data boxes are displayed in this case. Start address adjustment with **<EXECUTE>**.
- Manual adjustment:  
Enter the first and last line of the range to be edited and the start value for address counting. Operation the same as for other editing functions, e.g. **<COPY>** (**>**) „Copying control data lines with **<COPY>**“ on page 17-40).


- Return to the softkey menu for control data correction with **<TERMIN>**.


### Searching for control data lines **< FUNCT ->**, **FUNCT <-**, **CHAR. ->**, **CHAR. <->**

#### Application

These functions make it easier to search for control data lines which encode a certain function or contain a particular character or digit string.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1642 CNCCORR	CNC Control data correct... <SELECT L>	



The arrow indicates the searching direction.

- Forwards: Search starts in the lines following the current control data line.
- Reverse: Search starts in the lines before the current control data lines.

Regardless of the direction selected, the entire program will be taken into account: As soon as the last or first control data line has been reached, the search will continue in the other section ("wrap mode").

#### Data boxes

#### Function

Here you can enter:

- the DI number of the function being looked for or
- its abbreviation as it appears in the **Function** column of the control data list. The exact and complete notation is required, e.g. **RECALL 1 ADR.**

# Control data modification and management

**Charact** Specify the character or digit string to be searched for here (max. 12 positions), e.g. **RECALL** or **-77.** or **11108.**

Dialog

look for next control data function

Charact

---

L-No	X	Y	Z	Function	SC2	SC1	PCN	CCN	ADR
1	1001	3	0	0.0000	0.5000	P_PARAM	2	6	0 1500
2	2001	3	0	0.0000	0.0000	DL P_PARAM	2	0	0 1911
3	1020	3	0	0.0000	0.0000	DL F_PARAM	1	0	0 1911
4	2000	3	0	0.2000	2.0000	MEAS FORCE	3	0	0 1911
5	1004	3	0	0.0000	15.0000	DL F_PARAM	1	0	0 1911
<input type="checkbox"/>	6	1001	3	0	0.0000	100.000	LDL F_PARAM	1	0 0 1919
7						BLANK	0	0	MMMM MMMM
8						PRINTER ON	0	0	1614 0
9	OP-30	MES				RECORD HEAD	0	8	1610 1650
10	97	GH-6090-CC				DL R HEAD	0	0	9911 0
11	145-	14578				DL R HEAD	0	0	9911 0
12	xyz					DL R HEAD	0	0	9911 0

MODIFY UNDO FUNCT -> CHAR. ->

\*

AUTO-ADR FORMULA EXECUTE TERMIN

BACK FUNCT <- CHAR. <-

MAN-ADR NOM CONV MIX INFO

### Procedure

Type in the function or character string to be searched for and confirm with **<Enter>**. If the search is successful, the corresponding control data block will be moved to the correction window with the line searched for in the center. You can then select editing of this line (**<MODIFY>** softkey), continue searching or select another editing function with a softkey.

**Failed search** If the search has failed, the program outputs a corresponding message.


## Systematically changing control data coordinates <FORMULA>

### Application

You can systematically change the X, Y, Z control coordinates by a defined value or factor.

### Application example

The bore depth in the +X direction has been increased by 5 mm, cf. explanation. This may be restricted to certain control data lines.



<b>DI</b>	<b>Pull-Down-Menu</b>	<b>Pictogram</b>
1642 CNCCORR	CNC Control data correct... <SELECT L>	

Dialog

Formula operat.:

<input type="checkbox"/>	Coordinate (s)	<input type="checkbox"/>	Operation	<input type="checkbox"/>	val	<input type="text" value="5.000"/>					
	L-No	X	Y	Z	Function	SC2	SC1	PCN	CCN	ADR	
	1	1001	3	0	0.0000	0.5000	P_PARAM	2	6	0	1500
	2	2001	3	0	0.0000	0.0000	DL P_PARAM	2	0	0	1911
	3	1020	3	0	0.0000	0.0000	DL F_PARAM	1	0	0	1911
	4	2000	3	0	0.2000	0.0000	MEAS FORCE	3	0	0	1911
	5	1004	3	0	0.0000	15.0000	DL F_PARAM	1	0	0	1911
<input type="checkbox"/>	6	1001	3	0	0.0000	100.000	LDL F_PARAM	1	0	0	1919
	7						BLANK	0	0		MMMM MMMM
	8						PRINTER ON	0	0		1614 0
	9	OP-30	MES				RECORD HEAD	0	8		1610 1650
	10	97	GH-6090-CC				DL R HEAD	0	0		9911 0
	11	145-14578					DL R HEAD	0	0		9911 0
	12	xyz					DL R HEAD	0	0		9911 0

MODIFY UNDO FUNCT -> CHAR. ->

AUTO-ADR FORMULA EXECUTE TERMIN

BACK FUNCT <- CHAR. <-

MAN-ADR NOM CONV MIX INFO

**Explanation**

**Formula operat.:**

Specify coordinate change; permissible input values:

<b>Coordinate(s)</b>	<b>X, Y, Z</b>	If applicable, you can change 2 or 3 coordinates simultaneously. X would have to be entered for the above example.
<b>Operation</b>	<b>+, -, *, /, =</b>	You would have to enter + in our example.
<b>val</b>	Numerical value (mm, inch);	Our example requires an input of 5.

**Formula operat.: (X) + 5.000**  
From line To line

Specify the line range to which the change should apply. Operation as for **► „Masking a control data line <MASK>“ on page 17-37.**

**Automatic nominal value adjustment <NOM CONV>**



**Application**

Due to the further development of the UMESS software, the structure of nominal values in the control data has changed. Existing CNC programs can still be run without converting the nominal values. The control data must be converted if existing control data is to be supplemented or changed.

**UMESS 300**

CNC runs which have been converted from UMESS 300 to UMESS should also be edited with this function.

The following may be affected by the conversion: DIN nominals, UMESS nominals, nominals for 2D best fit, nominals for 3D best fit and parameterized nominals. Reserved nominal lines are deleted.



**NOM CONV**

**Convert old nominals to new**

The change is executed by pressing the **<EXECUTE>** softkey.



## Copying control data lines from other workpieces <MIX>

### Application


You can use this function to copy individual or all control data lines from another CNC program to the one currently being edited.


### Preparations

- Note the last address of the workpiece to which you want to copy (workpiece 1).
- Create a copy of the workpiece from which you want to copy (workpiece 2). > „**Copying workpieces <DI 1643>**“ on page **17-18**. You can delete the copy later on.
- Adapt the address of workpiece 2: <MAN-ADR>, St-adr = last address of workpiece 1 or higher (> „**Adjusting control data addresses <AUTO-ADR>, <MAN-ADR>**“ on page **17-49**).
- Request workpiece 1 for control data correction and copy workpiece 2 to it.

### NOTE

Please note that this is purely an editor function. The program does not check whether the control data lines you have copied together are operable. Make sure e.g. that you do not copy to N point programs, loops, continuation lines, etc. Also make sure that both programs have been created with software of the same revision status.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1642 CNCCORR	CNC Control data correct... <SPEC FCT>	

MIX

MIX CNC DATA				Standardkatalog			
<input type="checkbox"/> c	WP code	<input type="text" value="2002"/>		Workpiece name	<input type="text" value="1463199.01"/>		
	from line	<input type="text" value="7"/>		Comment	<input type="text" value="SUB-routine ZF-GE-RENAULT"/>		
				to line	<input type="text" value="166"/>		
	61			ROTATE SPACE	0	1	1706 1640 14
	62			ZERO POINT	0	1	1701 1640 15
	63	*****		CTEXT	0	1	1679 0
	64	1		EXCALL ADR	0	1	1691 0 16
	53	0.5074	84.5480 -426.0750	VAST LINE	2	11109	1535 1352
	54			VAST END	0	1	1535 1359
<input type="checkbox"/>	55	107.0070	84.5474 -426.0740	POSITION ITP	0	11110	1511 1111
	56			N POINT TERM	1	2	1191 1420 13
	57	8.0000	0 0	LDL FILTER1	0	0	9919 0
	58	3	1 0 0	MCC - MIC	1	1	MMMM MMMM 14
	59	1 1 1	0 1 0 0 0	FILTER MODI	0	1	1185 0
	60	10.0000	0.0000 0.0000	I-POS	0	11110	0 1101
				*	<input type="text" value="CATALOG"/> <input type="text" value="TERMIN"/>		
<input type="text" value="BACK"/>					<input type="text" value="INFO"/>		


**Procedure**

- Specify the name or number of the CNC program from which you want to copy. The program to be copied then appears on the screen.
- Enter the first (or last) line of the block to be copied in the **from line** box. **<Enter>** first selects the requested line and then offers the value to be accepted or overwritten, if this has not already been done. Jump to the end line box by pressing **<Enter>** again or the v cursor key.
- Enter the last (or first) line of the area to be deleted in the **To line** box. **<Enter>** first selects the requested line and then offers the value to be accepted or overwritten, if this has not already been done. If necessary, return to the **From line** data box with the ^ cursor key.
- Press **<TERMIN>**; the control data lines of the program to which you want to copy now appear again with the **Bef. line** inquiry. Enter the number of the line in front of which the line(s) copied should be placed. **<Enter>** first selects the requested line and then

offers the value to be accepted or overwritten, if this has not already been done.

- Perform copy process with **<EXECUTE>**. The lines copied appear at the position requested.
- Copy the same line block again to another position, copy another line block in the same way, select another editing function with a softkey or terminate the control data correction process.
- Check the addresses of workpiece 1 if necessary (**>** „*Adjusting control data addresses <AUTO-ADR>, <MAN-ADR>*“ on page **17-49**) and delete workpiece 2.

## Terminating the control data correction <TERMIN>



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1642 CNCCORR	CNC Control data correct...	

**TERMIN**

Dialog							
CNC adm.: End control data correct. Cat name:Standardkatalog							
Control dat lines	<input type="text" value="173"/>	Nominal lines	<input type="text" value="0"/>				
<input checked="" type="checkbox"/> Y	Overwrite	<input type="checkbox"/>	*				
or store as							
WP code	<input type="text" value="5471"/>	Workpiece name	<input type="text" value="0105 547 ZSB.tank flap 2"/>				
		Comment	<input type="text"/>				
<input type="button" value="* YES"/>		<input type="button" value="NO"/>			*	<input type="button" value="CATALOG"/>	<input type="button" value="TERMIN"/>
<input type="button" value="BACK"/>	<input type="button" value="CORR CAN"/>					<input type="button" value="INFO"/>	

### Softkeys

**CORR CAN**

The control data correction is canceled. All changes which have been made are lost. The CNC run remains in its original state.

### Data boxes

Control data lines,  
Nominal lines

Display of scope.

Overwrite

– **<YES>**

The original file will be overwritten. The control data modifications will be transferred to the original control data file.

– **<NO>**

The original file will be retained. The modified control data will be stored in a new file.

or store as WP code ...

Enter the identification of the new file. If you enter a file name which already exists in the control data catalog, a corresponding message will prompt you to make another input. If you then would like to find out which file names have already been assigned, you can list the control data catalog on the screen beforehand. (► **„Listing the workpiece catalog <DI 1630, 1650>“ on page 17-5**).

#### NOTE

Please follow the instructions on identification (► **„Entering a workpiece in the workpiece catalog <DI 1634>“ on page 17-10**) to prevent complications when deleting or entering workpieces.



# Chapter 18

## CNC run

---

During a CNC run, the coordinate measuring machine automatically performs a measurement with the help of a previously created CNC program. The computer processes the programmed control data in chronological order. Computing and travel commands result which reproduce the programmed run exactly.

### **This chapter contains:**

Procedure .....	18-2
Starting a CNC run for a single workpiece <DI 1640> .....	18-3
Starting a CNC run for multiple workpieces .....	18-5
Interrupting and continuing a CNC run .....	18-11
CNC debugger <DI 1070> .....	18-17
Determining the probing direction for single points of a CNC run <DI 1178> .....	18-21

## Procedure

<b>Clamping</b>	Clamp the workpiece(s) with the same orientation as for learn programming.
<b>Probes (styli)</b>	Use the same probe configuration as for learn programming (the same physical arrangement of the probes and the same allocation of the probe numbers).
<b>W-position</b>	If the control coordinate system with which the CNC program was generated is not (no longer) stored: Redefine the W-position (▶ <b>„Control coordinate system“ on page 16-6</b> ).
<b>Parameters</b>	If necessary/required: Set/modify the probing and machine parameters (▶ <b>„Probing, probing parameters, machine parameters“ on page 16-20</b> ).
<b>Start position</b>	Position the probe head so that the first probing or intermediate position of the CNC program can be reached without a collision.
<b>CNC start</b>	Start the CNC measurement; UMESS features the following options for starting automatic measuring runs: <ul style="list-style-type: none"> <li>– CNC start of a single workpiece (▶ <b>„Starting a CNC run for a single workpiece &lt;DI 1640&gt;“ on page 18-3</b>);</li> <li>– CNC start of several identical or different workpieces (▶ <b>„Starting a CNC run for multiple workpieces“ on page 18-5</b>).</li> </ul>
<b>Interruption</b>	Interruption of a CNC measurement and its continuation following interruption (▶ <b>„Interrupting and continuing a CNC run“ on page 18-11</b> ).
<b>Repetition record</b>	If necessary, call up the repetition record after ending the measurement (▶ <b>„Repetition record &lt;DI 1613&gt;“ on page 5-40</b> ).
<b>CNC debugger</b>	If necessary, check and correct with the CNC debugger (▶ <b>„CNC debugger &lt;DI 1070&gt;“ on page 18-17</b> ).





**Data boxes**

<b>WP code</b>	Code of the CNC run.
<b>Workpiece name</b>	Name of the CNC run.
<b>Comment</b>	Comment on this CNC run.
<b>Start line / End line</b>	<p><b>Start line</b> enables the program to be entered at any point. If program sections which generate results are skipped, the following conditions must be met:</p> <ul style="list-style-type: none"> <li>– The CNC run must be started with the W-position valid at the entry point.</li> <li>– The workpiece coordinate system valid at the entry point must be defined.</li> <li>– The address counter must be set to the next record address.</li> <li>– All of the measuring results required for a recall must be available.</li> <li>– The <b>&lt;FIXED PLANE&gt;</b> or <b>&lt;PRB MODE&gt;</b> which may be required for the next measuring run must be specified.</li> <li>– The probe must be located in a starting position which enables collision-free travel to the first intermediate position.</li> <li>– The probe combination must have been selected correctly.</li> </ul> <p><b>End line</b> makes it possible to set the end point anywhere within the program.</p>
<b>W-Position</b>	Enter the number of the required W-position.
<b>Paper start manual or autom.</b>	Used to select automatic or manually loading of paper.
<b>Part number</b>	Input of the part number.

# Starting a CNC run for multiple workpieces

## Overview

With the methods described here you can

- combine multiple CNC programs in any sequence to form a continuous measuring run;
- start a program several times in succession.

### Batch

A CNC run extending over multiple workpieces is generally referred to in UMESS as a batch or series.

### Methods for creating a batch

Combine several different CNC program runs with

- Workpiece jump **EXCALL** (➤ *„Compiling a batch measurement with EXCALL“ on page 18-6*)

or

- with **<DI 1644>** (➤ *„Batch measurement with <DI 1644>“ on page 18-8*).

### Preparations for measuring multiple workpieces by batch

#### Clamping

Clamp the workpiece(s) with the same orientation as for learn programming.

#### Probes

Use the same probe configuration as for learn programming (the same physical arrangement of the probes and the same allocation of probe numbers); all of the measuring elements included in the batch must be accessible with a single probe configuration or a probe changer must be available.

#### Starting position

The starting position must be selected so as to ensure collision-free travel to the first intermediate position or probing.

#### Travel paths

Ensure collision-free travel between workpieces.

#### Catalog function

Make sure that all the measuring runs required are stored in the workpiece catalog.

#### W-position

If the control coordinate systems with which the CNC programs were generated are not (no longer) stored: Redefine the W-positions (➤ *„Control coordinate system“ on page 16-6*).

#### Parameters

If necessary: Set/modify the CNC probing and machine parameters (cf. ➤ *„Probing, probing parameters, machine parameters“ on page 16-20*).

**Batch** Define or start batch according to the preceding method of combining with **EXCALL** (➤ „**Compiling a batch measurement with EXCALL**“ on page 18-6) or with <DI 1644> and <CNC RUN> (➤ „**Batch measurement with <DI 1644>**“ on page 18-8).

## Compiling a batch measurement with EXCALL

**Application** If you want to keep several batches ready for call, you must link the applicable CNC programs via the **EXCALL** workpiece jump, ➤ „**EXCALL workpiece jump**“ on page 16-71.

You can generate a batch by appending the **EXCALL** control data lines the lines needed to update the coordinate system


- to the end of the first workpiece or
- or by combining them to form a special CNC program containing only these control data lines.

**Correction option** Using the control data correction feature, you can quickly modify the sequence and number of workpieces linked or generate a new batch..

**Batch start** Start the batch with <DI 1640> and with the W-position of the first workpiece.

Preparations for starting multiple workpieces ➤ „**Overview**“ on page 18-5.

**Example 1** You want to measure three different workpieces in succession:




Control data list for the batch measurement:

Record									
NO	X	Y	Z	Function	SC2	SC1	PCN	CCN	ADR
Dialog				Function	SC2	SC1	PCN	CCN	ADR
NO	Nominal	U.Tol	L.Tol	Function	SC2	SC1	PCN	CCN	ADR
Identification				Function	SC2	SC1	PCN	CCN	ADR
1	Three workpieces			TEXT			0	0	1676 0
2	in succession			TEXT			0	0	1676 0
3	10			WPOS F DISK			0	1	1712 1610
4	W1			EXCALL			0	1	9971 1971
5	12			WPOS F DISK			0	1	1712 1610
6	W2			EXCALL			0	1	9971 1971
7	11			WPOS F DISK			0	1	1712 1610
8	W3			EXCALL			0	1	9971 1971
9	0.0000	0.0000	0.0000	P-END			0	0	9999 1999

**Example 2**

You would like to measure 6 uniform parts as a batch, the parts are arranged symmetrically on the measuring machine:




Control data list for the batch measurement:

Record									
NO	X	Y	Z	Function	SC2	SC1	PCN	CCN	ADR
Dialog				Function	SC2	SC1	PCN	CCN	ADR
NO	Nominal	U.Tol	L.Tol	Function	SC2	SC1	PCN	CCN	ADR
Identification				Function	SC2	SC1	PCN	CCN	ADR
1	Six parts in			TEXT			0	0	1676 0
2	batch			TEXT			0	0	1676 0
3	1	2	1	0 DO LOOP			1	1	9941 1941
4	1	3	1	0 DO LOOP			2	1	9941 1941
5	W2			EXCALL			0	1	9971 1971
6	200.0000	0.0000	0.0000	WPOS DIS CAR			0	1	1771 1610
7				END LOOP	1002		1	1	9949 1949
8	-600.0000	-150.0000	0.0000	WPOS DIS CAR			0	1	1771 1610
9				END LOOP	1001		1	1	9949 1949
10	0.0000	0.0000	0.0000	P-END			0	0	9999 1999

### Batch measurement with <DI 1644>

**Sequence of steps required**

- Define record header with <DI 1612>.
- Call batch measurement with <DI 1644>.
- Select define batch name with <SER CHAN>.
- Further inputs using the Run definition dialog window.
- Start the batch measurement with <CNC RUN>



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
1644	CNC Start CNC Run macro...	

Dialog							
CNC Batch meas.	Run definition	Series name:	XXX				
Run no	<input type="text" value="1"/>	from	<input type="text" value="3"/>	Runs			
WP code	<input type="text" value="42"/>	Workpiece name	<input type="text" value="341122-0001 9611400 short form"/>				
		Comment	<input type="text"/>				
<input type="checkbox"/> C	W-Position	<input type="text" value="1"/>					
	No. of cycles	<input type="text" value="1"/>	from line	<input type="text" value="1"/>	to line	<input type="text"/>	
	Part number	<input type="text"/>					
* YES NO < + > < - >		*	CNC RUN	CATALOG	SER CHAN	TERMIN	
BACK		Delete		INFO			

**Softkeys**

< + >

Store the individual run currently displayed, move to the next/previous run in the batch.

< - >

CNC RUN

Start the batch selected.

CATALOG


Call the workpiece catalog to select a workpiece.

TERMIN

Store the page currently displayed, exit the dialog window.

SER CHAN

Select the **Series selection** dialog window.



LIST

Display of the existing batch names.

### Data boxes

<b>Series name:</b>	The name of the batch is defined in the <b>Series selection</b> window. Select using <b>&lt;SER CHAN&gt;</b> . Acknowledge with <b>&lt;TERMIN&gt;</b> .
<b>Run no. .. from .. Runs</b>	Display of the current run (number) and the total number of runs planned for the current batch.
<b>WP code</b>	Input of the workpiece code. The required workpiece code can also be entered via the <b>&lt;CATALOG&gt;</b> function.
<b>Workpiece name/ Comment</b>	Display boxes for the workpiece currently selected.
<b>W-Position</b>	Input of the W-position stored for the batch run.
<b>No. of cycles</b>	Input for the individual measuring run.
<b>from line / to line</b>	Input for partial run.
<b>Part number</b>	Input of the part number for the record header. Further inputs for the record header will then be prompted if the identification of the record header input column begins with an "*" (asterisk) ▶ <b>„Modification of variable header I &lt;DI 1612&gt;“ on page 5-22.</b>




## Interrupting and continuing a CNC run

The CNC run is interrupted:

- intentionally through intervention by the operator or a stop command ▶ **„*Interruption by the operator*“ on page 18-11**
- unintentionally by a collision or some other malfunction ▶ **„*Interruption due to malfunction*“ on page 18-14**
- if manually guided measurement sections are programmed ▶ **„*User guidance in manual sections*“ on page 18-16**

### Interruption by the operator

Softkey assignment during the CNC run:






Cancels the CNC run at any point (takes a few seconds).



The CNC run is stopped and you have the following options:



Continues the CNC run.



Calls a function during the stop phase or switches to the CNC debugger, ➤ „*Function call during the stop phase*“ on page 18-13.



Cancels the CNC run.

**Programmed stop**

Following a programmed stop via <DI 1096> the CNC run is automatically interrupted. The following then appear:

- The same softkey assignment as for after <STOP>, if you have not selected **with rapidly program call**; operation ➤ „*Function call during the stop phase*“ on page 18-13;
- The dialog window of the requested function, if you selected **with rapidly program call**. Fill in and accept the dialog window; the

CNC run will continue automatically after the function has been executed.

### Function call during the stop phase

**DIR\_INP**


During the stop phase of a CNC run

- any function selection is allowed (with the exceptions mentioned below) and/or
- you can switch to the Debugger mode.

**Prerequisite**

The CNC run has been interrupted manually with <STOP> (▶ „*Interruption by the operator*“ on page 18-11) or contains a stop command which was programmed with <DI 1096>, with rapidly program call = NO (▶ „*Programmable stop <DI 1096>*“ on page 16-21).

The following dialog window appears for command input:



### Softkeys

**CONTINUE**

Continue the CNC run.


 A rectangular button with a black border and the word "DEBUGGER" in black capital letters on a white background.
 

DEBUGGER

Start the CNC debugger (▶ *„CNC debugger <DI 1070>“* on page 18-17).


 A rectangular button with a black border and the word "CANCEL" in black capital letters on a white background.
 

CANCEL

Cancel the CNC run.

### Data boxes

#### Direct input

Any UMESS function is allowed with the following exceptions: **<DI 1610, 1612, 1613, 1629, 1632, 1633, 1634, 1635, 1636, 1639, 1640, 1641, 1642, 1644, 1649>**.

#### Procedure

Select the required function/softkey. After the selected softkey function has been terminated, the stop dialog window is displayed again.

### Interruption due to malfunction

#### Application


Collision, overtravel of the clamping (measuring probe head), insufficient weight balancing (measuring probe head), reaching the limit stop etc. may cause interruption of a CNC run.

#### NOTE

If necessary, the run safety can be improved by programming the Safety mode (▶ *„Continuation after a missing bore <DI 1080>“* on page 16-32).

## Display message

In case of an interruption due to a malfunction, the dialog window will output a corresponding message on the cause of the error and the possible remedy. At the same time, the following softkey assignment will also be displayed:



## Softkeys

**CONTINUE**

To continue the CNC run from the next intermediate position/probing.

**REPEAT**

To continue the CNC run from the last intermediate position/probing.

**CANCEL**

To cancel the CNC run.

## Procedure

Proceed as prompted on the screen and continue/cancel the CNC run with the corresponding softkey.

If necessary, reset UMESS with the **<Break>** key (▶ *„Switching on the measuring machine and computer“ on page 2-4*). Then look for the programming error e.g. with the CNC debugger (▶ *„CNC debugger <DI 1070>“ on page 18-17*).

## User guidance in manual sections

<b>Application</b>	If the CNC program contains computer prompted manual measuring sections (<DI 1077>, >„ <b>Comment line in the control data &lt;DI 1679&gt;</b> “ on page 16-28), The CNC run will stop at the first probing located inside of the manual section. The operator must then perform all subsequent probeings in the manual section.
<b>User prompting</b>	The following instructions are displayed in the list and message window:
<b>8 Point</b>	
<b>MAN CNC STEP</b>	<b>14 PRBD -Z NOM CO: X= -64.0668 Y= 57.6859 Z= 6.8818</b>
	An additional reading is displayed on the Dynalog control panel:
<b>Point number</b>	<b>3 Probe no. 1 DIFF: X= -4.0688 Y= 0.9906 Z= -1.2424</b>
	<b>Explanation</b>
<b>MAN CNC STEP</b>	Control step CNC run.
<b>PRBD</b>	Probing direction; the probing will always be calculated with this direction even if you have used another probing direction contrary to instructions.
<b>NOM CO</b>	Nominal coordinates of the probing in the control coordinate system (as in the control data).
<b>Point number</b>	Consecutive number of the point of an element to be probed.
<b>Probe no.</b>	Display of the probe with which programming was performed; this probe is also displayed on the control panel. The probing will always be calculated based on this probe, even if you select another probe on the control panel and probe with it.
<b>DIFF</b>	Current difference between the nominal and actual coordinates of the probe to facilitate control.

## CNC debugger <DI 1070>

### Application

You can use the CNC debugger to test and improve a CNC program. The debugger edits a CNC program step by step. The control data is displayed in the dialog window.


### Procedure

In the debugger mode you must determine when the CNC program should start and how far it should run. I.e. you cause the program to stop at the next function (editable control data line), at a certain control data line or at so-called break points. There you can check the control data and edit it if necessary. The program will continue on to the next function, control data line, break point or the end of the program only after you have entered the corresponding command. In this way travel paths and probings can be optimized.


### Function call

You can activate the debugger with <DI 1070> before starting a workpiece (program) or afterwards with the <STOP> softkey, cf. function call.

When you call <DI 1070> the CNC run will automatically be activated.



First dialog window as for normal CNC start (> „Starting a CNC run for a single workpiece <DI 1640>“ on page 18-3)



### Softkeys



Is activated during the CNC phase, e.g. **STEP** during probe change.



The program continues running up to the next function (editable control data line).

If you want to execute several functions in succession or execute the run up to a certain function, you must specify this in the data box, see below under "**Data box**".



The program then continues on to the next break point or (if no break point has been set) to the end of the program.

If you want the program to run through several breakpoints or up to a certain break point, you must specify this in the data box, see below under "**Data box**". This also explains how breakpoints are set.



Cancels the CNC run/debugger. Any changes you have made with <**MODIFY**> or <**PROG**> will be lost.



**MODIFY**

Requests control data for editing; the softkey has the same effect as the function call for correcting control data <DI 1642>:

- Make corrections as described in [▶ „Correcting control data <DI 1642>“ on page 17-31](#). Be careful when modifying control data lines which have already been edited.
- After you terminate the corrections with <TERMIN> the CNC debugger will continue at the control data line where you requested the modification.
- At the end of a CNC run edited with <MODIFY> you must decide whether you want to accept the modifications. The dialog window explained in [▶ „Copying control data lines from other workpieces <MIX>“ on page 17-55](#) will appear, see operation there.

**PROG**

Used to edit the current control data line via learn programming. The CNC debugger then continues with the next control data line.

At the end of a CNC run edited with <PROG> you must decide whether you want to accept the modifications you have made. The dialog window described in [▶ „Copying control data lines from other workpieces <MIX>“ on page 17-55](#) will be displayed, see operation there.

**EXIT**

Terminates the debugger. The CNC run will continue and run to the end of the program as always.

**Input box**

You can enter more debugger commands in the input box below the softkeys: (**N** = whole number)

- Instead of pressing the softkey, type in its text and activate the corresponding task with <Enter>. The text from the softkey pressed last will automatically be displayed in the input box.
- **BREAKPOINT,N**: Set the break point to control data line n. As a result, you mark the stop points which can be selected with <CONTINUE> or **N,CONTINUE**, see corresponding explanation. The break points are valid only for the current debugger. You must make a note of where you have set them, since the program does not list this information.
- Extend the softkey commands to include the following options:
  - **N,STEP**: Used to execute the next n functions and then stop (usually the next editable control data lines including the continuation lines).
  - **CONTINUE,N**: Used to run up to the control data line and stop there.

- **N,CONTINUE**: Used to run up to the nth break point. Useful e.g. for testing a loop in which a break point has been set. This loop is then run n-1 times until before the CNC run stops again.
- To list control data, type in one of the following commands:
  - **VIEW**: Control data starting with the current line.
  - **VIEW,BACK**: Control data preceding the current line.
  - **VIEW,N**: Control data starting with line n.
- You do not have to type in the commands in full. An unambiguous character string will do, for example **M** or **MOD** for **MODIFY**.
- You can also enter one or more blanks instead of a comma, e.g. **VIEW BACK** or **B 123**.

#### Notes on input



## Determining the probing direction for single points of a CNC run <DI 1178>

**Application**

In borderline cases (e.g. less than 45°) the probing direction may change sporadically. You can then determine the probing direction for a single point of the CNC run. This is done by determining the probing direction based on the plane code number.

**Duration of function**

The probing direction determination mode remains activated during the CNC run until you deactivate it or reset the CNC program to its initial state. This mode is always deactivated in the manual mode (MAN) and during learn programming (PROG).



<b>DI</b>	<b><u>Pull-Down-Menu</u></b>	<b><u>Pictogram</u></b>
1178		



# Chapter 19

## Scanning

---

### **This chapter contains:**

General . . . . .	19-2
Preparations. . . . .	19-3
Scanning measuring run . . . . .	19-10
Details on the scanning mode . . . . .	19-15
Explanation of the scanning parameters. . . . .	19-25
Explanation of the scanning measuring run . . . . .	19-39
Learn programming . . . . .	19-70

# General

### Scanning method

The scanning method which should be selected depends on the specified measuring task, the existing workpiece geometry data and the measuring machine used. In individual cases you can choose from several different scanning methods.

### **The following criteria must be considered**

#### **Measuring task**

- UMESS (circle, cylinder, line, surface)
- KUM (generate KUM nominals, measure)
- HOLOS (generate, measure HOLOS surface data)

#### **Measuring machine**

- Type of probe system (MT, VAST, ST, LTP, OTM)
- CMM operating mode (manual, CNC)

#### **Geometry data**

- The nominal values of the geometry to be scanned are known (scanning known contours)
- The nominal values of the geometry to be scanned are not known (scanning unknown contours)

# Preparations

## Selecting the scanning method

### Probe systems

Measuring machines can be equipped with different types of probing systems.

The type of probing system determines its use during scanning. The following types are differentiated:

- Measuring probe system with high-speed scanning, can be unclamped for scanning (MT with HSS)
- VAST measuring probe system
- Measuring probe system, not unclampable for scanning (MT without HSS)
- Trigger probe systems such as RST, ST2 (ST)
- Laser probes (LTP, OTM)

First find out which scanning methods your measuring machine can perform:

Scanning method 1st dialog window	MT with HSS, VAST	MT with- out HSS	ST, RST	LTP	OTM
<b>Known contour</b> (The coordinates are entered in the dialog window)	X				
<b>Unknown contour</b> (The start and end point are entered at the measuring machine)	X			X	X
<b>Unknown contour, clamped</b> (Only for ST/RST: The coordinates can be entered in the dialog window or the start and end point at the measuring machine)	X	X	X	X	X
<b>Unknown contour, manual</b> (The section plane and intersection height are entered in the dialog window)					X
<b>Form line</b> (only for CADLINK, manual point transfer)					X

Then select the scanning mode based on the scanning method possible and the measuring task:

Scanning method	Measuring task / Scanning mode			
	CIRCLE	CYLINDER	LINE	SURFACE
Known contour	Circle	Circle or Any inters. plane (surface line)	Any inters. plane	Any inters. plane or Plane on circle path
Unknown contour	Inters. plane in WP	Inters. plane in WP	Any inters. plane or Inters. plane in WP	Any inters. plane or Inters. plane in WP
Unknown contour, clamped	Plane in WP system	Plane in WS-System or Line in WP system (surface line)	Line in WP system	Line in WP system or Circle path
Unknown contour, manual			Any inters. plane and inters. plane in WP system possible	

UMESS scanning functions are also available in KUM and CADLINK:

Scanning method	Measuring task / Scanning mode	
	KUM nominal data	CADLINK
Known contour	Nominals	
Unknown contour	Any inters. plane	Any inters. plane
Unknown contour, clamped	Scanning acc. to nominals or measurement acc. to nominals	
Unknown contour, manual	Any inters. plane	
Form lines		only for DSE with OTM probe



## Preparations for measuring probe heads

### Application


For measuring probe heads, the operating mode, probe calibration and probe bend must be considered depending on the scanning method selected and based on the following table:

Procedure	Scanning method known contour unknown contour	Scanning method unknown contour, clamped
Set operating mode of probe head	<DI 1502> Vectorial probing ON ► „Setting the operating mode for the measuring probe head <DI 1502>“ on page 6-18	<DI 1502> Vectorial probing is OFF ► „Setting the operating mode for the measuring probe head <DI 1502>“ on page 6-18
Determine probes	<DI 6528> ► „Semiautomatic probe calibration with <DI 15228> (tensor calibration)“ on page 7-19	<DI 6501 / 6502> ► „Semiautomatic probe calibration with <DI 6501>“ on page 7-17 / ► „Manual probe calibration <DI 6502>“ on page 7-29
Determine probe bend	Contained in <DI 6528> for extreme speeds <DI 1184> ► „Determining bend parameters for unclamped scanning <DI 1184>“ on page 7-46	<DI 6520> ► „Determining bend parameters for the "clamped" probe head mode <DI 6520>“ on page 7-36
probe bend taken into account in UMESS	Automatically taken into account when calibrating with <DI 6528> Call <DI 1186> ► „Measuring with compensation of the probe bend <DI 1186>“ on page 7-47 required when scanning with <DI 1184>	<DI 1186> ► „Probe bend compensation“ on page 7-34
Adapt probing behavior with probe radius < 1 mm	<DI 1574> ► „Adapting the probing behavior <DI 1574>“ on page 6-20	---


## Defining the scanning mode <DI 1530>

**Application**

Using the scanning mode you can define and store the parameters required for scanning.



You must define the scanning mode in several different dialog windows depending on the measuring task planned.



**NOTE**

Depending on the probe system connected, the **Scanning method** menu is supplemented with special menu options.

**Softkeys****MODE X**

Selects long-term mode 1,2 or 3 for setting or editing. Your selection can then be stored under any number as a long-term or short-term mode.

**TERMIN**

Fetch the short-term mode currently valid for editing. It can then be stored under any number either as a short-term mode or as a long-term mode.

**BACK**

Return to the calling menu. The mode currently valid becomes/remains the short-term mode.

**MOD TOT**

Lists the long-term modes currently stored.

**Data boxes**

known contour

&lt;YES&gt;

Control travels according to nominal data, explanations ► **„Scanning in the known contour mode“ on page 19-16**

unknown contour

&lt;YES&gt;

The control probes along the contour. See additional dialog window, explanations ► **„Scanning in the unknown contour mode“ on page 19-19**

unknown contour,  
clamped

&lt;YES&gt;

Scanning with the measuring probe head, the trigger probe head and optical probe heads (OTM), explanations ► **„Scanning in the known contour clamped mode“ on page 19-21**

**NOTE**

- Three different scanning modes can be set and retained for call at any time (long-term modes). A fourth mode can be set temporarily (short-term mode).
- The last mode used is always the one which is currently valid .

## Transferring the scanning mode

### Application

If you close the dialog window with **<TERMIN>**, a softkey assignment will appear via which you must specify how you want to store the set mode.

Dialog			
Scanning method			
<input checked="" type="checkbox"/>	known	Contour	<input checked="" type="checkbox"/>
	unknown	contour	<input type="checkbox"/>
	unknown	contour, clamped	<input type="checkbox"/>
* YES		NO	
		*	
		STORE 1	STORE 2
		STORE 3	TERMIN
BACK	PRE MENU		
			INFO

### Softkeys

**STORE x**

Stores the mode currently valid as long-term mode 1,2 or 3 (and at the same time as the new short-term mode).

**TERMIN**

Stores the mode currently valid as short-term mode and returns to the calling menu.

## Listing the scanning modes <MOD TOT>

**MOD TOT**

The <MOD TOT> softkey lists the long-term modes set on the screen. Other infos can also be called up or printed.

		Mode 1	Mode 2	Mode 3
<input type="checkbox"/> Scanning mode: General outlay				
Operat. mode		2	2	1
Path mode		33	2	3
Point density mode		1	1	1
Curvature tolerance	+/-			
Reclamping mode		0	0	0
Reclamping dist.		3.0000	3.0000	3.0000
Overlapping distance		0.0000	0.0000	0.0000
Target code		0	0	2
Targ.window	Travel. dir.	0.0000	0.0000	2.0000
	Prb. direction +/-	1.0000	1.0000	3.0000
Scanning speed		0.0000	0.0000	0.0000
		PRINTER	*	TERMIN
BACK	PRE MENU			INFO

### Softkeys

**PRINTER**

Printout of the entire overview.

**TERMIN**


Return to the **Scanning method** dialog window.

# Scanning measuring run

## Branching of dialog windows

**Overview**

The following overview shows how the dialogs/dialog windows branch following the start of the scanning run:




## Scanning with UMESS

### Preparations

- If necessary, set the scanning mode (the mode used last is always the one currently valid and therefore the short-term mode).
- Define the workpiece coordinate system if this has not already been done.
- For scanning a known contour: If you have not already done so, you can activate the filter with **<DI 1185>** and the outlier elimination with **<DI 1181>**.
- For scanning in the workpiece plane: If you have not already done so, align the workpiece coordinate system parallel to the planned scanning plane.

### NOTE

The scanning run automatically terminates when 32,000 per element have been scanned.



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
	Within a geometric element Measure/Eval...	
	Scanning run	

Dialog									
SCANNING RUN									
<input type="checkbox"/> Y	Select function please								<input type="checkbox"/>
				*	RUN 1	RUN 2	RUN 3	CONT	
BACK	PRE MENU							INFO	

**Softkeys****RUN X**

Scanning with the parameters from long-term mode x (stored in the Scanning mode with **<STORE x >**, x = 1,2,3).

During learn programming, the control data accepts the long-term mode after error free scanning. I.e. this mode no longer needs to be stored at the CNC start.

**CONT**

Scanning with the mode currently valid.

The control data does not accept this mode during learn programming. I.e. this mode must be programmed with **<SCAN MOD>** or available at the CNC start as the mode currently valid.

If **<RUN x>** or **<CONT>** is called, more dialog windows for entering the parameters required will follow.

**NOTE**


- Special features of learn programming/CNC run: ► „*Learn programming*“ on page 19-70
- If desired: Subsequent graphic evaluation (see Option 2 operating instructions).
- A surface usually must be scanned in multiple paths. This also applies to elements such as cylinders or cones, which must be scanned in multiple sections and/or surface lines.

**<SCAN RUN>** must be called for each line/surface line and for each workpiece plane to be scanned .




**Examples:**

Lines scanned for calculating a surface



↑ Each arrow marks the start of a scanning routine.



Circles scanned in several intersection planes for calculating a cylinder.

**Scanning with KUM**

**Application**

In KUM you can measure existing nominal values or generate new ones via scanning with the help of a master part:

**Measuring with existing nominals**

Step	Program call
Call measuring run	<b>KUM</b> <b>&lt;MEASURE&gt;</b>
Define the scanning mode	<b>&lt;SCAN MOD&gt;</b> <b>Scanning known contour</b> <b>Nominals</b>
Start the scanning run	<b>&lt;SCAN RUN&gt;</b>
End program	<b>&lt;TERMIN&gt;</b>

**To generate nominals**

Step	Program call
Call measuring run	<b>KUM &lt;MEASURE&gt;</b>
Define scanning mode	<b>&lt;SCAN MOD&gt; Scanning unknown contour Intersection plane in WP</b>
Start the scanning run	<b>&lt;SCAN RUN&gt;</b>
End the program	<b>&lt;TERMIN&gt;</b>

**Scanning with HOLOS**

**Restriction**

In HOLOS, scanning functions can be activated only for measuring machines equipped with both a measuring probe head and a laser probe head:

**Scanning with HOLOS (digitization)**

Step	Program call
Define scanning area by lofting a surface	<b>Digitize Scan area</b>

**Scanning with HOLOS (measurement)**

Step	Program call
Define scanning area by clicking on a line	<b>Measure Define measuring run Scan line</b>
Start scanning run	<b>Start run</b>


Step	Program call
Define scanning area by clicking on four corner points	<b>Measure Define measuring run Scan area</b>
Start scanning run	<b>Start run</b>

# Details on the scanning mode

## Branching of dialog windows


### Overview

The following overview shows how dialogs / dialog windows branch when defining the scanning mode:



## Scanning in the known contour mode

### Function call



Dialog

Scanning known contour

<input type="checkbox"/> any intersection plane	<input type="checkbox"/>	
<input checked="" type="checkbox"/> Circle	<input checked="" type="checkbox"/>	
<input type="checkbox"/> Plane on circular path	<input type="checkbox"/>	
<input type="checkbox"/> Nominals	<input type="checkbox"/>	<input type="checkbox"/>
		Nominals with dynamic follow-up
		Nominals data with large deviation
<input type="checkbox"/> Pitch measurement	<input type="checkbox"/>	

* YES	NO		
-------	----	--	--

\*

			TERMIN
--	--	--	--------

BACK	PRE MENU		
------	----------	--	--

			INFO
--	--	--	------

### Data boxes

any intersection plane

<YES>

Scanning of a line in any intersection plane. The intersection plane is defined by the start point and target point of the line as well as by the probing direction.

Circle


<YES>

Scanning of a circle in the workpiece coordinate system.

**Plane on circular path**

**<YES>**

Circular scanning of a plane in the workpiece coordinate system.



**Nominals (nominal data)**

**<YES>**

Scanning based on KUM nominals in the workpiece coordinate system.

**Nominals with dynamic follow-up**

Measurement according to nominals; for larger deviations, insertion depth > 0.1 mm

**<YES>,**

the dialog window follows

Dialog											
Scanning mode - nominals											
<input type="checkbox"/> Y	Point density		<input type="checkbox"/> *	Curvature tolerance +/-		<input type="checkbox"/>	Step size.....		<input type="checkbox"/>		
	Nominals		<input type="checkbox"/>			<input type="checkbox"/>			<input type="checkbox"/>		
	curvature dependent		<input type="checkbox"/>			<input type="checkbox"/>			<input type="checkbox"/>		
	constant		<input type="checkbox"/>			<input type="checkbox"/>			<input type="checkbox"/>		
* YES				NO				*      TERMIN			
BACK				PRE MENU				INFO			


### Nominal data with large deviation

Measurement according to "unknown" contour, point acquisition between support points, input of start point and target point. The program calculates a "middle surface" between these points.

Please note: The nominals must lie in the same plane.

**<YES>**

The dialog window is displayed as shown above



### Pitch measurement


A pitch measurement can only be executed with a rotary table.

**<YES>**

A special menu will follow if a rotary table is installed.

## Scanning in the unknown contour mode

### Function call



Dialog

Scanning unknown contour

any intersection plane

Intersection plane in WP

\* YES

NO

\*

TERMIN

BACK

PRE MENU

INFO

### Data boxes

any intersection plane

<YES>

Scanning of a line in any intersection plane. The intersection plane is defined by the start point and target point of the line as well as the probing direction.

Intersection plane in WP

<YES>

Scanning in a plane of the workpiece coordinate system.

Dialog

Scanning mode- unknown contour

Point density  
 Y  
 constant  \*  
 curvature dependent

Curvature tolerance +/-

Target code  
 Plane   
 or sphere  \*  
 or cylinder

Diameter   
 Diameter

Axis (X, Y, Z)

Point reduction at start and target point  \*

\* YES NO   \*    TERMIN

BACK PRE MENU     INFO

Point density constant

Default setting

curvature dependent

Function not yet supported.

Curvature tolerance +/-


**NOTE**

At speeds of < 1 mm/s, the measuring machine may first move in the direction opposite to the one required (approx. 0.1 mm at 0.1 mm/s). This is unavoidable due to the system.



## Scanning in the known contour clamped mode

### Function call



### 1st dialog window

Dialog									
SCANNING									
<input type="checkbox"/> I	Operat.mode	<input type="checkbox"/> 1	1 = computer-guided						
			2 = Cabinet control						
			3 = Joystick free						
			4 = Joystick WP Plane						
	Path mode	<input type="checkbox"/> 2	2 = Line in WP system						
			3 = Plane in WP system						
			4 = self centering						
			9 = Cylinder surface						
			12 = Circ.path						
			21 = measurement according to nominals						
			22 = Scanning according to nominals						
			98 = controlled laser scanning						
			99 = rapid laser scanning						
* YES NO				*	TERMIN				
BACK PRE MENU									

### Softkey



Call of dialog window 2.

**Data boxes**

**Operat.mode**

➤ „Mode of operation“ on page 19-25

**Path mode**

➤ „Path modes“ on page 19-25

**Procedure**

If you do not want to change anything, jump to page 2 with **<TERMIN>**. Otherwise enter codes and accept with **<Enter>**. Use the **v** and **^** keys to move between boxes. Terminate with **<TERMIN>**.

**2nd dialog window**

for measuring probe head (not applicable if **Path mode = measurement according to nominals**)

Dialog			
Scanning Mode (Page 2)			
<input type="checkbox"/> D	Scanning speed	<input type="text" value="3.0000"/>	max <input type="text" value="150.0000"/>
	Point density constant <input type="checkbox"/> *	at nom point <input type="checkbox"/>	curvature dependent <input type="checkbox"/>
		Curvature tolerance +/-	<input type="text" value="0.1000"/>
	Reclamping default <input type="checkbox"/> *	automatic <input type="checkbox"/>	suppress <input type="checkbox"/>
	Reclamping dist. <input type="text" value="3.0000"/>	Overlapping distance	<input type="text" value="0.0000"/>
	Target code default <input type="checkbox"/> *	Plane <input type="checkbox"/>	Window <input type="checkbox"/>
	Targ.window Travel. dir. <input type="text" value="0.6000"/>	Prbg direction	<input type="text" value="4.3495"/>
<input type="checkbox"/> * YES	<input type="checkbox"/> NO	<input type="checkbox"/> *	<input type="text" value="FILENAME"/> <input type="text" value="TERMIN"/>
<input type="checkbox"/> BACK	<input type="checkbox"/> PRE MENU	<input type="checkbox"/>	<input type="text" value="INFO"/>

2nd dialog window

for trigger probe head (also for measuring probe head if **Path mode = measurement according to nominals**)

Dialog			
Scanning Mode ( 2nd page )			
D	Dist. btw. interm. positions:		
	before probing:	manual	2.0000
	after probing :	automatic	2.0000
		manual	0.0000
Type of intermediate pos.:		Coarse pos. <input checked="" type="checkbox"/>	Fine pos. <input type="checkbox"/>
Pt. density:		constant <input checked="" type="checkbox"/>	at nom point <input type="checkbox"/> curvature dependent <input type="checkbox"/>
		Curvature tolerance +/-	0.1000
Target code:		Window <input checked="" type="checkbox"/>	Plane <input type="checkbox"/>
Window :		Travel. dir. 0.2000	Prbg direction 3.0000
* YES NO		* REPEAT TERMIN	
BACK PRE MENU		INFO	

**Softkeys**

**REPEAT**

Resets all window contents to the status they had prior to the call of the dialog window (cancels entries made since call).

**TERMIN**

The status set becomes the current mode, change-over to **SCANNING MODE** menu (> „Listing the scanning modes <MOD TOT>“ on page 19-9). From there final storage with <STORE x> or <TERMIN>.

**Data boxes**

Scanning speed

> „Scanning speed“ on page 19-28

Dist. btw. interm. positions

> „Intermediate position during scanning“ on page 19-28

Point density

> „Point density“ on page 19-30

Reclamping

> „Reclamping“ on page 19-33

Target code

> „Target code/target window“ on page 19-35

Targ.window

> „Target code/target window“ on page 19-35

### Procedure

The program highlights the box where an input is required.

- Boxes where values must be entered: Accept current data or type in new data, terminate with **<Enter>**.
- **<YES/NO>**-boxes: accept or reject with **<\* YES>/<NO>**.
- Select individual boxes or browse step by step with the **v** and **^** cursor keys.
- Close dialog window with **<TERMIN>**, continue **▶ „Listing the scanning modes <MOD TOT>“ on page 19-9**

# Explanation of the scanning parameters

**Definition** The parameters explained in this chapter refer to **Scanning unknown contour, clamped**.

## Mode of operation

**Definition** The mode of operation or operating mode indicates who or what controls the coordinate measuring machine during scanning.

### Possible operating modes

**computer-guided** Controlled by the computer.

**Cabinet control** Controlled by the CMM control, at present only for the path mode **Plane in WP system**.

**Joystick free** Only with measuring probe head; The operator controls the probe manually with the joysticks. The measured element can be scanned independently of a workpiece plane, i.e. free in space.

**Joystick WP Plane** Only with measuring probe head; the operator controls the probe manually with the joysticks. Scanning takes place here in a predefined section plane which lies parallel to the workpiece plane. The measuring machine is controlled so that the measured points lie in the section plane. You control the scanning speed by altering the deflection of the joysticks.


## Path modes

### Definition

**Measuring probe head** The measuring probe head travels along the scanning path with the probe in contact. Its control behavior corresponds to the selected path (path mode).

**Trigger probe head** The trigger probe head must back away prior to each data transfer (probing). The scanning path is thus comprised of a series of probings with two intermediate positions set in-between in each case. These positions are generated by the program according to the required path mode.

**Path mode 2**



**Possible path modes:**

**Line in WP system**


All lines located within the workpiece coordinate system can be scanned, regardless of the direction.

Application: Fast scanning of lines

Control response of the measuring probe head:

- The first axis is probed.
- The second axis is traversed at constant speed.
- The third axis controls the path accuracy
- Reclamping: **default** = no reclamping.

**Path mode 3**



**Plane in WP system**


During scanning in workpiece planes, a geometric element is measured whose axis is almost vertical to a plane of the workpiece coordinate system (e.g. circle).

Application: Scanning of geometric elements in a defined intersection plane.

Control response of the measuring probe head:

- The first axis is probed.
- The second axis controls the speed.
- The third axis controls the position of the probe in reference to the section plane
- Reclamping: **default** = automatic reclamping.

**Path mode 4**



**self centering**

Scanning with self-centering probing, only with measuring probe head.

Application: Scanning of grooves, edges etc.

Control response of measuring probe head:

- First axis and second axis are probed.
- Third axis travels at a constant speed
- Reclamping: ➤ „Self-centering path mode“ on page 19-56

**Path mode 9**


**Cylinder surface**

Application: Primarily gear measurement, only for experienced users.

Control response of measuring probe head:

- The first axis is probed
- The second axis is traversed at a constant speed in the axial direction
- The third axis controls the distance of the probe relative to the workpiece plane.
- Reclamping: No reclamping

### Path mode 12



### Circ. path


Scanning on circular path (surfaces!).

Application: Scanning of flange surfaces, plane surfaces etc.

Control response of measuring probe head

- The first axis is probed.
- The second axis is traversed at constant speed.
- The third axis controls the path accuracy.
- Reclamping: No reclamping.

### Path mode 21 / 22



### Scanning according to nominals/ measurement according to nominals

Scanning according to KUM nominals (target values) with known normal direction. The measuring probe head travels with the probe in contact from nominal (target) point to nominal point. The trigger probe head backs away between the nominals.

Application: Scanning any curves with known normal direction in KUM; not for UMESS.

Control response of the measuring probe head:

- As for scanning in workpiece plane.
- Reclamping: By **default**: Reclamping takes place at the nominal point if the nominal direction does not match the probing direction; no reclamping between nominal points. With **automatic** the measuring probe head reclamps as usual.

Measurement according to KUM nominals with known normal direction. The measuring probe head also probes between the nominals.

For the trigger probe head this method is identical to **Scanning according to nominals**.

Application: If problems arise with the measuring probe head when **Scanning according to nominals**, e.g. due to a collision during travel with the probe in contact; not for UMESS.

**Path mode 98**

**controlled laser scanning**

**Path mode 99**

**rapid laser scanning**

Concerns LTP laser triangular probe, cf. applicable DSE operating instructions.

### Scanning speed

**Application**

This input is possible only with the measuring probe head in the **computer-guided** mode.

Minimum speed: 0.01mm/s.

Maximum speed: See screen display. You can not change this value.

The **Permissible speed** input box accepts any value within these limits.

#### NOTE

- The speed should be selected depending on the surface and curvature of the workpiece. Too high a speed can overload the control of the measuring probe head and thus cause poor travel response.
- If a lower speed value is displayed after the dialog window is called again, the value originally entered did not match the **Step width**. The program performs this correction automatically.

### Intermediate position during scanning

**Application**

These parameters concern the trigger probe head in general and the measuring probe head only with **Path mode = measurement according to nominals**. If control data for the trigger probe head is used on CMMs with a measuring probe head, please refer to the information on the control data line **SCA BADIST** in **„Learn programming“ on page 19-70**.

**Dist. btw. interm. positions before probing**

Input of a distance > 0. The program calculates the intermediate position from the input value, the generated probing point and the probing vector.







## Important:

When scanning with a large step width, you should choose a distance from the intermediate position of equal size to prevent collisions, cf. sketch sketch.

A small distance between intermediate positions and large step widths will lead to a collision if the surface curvature suddenly changes:



Avoid collisions by selecting a larger distance between the intermediate positions:



## Dist. btw. interm. positions before probing

### automatic

- Trigger probe head: Automatically travels to an intermediate position whose distance is displayed on the screen after each probing. If this backaway or retract distance is not sufficient (e.g. when probing soft parts), switch over to **manual** and enter the required value. It is not possible to omit the backaway distance when measuring with a trigger probe head.
- Measuring probe head: After probing travels directly to the next **interm. position before probing**. If an intermediate position is required after probing, switch over to **manual**.

### manual

Selection of a backaway path to meet your requirements. Enter a value  $> 0$  when using a trigger probe head and  $\geq 0$  (= 0 corresponding to **automatic**) for a measuring probe head.

## Coarse pos.

Fast positioning without special demands for positioning accuracy (measuring time optimization).

**Fine pos.** Exact travel to positions with a higher time requirement. Application for problematical workpieces/areas.

## Point density

**Measuring probe head**

The measuring machine with measuring probe head continually accepts points and the corresponding X, Y, Z coordinates.

**Trigger probe head**

A measuring machine with a trigger probe head generates the scanning path from probings and intermediate positions. The input value **Step width** determines the distance between the probings (which must be input at the start of the scanning run). If the trigger probe head can not find the generated probing, it will search for the 50% reduced **Step width** beginning with the last intermediate position. If this function fails, it will be repeated max. 9 times and the step width will be reduced another 50% each time.


If a collision occurs before the generated probing, the repetition with a 50% reduced **Step width** described above will be performed only once. If the probe then continues to collide, the probing direction and travel direction will be exchanged.

For both types of probe head: The parameter **Point density** decides when a probed point will be stored as a measured value.

### The following options are available:

**constant**

The distance between two stored points is always the same:



- Continuously probed points with measuring probe head (CMM cycle); trigger probe head does not probe here.
- ⊙ Measuring probe head: points stored as measured values at a constant distance  $a = \text{Step width}$ .  
Trigger probe head: generated and stored probings at a constant distance  $a = \text{Step width}$ .

### NOTE

Enter **Step width** at the start of the scanning run.

**Curvature dependent**

The distance between two stored measured points varies depending on the path curvature. At least 3 points must be stored:


- 1st point: start point;
- 2nd point very near the start point (selected according to program-internal criteria to determine the start position of the tolerance cylinder described below);
- Last point: target point.

**Curvature tolerance +/-**

A tolerance cylinder decides whether more points will be stored between the 2nd point and the target point. You define its radius with **Curvature tolerance**. The program always places its axis through the two points stored last (n and n+1). The next point stored must fulfill one of the following conditions:

**1st possibility**


The point must lie outside the tolerance cylinder:



- Continuously probed points; measuring probe head: CMM cycle; trigger probe head: probings generated in distance **Step width**.


⊙ Points stored as a measured value n.

In this case point n+2 is stored. At the same time the tolerance cylinder turns so that the cylinder axis again runs through the last two points stored:



**2nd possibility**

The angle difference between two points within the tolerance cylinder must be:  $> 12^\circ$  (angle criteria)



- Continually probed points; measuring probe head: CMM cycle; trigger probe head: probings generated in distance **Step width**.

⊙ Points stores as measured value n.

In this case point  $n + 3$  is stored. The tolerance cylinder then turns here as well.

The angle criterion ensures that sharp turns in the measured curve (kinks) are measured with a sufficient number of points.

**NOTE**

The **Step width** must be input at the start of the scanning run.


Define the radius of the tolerance cylinder under **Curvature tolerance**. This value influences the number of points measured per path segment and therefore the accuracy of the measurement.

**Please note**

- Points can also be probed with **Step width** within the tolerance cylinder. In this case, select both **constant** and **Curvature dependent** at the same time.
- Even with very large values for **Curvature tolerance**, the measured result can not be "coarsened" in any way. Due to the angle criterion, the same points are always stored even with large tolerances.

## at nom point

This point transfer mode concerns **Path mode = Scanning according to nominals** or **measurement according to nominals** in KUM. The measured point is stored at the nominal point. Nominal point input: See KUM operating instructions. As in KUM the probe center points are stored.



× Nominal points

- Continually recorded points;  
Measuring probe head with **Path mode = Scanning according to nominals**: CMM cycle, travelling with probe in contact.  
Trigger probe head and measuring probe head with **Path mode = measurement according to nominals** do not probe here.
- ⊙ Measuring probe head with **Path mode = Scanning according to nominals**: points stored as measured value.  
Trigger probe head and measuring probe head with **Path mode = measurement according to nominals** probe here and store the measuring value.


## Reclamping

### Restriction

Relevant only for the measuring probe head in the **clamped mode**; if you are using control data from the measuring probe head on machines equipped with a trigger probe head, please follow the instructions in ► **„Learn programming“ on page 19-70.**

## Application

When scanning curved contours, the measuring probe head must back away and reclamp once the angle between the probing direction and the workpiece surface has reached a limit value. This limit value equals **roughly** 45°, can, however, also be greater or smaller, depending on the prevailing conditions.



## The following parameters influence the re-clamping procedure:

### Re-clamping = default

Re-clamping takes place if the **Path mode =**

- **Plane in WP system,**
- **Scanning according to nominals** (at the nominal point, ➤ „*Path modes*“ on page 19-25),
- **Cylinder surface**

and is omitted in all other cases.

### Re-clamping = automatic

Regardless of the path mode set, re-clamping occurs automatically if the limit value between the probing direction and the workpiece surface is reached.

### Re-clamping = suppress

Re-clamping is always omitted in this setting.

## Values to be set

### Re-clamping dist.


Distance between the workpiece and the position of the probe during the re-clamping procedure. The space available in or on the workpiece can thus be taken into account.

### Overlapping distance

Defines the path to be scanned again after the re-clamping procedure (without point acceptance). Advantage: Improved travel response.


## Target code/target window

- Application** These parameters specify how the program will be able to recognize the target point.
- default** For **Scanning according to nominals** the parameter **Plane** automatically applies. Otherwise the **Window** with default values applies. See this location for explanation.
- Plane** **Plane** is recommended for scanning paths which are not curved (this saves measuring time, since the speed reduction is thus omitted).  
 The program calculates an end plane which runs through the target point. The scanning run stops if the probe penetrates the end plane **in its normal direction**, see also sketch with **Window**.  
 Calculation according to the "three-finger rule": Normal vector of end plane = cross product of the probing vector in the target point and the normal vector of the scanning intersection plane, multiplied by +1 or -1, depending on the measuring direction (rotational sense) (which must be entered at the start of a scanning run, ► „**Explanation of the scanning measuring run**“ on page 19-39)



**Window**

When the probe moves into the target window the speed decreases (speed reduction). The end plane is calculated in the target window (as for **Plane**). The run is stopped when this plane has been penetrated:



If **Window = \*** its size can be defined in the **Trav dir** and **Prb. direction** input boxes. These boxes are preassigned with default values. The **Trav dir** box remains blank in the manual mode.


**Plane, Sphere, Cylinder**

Space surrounding the target point. Special cases which should be selected depending on the application.



## Diameter

The diameter of the target sphere or target cylinder must be greater than the overlapping path, but smaller than the diameter of the contour to be scanned. The probe must exit the diameter once during scanning.



## Axis

(Workpiece) axis of target cylinder (in X, Y or Z).

## Overlapping mode <DI 1176>

## Application


It is normally advisable to scan a travel angle of 450° for a closed contour (e.g. a full circle) to eliminate the starting and braking reaction by overlapping the full circle 90 degrees. However, this may be undesirable for several special applications (e.g. measuring a spiral).



# Explanation of the scanning measuring run

## Scanning a known contour

Function call



Dialog window

for calling from the <LINE> element after the start and target point inquiries.

Dialog									
Scanning run - Line, known contour									
[D]	Speed	40.0000	Step width	1.5000	minimum	0.4000			
* YES				NO		*		TERMIN	
BACK		PRE MENU						INFO	

Dialog window for calling from the <CIRCLE> element

Dialog												
Scanning run - Circle, known contour												
<input type="checkbox"/> C	Scanning plane	<input type="checkbox"/> XY										
Cent. point	X	<input type="text" value="-20.0000"/>	Y	<input type="text" value="12.0000"/>	Z	<input type="text" value="-3.0000"/>						
Diameter	<input type="text" value="12.0000"/>											
Start angle	<input type="text" value="0.0000"/>											
Travel angle	<input type="text" value="450.0000"/> (<0: Left curve)											
Speed	<input type="text" value="1.0000"/>	Step width	<input type="text" value="0.0100"/>	minimum	<input type="text" value="0.0100"/>							
Scanning with rotary table <input type="checkbox"/>												
* YES			NO			PROBE		*		RT 05	XYZ	TERMIN
BACK		PRE MENU								INFO		

**NOTE**

- Following a call within <CYLINDER>, <SPHERE> or <TORUS> a message will appear beforehand prompting you to probe 3 points vertical to the axis (➤ „Scanning cylinder, cone, torus“ on page 19-59).
- The interrelationship between the scanning speed, the radius of the scanned contour and the accuracy is described in the chapter ➤ „Semiautomatic probe calibration with <DI 15228> (tensor calibration)“ on page 7-19.

## Softkeys

**PROBE**

After activation, the start point, the target point and - with a large interval - the direction point (for the travel direction) must be probed. Based on this information, the computer then determines the preassignment of the dialog window, which can then be adapted manually.

**RT 05**

Switch to scanning with the rotary table.

**XYZ**

Switch to scanning with machine axes.


**TERMIN**

When the dialog window is terminated, the prompt **Travel to start point!** will be displayed. You can then start the measurement by pressing **<TERMIN>** again.

## Data boxes


<b>Speed</b>	With unknown contour, max. 8 mm/s, with known contour max 40 mm/s.
<b>Step width</b>	First value = preset nominal value, second value = smallest possible step width (depending on the speed).
<b>Scanning plane</b>	Input of measuring plane.
<b>Cent. point</b>	Circle center point for a known contour. Data in workpiece coordinates.
<b>Diameter</b>	Nominal diameter, diameter of circular path.
<b>Start angle</b>	Explanation ► „ <b>Circular path mode</b> “ on page 19-52
<b>Travel angle</b>	Input of the scanning range in degrees. The measuring direction depends on the +/- sign of the travel angle. A default value of 450° is recommended for full circles. This overlapping of 90° is used to eliminate the starting and braking reaction.
<b>Rot. sense</b>	When scanning unknown contours, the rotational sense results when viewing the measuring plane from the positive direction of the 3rd axis. See the explanation on the next page.
<b>Scanning with rotary table</b>	The measuring machine probes the workpiece in the start position. The the rotary table travels the set step size.

Explanation of "rot.sense" (direction of travel)



Scanning unknown contours

Funktionsaufruf



<u>DI</u>	<u>Pull-Down-Menu</u>	<u>Pictogram</u>
Within a geometric element Measure/Eval... Scanning run		

**Dialog window** for a defined mode **any intersection plane** after the inquiry for start and target point.

Dialog									
Scanning run - any line in the workpiece system, unknown contour									
D	Speed	40.0000	Step width	1.5000	minimum	0.4000			
* YES				NO		*		TERMIN	
BACK				PRE MENU				INFO	

### Data boxes

**Speed** With unknown contour max. 8 mm/s.

**Step width / minimum** First value = preset nominal value,  
second value = smallest possible step width (depending on the speed).

## Dialog window

for a defined mode **Intersection plane in WP** after the inquiry for start and target point.

Scanning run - unknown contour, in workpiece planes

Speed  Step width  minimum

WP Plane  Sect. height  Rot. sense

\* YES NO \* TERMIN

BACK PRE MENU INFO

## Data boxes

### WP Plane

Specification of the workpiece plane in which scanning is to be executed.

### Sect. height

Height of the scanning path above the zero point of the workpiece coordinate system.

### Rot. sense

When scanning unknown contours, the rotational sense or direction of travel results vwhen viewing the measuring plane from the positive direction of the 3rd axis. Explanation ► **„Scanning unknown contours“ on page 19-42.**

## Scanning unknown contours, clamped

### Path mode in WP system or workpiece plane

#### Definition

The dialog described here applies to the following parameter settings:


- Operating mode: **computer-guided**;
- Path mode: **Line in WP system** or **Plane in WP system**.



**NOTE**

If **Path mode = Line in WP system** the following prompt may appear at the end of the dialog: **Please enter start point with new probing direction !**


Prerequisite for this prompt: Scanning over edges under unfavorable conditions (the start and target points are probed in the main direction of travel). Probe start point with another probing direction (if possible), otherwise divide the scanning path:



Function call

► *„Branching of dialog windows“ on page 19-10*

Please probe start point/ target point or select function



## Softkeys

**PROBE**

Accepts the current position, if still being probed (only with measuring probe head).

**STEP**

Travel of the probe from the current position with or without search run (▶ **„Travel from the current position in fixed steps <DI 1515>“ on page 10-41**). If no probing takes place, the request for probing or function selection will be repeated.

**POSITION**

Fine positioning with or without search run (▶ **„Positioning to workpiece coordinates <DI 1511>“ on page 10-37**). If no probing takes place, the request for probing or function selection will be repeated.

**DIALOG**

Used to enter start/target point as coordinates instead of probing (▶ **„Entering a start/target point via dialog“ on page 19-59**).

**ORDER**

Reverses the sequence of the start and target point input or continues the following run at the target point of the previous run. Remains activated only until the first point has been determined.

**Possibilities:**

- Press the key once: The order of the points will be reversed and the following message will be displayed:

**Please probe target point or select function.**

- Press the key twice: The target point of the previous scanning run will be assigned as the starting point for the next one; the display will read:

**Start point = last target point -> Please probe target point.**

- If you press the key three times, the following message will appear again:

**Please probe start point or select function.**

The key will be disabled as soon as the first point has been defined.

**Prbg. direction**

An inquiry will appear only if you selected the **Cartesian coord** option after **<DIALOG>** (► *„Entering a start/target point via dialog“ on page 19-59*). Select the probing direction via softkey or by typing it in.

**Scanning Run parameters**

Dialog									
Scanning Run parameters									
[D]	Step width	:	[ 1.0000 ]	Plane:	[ XY ]	Inter height:	[ 0.0000 ]	Run:	[ + ]
[ ] [ ] [ ] [ STEP WID ]				*	[ PLANE ] [ SECT HEI ] [ TRAV DIR ] [ TERMIN ]				
[ BACK ] [ PRE MENU ] [ ] [ ]					[ ] [ ] [ ] [ INFO ]				

If **Path mode = Line in WP system**, only **Step width** is of interest. The softkey assignment is therefore reduced correspondingly.

The displayed values are currently valid. If they must be changed, press the corresponding softkey and enter the data.

## Data boxes

### Step width

Measuring probe head: Distance between two points accepted as measured values (▶ „**Point density**“ on page 19-30). This input is not evaluated for **Curvature dependent**.

Trigger probe head: Distance between two generated probings (▶ „**Point density**“ on page 19-30).

### Plane

Workpiece plane where scanning takes place.

Important: Enter plane correctly; otherwise the scanning run will fail.

### Inter height

Height of the scanning path above the zero point of the workpiece coordinate system. Pressing the **<SECT HEI>** softkey enters the distance between the zero plane and the target point. Editing is possible. When changing the section height, please note that the starting and target point will be projected into the plane.


Using this softkey, it is much easier to enter data when scanning multiple parallel sections.

### Run

Define the travel direction (rotational sense) of the probe. Definition for positive rotational sense:

When you are looking in the probing direction with your eyes parallel to the normal plane, the probe will start in a clockwise direction (mathematically: starting direction = cross product from probing vector and normal vector).

### Example



The travel direction is therefore different for the outer and inner contour.

**Input options:**

<b>Blank</b>	Determines measuring direction by probing.
<b>+</b>	Positive measuring direction as defined above.
<b>-</b>	negative measuring direction, probe starts to the left

**NOTE**

It is usually a good idea to enter a blank and then probe to save theoretical considerations. The program will then calculate the applicable plus/minus sign based on this input. If parallel sections then follow, the dialog will offer this +/- sign again as the default value. In this case, accept the default value offered.

**Scanning in workpiece coordinates**  
**Please probe direction point or select function**

Prompt for a direction point appears if **Path mode = Plane in WP system** and a blank has been entered for **Run**. probe or enter the point in the approach direction near the **Start point** (probing direction same as for **Start point**).

**Travel to start point!**

Position the probe in front of the starting point. **<TERMIN>** starts the scanning run.

**Scanning point ...**

During scanning the screen shows the number of points stored.

**Joystick mode of operation**

**Definition**

The dialog described here applies to **Joystick (free)** or **Joystick (WP plane)**, i.e. manual scanning with a measuring probe head.


**Please note:**

No control data can be produced with manual scanning.

**Function call**

► **„Branching of dialog windows“ on page 19-10**

Please probe start point  
/target point or select  
function



### Softkeys

**PROBE**

Accepts the current position if the measuring probe head is still in contact.

**STEP**

Probe travel from current position with or without search run (▶ **„Travel from the current position in fixed steps <DI 1515>“ on page 10-41**). If no probing takes place, the request for probing or for function selection will be repeated.

**POSITION**

Fine positioning with or without search run (▶ **„Positioning to workpiece coordinates <DI 1511>“ on page 10-37**). If no probing takes place, the request for probing or for function selection is repeated.

**DIALOG**

Used to enter start point as coordinates instead of by probing (▶ **„Entering a start/target point via dialog“ on page 19-59**).

**ORDER**

Not activated.

- Prbg. direction                      The inquiry will appear only if you selected the **Cartesian coordinates** option after <DIALOG> (➤ „**Entering a start/target point via dialog**“ on page 19-59). Select probing direction via softkey or by typing it in.
  
- Scanning Run parameters              For explanations see ➤ „**Path mode in WP system or workpiece plane**“ on page 19-44
  
- Manual scanning  
Please probe direction point or select function      Prompt for a direction point will appear if **Path mode = Joystick WP system** and a blank was entered for **Run**. Probe or enter the point in the approach direction near the **Start point** (probing direction as for **Start point**).

Scanning point ...                      The measuring machine automatically travels to starting point. Manual scanning can then begin. During scanning, the number of points already stored are displayed on the screen. At the same time, the following softkey assignment also appears:

Before pressing any of these softkeys, always back the probe away first and then wait for the **Please select function** prompt (manual scanning then stops). These softkeys are not active as long as the probe is in contact.

### Softkeys

- STEP WID**                      Change of the distance between two stored points (➤ „**Point density**“ on page 19-30). The current value is offered. The measuring machine then starts probing automatically.
  
- SC\_RANGE**                      Application only for experienced users to change the range of scanning deflection (input in%). The greater the permissible deflection, the more inaccurate the measurement will become. If the permissible deflection is exceeded, an acoustic signal will prompt the operator to scan more slowly.
  
- LAST PNT**                      Correction possibility, e.g. after a measurement error; back the probe away and probe again on the scanning path. New points will be accepted and old points deleted starting from this position. This function can also be used for a probe change to check for overlapping.
  
- POSITION**                      Used to cancel scanning and continue from a new point (e.g. because of a groove). If you inadvertently move the probe back and probe the scanning path again, the points already stored will not be lost (in contrast to <LAST PNT>). This will result in overlapping, i.e. a single section will be measured twice.
  
- CANCEL**                      Cancels a scanning run and returns the program to the calling menu. Any points stored in the meantime will be deleted.
  
- AUTO\_CLA**                      Automatic reclamping (➤ „**Reclamping**“ on page 19-33).

**MAN\_CLAM**

Automatically suppresses reclamping (▶ „*Reclamping*“ on page 19-33).

After pressing a softkey, continue manual scanning (except for after pressing <TERMIN> and <CANCEL>).

**Circular path mode**

**Definition**

The dialog described here applies to the following parameter setting:

- Operat.mode: computer-guided;
- Path mode: Circ. path.

**Function call**

▶ „*Branching of dialog windows*“ on page 19-10

Dialog									
Scanning on circ. paths									
<input type="checkbox"/>	Probe numer	1	Prbg direction	-Z					
	Center point coordinates	X =	Arc radius =						
		Y =							
		Z =							
	Start point	X =	Start angle =						
		Y =							
	Left arc <input type="checkbox"/>		Right arc <input type="checkbox"/>						
	Target point	X =	Travel angle =						
		Y =	Target angle =						
	Any point on arc		X =						
			Y =						
	Pitch factor =		Pitch step =						
* YES		NO		*		+X	+Y	+Z	TERMIN
PRE MENU				-X	-Y	+Z	INFO		



### Softkeys

+X -X

Entry in **Prbg direction** input box.


+Y -Y

+Z -Z

TERMIN

Closes the dialog window and stores the values entered, see information under "Procedure".

### Data boxes



----- Scanning path with  
**Pitch factor = 8**  
**Start angle = 45**  
**Travel angle = 225 or Target angle = 270**

**Probe number**

Specify which probe should be used for scanning.

**Prbg direction**

Type in value or use softkeys; cf. sketch.

**Center point coordinates**

Position of the circular path in workpiece coordinates, cf. sketch.

**Arc radius**

Radius of the circle path center, cf. sketch. Input not necessary (blank with space key). In this case, the program will demand input of the coordinates of a point on the circular path in order to calculate the radius later on (see **Any point on arc**).

**Start point**

Starting point in workpiece coordinates, cf. sketch. An input is not necessary (blank with space key). In this case, the program will jump to **Start angle**.

**Start angle**

Make an entry in this box if **Start point X = blank**. The starting angle is incremented counterclockwise starting from the reference axis (with a positive sign, cf. sketch) and vice versa with a negative sign. If the **start angle = 0** the starting point lies on the reference axis.

Probing dir.	PCLN	Reference axis
+X, -X	1	+Y
+Y, -Y	2	+Z
+Z, -Z	3	+X

**Left arc**

- **<\* YES>**  
The probe travels to the left in an arc from the starting point, cf. sketch.
- **<NO>**  
Jump to **Right arc**.

**Right arc**

- **<\* YES>**  
The probe travels to the right in an arc from the starting point, cf. sketch.
- **<NO>**  
Jump to **Left arc**.

**Target point**

Target point in workpiece coordinates, cf. sketch. Input can be omitted (blank with space key). In this case, the program will jump to **Travel angle**.

**Travel angle**

Make an entry in this box if **Target point X = blank**. The **Travel angle** will be counted starting from the **Start angle** or the **Start point** counterclockwise (with a positive sign, cf. sketch) and clockwise with a negative sign.

**Target angle**

Make an entry in this box only if **Center point coordinates X = blank, Target point X = blank, Travel angle = blank**.  
The **Target angle** will be counted from the reference axis counterclockwise (mathematically positive, cf. sketch) and vice versa with a negative sign.

**Any point on arc**

Make an entry in this box if **Arc radius = blank**. The program calculates the arc radius from the coordinates entered.

**Pitch factor**

The sketch shows that the scanning path is composed of short, straight lines (polygon). A large value for the **Pitch factor** causes an approximate circular path. No input is required (blank with space key). In this case, the program jumps to **Pitch step**.

Note for trigger probe head: Only the corner points of the polygon will be probed. You should therefore select a large pitch for a high point numbers. If necessary, the program will modify the value entered depending on the arc radius.

**Pitch step** Make an entry in this box if **Pitch factor = blank** as an angle in deg/min/sec. The program will then calculate the corresponding pitch factor based on your entry.

Please observe notes on **Pitch factor**.

### Procedure

The program highlights the box where the next input should be made.

- Entering values: Accept data already entered or press **<Delete>** and type in new data, confirm with **<Enter>**.
- **<YES/NO>** boxes: Accept or reject with **<\* YES>/<NO>**.
- Select individual boxes or step through: with the  $\vee$  and  $\wedge$  cursor keys.

After you close the dialog window with **<TERMIN>** the following dialog will appear:

**Travel to start point !** Position probe in front of starting point. **<TERMIN>** starts the scanning run.

**Scanning point ...** During scanning, the screen number of points already scanned are displayed on the screen.

**e.g.: SURFACE**  
**Please probe point or select function** At the same time the softkey menu for measuring geometric elements is displayed again ( $\blacktriangleright$  „*Probing possibilities*“ on page 10-5). Now you can e.g. scan another path with **<Scanning run>** or calculate an element or feature with **<TERMIN>** etc.

### Scanning in the path mode and measuring according to nominal values

**Definition** The dialog described here applies to the following parameter setting:

- **Op. mode: computer-guided;**
- **Path mode: Scanning according to nominals** or **Measurement according to nominals.**

**Function call** See KUM Operating Instructions.

### Data boxes

**Scanning/measurement according to nominals**  
**Please probe start point/target point or select function** The same functions (softkeys) are available as when **Path mode = Line in WP system/Plane in WP system**,  $\blacktriangleright$  „*Path mode in WP system or workpiece plane*“ on page 19-44.

Difference: With **<DIALOG>** you can use the points from a nominal data file ( $\blacktriangleright$  „*Entering a start/target point via dialog*“ on page 19-59).

Scanning/measurement according to nominals  
Prbg. direction =

An inquiry will appear only if you have checked the **Cartesian coordinates** option after <DIALOG> (► „*Entering a start/target point via dialog*“ on page 19-59). Select the probing direction by softkey or by typing it in.

Scanning/measurement according to nominals  
Please travel to safety position !

Position probe in front of starting point. Press <TERMIN> to start the scanning run.

Scanning/measurement according to nominals  
Scanning Point ...

During scanning/measurement the number of points already stored is displayed on the screen.

CURVE POINT ...  
Please probe point or select function

For more details: See KUM Operating Instructions.

## Cylinder surface path mode

Definition

The **Cylinder surface path mode** is primarily used to scan tooth flanks (gear measurement) etc. Only trained users should use this technique. For this reason, no description will be provided here.

## Self-centering path mode

Definition

The dialog described here applies to self-centering scanning, i.e. to the following parameter settings:

- **Operat.mode: computer-guided;**
- **Path mode: self centering.**

Function call

► „*Scanning in the unknown contour mode*“ on page 19-19

### NOTE

<DI 1502>: Vectorial probing must be deactivated.

<DI 1551>: Must not be used for this function.

## Data boxes


Please enter 2 meas. forces with correct sign  
X = N, Y = N, Z = N

The probing direction with the highest force is the main probing direction. If both forces are the same, the first probing direction will be assigned as the main one. Messages are displayed following incorrect inputs (excessive values, more than 2 measuring forces, etc.).

### NOTE


Correct selection of the main probing direction is important with poorly defined edges and/or when reclamping is necessary.

**Example 1**



If the main probing direction here is  $-X$  (or  $+Y$ ), there is risk of drifting due to the poorly defined edge. The main probing direction should therefore be  $-Z$ .

**Example 2**




Reclamping exchanges the main probing direction and the travel direction. If the main probing direction is  $-Z$ , an exchange between  $X$  and  $Y$  would not be possible. For this reason, the main probing direction must be  $-X$ . If this is not possible (e.g. due to a poorly defined edge) you must scan this path in two sections without reclamping.

This means that a complete circle which is to be measured with self-centering probing should be divided into 4 sections.

**Scanning with two measuring forces**  
**Please probe start point/target point or select function**

As for **Path mode = Plane in WP system**, ► „**Path mode in WP system or workpiece plane**“ on page 19-44. If you probe in only one of the directions selected above, the probe automatically travels in the other direction until it reaches an edge.



**Scanning with two measuring forces**  
**Prbg. direction =**

An inquiry will appear only if you have checked the **Cartesian coordinates** option after <DIALOG> (► „**Entering a start/target point via dialog**“ on page 19-59). Select the probing direction by softkey or by typing it in.

**Scanning with two measuring forces**  
**Measuring force selected is set !**

This screen message appears if you probe only in one direction when defining the start/target point, see above.

e.g.: **LINE**  
**Please probe point or select function**

As for the corresponding dialog lines of **Path mode = Plane in WP system**, ► „**Path mode in WP system or workpiece plane**“ on page 19-44.


### Scanning cylinder, cone, torus

#### Application

If you use **<Scanning run>** within **<CYLINDER>**, **<CONE>** or **<TORUS>**, the dialog will first prompt you to probe 3 points which lie in a section perpendicular to the axis of the measured element:

#### Probe 3 points on vertical axis of section

The program calculates the rough direction of the measured element. This advance information considerably shortens the time required to calculate the element from numerous probed points later on:



The **SCANNING RUN** dialog window is then displayed. (➤ *„Branching of dialog windows“ on page 19-10*). Continue as described there.

### Entering a start/target point via dialog

#### Application

Within the dialog opened with **<Scanning run>** the start point and/or target point and if necessary the direction point can be entered as coordinates or as a point from the KUM nominal data file instead of being probed. This input mode must be selected with the **<DIALOG>** softkey (➤ *„Path mode in WP system or workpiece plane“ on page 19-44*, ➤ *„Joystick mode of operation“ on page 19-49*, ➤ *„Scanning in the path mode and measuring according to nominal values“ on page 19-55*, ➤ *„Self-centering path mode“ on page 19-56*).

This type of input is not available for **Path mode = Circ.path**.

**DIALOG**

The screenshot shows a window titled "Dialog" with the following elements:

- Header: Dialog
- Title: Input of start point
- Input options:
  - Cartesian coord
  - X coord (value: 0.0000)
  - Y coord (value: 0.0000)
  - Z coord (value: 0.0000)
  - Prb. dir. (value: +X)
- Alternative input: or from nominal file  Point number (empty field)
- Control buttons at the bottom:
  - \* YES NO
  - \* REPEAT TERMIN
  - BACK PRE MENU
  - INFO

**Softkeys**

**REPEAT**

Cancels changes (window contents reset to pre-call status). After a nominal point is entered, the applicable coordinates can be displayed with this key, see explanations on **from nominal file**.

**TERMIN**

Closes the dialog window. The values entered are validated and the dialog is continued.

**Data boxes**

**Cartesian coordinates**

Input of start or target point in workpiece coordinates.

**from nominal file**

Point from the KUM nominal point as start and/or target point. Prerequisite: Nominal data file exists and **Path mode** is **Scanning according to nominals** or **Measurement according to nominals**. After the number has been entered, the applicable coordinates can be displayed with **<REPEAT>**.

**Procedure**

Select required input type with **<\* YES>/<NO>** and enter the data. The dialog continues after **<TERMIN>**, see corresponding chapter.



## Scanning an unknown contour manually

**Restriction**

This scanning method is possible only with the OTM optical probe head.

### Manual scanning of random lines

**Application**

With this method you can probe lines arranged randomly in space.


**Function call**

► *„Branching of dialog windows“ on page 19-10.*



### Databox

**No. of points** Input of the desired number of points.



### Softkeys

- SC-PLANE** Positioning of the probe to the section plane.
- BEF-PT** Positioning of the probe with probing at the last measured point.
- DSE-POS** Branching to the DSE setting routines.
- SCANNING** Fixing of the laser beam in the scanning plane. Afterwards it is only possible to move and scan in the scanning plane using the joysticks.
- TERMIN** Exit from scanning mode.

### Procedure

- **Probe start and target point**

The target point is used here only for determining the direction of the scanning path.

- **Travel to (in front of) start(-ing) point**

Move the probe to an initial position from where the starting point can be reached without a collision.

- The system probes automatically and then releases (i.e. enables) the joysticks in the scanning plane.

- After terminating a section with the **<CANCEL>** softkey, you can e.g. perform travel around an obstacle and then continue manual scanning.

### **Manual scanning of sections in the workpiece coordinate system**

### Application

With this method you can manually scan an element whose axis lies roughly perpendicular to a plane of the workpiece coordinate system.

### Function call

➤ *„Branching of dialog windows“ on page 19-10.*

Dialog									
Scanning run - unknown contour, in workpiece planes									
<input type="checkbox"/>	Speed	<input type="text"/>	Step size	<input type="text"/>	minimum	<input type="text"/>			
	WP plane	<input type="text"/>	Section height	<input type="text"/>	Dir. of rot	<input type="text"/>			
* YES				NO				*	
BACK				PRE MENU				TERMIN	

Dialog									
Scanning unknown contour									
<input type="checkbox"/>	Settings in front of new scanning section								
	Continue with <SCANNING> softkey								
SC-PLANE				ROT-SCPL				*	
DSE-POS				SCANNING				TERMIN	


### Softkeys

<b>SC-PLANE</b>	Positioning of the probe into the section plane.
<b>ROT-SCPL</b>	Branches to a dialog window for rotation of the scanning plane. ➤ <b>„Manual scanning of radial sections“ on page 19-66</b>
<b>DSE-POS</b>	Branches to the DSE setting routines.
<b>SCANNING</b>	Fixing of the laser beam in the scanning plane. Afterwards, travel and scanning are possible only in the scanning plane via joystick control.
<b>TERMIN</b>	Closes the dialog window and terminates the scanning mode.

### Data boxes

<b>Speed</b>	Max. 8mm/s for unknown contour. This speed is reached at maximum deflection of the joystick.
<b>Step size/minimum</b>	First value = input nominal, second value = smallest possible step size (depending on the speed).
<b>WP Plane</b>	Specification of the workpiece plane where scanning is to be performed.
<b>Section height</b>	Height of the scanning path above the zero point of the workpiece coordinate system.
<b>Dir. of rot.</b>	When scanning unknown contours, the direction of rotation always results when viewing the measuring plane from the positive direction of the 3rd axis. Explanation: ➤ <b>„Scanning a known contour“ on page 19-39.</b>





## Scanning contour lines

### Application

In **CADLINK** you can use this function to manually probe **contour lines** (characterization lines) on car bodies. To do this, insert an OTM laser probe in a DSE. Each probing is transferred to the **HOLOS** software.

### Function call

► „*Branching of dialog windows*“ on page 19-10.

Recording of form lines

POINT    BEF PT    \*    DSE-POS    TERMIN

\_\_\_\_\_

\_\_\_\_\_

### Softkeys

**POINT**

Transfer of a probing point.

**BEF PT**

If the laser probe has to be adjusted via DSE-POS during a measurement, you can then travel back to the last probing and continue the measurement from there.

The measuring machine moves the laser probe to a position located 15 mm above the last probing position.

**DSE-POS**

Branching to program functions for adjusting the DSE.

**TERMIN**

End of measurement.



### Procedure

After calling the function, you can probe with the joysticks. During joystick controlled travel perpendicular to the probing direction, the laser probe is readjusted so that it remains in contact with the measuring surface.

The probe can be backed away from the surface during measurement e.g. to travel around bores or to readjust the DSE.

## Learn programming

### NOTE

- The control data stores the scanning mode in 3 or 4 related control lines. Changes made in only one of the two der **SCANNING MODE** dialog windows generate all new control data lines.
- The control data codes are easy to interpret. You can list the codes for the path mode after **<MOD TOT>** with the **<INFO>** softkey (► „*Listing the scanning modes <MOD TOT>*“ on page 19-9).
- The control data for the measuring and trigger probe head are basically interchangeable; Exception: Self-centering scanning does not run with the trigger probe head.

Control line **SCA-KLEM-MOD** for the measuring probe head corresponds to control line **SCA-ABTAST** for the trigger probe head:

#### Measuring probe head:

```
0  3.0000  0.0000  SCA CLAM MOD  5  1  9911  1911
```

Reclamping mode

Backway distance for reclamping

Overlapping distance

#### Trigger probe head:

```
0  3.0000  0.0000  SCA BADIST  5  1  9911  1911
```

Type of intermediate position (fine/rough position)

Intermediate position before probing

Intermediate position after probing

The data must be adapted accordingly.

- If you scan with a long-term mode (**<RUN x>**) in the learn program, you do not need to program it with **<MODE x>** as well. **<RUN x>** permanently stores the long-term mode used in the control data following error-free scanning.  
If you scan in the learn program with the short-term mode, you must enter it in the control data with **<SCAN MOD>** beforehand or it must be currently valid when the scanning run is started (► „*Transferring the scanning mode*“ on page 19-8).
- The mode used last during learn programming or during a CNC run is always the short-term mode currently valid.

- You must define the workpiece coordinate system by scanning in the learn program (the starting point and target point are stored in the workpiece coordinates).

If you want to define the workpiece coordinate system by scanning (e.g. with the step sequence (<**SURFACE**>) <**SCAN RUN**>, <**GDT-PLA**>, <**RO SPACE**>), first call the W-position into the computer as the workpiece coordinate system with <**DI 1713**>.



# Index

## Symbole

<Alt> 3-11  
<BACK> 15-5  
<Break> 2-18, 18-15  
<Colors> 3-33  
<Enter> 3-24  
<F10> 3-11, 3-24  
<F12> 3-27  
<F9> 3-25  
<Fonts> 3-34  
<OK> 3-24  
<Shuffle up> 3-8  
<Tab> 2-13, 3-24  
<TERMIN> 3-8  
<UMESS End> 3-42  
% Page 9-4 3-14

## 0-9

1st submenu level 3-10  
2D transformation with selectable  
coordinate axis 9-11  
2nd submenu level 3-10  
3D circle 11-58  
3D transformation with selectable  
coordinate axis 9-10  
64 pictograms (icons) 3-6

## A

Abbreviations 2-16  
Absolute recall 16-80  
Accidental actuation 15-4  
Accuracy of probe calibration 7-6  
Activating windows 3-2  
Activating/deactivating the UMESS main  
menu 3-41  
Adapting the probing behavior 6-20  
Additional cone program 13-13  
Address adjustment, types 17-49  
Address counter 5-8, 16-15, 16-19  
Address counting 16-74  
Adjusting control data addresses 17-49  
Administration of output devices 5-50  
ADR 17-31, 17-49  
Aligning the rotary table parallel to the  
machine coordinates 15-9  
Aligning the workpiece parallel 9-3  
Alignment 16-32  
Alt key 3-11  
Angle criterion 19-32

Angle output in degrees, minutes and  
seconds 13-2  
Angularity (slope) 14-38  
Any (random) intersection plane 19-16  
Auto Termin 10-10  
Auto\_Nominal 10-12  
Auto\_Termin 10-10, 10-11  
Automatic probe change 8-17

## B

Backup medium 4-3, 4-7  
Batch (serial) measurement 16-72, 18-5,  
18-8  
Batch measurement with EXCALL 18-6  
Bend parameters 7-34  
Bend parameters for the "clamped"  
probe head mode 7-36  
Bore element 16-34  
Bore patterns 16-36  
Branching 16-36, 16-49  
Branchings 16-58, 16-64  
Break points 18-19

## C

Calculation of polar distances 13-7  
Calculation of rotation and tilt angle  
13-2  
Calibrating disk and cylinder probes 7-32  
Calibration mode 7-10  
Call (invocation) of a geometric element  
10-5  
Calling N point programs 16-20  
Calling the default head and variable  
header I 5-24  
Calling UMESS functions using menus  
3-10  
Calling UMESS functions via pictograms  
(icons) 3-23  
Calling variable header II 5-27  
Car body mode 14-6  
Castings 16-25  
Changing probe combinations 16-80  
Changing probes 8-12  
Changing the allocation of joystick  
deflection to travel movements  
10-18  
Changing the combination 8-11  
Changing the language 3-42  
Changing the reference axis and

direction of rotation 13-5  
 Changing the user name 5-45  
 Changing the workpiece coordinate system 16-20  
 Chebyshev 11-15  
 Checking control data 18-17  
 CIRCLE 11-9  
 Circle segment 11-53  
 Circular path mode 19-52  
 Close 3-5  
 Closed loop 16-38  
 CNC end 15-22  
 CNC program 16-2, 16-16, 17-2, 18-1  
 CNC program, correction or extension 16-5  
 CNC run with rotary table 15-3  
 CNC start 15-22  
 Coaxiality with MMC 14-57  
 Collecting points in a file 10-21  
 Collision 2-7, 6-2, 15-10, 16-25, 16-30, 16-33, 16-34, 19-30  
 Collisions 2-18, 19-29  
 Combination 7-4  
 Combinations 8-2  
 Comment input 5-33  
 Comments in the measurement record 5-33  
 Comments on the alphanumeric control panel 5-37  
 Computer 1-5  
 Computer controlled manually measured sections 16-25  
 Computer keyboard 2-11  
 Computer prompted manual measuring sections 18-16  
 Concentricity with MMC 14-55  
 CONE 11-41  
 Cone angle correction 13-15  
 Cones 19-12  
 Configuration 7-4  
 Configurations 8-2  
 Continuing the learn programming of an existing workpiece 16-14  
 Control coordinate system 16-3, 16-6, 16-12  
 Control data 18-1  
 Control in the control coordinate system 10-19  
 Control in the workpiece coordinate system 10-19  
 Control panel 15-19  
 Control parameters 16-16  
 Conversion of angles 13-2  
 Conversion of nominal values 17-54  
 Converting control data 17-44  
 Coordinate measuring machine 1-5  
 Coordinate systems 9-2  
 Copying a macro to a learn program 16-81  
 Copying control data lines 17-40  
 Copying control data lines from other workpieces 17-55  
 Copying from workpiece catalog to intermediate store 4-8  
 Copying pictograms (icons) 3-26  
 Copying to workpiece catalog from buffer store 4-8  
 Copying workpieces 17-18  
 Correcting control data 17-31  
 Correcting the rotary table axis 15-12, 15-14  
 Correction during learn programming 16-17  
 Correction of probing errors 10-15  
 Correction programming 16-77, 16-83  
 Creating macros 16-78  
 Creating/evaluating point collection files 10-21  
 Cursor 2-11  
 Cursor control 2-11  
 Cursor control device (mouse) 2-15  
 Cursor control keys 2-12  
 Cursor keys 3-11, 3-12  
 CYLINDER 11-36  
 Cylinders 19-12  
 Cylindricity 14-28

**D**

Danger of collision 2-7, 6-2  
 Data transfer in VDA format 10-26  
 Daten backup 4-3  
 Deactivating the rotary table axis 15-12, 15-14  
 DEBUG ON 16-79  
 Debugger 18-15, 18-17  
 Decisions 6-16  
 Default names 5-10  
 Default record header 5-21  
 Defining and storing the control coordinate system 16-6  
 Defining the control mode 6-10  
 Defining the language 5-16  
 Defining the mode for the WP reference axis 9-27  
 Defining the no. of decimal places 5-16  
 Defining the output medium 5-12  
 Defining the print format 5-17  
 Defining the probe holder positions 6-32  
 Defining the rotary table axis 15-11, 15-12  
 Defining the scanning mode 19-6  
 Defining the unit of measurement 5-16  
 Defining the workpiece coordinate system 15-5, 16-16  
 Defining the W-position 16-16  
 Defining the scope of a record 5-14

- Deleting a pictogram 3-27
- Deleting and resetting probe data 8-9
- Deleting control data lines 17-43
- Deleting individual measuring points 10-15
- Deleting outliers 14-66
- Deleting the N point program completely 10-15
- Deleting the W-position 16-7
- Deleting workpieces 17-12
- Determining bend parameters for unclamped scanning 7-46
- Determining the probing direction for single points of a CNC run 18-21
- DI 2-16
- DI 1265 12-42
- DI 1266> 12-45
- DI No.> 3-26
- DI numbers 3-6
- Dialog window 3-8
- Dialog window in background 3-8
- Diameter of target sphere 19-37
- Dimension definition 11-16
- Dimension, form and position 11-13
- Dimensional tolerances 14-2
- Direct input 2-16
- Direct input numbers 3-6
- Direct inputs 2-16
- Direction point 19-49, 19-51, 19-59
- Dispersion (standard deviation) 10-55
- Displacing the zero point by a defined value 9-18
- Display of intermediate results 10-8
- Display of results in the measurement record 5-3
- Displaying the rotary table axis 15-16
- Distance in cartesian coordinates 12-20
- Drift of rotary table axis 15-12
- DSE 2-7
- DSE or RDS 1-2
- Duplex CMM 1-2
- Dynamic bend 7-34

## **E**

- Eccentricity error 15-3, 15-11, 15-19, 15-20
- Editing a pictogram page 3-25
- Editing pictogram pages with the "Direct input" window 3-26
- ELLIPSE 11-19
- End of operation 2-20
- Enter 3-11
- Entering a workpiece in the workpiece catalog 17-10
- Envelope symbol (mouse pointer) 3-25

- Error record 17-31
- Evaluation programs 16-16
- EXCALL 16-36, 16-71, 18-5, 18-6
- EXCALL address correction 16-74
- EXCALL workpiece jump 16-71
- Exchanging coordinates 17-44
- Execution of learn programming 16-16
- External storage (swap-out) of CNC programs 4-3
- Extreme values 10-45

## **F**

- Fast plot 11-16
- Faults 2-18
- FC 1-2, 2-7
- File evaluation 10-22
- File name 17-5, 17-10, 17-32
- Filtering points 14-69
- Filtration of measuring data 11-15
- Finding kink points 10-27
- Fine positioning in the workpiece coordinate system 16-30, 16-31
- Fixed plane 16-20
- Flatness 14-21
- Fonts and font sizes 3-34
- Form errors 10-46
- Form evaluation 11-15
- Form tolerance 11-14, 11-33
- Form tolerances 14-18
- Forming a workpiece coordinate system from a control coordinate system 9-31
- Formula calculation 12-27
- Function call during the stop phase 18-13
- Function call via direct input 2-16
- Function call with direct input 3-12
- Function calls 2-16
- Functions of UMESS main menu 3-6

## **G**

- Gauss method of least square errors 10-55
- General 7-2
- General comments on windowing 2-2
- General Information 7-2
- Generating a plane by linking 12-42
- Generating a point by projecting from point to line 12-45
- Generating programs 16-16, 16-36
- Graphic output 5-46
- Graphic symbol 3-26
- Graphic user interface 3-7

## H

Hardware 1-5  
Hole circles 16-36  
How to use the operating instructions 1-3  
HP 9000 Serie 700 oder Serie B 2-3

## I

Iconofy (Minimize) 3-5  
Icons with graphic symbols 3-23  
Inch inputs 3-39  
Incorrect probing 16-18  
Incorrectly set intermediate position 16-18  
Influence, correction and monitoring of temperature changes 6-21  
Initial status 16-16  
Initializing MASCH 15-22  
Initializing the graphic software 5-48  
Initializing the machine 6-37  
Input box 3-39  
Inserting blank lines 17-39  
Inserting control data lines 16-15, 17-39  
Intermediate (buffer) storage 4-3  
Intermediate position 15-11, 16-16, 16-26, 16-29, 16-30  
Intermediate position during scanning 19-28  
Intermediate positions 16-80  
Interpretation of control data 17-29  
Interpretation of measurement results 10-53  
Interrupting a CNC run 18-14  
Interruption by the operator 18-11  
Interruption due to malfunction 18-14  
Intersection point of axes in space 12-7  
Intersections 12-2

## J

Joints 16-34  
Joystick control of rotary table 15-4  
Joystick mode of operation 19-49  
Jumps 16-44, 16-73

## K

Keyboard 2-11  
Keylock switch 2-4  
Keys for text input and processing 2-12  
Known contours 19-7

## L

Learn (part) programming with the rotary table 15-5  
Learn programming 16-1, 17-11, 19-70  
Learn programming a new workpiece 16-13, 16-85  
Learn programming after a program

correction 16-85

Learn programming, procedure 16-5

LINE 11-22

Line mark 3-39

Lines 19-12

Listing control data 17-28, 18-20

Listing the rotary table axis 15-14, 15-16

Listing the scanning modes 19-9

Listing the storag positions 6-32

Login 2-10

Long-term mode 19-70

Loop 15-20, 16-36

Loop variable 16-43

Loop variables 16-49

Loop with condition at the end 16-38

Loop with condition at the start 16-39

Loop without condition 16-37

Loops 16-36, 16-49, 16-58, 16-64

LTP 19-28

## M

Machine coordinate system 15-12, 16-3

Machine parameters 6-13, 16-20

Macro 16-36, 16-77

Magazine mode 6-29

Main menu 3-6, 3-10

Malfunctions 18-15

Manual probe calibration 7-29

Manual scanning of radial sections 19-66

Manual scanning of random lines 19-61

Manual scanning of sections in the workpiece coordinate system 19-63

Manually measured sections 16-25

Masking a control data line 17-37

Master probe 7-4

Mathematical alignment 9-1

Mathematical alignment of workpiece 16-16

Mating size (sigma factor) 10-48

Maximize 3-5

Mean value calculation 12-25

Measurement on reversal 15-13, 15-14

Measurement record 5-2

Measuring 10-2

Measuring a circle semiautomatically 11-11

Measuring a surface manually 11-27

Measuring a surface semiautomatically 11-29

Measuring force 6-14

Measuring programs 16-16

Measuring time 16-16, 19-35

Measuring with compensation of the probe bend 7-47

Menu items 3-7

Menus 3-12

Min-max flatness 14-60



Min-max roundness 14-62  
 Mirroring coordinates 17-44  
 Missing bore 16-32  
 Mobile rotary table 15-12, 15-15, 15-16  
 Modifying (editing) a control data line 17-35  
 Modifying (editing) workpiece attributes 17-17  
 Modifying probe data 8-7  
 Modifying the window size 3-3  
 Modules 16-72  
 Mouse button 2-15  
 Mouse functions 2-15  
 Mouse pointer 2-15  
 Move 3-5  
 Moving control data lines 17-42  
 Moving windows 3-2  
 Multiple windows 2-16

**N**

Name allocation 5-9  
 Nesting 16-72  
 Nesting depth 16-37, 16-40, 16-46  
 NO RESULT 16-33  
 No result (function) 10-55  
 Nominal (size) input 16-80  
 Nominal data 19-17  
 Nominal data with large deviation 19-18  
 Nominal input 14-8  
 Nominal size 11-14  
 Nominal value 11-33  
 Nominal-actual mode 14-2  
 Nominals with dynamic follow-up 19-17  
 Number scale mode 14-4

**O**

Oblong holes 16-32, 16-34  
 Offset correction 6-4  
 Offset measurement 15-12  
 Optimizing travel paths 16-31  
 Options menu 3-21  
 Other windows in UMESS 3-36  
 Output and deletion of bend parameters 7-44  
 Output mode 5-12  
 Output of deviations referenced to tolerance center 14-16  
 Output of probe data 8-6  
 Overlapping distance 19-34  
 Overview of all menus 3-12  
 Overwriting a geometric element 10-15

**P**

Page feed in the record 5-19  
 Parallel displacement of the workpiece coordinate system 9-15  
 Parallelism 14-31  
 Partial runs 16-72  
 Patching 16-14  
 Path mode 19-44  
 Path mode 4, self-centering 19-26  
 Path mode 98, controlled laser scanning 19-28  
 Path mode 99, rapid laser scanning 19-28  
 Path modes 19-25  
 Penetration point 13-11  
 Permissible temperature range 7-7  
 Perpendicular calculations 12-15  
 Perpendicular distance 12-17  
 Perpendicularity with MMC 14-41  
 Pictogram pages (icon bars) 3-6  
 Pictogram pages after starting UMESS 3-32  
 Pictogram pages you last worked with 3-32  
 Pictograms (icons) in the UMESS main menu 3-23  
 Pictograms (pictographs or icons) 2-16  
 Pitch factor 19-54  
 Pitch measurement 19-18  
 Pitch measurements 12-30  
 Pitch step 19-55  
 Plane intersections 12-2  
 Plane on circular path 19-17  
 Plane through point and line 12-43  
 Plane through point vertical to line 12-43  
 POINT 11-6  
 Point density 19-30  
 Polar distance in one plane 13-7  
 Position definition 11-16  
 Position mit MMC 14-45  
 Position of probe rack 6-28  
 Position tolerances 14-30  
 Positioning the rotary table 15-4, 15-11  
 Positioning to a normal vector 10-40  
 Positioning to a result 10-38  
 Positioning to workpiece coordinates 10-37  
 Preparing for probe calibration 7-10  
 Preparing the rotary table 15-3  
 Prerequisites 2-3  
 Printing the last 10 measurement records 5-43  
 Probe 16-30  
 Probe bend 7-34  
 Probe bend compensation 7-34  
 Probe head 1-5  
 Probe head mode 16-24



## S

- Safety mode 18-14
- Saving a menu item as a pictogram 3-25
- Saving pictogram pages 3-28
- Saving pictogram pages to a file 3-28
- Saving records with a workpiece number or code 5-41
- Saving, outputting and deleting records 5-42
- SC1 17-30
- Scanning a known contour 19-39
- Scanning an unknown contour manually 19-61
- Scanning contour lines 19-68
- Scanning in the known contour clamped mode 19-21
- Scanning in the known contour mode 19-16
- Scanning in the unknown contour mode 19-19
- Scanning in the workpiece plane 19-11
- Scanning measuring points 11-15
- Scanning measuring run 19-10
- Scanning method 19-6
- Scanning mode 19-11
- Scanning over edges 19-45
- Scanning speed 11-15, 19-28
- Scanning unknown contours 19-42
- Scanning unknown contours, clamped 19-44
- Screen display during learn programming 16-17
- Screen display of comments 5-35
- Screen memory 2-11
- Scrolling the contents of the window 3-4
- Search criteria 17-7
- Searching for control data lines 17-51
- Section height 19-48
- Selecting a control data line 17-35
- Selecting another pictogram page 3-25
- Selecting the reference plane 10-50
- Selecting the space axis 9-23
- Self-centering path mode 19-56
- Self-centering probing (for the measuring probe head only) 10-16
- Self-centering scanning 19-56
- Semiautomatic probe calibration 7-17, 7-19
- Sending CNC programs 4-3
- Set keylock switch and main switch on control cabinet to '0' 2-20
- Setting colors and fonts 3-33
- Setting the address counter 6-7
- Setting the address counter to a random address 6-8
- Setting the initial status 6-7
- Setting the mode for graphic devices 5-47
- Setting the operating mode for the measuring probe head 6-18
- Setting the rotary table position to zero 15-10
- Short-term mode 19-70
- Shrinking the window to an icon 3-2
- Simplified termination of probings 10-10
- Single-click with left mouse button 3-10
- Slots 16-77
- Softkey 2-11, 2-13
- Space diagonal 13-9
- Specifying the reference probe 7-15
- SPHERE 11-49
- Standstill window 16-30
- Start or starting point 19-47
- Starting a CNC run for a single workpiece 18-3
- Starting a CNC run for multiple workpieces 18-5
- Starting learn programming 16-13
- Starting point 19-59
- Starting system programs 3-44
- Static bend 7-34
- Step width 11-15
- Stop 16-21, 16-23, 18-12
- Storing the rotary table axis 15-14
- Storing the W-position 16-7, 16-8
- Storing the W-position in the computer 16-9
- Straightness 14-19
- Strategies for time-optimized programs 16-29
- Structure of the UMESS main menu 3-8
- Submenu levels 3-6
- Subprograms 16-72
- Superposition of form and tolerance deviations 14-60
- Supplementary coordinates 10-47
- Suppression of reclamping 19-52
- SURFACE 11-27
- Surface lines 19-12
- Surface sections 12-9
- Surfaces 19-12, 19-13
- Switching on the intermediate result display 10-8
- Switch-on 2-4
- Symmetry 14-49
- Symmetry elements 12-22
- System hardware 1-5
- System information 6-36
- Systematically changing control data coordinates 17-53

## T

- Tangential surface 11-16
- Target angle 19-54
- Target code 19-35
- Target point 19-47, 19-59
- Target window 19-35, 19-36
- Temperature 15-12
- Temperature check 6-26
- Temperature compensation via input 6-22
- Temperature limit values 6-24
- Temperature monitoring 6-24
- Temperature record 6-27
- Terminating learn programming 16-85
- Terminating the control data correction 17-58
- Terminating the measuring program 3-42
- Terminating UMESS 2-20
- Testing a CNC program 18-17
- Text abbreviation 3-26
- Thermally induced displacement of axis 15-12
- Three-finger rule 19-35
- Time function 5-38
- Time-optimized CNC program 16-29
- Tolerance center 14-16
- Tolerance cylinder 19-31, 19-32
- TORUS 11-46
- Transferring the scanning mode 19-8
- Transformation plane 9-7
- Transformation space 9-4
- Transformation with selectable coordinate axes 9-10
- Trash can 3-27
- Travel angle 19-54
- Travel commands 10-34
- Travel from a probing position in fixed steps 10-43
- Travel from the current position in fixed steps 10-41
- Travel functions 16-31
- Travel path 16-16, 16-26, 16-30
- Travel paths 16-3, 18-17

## U

- UMESS functions 3-6
- UMESS main menu 3-6
- UMESS program system 3-6
- Underlined letters (in commands) 3-11
- Unmasking a control data line with 17-38
- User comment 16-26
- User guidance (prompting) 18-16
- Using the computer keyboard 3-11
- Using the mouse 3-10
- Using the standard control panel 3-11

Utilities for the pictogram pages 3-28

## V

- VAST icon bars 11-13
- VAST scanning 11-13
- VAST user mode 11-14

## W

- W/R filter 11-15
- Warning limit 10-10, 10-12, 14-13
- Warning limit input 10-10
- Window menu 3-4
- Window-driven program control 3-6
- Windowing 2-2, 2-16, 3-6
- Without CMM 2-9
- Wobble error 15-3, 15-11, 15-19, 15-20
- Working with windows 3-2
- Workpiece 17-2
- Workpiece catalog 4-3, 17-5, 17-11, 17-31
- Workpiece code 17-5
- Workpiece coordinate system 16-32, 19-11
- Workpiece family 16-44
- Workpiece information 17-15
- Workpiece jump 16-36, 18-5, 18-6
- Workpiece name 17-7
- W-pos 16-3, 16-6, 16-25, 16-67
- W-pos file 16-7, 16-8
- W-position catalog 16-11
- W-position displacement 16-36, 16-66
- W-position number 16-7, 16-11, 16-12

## Y

- YES/NO box 3-39

## Z

- Zero point 16-32
- Zeroing a coordinate 9-17
- Zeroing an element 9-15