


If you wish to move your model onto the machine worktable, use button 16. (Move CAD Model).



Select TARGET ONLY and POINT, as shown below. Then hit the POSITION button. Click a point on the bottom of your CAD model, then click the point on the worktable where you wish to place it. Hit APPLY. Your model is now placed on the worktable for better simulation.

